```
* 文件名: ad_test.c
* 功 能: 控制ad7606采集电压信 Å
* 说 明: 当ad7606转换结束,触发中断,对数据进行读;
*****************
#include <stdio.h>
#include <string.h>
#include "system.h"
                                  //包含基本的硬件描述信息
#include "altera_avalon_timer_regs.h"
//定义内核寄存器的映射,提供对底层硬件的符号化访问
#include "altera_avalon_pio_regs.h" //包含基本的I/O口信息
#include "alt_types.h"
                                  //Altera定义的数据类型
#include "sys/alt_irq.h"
                                //系统时钟服务头文件
#include "sys/alt_alarm.h"
#include "priv\alt_busy_sleep.h"
                                  //延时函数alt_busy_sleep()
//#define ad_busy *(volatile unsigned char *) AD_BUSY_BASE
alt_u8 led_state = 0;
alt_u16 ad_code[8];
/*********************

      ** 名
      称:
      uart_SendByte

      ** 功
      能:
      向串口发送字 Ú

                           *********
void uart_SendByte (alt_u8 ucDat)
   while(!(IORD_ALTERA_AVALON_UART_STATUS(UART_BASE)&0x0040));
   //等待数据发送完毕
   IOWR ALTERA AVALON UART TXDATA(UART BASE, ucDat);
/***********************
* 名称: uart SendStr
* 功能: 向串口发送字符 ®
* ***********************
void uart_SendStr (alt_u8 const *puiStr)
   while (1) {
      if (*puiStr == '\0') {
                                 /* 遇到结束符,退出 */
         break;
      uart SendByte (*puiStr++);
   }
 *****************
* 名 称: ad_data()
* 功
     能:将读取的数字量转换成相应的电压 µ
*****************
float ad_data(alt_u16 code)
   float ad_data;
   if(code<=0x7FFF)</pre>
      ad_data=code*0.00030517578125;
```

```
else if (code > = 0x8000)
     ad data=(code*0.00030517578125)-20;
  return ad_data;
******************
* 名
      称: ad7606 irg Init()
* 功
     能:初始化ad7606中断,开中断,清边沿捕获寄存:
* 入口参数: P
* 出口参数: Þ
************************
void ad7606_irq_Init()
  IOWR_ALTERA_AVALON_PIO_IRQ_MASK(AD_BUSY_BASE, 0x01); //开AD_BUSY中断
  IOWR_ALTERA_AVALON_PIO_EDGE_CAP(AD_BUSY_BASE, 0x00); //清中断捕获寄存器
  alt_irq_register(AD_BUSY_IRQ, 0, AD7606_ISR);
                                         //注册中断函数
******************
* 名
      称: void ad7606_Init()
* 功
      能: 初始化ad7606 对ad7606进行复 »
* 入口参数: Þ
* 出口参数: P
*****************
void AD7606_Init()
  IOWR ALTERA AVALON PIO DATA(AD REST BASE, 1);
  alt_busy_sleep(1);
  IOWR_ALTERA_AVALON_PIO_DATA(AD_REST_BASE, 0);
  AD7606_irq_Init();
/**********************
* 名 称: AD7606_ISR()
* 功
     能: AD7606中断服务程 ò
void AD7606_ISR(void* context, alt_u32 id)
  alt_u8 i;
  char chars[1];
  float voltage[8];
  IOWR ALTERA AVALON PIO DATA (AD CONVEST BASE, 0);
   for(i=0;i<8;i++)
```

```
IOWR_ALTERA_AVALON_PIO_DATA(AD_CS_BASE, 0);
                                              //使能ad7606
      ad_code[i] = IORD_ALTERA_AVALON_PIO_DATA(AD_DATA_BASE);
      //读取ad7606转换值
      voltage[i] = ad_data(ad_code[i]);
                                              //得到电压值
      IOWR_ALTERA_AVALON_PIO_DATA(AD_CS_BASE, 1);
   for(i=0;i<8;i++)
      sprintf(chars, "%f", voltage[i]);
                                              //通过串口发送转换数据
      uart_SendStr(chars);
      uart_SendStr(" ");
   uart\_SendStr("\n");
   IOWR_ALTERA_AVALON_PIO_EDGE_CAP(AD_BUSY_BASE, 0x00);//清中断捕获寄存器
   IOWR_ALTERA_AVALON_PIO_DATA(LED_BASE,led_state);
   led_state=~led_state;
   alt_busy_sleep(1000000);
   IOWR_ALTERA_AVALON_PIO_DATA(AD_CONVEST_BASE,1); //开启转换
}
/********************
* 名
     称: main()
* 功
     能: 等待ad7606中 Ï
*****************
int main()
   ad7606_Init();
   while(1);
   return 0;
```