Rapport Microcontrôleur

1 Introduction

Ce rapport documente le développement de notre projet réalisé dans le cadre du cours *EE-208 Microcontrôleurs et système numérique*. Suite à l'acquis de formation de ce cours, nous avons entrepris la réalisation d'un dispositif employant un microcontrôleur ATmega-128. Celui-ci s'y retrouve dans de nombreux objets du quotidien, ainsi programmer un système embarqué en faisant l'utilisation est donc quelque chose de très raisonnable. La réalisation de ce projet nous a permis d'ajouter une partie pratique à notre apprentissage, nous entrainant à consolider fortement nos connaissances quant à la programmation des microcontrôleurs en langage assembleur.

1.1 Description de l'application

Le dispositif que nous avons réalisé est un système paramétrable, par l'utilisateur, qui permet d'activer une alarme lorsqu'une certaine température seuille est dépassée et qui s'arrête uniquement lorsqu'un certain code est entré. A sa désactivation, une pompe montée sur un moteur servo permet l'arrosage à 360 degrés afin de refroidir, avec de l'eau, le potentiel environnement dans lequel le système se trouve. Le temps de rotation est choisi à l'aide de l'équation d'Arrhenius qui est la loi, dans le monde des chimistes, qui lie la vitesse d'une réaction chimique à la température. Ainsi nous avons remplacé la vitesse de réaction chimique par celle du temps de rotation du moteur servo. Une interface visuelle est proposée avec un écran LCD. L'équation d'Arrhenius est la suivante :

$$k = Ae^{\frac{-E_a}{RT}}$$

Où k est la vitesse de réaction chimique, dans notre cas le temps de rotation du servo moteur. A est une constante, pour ce projet nous avons choisi A=1. E_a est l'énergie d'activation, dans nos calculs, nous avons choisis $E_a=-100$. R est la constante des gaz parfaits et T la température.

1.2 Objectifs

Notre objectif était de créer un dispositif alignant plusieurs périphériques ainsi qu'une interface utilisateur qui soit la plus instinctive possible. Nous voulions également que notre système soit utilisé afin de récolter une donnée d'un capteur, avec laquelle il fasse un calcul complexe et qu'en fonction de cette donnée et ce calcul, il génère autonomement un certain comportement afin d'avoir système automatisé. L'idée était de créer un system de control avec un « feedback loop » complet et rigoureux.


Un autre objectif fixé était celui d'avoir un code optimisé afin de bénéficier du plein avantage de programmer en assembleur et d'économiser de la mémoire et des coups d'horloge inutiles.

2 Mode d'emploi

2.1 Montage du système

Avant de détailler l'utilisation du dispositif, il est important d'effectuer le bon montage afin que le dispositif fonctionne comme il se doit.

- 1. Alimenter la carte sur une prise secteur.
- 2. Branchement les périphériques :
 - 2.1. **Key-pad:** Brancher les lignes 1 à 4 du keypad sur les bits 4 à 7, respectivement du Port E.
 - 2.2. Encodeur: Brancher le module de l'encodeur sur le Port D.
 - 2.3. Servo: Brancher le module du moteur servo sur le Port C
 - 2.4. Capteur de température : Brancher le sur le Port B.
 - 2.5. **Pompe:** Brancher la base d'un transistor NPN au pin 1 du Port A et, en utilisant le module d'alimentation externe, alimenter la pompe avec la sortie 5 V. Connecter le GND de la carte avec celui du module d'alimentation ainsi qu'au collecteur du transistor. Finalement, connecter l'émetteur du transistor au GND de la pompe.
 - 2.6. LCD: Mettre l'écran LCD tout en haut de la carte, sur ces pins attitrés.
- 3. Allumer la carte et flasher le programme depuis un ordinateur.




1.Schéma du montage

2.1 Utilisation du système

Mode d'accueil:


Le système dans son mode de repos affiche sur l'écran LCD la température actuelle qui se rafraichi environ toutes les 2 secondes. A chaque rafraichissement, le système vérifie si la température lue dépasse la température seuille, et si cela est le cas, on entre dans le mode alarme.



2. Affichage du LCD en mode Accueil

Mode alarme:

Dès lors qu'on entre dans ce mode, le buzzer retentit et l'affichage du LCD montre que le système attend un code de cette façon :



3. Affichage du LCD en mode Alarme

Une fois le bon code entré, il faut appuyer sur la touche « B » du key-pad pour le valider. Le servo moteur se met, ensuite, à tourner pendant x secondes, et la pompe fixée sur le servo permet de propulser un faible jet d'eau. x est calculé grâce à une série de Taylor sur 2-bytes qui approxime l'équation d'Arrhenius. Lorsque ces secondes sont écoulées, on revient au menu d'accueil et la température seuille est remise à celle originale (30 degrés Celsuis).

Select mode:

Si l'on désire modifier la température seuille ou le code, il faut, lorsque nous somme dans le mode d'accueil, appuyer sur n'importe quelle touche du key-pad, ensuite entrer le code actuel et le valider en appuyant sur « B ». Une fois cela fait, l'état du LCD devient le suivant :




4. Affichage LCD mode : select mode

(Attention, une fois quitté le mode d'accueil l'alarme ne peut plus retentir). Comme indiqué, pour choisir quel paramètre modifier, il faut appuyer sur « A » ou « B ».

Mode changer température :


Pour changer la température la température seuille, il faut actionner l'encodeur. En le tournant dans le sens horaire, nous incrémentons la température et inversement pour la diminuer. Si nous actionnons l'encodeur sans appuyer dessus, cela inc/décrémentera la température à la valeur décimale le plus petit possible, cependant, si nous appuyons sur l'encodeur en même temps, la température est inc/décrémenté à l'unité. Pour sauvegarder cela, il faut appuyer sur « A » et nous retournons dans le mode d'accueil. Un exemple de l'affichage dans ce mode peut être vu cidessous :



5. Mode changer la température seuille

Mode changer le code

Pour changer le code, il faut réécrire son nouveau code (l'ancien code est lui disposé dès le début afin de pouvoir comparer). Une fois le code choisi, il faut appuyer sur « B » pour sauvegarder le nouveau code qui sera sauvegardé dans l'EEPROM interne du microcontrôleur. Une fois cela fait nous retournons dans le mode d'accueil. L'exemple ci-dessous montre une transition d'un code « 1111 » a « 4567 » :




6.Mode changer le code

3 Aspect technique

Cette partie du rapport décrit les aspects techniques du dispositif d'un point de vue matériel et d'un point de vue du programme. Nous en profiterons pour présenter les différentes librairies utilisées.

3.1 Mise en place matérielle de l'application

Tous les périphériques utilisés ont été listé dans la section 2.1 et certains seront plus détaillés dans la section 4. La mise en place matérielle du dispositif peut être résumé de façon explicite à l'aide d'un schéma :



7.Logistique matérielle

Le microcontrôleur (MCU) est donc au milieu et gère tout ce qui est niveau code pour le transfert de données et exécution d'instructions.

3.2 Bibliothèques

Le lien entre les périphériques est la plupart du temps effectué à l'aide de bibliothèques qui sont expliquées ci-dessous :

Certains modules ont été emprunté du cours, parmi eux, certains ont été utilisés tel-quel, sans modifications. Font partis de cette catégorie : wire1.asm, macro.asm, lcd.asm, definitons.asm, eeprom.asm et math.asm.

Toujours parmi les modules du cours, nous avons fait la décision de modifier la bibliothèque encoder.asm, afin de pouvoir l'adapter à notre système afin que l'inc/décrémentation se fasse sur 2 bytes et non 1. Nous voulions également ajouter la fonctionnalité de pouvoir, lorsque l'encodeur est appuyé, inc/décrémenter un certain bit du premier octet. Cela devait être fait afin d'inc/décrémenter par unité (en degré Celsius) et donc gagner un temps considérable et une excellente précision pour régler la température seuille.


Finalement, nous avons créé la bibliothèques « taylor_2byte.asm ». Cette bibliothèque a pour objectif de calculer le coefficient d'Arrhenius en utilisant une série de Taylor pour e^x sur 2-bytes en utilisant une méthode itérative. Son fonctionnement principal commence par initialiser les variables nécessaires, stocker la valeur initiale de la température et push sur la pile les valeurs des registre r0 à r32. Le code procède ensuite à calculer le facteur exponentiel $k=e^{\frac{100}{8.31 \cdot T}}$, où la division et l'échelle sont gérées par des sous-routines spécifiques.

Parmi ce module, la sous-routine exp_cal calcule la série de Taylor pour e^x en utilisant la formule $1+x+\frac{x^2}{2}+\frac{x^3}{6}$. La boucle itère à travers les calculs nécessaires pour chaque terme, mettant à jour le résultat en effectuant des multiplications pour les puissances de x et des divisions pour les termes factoriels. Les résultats intermédiaires sont stockés dans des registres et, après le calcul du terme final, le résultat est stocké en mémoire SRAM. L'opération entière implique plusieurs niveaux de sous-routines imbriquées pour la multiplication, la division et le calcul de puissance, assurant ainsi la précision dans le calcul de la série de Taylor. Enfin, le code restaure la pile et retourne, laissant le résultat de e^x dans des emplacements mémoire désignés.

3.3 Boucle principale

La boucle principale effectuée par le main est toute petite comparée à la taille du code. En effet, un registre *state* décrit dans quel état est le système et la boucle main compare ce registre avec ses valeurs possibles et effectue des branchements à d'autre sous-routines permettant la réalisation de toutes les fonctions du système. Voici le schéma illustrant sa manière d'opérer.

Sur le schéma on peut observer :



8. Main loop

State_0 routine qui correspond au dispositif dans son état d'accueil.

State_1 routine correspond à l'état lorsqu'on veut changer des paramètres du système. (Il est bon de savoir que d'autres branchements se font après cette routine.)

Alarm correspond au mode lorsque le dispositif détecte une température supérieure à celle qui est seuille. Ici aussi, des branchements se font après celui-ci. Ces branchements ne seront pas détaillés dans ce rapport car ils susciteraient trop de place mais vous pouvez les observer dans le code en annexe qui est très bien commenté.

Concernant les manières dont *state* est modifié, elles seront traitées dans la section 3.5, car nous devons d'abord développer les interruptions et timers utilisés dans le projet.

A l'issue de *Alarm*, nous retournons dans le reset car ceci nous permet de retourner le système à son état initial et de réallouer complétement la mémoire qui nous permet d'éviter de potentiel collision de données. Ceci n'impose pas de problème pour la suite de l'utilisation du système car le code, lorsqu'il est modifié, est stocké dans l'EEPROM garantissant que même si la carte est éteinte, le code choisit par l'utilisateur reste le même.

3.4 Timers et interruptions

Dans ce projet, nous utilisons les timers 0 et 2. Leurs paramétrisations est indiquées dans le tableau ci-dessous.

Timer	Nb de bits	Clock	Prescaler	Interrupt type	Overflow period
Timer 0	8	32'768 Hz	6	Overflow	2s
Timer 2	8	4MHz	2	Overflow	0.512ms

Le timer 0 est utilisé pour réactualiser la température toutes les 2 secondes. Tandis que le timer 2 est utilisé pour générer un son sur le buzzer lorsque le dispositif est en mode *alarm*.

Pour ce qui est des interruptions sur les ports utilisés, nous utilisons les 4 interruptions INT 4-7 qui sont configurées pour être activée si le pin détecte une tension au niveau bas. Celles-ci sont utilisées pour l'utilisation du key-pad.

3.5 Modification de state

Par défaut *state* est mis à 0 et le système est dans son mode d'accueil. Lorsqu'une interruption du key-pad est détectée, la sous routine lié vérifie l'état de *state* et s'il est à 0, elle le met à 1, afin d'entrer dans le mode *state 1 une fois de retour dans le main*. Une fois le branchement vers *state_1*, à l'issu des divers branchements effectués, *state* est remis à 0. Lorsqu'un excès de température est détecté, state est mis à 2 et une fois tous les branchements effectués, après le mode *alarm*, la boucle repasse par le reset est donc *state* est remis à 0.

4 Accès aux périphériques

Dans cette section figure quelques détails, concernant certains périphériques, qui n'ont pas encore était expliqué dans ce rapport.

4.1 Capteur de température

Le périphérique qui permet l'accès à la température courante communique, avec le microcontrôleur, grâce au protocole Dallas 1-wire. Étant donné le long temps de latence demandé par ce processus, lorsque *state* n'est pas égal à 0, la communication ne s'effectue pas, et l'interruption généré par le timer 0 n'a pas d'action particulière. Cela est nécessaire dans le cas où le microcontrôleur n'est pas au repos car le programme doit être réactif face aux interactions de l'utilisateur, que ça soit par le key-pad ou l'encoder.

4.2 Servo moteur

La rotation du servo moteur est générée, dans une boucle « loop », par un signal PWM. Le nombre de fois que cette boucle est parcourue dépend du résultat du calcul de l'équation d'Arrhenius, mais, est programmé avec un offset de 0xf0 afin de garantir dans tous les cas une rotation du moteur.

4.3 LCD

L'affichage sur l'écran LCD se fait grâce aux méthodes du fichier *printf.asm* fournit par le cours. Ce périphérique utilise également un module de transmission qui est UART. De plus, nous avons remarqué que dû au nombre de périphériques utilisé dans notre projet, des collisions sur les bus de la carte entre le LCD et certains ports pouvaient entrainer des comportements erronés. Ainsi notre solution pour remédier à ce problème, a été de réactualiser l'affichage du LCD le moins souvent possible.

4.4 Pompe

La pompe employée est un périphérique qui demande plus de puissance que ce que la carte permet de fournir. Ainsi l'utilisation d'une alimentation externe avec un transistor fonctionnant comme un switch était nécessaire pour la faire fonctionner comme il se doit.

5 Annexes

5.1 Code Principale - 355665_364154.asm

```
Created: 22/05/2024 23:41:19
     Author: eliot
    EPFL - EE-208: Microcontroleurs et Systemes Numeriques
    Semester Project - Spring Semester 2024
    Groupe 014:
    Eliot Abramo - SCIPER 355665
    Mathias Rainaldi - SCIPER 364154
    Project description:
    Sprinkler System with user interface
.include "macros.asm" ; include macro definitions
.include "definitions.asm" ; include register/constant definitions
; ===== macros =====
; ------
.macro VERIFY ENTER
    /* check entry of keypads, deactivates certain keys in certain modes. Check
    if 'B','C','D','*' or '#' and loads case into interm register. */
; @2 = interm = intermediate register used to temporary store values
    ; @1 = wr1 = column counter
    ; @0 = wr0 = row counter
     _CPI
             @1,0x03
    brne
             not letter
     _CPI
             @0,0x01
    breq
             verif
    ldi
             @2.0x02
             fin
    dmi
verif:
    1di
             @2.0x01
                                       ; update the interm to the wanted value
    jmp
             fin
                                       ; jump to end
not_letter:
             @0,0x03
                                       ; check if on column 3
    CPI
    brne
             okay
    _CPI
             @1,0x01
                                       ; check if column 1
    breq
             okay
    1di
             @2,0x02
                                       ; update the interm to the wanted value
    jmp
             fin
okay:
    1di
            @2.0x00
                                       : set default value
fin:
.endmacro
.macro CHECK_AND_SET
   ; @5 = count = bit of code you want to change ; @4 = interm = intermediate register used to temporary store values
    ; @3 = a3 = fourth bit of code
; @2 = a2 = third bit of code
    ; @1 = a1 = second bit of code
    ; @0 = a0 = first bit of code
    cpi
            @5, 0x00
                                       ; compare a3 with 0x23 ('#' ASCII code)
                                      ; if equal, branch to set_a0
; compare a2 with 0x23
    breq
            set_a0
             @5, 0x01
             set_a1
                                       ; if equal, branch to set_a1
             @5, 0x02
                                       ; compare a1 with 0x23
    breq
            set_a2
                                       ; if equal, branch to set_a2
                                       ; compare a0 with 0x23
    cpi
             @5, 0x03
                                       ; if equal, branch to set_a3
    breq
            set a3
```

```
set_a0:
                                  ldi
                                                                   @5, 0x01
                                                                                                                                              ; set a3 to interm
                                   mov
                                                                    <u>@</u>0, <u>@</u>4
                                  rjmp
                                                                   end
                                                                                                                                                     ; jump to end
                  set_a1:
                                                                   <u>@</u>5, 0x02
                                  ldi
                                                                                                                                                   ; set a2 to interm
                                                                   @1, @4
                                  mov
                                  rjmp
                                                                   end
                                                                                                                                                     ; jump to end
                  set_a2:
                                  ldi
                                                                   @5, 0x03
                                   mov
                                                                   @2, @4
                                                                                                                                     ; set a1 to interm
                                  rjmp
                                                                   end
                                                                                                                                                   ; jump to end
                  set_a3:
                                                                  <u>@</u>5, 0x00
                                 ldi
                                                                                                                         ; set a0 to interm
                                                                  @3, @4
                                mov
                  end:
                               nop
 .endmacro
 .macro DECODE_ASCII
                 ; used to decode the input into an ASCII value \,
                  ; @2 = interm = intermediate 'temporary' register used in calculations
                  ; @1 = wr1 = r1 = column = high bit
                  ; @0 = wr0 = r2 = row = low bit
                  CLR2 ZL, ZH
                  ;point Z to ASCII table
                  ldi ZL, low(2*(KeySet01))
ldi ZH, high(2*(KeySet01))
                  ; move pointer to value pressed on keypad % \left( 1\right) =\left( 1\right) \left( 1\right) +\left( 1\right) \left( 1\right) \left( 1\right) +\left( 1\right) \left( 1\right) \left(
                                      ZL, @0
ZL, @0
                  add
                  add
                  add
                                           ZL, @0
                                       ZL, @0
ZL, @1
                  add
                  add
                  ;load ASCII value to temporary register to be used later
.endmacro
.macro ROW_MACRO
                ; used to simplify the detection of the correct row of the keypad
                  ; @4 = state = current state of system
                  ; @3 = mask for the row
                 ; @2 = wr0 = row counter
                 ; @1 = mask to extract correct row
                 ; @0 = row number on keypad (0->3)
                  ; check if in state_0, if not update the position on keypad
                _CPI @4, 0x00
brne not_state_0
                WAIT_MS 500
                _LDI
                                           @4, 0x01
                 reti
not_state_0:
               _LDI @2, @0
                 _LDI
                                             @3, @1
.endmacro
.macro COLUMN_MACRO
               ; used to simplify the detection of the correct column of the keypad
                  ; @2 = column number (0->3)
                ; @1 = next column subroutine address
                ; @0 = column identification
                WAIT_MS
                                                                   KPD_DELAY
                OUTT
                                                                   KPDO, @0
                WAIT_MS
                                                                   KPD DELAY
                                                                   w.KPDI
                in
                 and
                                                                   w.mask
                 tst
                                                                   @1
                brne
                 _LDI
                                                                   wr1,@2
      .endmacro
```

```
.macro READ_EEPROM
     ; used to read the value at an EEPROM address and store it accordingly
     ; @1 = register to store value at address
     ; @0 = value address in EEPROM
     push xh
     push a0
     clr a0
     ldi xl, low(@0)
     ldi xh, high(@0)
rcall eeprom_load
     mov @1, a0
     pop xh
     pop xl
 .endmacro
 .macro WRITE_EEPROM
     ; used to write a value to an EEPROM address
     ;@1 = address in EEPROM to store value at
     ;@0 = value to store in EEPROM
     push
     push
            xl
     push
            xh
     ;store selected value in the selected adress in the EEPROM
     mov
            a0, @0
             xl, low(@1)
     ldi
     ldi
             xh, high(@1)
     rcall
            eeprom_store
     pop
             xh
             xl
     pop
             a0
     sei
 .endmacro
.macro INITIALZE_CODE
    ; used to read the code in the EEPROM and check if it is a possible code
    ; (i.e. the values between \theta-9) and store it in the system.
    ; @1 = address in EEPROM
    ; @0 = value to save at address
    push
           b0
    clr
            b0
    READ_EEPROM
                   @1, b0
    cpi
            b0,0x31
    brlo
            set_default
    cpi
            b0, 0x44
    brsh
            set_default
set_val:
    nop
    mov
            @0, b0
    rjmp
            end
set_default:
           @0, 0x31
    _LDI
end:
    nop
    pop
.endmacro
; === definitions ===
.equ KPDD = DDRE
.equ KPDO = PORTE
.equ KPDI = PINE
.equ KPD_DELAY = 30
                                    ; msec, debouncing keys of keypad
.def
        wr0 = r2
                                    ; detected row in hex
        wr1 = r1
                                     ; detected column in hex
.def
.def
        mask = r14
                                     ; row mask indicating which row has been detected in bin
```

```
wr2 = r15
                                    ; semaphore: must enter LCD display routine, unary: 0 or other
.def
        interm = r16
                                   ; intermediate register used in calculations
.def
        state = r6
                                   ; store state of system, three states total
.def
       temp0 = r8
temp1 = r9
                                   ; temperature0 (LSB)
.def
                                   ; temperature1 (MSB)
       chg = r26
                                   ; reload temperature
.def
        count = r27
                                   ; to know at which character of code to change
.def
       temp_MSB = 0xff0a
                                   ; temperature MSB address
.equ
                                   ; temperature LSB address
        temp_LSB = 0xff0b
       code1_address = 0xff0c
.equ
                                   ; first address for passcode
       code2_address = 0xff0d
.equ
                                   ; second address for passcode
       code3 address = 0xff0e
                                   ; third address for passcode
.equ
       code4_address = 0xff0f
                                   ; fourth address for passcode
.equ
.dseg
.org 0x0100
   temp_seuil: .byte 2
                                   ; stores the threshold value for the temperature
    code: .byte 4
exp_result: .byte 2
                                   ; stores the code of the system
; stores the result of the taylor series
; === interrupt vector table ===
.org 0
    jmp reset
.org 10
    jmp isr_ext_int0
                                   ; external interrupt INT4
    jmp isr_ext_int1
                                   ; external interrupt INT5
                                   ; external interrupt INT6
    jmp isr_ext_int2
    jmp isr_ext_int3
                                   ; external interrupt INT7
.org OVF0addr
                                   ; external interrupt for temperature sensor
   rjmp read_temp
.org OVF2addr
                                   ; timer overflow 2 interrupt vector
   rjmp overflow2
; === interrupt service routines ===
      0x30
isr_ext_int0: ; detect row 0
    ROW_MACRO 0x00, 0b00010000, wr0, mask, state
                column_detect
    rimp
isr_ext_int1: ; detect row 1
    ROW_MACRO 0x01, 0b00100000, wr0, mask, state
                column_detect
isr_ext_int2: ; detect row 2
    ROW_MACRO 0x02, 0b01000000, wr0, mask, state
                column_detect
    rjmp
isr_ext_int3: ; detect row 3
    ROW_MACRO 0x03, 0b10000000, wr0, mask, state
    rjmp
                column_detect
column detect:
                KPDO,0xff ; bit4-7 driven high
    OUTI
col7: ; check column 7
    COLUMN_MACRO 0xf7, col6, 0x03
                   isr_return
col6: ; check column 6
    COLUMN_MACRO 0xfb, col5, 0x02
                   isr return
    rimp
col5: ; check column 5
    COLUMN_MACRO 0xfd, col4, 0x01
                   isr_return
col4: ; check column 4
                   0xfe, isr_return, 0x00
    COLUMN MACRO
```

```
rjmp isr_return
isr_return:
                      _w,10 ; sound feedback of key pressed acknowledge
beep01:
    OUTI KPDO,
                      0xf0
    _LDI
                      wr2,0xff
    reti
read_temp: ; temperature sensor interrupt routine
                                            ; check if in first state
             state,0x00
     CPI
     breq
             PC+2
    reti
    push
             a0
                                            ; a0 might change, save on stack in case
    push
             a1
    rcall
             wire1_reset
                                           ; send a reset pulse
    CA
             wire1_write, skipROM
                                            ; skip ROM identification
                                            ; initiate temp conversion
    CA
             wire1_write, convertT
    WAIT MS 750
                                            ; wait 750 msec
    rcall
            1cd home
                                            ; place cursor to home position
    rcall
             wire1_reset
                                            ; send a reset pulse
             wire1_write, skipROM
             wire1_write, readScratchpad; send address to read value from sensor
    rcall
                                            ; read temperature LSB
             c0, a0
                                            ; save temperature LSB
                                            ; read temperature MSB
             wire1_read
    rcall
     mov
             temp1,a0
                                            ; save temperature MSB
     mov
             temp0,c0
    ldi
             chg,0xff
                                            ; indicate temperature has changed
     ; now we compare with the temperature seuil
            xl, low(temp_seuil)
     ldi
              xh, high(temp_seuil)
     ld
              a0, x+
     1d
             a1, x
     CP2
             temp1,temp0,a1,a0
                                            ; restore a1
             a1
     pop
              a0
                                            ; restore a0
     pop
     brlo
             PC+2
     _LDI
             state, 0x02
     reti
overflow2 :
     INVP DDRD, SPEAKER
     reti
; === include necessary libraries ===
; === Include necessary libraries ===
.include "lcd.asm" ; include UART routines
.include "printf.asm" ; include formatted printing routines
.include "eeprom.asm" ; include internal EEPROM routines
.include "wire1.asm" ; include one-wire protocol routines
.include "encoder.asm" ; include encoder routines
                          ; include formatted printing routines
; === initialization and configuration ===
.org 0x400
reset:
     LDSP
             RAMEND
                                  ; Load Stack Pointer (SP)
     ;=== save state of MCU control register ===
     in _w, MCUCR
     sts
              0xDDDD, _w
     clr
     ;=== initialize the protocols ===
     rcall LCD_init ; initialize UART
                                    ; initialize 1-wire(R) interface
             wire1 init
     rcall
                                    ; initialize encoder interface
     rcall
              encoder init
```

```
;=== configure output pins ===
                             ; configure PORTA to output
   OUTI
           DDRA, 0x01
   OUTI
           PORTA, 0x00
                             ; ensure pin not yet activated
   OUTI
           DDRC, 0xff
                              ; configure portC to output
   OUTT
           DDRD. 0xff
                              ; configure portD to output
                              ; set bit speaker is connected to 1
           DDRD, SPEAKER
   sbi
   ;=== configure keypad pins ===
                          ; bit0-3 pull-up and bits4-7 driven low
   OUTI
           KPDD, 0x0f
   OUTI
           KPDO,0xf0
                              ; >(needs the two lines)
    ;=== configure interrupts ===
                              ; enable INT4-INT7
   OUTI
           EIMSK.0xf0
   OUTI
          EICRB, 0b00
                              ; >at low level
   ;=== configure timer ===
   OUTI
           TIMSK, (1<<TOIE0) ; timer0 overflow interrupt enable
   OUTI
           ASSR, (1<<AS0)
                              ; clock from TOSC1 (external)
   OUTI
           TCCR0,6
                              ; CS0=1 CK
   OUTI
           TCCR2.2
                              ; prescaler for the buzzer
   ;=== set temperature limit ===
   _LDI
                              ; corresponds to 30 degree celcius
          a0,0xe0
          a1,0x01
   ldi
           xl,low(temp_seuil)
   ldi
          xh,high(temp_seuil)
   st
          x,a0
   inc
          xl
          x,a1
   st
   ;=== set initial code ===
    ; initializes all 4 bits of the code using macro
   INITIALZE_CODE
                     a0, code1_address
   INITIALZE_CODE
                       a1, code2_address
   INITIALZE CODE
                      a2, code3 address
                   a3, code4_address
   INITIALZE_CODE
    ; add code loaded in to pointer x, to be used later in verification
   1di
         xl,low(code)
   1di
           xh, high(code)
   st
           x+, a0
          x+,a1
   st
   st
          x+, a2
   st
           x, a3
   ;=== set initial values ===
   PRINTF LCD
                              ; display initial LCD message
.db FF,CR,"Sprinkler Sys",0
   _LDI
          a0, 0x23
                            ; sets the a registers to #
   _LDI
          a1, 0x23
                              ; for display purposes
   _LDI
          a2, 0x23
          a3, 0x23
   LDI
          state, 0x00
                              ; set initial state to 0
   _LDI
    ;=== clear registers ===
   CLR8 count, wr0, wr1, wr2, chg, b1, b2, b3
   sei
                              ; enable interrupt
: === main program ===
main:
   CPI
          state,0x00 ; check if in state 0
   breq
           state_0
    _CPI
           state,0x01 ; check if in state 1
   brne
           PC+2
   rjmp
           state 1
    CPI
           state,0x02 ; check if in state 2
           PC+2
   brne
   rjmp
           alarm
```

```
nop
     rjmp
            main
 ; ==== sub-routines ====
 /***** Ordered as followed *****
    -> State 0 - Home Page
-> State 1 - Enter Code
    -> State 2 - Alarm and Servo
     -> Code Verifcation
     -> Store and Load from EEPROM
     -> Menu System
         -> Temperature sub-menu
        -> Code sub-menu
     -> Math calculations sub-routines
 /*************************/
 ;==== State 0 - Home Page ====
 state_0:
     tst
            chg
                        ; check flag/semaphore
     breq
            main
                        ; if no change, back to main
     clr
            chg
            a0, temp0 ; update temperature values
     mov
            a1, temp1
     mov
     PRINTE LCD
                         ; print temperature
 .db LF, "Curr Temp=", FFRAC2+FSIGN, a, 4, $22, "C ", 0
           main
    rjmp
 ;==== State 1 - Enter code ====
 state_1:
    rcall LCD_clear
                          : clear LCD
     clr
            count
     PRINTF LCD
                           ; update LCD display
 .db FF,CR, "ENTER: ",0
                         ; reset a values to # for display
   LDI
          a0. 0x23
   LDI
         a1, 0x23
                         ; purposes
   _LDI
           a2, 0x23
   _LDI
           a3, 0x23
display_code:
                         ; check flag/semaphore
   tst
   breq
           display_code ; loop back till not 0
   clr
           wr2
   VERIFY_ENTER wr0,wr1,interm ; check if BCD*# dont count,if A,verify code,otherwise ok
                                 ; interm=0 ok, interm=1 verify code, interm=2 dont count
   cpi
           interm, 0x01
   brne
           PC+2
           verify_code
   jmp
   cpi
           interm.0x02
         display_code
   brea
   DECODE_ASCII wr0, wr1, interm
CHECK_AND_SET a0, a1, a2, a3, interm, count
                                                ; decode the input from keypad into the ascii value
                                                ; Update value accordingly (change incremental
                                                 ; bit of the code)
   PRINTF LCD
                                                ; update LCD
.db LF, "Code in: ",FSTR, a,0
   rjmp display_code
;==== State 2 - Alarm and Servo system ====
         TIMSK,(1<<TOIE2)
   OUTI
                               ; enable the timer
   rjmp
         state_1
stop_alarm :
                                     ; sub-routine to turn off alarm
   WAIT_MS 1000
                                    ; clear display
   rcall LCD_clear
   PRINTF LCD
                                     ; update display
   .db FF,CR,"Sprinkler Sys",0
```

```
OUTI TIMSK,(1<<TOIE0)
                                          ; Disable the timer
    _LDI state,0x00
                                          ; update the state of the system
servo_routine:
                                         ; disable interrupts to ensure execution of sub-routine
; add initial offset to duration of movement of servo
; call the sub-routine to calculate the coefficient of Arrhenius
    cli
    ldi _w, 0xf0
    call calculate_math
    add _w, a0
                                          ; add result of exponential to offset
    add _w, a1
rcall LCD_clear
                                         ; clear LCD
    PRINTF LCD
                                          ; update LCD
    .db FF,CR,"Servo activated",0
    OUTI DDRA, 0x01
                                          ; Activate the pump by activating correct pin
    OUTI PORTA, 0x01
    lds interm, 0xDDDD
                                         ; reset the MCUCR to initial state to ensure
    out MCUCR, interm
                                         ; correct working of servo motor
loop:
    tst _w
                                         ; test to see if end of loop
    breq end
   dec _w
P0 PORTC,SERVO1
                                         ; send PWM impulse in order to move the servo
    WAIT_US 1900000
    P1 PORTC, SERVO1
    WAIT_US 100000
    rjmp loop
    sei
                                          : reactivate the interrupts
    jmp reset
                                          ; reset the system to initial state
;==== Code verification ====
verify_code:
                                         ; clear LCD
    rcall
                 LCD_clear
    PRINTF
                                          ; Update LCD
  .db CR, CR, "verification...",0
       WAIT_MS
                                               ; Add wait to ensure message can be seen by user
                    1000
       push
                c0
                                               ; Push registers on SRAM in order to be able to
       push
                                               ; recover them after
                c1
       push
                c2
       push
                с3
       ldi
                xl,low(code)
                                               ; load code from SRAM address into x pointer
       ldi
                xh, high(code)
                c0,x+
       1d
       1d
                c1,x+
       1d
                c2,x+
                c3,x
                a0,c0
                                               ; check if each bit of the code is correct
       breq
                PC+2
       rjmp
                wrong_code
                a1.c1
       ср
       brea
                PC+2
       rjmp
                wrong_code
                a2,c2
       ср
                PC+2
       rjmp
                wrong_code
                a3,c3
       breq
                PC+2
       rjmp
                wrong_code
       nop
       ; restore values
       pop c3
       pop c2
       pop c1
       pop c0
   correct_code:
       nop
```

```
PRINTF LCD
.db CR, LF, "Correct Code"
                                   ; update LCD display
.db 0
    _CPI
           state,0x02
                                     ; check if in alarm state
           PC+2
    rjmp
          stop_alarm
   rimp menu
                                     : loop back to menu
wrong_code:
           c3
                                     : restore initial values of registers
    pop
    pop
           c1
    pop
           c0
   PRINTF LCD
                                     ; update LCD
.db LF, "Wrong code ",0
WAIT_MS 1000
    CPI
                                   ; check if in Alarm mode
           state,0x02
           PC+2
    brne
   rjmp
           state_1
    _LDI
           state,0x00
                                     ; check if in normal mode
    rcall LCD_clear
    PRINTF LCD
                                     ; update LCD
.db FF,CR,"Sprinkler Sys",0
   rjmp
          main
;==== Menu System ====
menu:
   WAIT_MS 1000
                                     ; add wait offset in order to ensure correct functioning of system
   rcall LCD_clear
                                     ; clear LCD display
menu1:
   WAIT_MS 100
                                     ; add wait to ensure correct functioning
   PRINTF LCD
                                     ; Update LCD display
.db FF,CR,"A=CHANGE CODE",0
 PRINTF LCD
                                          ; Update LCD display
  .db LF,"B=CHANGE TEMP ",0
      tst
              wr2
                                          ; check flag/semaphore
      breq
              menu1
      clr
              wr2
      DECODE_ASCII wr0, wr1, interm ; Decode input into ASCII value
              interm,0x41
                                          ; branching operations based on the result of interm
      cpi
              PC+2
      brne
      rjmp
              change_code
                                          ; change code option
      cpi
              interm,0x42
              change_temp
                                          ; change temp option
      rjmp
              menu1
  ;==== Temperature sub-menu ====
  change_temp:
             xl,low(temp_seuil)
                                          : load the threshold temperature into pointer X
      ldi
      ldi
              xh,high(temp_seuil)
      ld
              a0,x+
                                          ; load values into a registers
      ld
              a1,x
      rcall LCD_clear
                                          ; clear LCD display
      PRINTF LCD
                                          ; update LCD display
  .db FF,CR,"Change temp:",0
  change_temp1:
                                          ; change temp sub-routine part 2, needed for looping
      WAIT_MS 10
                                          ; poll encoder
      rcall encoder
      PRINTF LCD
                                           : update LCD
  .db LF, "Temp=", FFRAC2+FSIGN, a, 4, $32, "C ",0
                                          ; check flag/semaphore
      breq change_temp1
                                          ; loop back
      clr
            wr2
      DECODE_ASCII wr0, wr1, interm
                                         ; decoode input into ASCII
      cpi
            interm,0x41
set new temp
                                          ; branching on state of interm
      brea
                                          ; save new temp
```

```
rjmp
            change_temp1
                                        ; loop back
set_new_temp
    ldi
            xl,low(temp_seuil)
                                        ; load threshold temp into x pointer
    1di
            xh,high(temp_seuil)
    st
            x+, a0
    st
            x,a1
    rcall LCD clear
                                        ; clear LCD
    PRINTF LCD
                                        ; update LCD
.db LF, "NEW TEMP SET",0
    _LDI state,0x00
                                        ; reset state of system to default
    WAIT_MS 1000
                                        ; wait to ensure system has time to react
   rcall LCD_clear
PRINTF LCD
                                        ; clear LCD display
                                        ; update LCD display
.db FF,CR,"Sprinkler Sys",0
                                        : loop back to main
    rjmp main
;==== Change code sub-menu ====
change_code :
    rcall LCD_clear
PRINTF LCD
                                        ; clear LCD display
                                        ; update LCD display
.db FF,CR,"WRITE NEW CODE:",0
    1di
            xl.low(code)
                                        ; load existing code
    ldi
            xh, high(code)
            a0,x+
    1d
    1d
            a1,x+
    1d
            a2,x+
            a3,x
    PRINTF LCD
                                        ; update LCD display
.db LF, "NEW CODE: ",FSTR, a,0
    WAIT_MS 500
                                        ; wait to ensure system has time to react
    ldi
         count,0x00
                                        ; reset count to 0
change code 1:
                                         ; second change code sub-routine, used for looping
    WAIT MS 1
                                         ; wait to ensure time has time to react
                                         ; check flag/semaphore
    tst
    breq
           change_code_1
    VERIFY_ENTER wr0,wr1,interm
                                         ; loads case of key pressed into interm
    cpi
            interm,0x01
                                         ; performs branching to redirect to correct case
    brne
            PC+2
    jmp
            set new code
            interm,0x02
    cpi
            PC+2
    brne
            change_code_1
    rjmp
    DECODE_ASCII
                     wr0, wr1, interm
                                        ; decode input to ASCII value
    CHECK_AND_SET
                    a0, a1, a2, a3, interm, count
    PRINTF LCD
                                        ; update LCD display
 .db LF, "NEW CODE: ",FSTR, a,0
                    change_code_1
    rjmp
                                         : loop back
 set_new_code:
            xl,low(code)
                                         ; load existing code
     ldi
             xh, high(code)
            x+,a0
     st
            x+,a1
    st
            x+,a2
    st
            x, a3
                                         ; push registers to SRAM in order to restore their
    push
            a0
                                         ; initial values later
    push
            a1
    push
            a3
                                         ; clear LCD display
     rcall
            LCD_clear
                                         ; update LCD display
    PRINTF LCD
```

```
.db LF, "NEW CODE SET",0
                                         ; reset state of system
    _LDI
           state,0x00
                                        ; wait to ensure the user can see message
    WAIT_MS 1000
    rcall LCD_clear
PRINTF LCD
                                         ; clear LCD display
                                         ; update LCD display
.db FF,CR,"Sprinkler Sys",0
    pop a3
                                         ; restore registers
    pop a2
    pop a1
    pop a0
    WRITE_EEPROM a0, code1_address
                                         ; write new code to EEPROM
    WRITE_EEPROM a1, code2_address
    WRITE_EEPROM a2, code3_address
    WRITE_EEPROM a3, code4_address
                                         ; loop back
;==== Math calculations sub-routines ====
; these libraries were imported here as otherwise they occupy too much SRAM and it can cause
; conflicts with the rest of the program.
.include "math.asm"
.include "taylor_2byte.asm"
                                        ; include math libraries
                                         ; include Taylor series library
{\tt calculate\_math:}
    call calculation_speed ; call function to calculate the coefficient of Arrhenius lds a0, exp_result ; load results into register
    lds
           a1, exp_result
    ret
                                         ; return to where function was cllaed
; === look up table for ASCII values===
KeySet01:
    .db 0x31, 0x32, 0x33, 0x41; 1, 2, 3, A
    .db 0x34, 0x35, 0x36, 0x42 ; 4, 5, 6, B
    .db 0x37, 0x38, 0x39, 0x43; 7, 8, 9, C
    .db 0x2A, 0x30, 0x23, 0x44; *, 0, #, D
```

5.2 Bibliothèque pour calculer coefficient d'Arrhenius – taylor_2byte.asm

```
EPFL - EE-208: Microcontroleurs et Systemes Numeriques
   Semester Project - Spring Semester 2024
   Groupe 014:
   Eliot Abramo - SCIPER 355665
   Mathias Rainaldi - SCIPER 364154
   Custom written math library to calculate the coefficient of Arrhenius
   on a 2-byte floating decimal system.
   k = \exp(E/(R*temp)) = \exp(x)
start_math:
   ; save current state of system in order to restore it after
           _sreg, SREG
   push
            sreg
   push
           zh
    push
           z1
   push
           yh
    push
           y1
   push
           xh
    push
           x1
    push
           _w
    push
    push
           d3
    push
           d2
    push
           d1
    push
           c3
    push
   push
   push
           c1
   push
           b3
   push
   push
           b2
   push
           b1
```

```
b0
   push
    push
           a3
   push
           a2
    push
           a1
   push
           a0
calculation_speed:
          xl, high(exp_result)
                                          ; load value of exponential from memory into x pointer
    lds
    lds
          xh, low(exp_result)
    lds
          zl, temp_LSB
                                          ; load threshold temperature from memory into \boldsymbol{z} pointer
   lds
          zh, temp_MSB
   ; Calculate k = \exp(E/(R*temp)) = \exp(x)
    ;x = x/temperature
    ;initial division
    ldi
         a0, 0x10
   ldi
           a1, 0x27
    mov
           b0, zl
           b1. zh
   mov
    call
           div22
           r17, c0
   mov
    ;scale remainder to adapt floating decimal
    mov
           a0, d0
           a1, d1
b0, 0x64
    mov
   ldi
   call
           mul21
    ;second division to calculate decimal part
           a0, c0
    mov
           a1, c1
    mov
           a2, c2
    mov
           b0, zl
           b1, zh
    mov
    call
          div32
           r16, c0
      ;update pointer
              zl, r16
      mov
              zh, r17
              r16
      clr
              r17
  ; result = exp(x)
  exp_cal:
      ; initialize all of the counters and placeholder values needed
      ldi
              r17, 0x01
      ldi
              r26, 0x02
      ldi
              r27, 0x02
      ADD2 r17, r16,
                           zh,zl
      ; Calculate e^x using Taylor series
      ; 1 + x + x^2/2 + x^3/6
  exp_loop:
      ; Calculate x^i
      clr
              r11
      inc
              r11
      push
              r17
      push
              r16
      rcall pow_loop
      ; Calculate x/i! = r28/r27
      pop
      pop
      ;initial division
              a0, r29
      mov
      mov
              b0, r27
      call
              div11
      add
              r17, c0
      ;second devision to adapt data in order to find decimal part
      add
            r28, d0
              a0, r28
      mov
```

```
b0, r27
   mov
   call
           div11
   add
           r16, c0
   ;Update i and factorial
   inc
          r26
           a0, r27
           b0, r26
   call
           mu144
   mov
           r27, c0
   ; Repeat for 3 terms (3 because max value is ff = 256 and worst case 5^3 < 256 but not 5^4)
   cpi
           r26, 4
   brne
           exp_loop
           high(exp_result), r17
                                    ; write results to memory to ensure accessible later
   sts
   sts
           low(exp_result), r16
end_math:
   ; restore system state
   pop
           a0
   pop
           a1
   pop
           a2
   pop
           a3
   pop
           b0
   pop
           b1
   pop
           b2
   pop
           b3
   pop
           c0
   pop
           c1
   pop
           c2
   pop
           c3
   pop
           d0
   pop
           d1
   pop
           d2
   pop
           d3
   pop
             _w
xl
     pop
     pop
     pop
             xh
     pop
             yl
             yh
     pop
     pop
             zl
             zh
     pop
     pop
             _sreg
     out
             SREG, _sreg
             ; return to where math functions called in main program
 ; ==== sub-routines ====
 ;-----
 pow_loop:
     ; calculate x^i
            a0, zl
     mov
     mov
             b0, z1
           mul11
     call
             a0, c0
     mov
            a1, c1
     mov
             b0, 0x64
     ldi
            div21
     call
     add
             r28, c0
             a0, zh
     mov
             b0, zh
     mov
     call
             mul11
     add
             r29, c0
     inc
             r11, r26; compare i and r11
     ср
     brlt
             pow_loop ; if i != interm2, repeat loop
     ret
```

5.3 Bibliothèque pour l'encodeur - encoder.asm

Pour l'encodeur, puisque nos fonctions non seulement s'ajoute à la bibliothèque du cours mais la complémente aussi et donc il y a une grande différence entre la nôtre et celle du livre, nous avons fait le choix de la présenter en complet dans l'annexe. C'est pour cette raison nous avons inclus la bibliothèque en entier ci-dessous.

```
EPFL - EE-208: Microcontroleurs et Systemes Numeriques
    Semester Project - Spring Semester 2024
    Groupe 014:
    Eliot Abramo - SCIPER 355665
    Mathias Rainaldi - SCIPER 364154
    Modified encoder.asm file in order to function on a 2 byte system
    instead of 1 byte.
; === definitions ===
.equ ENCOD = PORTD
enc_old:.byte 1
.cseg
; === macro ===
.macro add_volker2
                            ;if button down, macro to increment the
    add @0,a2
                            ;fourth bit of the first byte while
    brcc end2
                            ;checking and avoid errors du to
    inc @1
                            ;overflow/carry
    ldi a3,0x01
end2 :
    nop
.endmacro
.macro add_volker
                            ;if button up, macro to incrment on
    inc @0
                            ;two bytes while checking and avoid
    cpi @0,0x00
                            ;errors due to overflow/carry
    brne end1
    inc @1
    ldi a3,0x01
end1 :
  .endmacro
  .macro sub_volker2
                             ;if button down, macro to decrement the
     push @0
                             ;fourth bit of the first byte while
     push a2
                             ;checking and avoid errors du to
     ldi a2,0xf0
                             :overflow/carry
     and @0,a2
     pop a2
     cpi @0,0x00
     pop @0
     breq mala
     subi @0,0x10
     jmp end3
 mala:
     subi @1,0x01
     subi @0,0x10
 end3 :
  .endmacro
 .macro sub_volker
                             ;if button up, macro to decrement on
     cpi @0,0x00
                             ;two bytes while checking and avoid
     breq mala
                             ;errors due to overflow/carry
     subi @0,1
     jmp end
 mala:
     subi @1.1
     subi @0,1
  .endmacro
 ; === routines ===
 encoder_init:
     in w,ENCOD-1
                         ; make 3 lines input
            w,0b10001111
```

```
out ENCOD-1,w
   in w, ENCOD
                        ; enable 3 internal pull-ups
   ori w,0b01110000
   out ENCOD, w
   ret
encoder:
; a0,b0 if button=up then increment/decrement a0
; a0,b0 if button=down then incremnt/decrement b0
       T=1 button press (transition up-down)
; Z Z=1 button down change
   clr a3
   ldi a2,0x10
   clt
                            ; preclear T
   in _w,ENCOD-2
                            ; read encoder port (_w=new)
   andi _w,0b01110000 ; mask encoder lines (A,B,I) lds _u,enc_old ; load prevous value ( u=old
                            ; load prevous value (_u=old)
                           ; compare new<>old ?
   cp _w,_u
brne PC+3
   clz
                            ; if new=old then return (Z=0)
   sts enc_old,_w
                           ; store encoder value for next time
    eor _u,_w
                            ; exclusive or detects transitions
   clz
                            ; clear Z flag
   sbrc
            u, ENCOD I
           encoder_button ; transition on I (button)
   rjmp
           _u,ENCOD_A
    shrs
                            ; return (no transition on I or A)
   ret
   sbrs
            _w, ENCOD_I
                            ; is the button up or down ?
   rjmp
           i_down
i_up:
    sbrc
            _w,ENCOD_A
    rjmp
            a_rise
a_fall:
    add_volker a0,a1
                                        ; if B=1 then increment
           _w,ENCOD_B
    rjmp i_up_done
    subi a0,1
    sub_volker a0,a1
                                ; if B=0 then decrement
    cpi a3,0x00
    breq PC+2
    subi a1,1
    rjmp
            i_up_done
a_rise:
    add_volker a0,a1
                                        ; if B=0 then increment
    sbrs _w,ENCOD_B
    rjmp i_up_done
    subi a0,1
sub_volker a0,a1
    cpi a3,0x00
    breq PC+2
    subi a1,1
                    ; if B=1 then decrement
i_up_done:
                            ; clear Z
i_down:
           _w,ENCOD_A
    sbrc
    rjmp a_rise2
a_fall2:
    add_volker2 a0,a1
                                        ; if B=1 then increment
    sbrc _w,ENCOD_B
    rjmp i_up_done
    subi a0,0x10
    sub_volker2 a0,a1
                                ; if B=0 then decrement
    cpi a3,0x00
    breq PC+2
    subi a1,0x01
           i_up_done
    rimp
a rise2:
    add_volker2 a0,a1
                                       ; if B=0 then increment
```

```
sbrs _w,ENCOD_B
rjmp i_up_done
subi a0,0x10
sub_volker2 a0,a1
cpi a3,0x00
breq PC+2
subi a1,0x01
i_down_done:
                                               ; set Z
      sez
encoder_button:
                  _w,ENCOD_I
i_rise
      sbrc
      rjmp
i_fall:
                                               ; set T=1 to indicate button press
      set
      ret
i_rise:
     ret
.macro CYCLIC ;reg,lo,hi
     cro CYCLIC;

cpi @0,@1-1

brne PC+2

ldi @0,@2

cpi @0,@2+1

brne PC+2

ldi @0,@1
.endmacro
```