MATLAB/SIMULINK MODEL OF SPACE VECTOR PWM FOR THREE-PHASE VOLTAGE SOURCE INVERTER

Atif Iqbal⁽¹⁾ Adoum Lamine⁽²⁾ Imtiaz Ashraf⁽¹⁾ Mohibullah⁽¹⁾

(1) Aligarh Muslim University, India (2) Liverpool John Moores University, UK

ABSTRACT

Variable voltage and frequency supply to ac drives is invariably obtained from a three-phase voltage source inverter (VSI). A number of Pulse width modulation (PWM) scheme is used to obtain variable voltage and frequency supply. The most widely used PWM schemes for three-phase VSI are carrier-based sinusoidal PWM and space vector PWM (SVPWM). There is an increasing trend of using space vector PWM (SVPWM) because of their easier digital realisation and better dc bus utilisation. This paper focuses on step by step development of MATLAB/SIMULINK model of SVPWM. Firstly model of a three-phase VSI is discussed based on space vector representation. Next simulation model of SVPWM is obtained using MATLAB/SIMULINK. Simulation results are also provided.

1. INTRODUCTION

Variable voltage and frequency supply for as drives is invariably obtained from a three-phase VSI. A number of PWM techniques have been presented to obtain variable voltage and frequency supply [1]. The most popular among those are carrier-based sinusoidal PWM and SVPWM. The major disadvantage of this scheme is lower dc bus utilisation. The maximum output voltage from VSI utilising this scheme is limited to 0.5V_{dc} (peak) or 0.353 rms. Space vector modulation improves dc bus utilisation by 15.15%, further digital implementation of this scheme is easier [1,2]. The SVPWM is identified as an alternative method of determination of switching pulse width and their position. The major advantage of SVWPM stem from the fact that there is a degree of freedom of space vector placement in a switching cycle. This improves the harmonic performance of this method.

The main focus of this paper is to develop a simple MATLAB/SIMULINK model. The reason for choice of MATLAB/SIMULINK as a development tool is because it is the most important and widely used simulation software and is an integral part of taught in most of the universities Electrical/Electronics Engineering courses. model of a three-phase inverter in presented on the basis of space vector representation. This is followed by the SVPWM. basic principle of MATLAB/SIMULINK model for the SVPWM is presented. Various simulation results are also included.

2. THREE-PHASE VSI MODELLING REVIEW

A mathematical model of three-phase is presented here based on space vector representation. The power circuit topology of a three-phase VSI is shown in Fig. 1 Each switch in the inverter leg is composed of two back-to-back connected semiconductor devices. One of these two is a controllable device and other one is a

diode for protection. Leg voltage waveforms is shown in Fig. 2 for 180° conduction mode.





Figure 1. Power circuit of a three-phase VSI.



It is observed from Fig. 2. that one inverter leg's state changes after an interval of 60° and their state remains constant for 60° interval. Thus it follows that the leg voltages will have six distinct and discrete values in one cycle (360°).

Space vector representation of the three-phase inverter output voltages is introduced next. Space vector is defined as;

where $\overline{a} = \exp(j2\pi/3)$. The space vector is a simultaneous representation of all the three-phase quantities. It is a complex variable and is function of time in contrast to the phasors.

Phase-to-neutral voltages of a star-connected load are most easily found by defining a voltage difference between the star point n of the load and the negative rail of the dc bus N. The following correlation then holds true:

$$v_A = v_a + v_{nN}$$

$$v_B = v_b + v_{nN}$$

$$v_C = v_c + v_{nN}$$
(2)

Since the phase voltages in a start connected load sum to zero, summation of equation (2) yields

$$v_{nN} = (1/3)(v_A + v_B + v_C) \tag{3}$$

Substitution of (3) into (2) yields phase-to-neutral voltages of the load in the following form:

$$v_a = (2/3)v_A - (1/3)(v_B + v_C)$$

$$v_b = (2/3)v_B - (1/3)(v_A + v_C)$$

$$v_c = (2/3)v_C - (1/3)(v_B + v_A)$$
(4)

Phase voltages are summarised in Table 1 and their corresponding space vectors are listed in Table 2.

Table 1 Phase voltage values for different switching states.

		Buttes.		
State	Switch On	v_A	v_B	v_C
1	1,4,6	$(2/3)V_{dc}$	$-(1/3)V_{dc}$	$-(1/3)V_{dc}$
2	1,3,6	$(1/3)V_{dc}$	$(1/3)V_{dc}$	$-(2/3)V_{dc}$
3	2,3,6	$-(1/3)V_{dc}$	$(2/3)V_{dc}$	$-(1/3)V_{dc}$
4	2,3,5	$-(2/3)V_{dc}$	$(1/3)V_{dc}$	$(1/3)V_{dc}$
5	2,4,5	$-(1/3)V_{dc}$	$-(1/3)V_{dc}$	$(2/3)V_{dc}$
6	1,4,5	$(1/3)V_{dc}$	$-(2/3)V_{dc}$	$(1/3)V_{dc}$
7 &	1,3,5	0	0	0
8	246		l	

Table 2 Phase voltage space vectors

rubic 2 i huse voltage space vectors			
State	Phase voltage space vectors		
1	$(2/3)V_{dc}$		
2	$(2/3)V_{dc}\exp(j\pi/3)$		
3	$(2/3)V_{dc}\exp(j2\pi/3)$		
4	$(2/3)V_{dc}\exp(j\pi)$		
5	$(2/3)V_{dc}\exp(j4\pi/3)$		
6	$(2/3)V_{dc}\exp(j5\pi/3)$		
7 and 8	0		

The discrete phase voltage space vector positions are shown in Fig. 3.




Figure 3. Phase voltage space vectors.

The binary numbers on the figure indicate the switch state of inverter legs. Here 1 implies upper switch being on and 0 refers to the lower switch of the leg being on. The most significant bit is for leg A, the least significant bit is related to leg C and the middle is for leg B.

3. SPACE VECTOR PWM

This section briefly discusses the space vector PWM principle. This PWM method is frequently used in vector controlled and direct torque controlled drives. In vector controlled drive this technique is used for reference voltage generation when current control is exercised in rotating reference frame.

It is seen in the previous section that a three-phase VSI generates eight switching states which include six active and two zero states. These vectors form a hexagon (Fig. 3) which can be seen as consisting of six sectors spanning 60° each. The reference vector which represents three-phase sinusoidal voltage is generated using SVPWM by switching between two nearest active vectors and zero vector. To calculate the time of application of different vectors, consider Fig. 4, depicting the position of different available space vectors and the reference vector in the first sector.




Figure 4. Principle of space vector time calculation. The time of application of active space voltage vectors is found from Fig. 4 as

$$t_{a} = \frac{\left| \frac{\overline{v_{s}^{*}}}{\left| \overline{v_{a}} \right|} \frac{\sin\left(\pi/3 - \alpha\right)}{\sin\left(2\pi/3\right)}$$

$$t_{b} = \frac{\left| \frac{\overline{v_{s}^{*}}}{\left| \overline{v_{b}} \right|} \frac{\sin\left(\alpha\right)}{\sin\left(2\pi/3\right)}$$
(5)

$$t_0 = t_s - t_a - t_b \tag{6}$$

where $|\overline{v_a}| = |\overline{v_b}| = (2/3)V_{dc}$. In order to obtain fixed frequency and optimum harmonic performance from SVPWM, each leg should change its sate only once in one switching period. This is achieved by applying zero state vector followed by two adjacent active state vector in half switching period. The next half of the switching period is the mirror image of the first half. The total switching period is divided intro 7 parts, the zero vector is applied for 1/4th of the total zero vector time first followed by the application of active vectors for half of their application time and then again zero vector is applied for 1/4th of the zero vector time. This is then repeated in the next half of the switching period. This is how symmetrical SVPWM is obtained. The leg voltage in one switching period is depicted in Fig. 5 for sector I.




Figure 5. Leg voltages and space vector disposition for one switching period in sector I.

The sinusoidal reference space vector form a circular trajectory inside the hexagon. The largest output voltage magnitude that can be achieved using SVPWM is the radius of the largest circle that can be inscribed within the hexagon. This circle is tangential to the mid points of the lines joining the ends of the active space vector. Thus the maximum obtainable fundamental output voltage is

$$\left| \overline{v_s^*} \right| = \frac{2}{3} V_{dc} \cos \left(\pi / 6 \right) = \frac{1}{\sqrt{3}} V_{dc}$$
 (7)

4. MATLAB/SIMULINK MODEL

This section details the step by step development of Matlab/Simulink model for SVPWM. The Simulink model is shown in Fig. 6. Each block is further elaborated in Fig. 7. The Matlab code used to generate the switching pattern is also provided. Each sub-blocks of Fig. 6 is described in the following subsection.

4.1 Reference Voltage Generation Block

Three-phase sinusoidal voltage is generated using 'function' block from 'Functions & Tables' sub-library of Simulink. This is then converted into two-phase equivalent using Clark's transformation equations [1]. This is once again implemented using the 'function' blocks. Further the two-phase equivalent is transformed to polar form using 'Cartesian to polar' block from 'Simulink extras' sub-library. The output of this block is the magnitude of the reference as the first output and the corresponding angle of the reference as the second output.

4.2 Switching Time Calculation

The switching time and corresponding switch state for each power switch is calculated in Matlab function block 'sf' using expressions (5) and (6). The Matlab code requires magnitude of the reference, the angle of the reference and timer signal for comparison. The angle of the reference voltage is hold for each switching period so that its value does not change during time calculation. The angle information is used for sector identification in Matlab code 'aaa'. Further, a ramping time signal is generated to be used in Matlab code. This ramp is generated using 'repeating sequence' from the source sub-library.

The Matlab code firstly identifies the sector of the reference voltage. The time of application of active and zero vectors are then calculated. The times are then arranged according to Fig. 5. This time is then compared with the ramp timer signal. Depending upon the location of the time signal, the switch state is defined. This switch state is then passed on to the inverter block. The code is given in Appendix 1.

4.3 Three-phase Inverter Block

The inverter model is build using 'function' blocks according to the expression (4). Thus the output of the inverter block is the phase voltages.

4.4 Filter Blocks

The PWM voltage signal is filtered using first order filter. This is implemented using 'Transfer function' block from 'Continuous' sub-library. The time constant of the first-order filter is chosen as 0.8ms.


4.5 Voltage Acquisition


The filtered phase voltages are stored in workspaces in this block.

Simulation is carried out using the developed model for maximum obtainable reference voltage and the resulting filtered leg and phase voltages are shown in Figs. 8 and 9.

5. CONCLUSIONS

A simple Matlab/Simulink model is presented to implement SVPWM for three-phase VSI. A brief review of the VSI model is also reported based on space vector representation. A Matlab/Simulink based model for implementation of SVPWM is presented. The step-by-








Figure 7. Sub-blocks of Matlab/Simulink model: (a) Reference voltage generation (b) VSI (c) Filters




Figure 8. Filtered leg voltages.




Figure 9. Filtered phase voltages.

step model development is reported. The presented model gives an insight into the SVPWM. By varying the magnitude of the input reference different modulation index can be achieved.

6. REFERENCES

- [1] Holmes, G.D. and Lipo, T.A., *Pulse Width Modulation for Power Converters Principles and Practice*, IEEE Press Series on Power Eng., John Wiley and Sons, Piscataway, NJ, USA, 2003.
- [2] Kazmierkowski, M.P., Krishnan, R. and Blaabjerg, F., *Control in power electronics- selected problems*, Academic Press, California, USA, 2002.
- [3] Implementing SVPWM with AMD, Application notes, Analogue Electronics
- [4] Matalb/Simulink reference guide www.mathworks.co.uk.

APPENDIX 1

```
%Matlab Code to generate Switching functions
         % Inputs are magnitude u1(:),angle u2(:)
         % and ramp time signal for comparison u3(:)
         function [sf]=aaa(u)
ts=0.0002;vdc=1;peak phase max= vdc/sqrt(3);
x=u(2); y=u(3); mag=(u(1)/peak_phase_max) * ts;
%sector I
         if (x>=0) & (x<pi/3)
         ta = mag * sin(pi/3-x); tb = mag * sin(x);
                  t0 = (ts-ta-tb);
t1=[t0/4 ta/2 tb/2 t0/2 tb/2 ta/2 t0/4];t1=cumsum(t1);
v1=[0\ 1\ 1\ 1\ 1\ 1\ 0]; v2=[0\ 0\ 1\ 1\ 1\ 0\ 0]; v3=[0\ 0\ 0\ 1\ 0\ 0\ 0];
                  for i=1:7
                            if(y < t1(i))
                           break
                            end
                  end
                  sa=v1(j);sb=v2(j);sc=v3(j);
end
% sector II
         if (x>=pi/3) & (x<2*pi/3)
                  adv = x-pi/3;
tb = mag * sin(pi/3-adv);ta = mag * sin(adv);
t0 = (ts-ta-tb);
t1=[t0/4 ta/2 tb/2 t0/2 tb/2 ta/2 t0/4];t1=cumsum(t1);
v1=[0 0 1 1 1 0 0];v2=[0 1 1 1 1 1 0];v3=[0 0 0 1 0 0 0];
                  for j=1:7
           if(y < t1(j))
              break
           end
         end
         sa=v1(j); sb=v2(j); sc=v3(j);
         end
%sector III
         if (x>=2*pi/3) & (x<pi)
                  adv=x-2*pi/3;
ta = mag * sin(pi/3-adv); tb = mag * sin(adv);
```

```
t0 = (ts-ta-tb):
t1=[t0/4 ta/2 tb/2 t0/2 tb/2 ta/2 t0/4];t1=cumsum(t1);
v1=[0 0 0 1 0 0 0];v2=[0 1 1 1 1 1 0];v3=[0 0 1 1 1 0 0];
                  for j=1:7
           if(y < t1(j))
              break
           end
         end
         sa=v1(j);sb=v2(j);sc=v3(j);
end
%sector IV
         if (x \ge -pi) & (x < -2*pi/3)
          adv = x + pi;
tb = mag * sin(pi/3 - adv); ta = mag * sin(adv);
                  t0 = (ts-ta-tb);
t1=[t0/4 ta/2 tb/2 t0/2 tb/2 ta/2 t0/4];t1=cumsum(t1);
v1=[0 0 0 1 0 0 0];v2=[0 0 1 1 1 0 0];v3=[0 1 1 1 1 1 0];
         for i=1:7
           if(y < t1(j))
              break
           end
         end
         sa=v1(j); sb=v2(j); sc=v3(j);
end
% sector V
         if (x>=-2*pi/3) & (x<-pi/3)
                  adv = x + 2*pi/3;
ta = mag * sin(pi/3-adv); tb = mag * sin(adv);
                  t0 = (ts-ta-tb);
t1=[t0/4 ta/2 tb/2 t0/2 tb/2 ta/2 t0/4];t1=cumsum(t1);
v1=[0 0 1 1 1 0 0];v2=[0 0 0 1 0 0 0];v3=[0 1 1 1 1 1 0];
                  for j=1:7
           if(y < t1(j))
              break
           end
         end
         sa=v1(i);sb=v2(i);sc=v3(i);
end
%Sector VI
         if (x \ge -pi/3) & (x < 0)
                  adv = x + pi/3;
tb = mag * sin(pi/3-adv); ta = mag * sin(adv);
                  t0 = (ts-ta-tb);
t1=[t0/4 ta/2 tb/2 t0/2 tb/2 ta/2 t0/4];t1=cumsum(t1);
v1=[0 1 1 1 1 1 0];v2=[0 0 0 1 0 0 0];v3=[0 0 1 1 1 0 0];
                  for j=1:7
           if(y < t1(j))
              break
           end
         end
         sa=v1(j);sb=v2(j);sc=v3(j);
                           end
                      sf=[sa, sb, sc];
Corresponding Author: Dr. Atif Iqbal,
Department of Electrical Engineering, Aligarh Muslim
```

Corresponding Author: Dr. Atif Iqbal, Reader, Department of Electrical Engineering, Aligarh Muslim University, Aligarh 202002, India. Phone: +91 571 2901029, Mob. +91 9411210372, Email: atif_iqbal1@rediffmail.com