A Damage Model for Meshless Fracture Simulation

Fei Zhu 10/28/2014

1 Basic Concepts

1.1 Damage State

We represent the damage state in the material with a second-order tensor D. It is defined by a linear transformation from the vector ndA in the current damaged configuration into $\tilde{n}d\tilde{A}$ in the fictitious undamaged configuration that is mechanically equivalent:

$$\tilde{\boldsymbol{n}}d\tilde{A} = (\boldsymbol{I} - \boldsymbol{D})\boldsymbol{n}dA,$$

where ndA and $\tilde{n}d\tilde{A}$ are the surface elements in the two configurations. The damage variable characterizes the net area reduction caused by damage of material.

1.2 Effective Stress Tensor and Damage Effect Tensor

$$\sigma(\mathbf{n}dA) = \tilde{\sigma}(\tilde{\mathbf{n}}d\tilde{A}) = \tilde{\sigma}(\mathbf{I} - \mathbf{D})(\mathbf{n}dA).$$

From this, the effective stress tensor $\tilde{\sigma}$ is given by:

$$\tilde{\sigma} = (\boldsymbol{I} - \boldsymbol{D})^{-1} \sigma.$$

The effective stress tensor defined above is asymmetric, it is usually inconvenient to use it in the formulation of constitutive and evolution equations. Different schemes of symmetrization have been proposed, which can be expressed in a unified form as:

$$\tilde{\sigma} = \mathbb{M}(\boldsymbol{D}) : \sigma,$$

where $\mathbb{M}(\mathbf{D})$ is a fourth-order tensor-valued tensor function which transforms the stress tensor into corresponding effective stress tensor, and is called a damage effect tensor.

It is often convenient to express tensors in the form of the matrices of their components, and the to execute the tensor operation as a matrix calculus. According to the Voigt notation, the second-order symmetric stress tensor σ and the related effective stress tensor $\tilde{\sigma}$ are expressed by the column vectors of six-dimension:

$$[\sigma] = [\sigma_{11} \ \sigma_{22} \ \sigma_{33} \ \sigma_{23} \ \sigma_{12} \ \sigma_{13}]^T$$

$$[\tilde{\sigma}] = [\tilde{\sigma}_{11} \ \tilde{\sigma}_{22} \ \tilde{\sigma}_{33} \ \tilde{\sigma}_{23} \ \tilde{\sigma}_{12} \ \tilde{\sigma}_{13}]^T$$

Considering the symmetry of stress tensors, the damage effect tensor is represented as a six by six matrix [M]. Then:

$$[\tilde{\sigma}] = [M][\sigma].$$

[M] is a diagonal matrix if the principal directions of the damage tensor D are taken as the orthonormal basis of the coordinate system. Suppose [Q] is the transformation matrix from principal basis $\{n_1, n_2, n_3\}$ to arbitrary basis $\{n_1', n_2', n_3'\}$, then:

$$egin{aligned} [ilde{\sigma}^{'}] &= [oldsymbol{Q}][oldsymbol{M}][oldsymbol{\sigma}] &= [oldsymbol{Q}][oldsymbol{M}'] = [oldsymbol{Q}][oldsymbol{M}][oldsymbol{Q}]^{-1} \ &[oldsymbol{M}^{'}] &= [oldsymbol{Q}][oldsymbol{M}][oldsymbol{Q}]^{-1} \end{aligned}$$

1.3 Effective Strain Tensor

The effective strain tensor is defined according to the hypothesis of equivalence of the strain energy, i.e., the strain energy of the damaged material is equivalent to the fictitious undamaged material:

$$\epsilon = \frac{\partial W(\sigma, \mathbf{D})}{\partial \sigma} = \frac{\partial W_o(\tilde{\sigma})}{\partial \sigma} = \frac{\partial W_o(\tilde{\sigma})}{\partial \tilde{\sigma}} : \frac{\partial \tilde{\sigma}}{\partial \sigma} = \mathbb{M}^T(\mathbf{D}) : \tilde{\epsilon}$$

Hence,

$$\tilde{\epsilon} = \mathbb{M}^{-T}(\boldsymbol{D}) : \epsilon$$

2 The Thermodynamic Approach

2.1 Finite Deformation Theory

The effective stress tensor and the effective strain tensor expressed in the finite deformation theory are:

$$ilde{m{S}} = \mathbb{M}(m{D}): m{S}$$
 $ilde{m{E}} = \mathbb{M}^{-T}(m{D}): m{E}$

 $m{E}$ and $m{S}$ are respectively the Green-Lagrange strain tensor and the second Piola-Kirchhoff stress tensor.

2.2 Plasticity Model

We employ the additive decomposition of the Green-Lagrange strain tensor to describe plasticity in the field of large deformation:

$$\boldsymbol{E}(\boldsymbol{X},t) = \boldsymbol{E}^{e}(\boldsymbol{X},t) + \boldsymbol{E}^{p}(\boldsymbol{X},t)$$

2.3 Helmholtz Free Energy

The Helmholtz free energy Ψ denotes the free energy per unit mass in the material. We assume it consists of the free energy Ψ^e caused by the elastic deformation, the energy Ψ^p due to plastic deformation, and of the free energy Ψ^D related to damage.

$$\Psi(\boldsymbol{E}^{e},\boldsymbol{D},\boldsymbol{\alpha},\boldsymbol{\beta}) = \Psi^{e}(\boldsymbol{E}^{e},\boldsymbol{D}) + \Psi^{p}(\boldsymbol{\alpha}) + \Psi^{\boldsymbol{D}}(\boldsymbol{\beta})$$

 $\Psi^p(\alpha)$ and $\Psi^D(\beta)$ measures the hardening (softening) effect due to plasticity and damage respectively. α and β are two scalars, α is the plastic hardening variable and β is the damage strengthening variable. They can be omitted when no hardening (softening) effect is presented, i.e., perfect plasticity (damage). $\Psi^e(E^e, D)$ is the general hyperelastic constitutive model coupled with damage. As hyperelastic materials are usually described with the energy density W (per unit volume), it's necessary to mention the relationship between the elastic part of Helmholtz free energy Ψ and the elastic strain energy density W (per unit volume): $W = \rho \Psi$.

2.4 The Clausius-Planck Inequality

The plastic deformation and damage process are irreversible accompanied with internal dissipation. From the second law of thermodynamics, the Clausius-Planck inequality in the reference configuration is given by:

$$\boldsymbol{D}_{int} = \boldsymbol{S} : \dot{\boldsymbol{E}} - \rho_0 [\eta \dot{T} + \dot{\Psi}] \ge 0$$

We assume the whole process is isothermal, i.e., the temperature stays fixed. The Clausius-Planck inequality becomes:

$$\boldsymbol{D}_{int} = \boldsymbol{S} : \dot{\boldsymbol{E}} - \rho_0 \dot{\Psi} \geq 0$$

From the rate of change of Ψ ,

$$\dot{\Psi} = \frac{\partial \Psi}{\partial \boldsymbol{E}^e} : \dot{\boldsymbol{E}}^e + \frac{\partial \Psi}{\partial \boldsymbol{D}} : \dot{\boldsymbol{D}} + \frac{\partial \Psi}{\partial \alpha} \cdot \dot{\alpha} + \frac{\partial \Psi}{\partial \beta} \cdot \dot{\beta}$$

the internal dissipation becomes:

$$\boldsymbol{D}_{int} = (\boldsymbol{S} - \rho_0 \frac{\partial \Psi}{\partial \boldsymbol{E}^e}) : \dot{\boldsymbol{E}}^e + \boldsymbol{S} : \dot{\boldsymbol{E}}^p - \rho_0 (\frac{\partial \Psi}{\partial \boldsymbol{D}} : \dot{\boldsymbol{D}} + \frac{\partial \Psi}{\partial \alpha} \cdot \dot{\alpha} + \frac{\partial \Psi}{\partial \beta} \cdot \dot{\beta}) \ge 0$$

The above inequality holds for any loading/unloading process, e.g., one where $\dot{E}^e = 0$. Hence:

$$m{S} =
ho_0 rac{\partial \Psi}{\partial m{E}^e}$$

Introduce the generalized forces associated with the free variables:

$$Y = -\rho_0 \frac{\partial \Psi}{\partial \mathbf{D}}, \ A = -\rho_0 \frac{\partial \Psi}{\partial \alpha}, \ B = -\rho_0 \frac{\partial \Psi}{\partial \beta}$$

The internal dissipation is expressed as:

$$D_{int} = S : \dot{E}^p + Y : \dot{D} + A \cdot \dot{\alpha} + B \cdot \dot{\beta} > 0$$

2.5 The Yield Criteria and Damage Criteria

The yield criteria is defined as follows, considering only isotropic hardening:

$$||\tilde{E}|| - F^p(\boldsymbol{S}, A, \boldsymbol{D}) \le 0$$

 $||\tilde{E}||$ is the norm of the effective stress tensor.

Similarly, the damage criteria is defined as:

$$||Y|| - F^D(\boldsymbol{Y}, B) \le 0$$

2.6 Evolution of Plasticity and Damage

References