# SENSOR DE TEMPERATURA

Diseño e implementación de un Sistema de Bardware y Software, basado en una arquitectura ARM, que toma valores de un sensor de temperatura y, mediante comunicación UART, envía los resultados en una PC que los presenta en una interfaz de usuario. Bollini Leonardo Martínez Franco

# Índice

Objetivo	2
Implementación	2
Elementos Principales Utilizados	2
Placa de Desarrollo LPCXpresso 1769. Microprocesador ARM Cortex M3	2
Potenciómetro de 1 KOhm	2
Driver Max 232 para la conexión serie entre ARM – PC.	2
LPC	3
Conexión	3
PC. Interfaz Gráfica	3
Código	5
Código C del programa del microcontrolador:	5
Código Python	7
Captura de Pantalla de la Interfaz gráfica	7
Conclusión	8
Anexo. Librerías	9
Uart.c	9
Uart.h	15
Adc.c	16
Adc h	20

## Objetivo

Este trabajo consiste en el diseño e implementación de un sistema encargado de censar la temperatura de una sala y mostrar, mediante una aplicación desarrollada en Python, los valores medidos y un gráfico con el histórico de temperaturas.

Para este trabajo, se decidió trabajar con un potenciómetro ya que éste nos permite mostrar la funcionalidad del sistema con mayor facilidad. La implementación de éste con un sensor de temperatura es trivial y no representa mayores complicaciones.

# Implementación

El sistema consiste de un potenciómetro que entrega un valor de tensión variable entre 0V y 3,3V. Este valor es tomado por el módulo ADC del microcontrolador LPC1769, convirtiendo esta señal a un valor digital de 12 bits. El LPC cada un intervalo de tiempo definido, lee el valor entregado por el potenciómetro.

El microcontrolador comunicará este valor a una computadora por UART. Para ello, convierte este valor binario a caracteres, para poder enviarlo correctamente.

La PC recibe el mensaje con el valor medido. Un programa desarrollado en Python toma esta medición, y muestra un gráfico de temperatura histórico con los últimos valores medidos.

Siendo que los valores entregados a la PC varían entre 0 y 4095, el programa agrupa las mediciones en rango que representan una variación entre 0°C y 45°C.

#### Elementos Principales Utilizados

#### Placa de Desarrollo LPCXpresso 1769. Microprocesador ARM Cortex M3.

Es el encargado de tomar el valor del sensor de temperatura (potenciómetro en este caso), prepararlo para comunicarlo, y enviarlo a la PC.

#### Potenciómetro de 1 KOhm.

Hace las veces de sensor de temperatura.

#### Driver Max 232 para la conexión serie entre ARM – PC.

Necesario para la comunicación serie. Adapta los niveles de tensiones de la señal que entrega el circuito del microprocesador y de lo que necesita la PC para interpretar correctamente el valor.

#### **LPC**

El microcontrolador se programó para que periódicamente cense el valor del potenciómetro. Esto se llevó a cabo utilizando interrupciones del Timero.

Al momento de obtener el valor, se utiliza el módulo ADC, obteniendo un valor digital de 12 bits que representa esta medición.

Utilizando librerías de C, se convierte este valor a una cadena de caracteres, ya que, al ser la comunicación UART, enviamos caracteres por el puerto (cada carácter es de 8 bits).

En la PC, un programa desarrollado en Python escucha el puerto. Cuando llega un valor, lo toma, lo transforma en un entero, y lo almacena en una cola FIFO de tamaño fijo.

Esta cola hace las veces de buffer. Aquí se almacenarán los datos que llegan, y será desde aquí donde el programa lee los datos para mostrarlos en un gráfico.

#### Conexión

La conexión entre LPC y PC es a través de un Driver MAX232, el cual se transforma los valores de tensión a niveles TTL, interpretables por la PC.


Se utilizó un cable Serial-USB y se instalaron drivers para emular el puerto COM, ya que las computadoras donde se probó el programa no contaban con puertos seriales.

#### PC. Interfaz Gráfica

Se definió la interfaz gráfica del usuario de la siguiente forma:

- La pantalla le muestra al usuario un resumen histórico de la temperatura.
- Un cuadro de entrada de texto permite que el usuario ingrese una nueva temperatura de umbral.

Cuando se pensó en la interfaz de usuario se planteó un sistema que pueda adquirir más características en el tiempo. Por ejemplo, que permita sonar una alarma en caso que se supere un valor de temperatura determinado. Este es una funcionalidad a agregar más adelante.



En el programa de la computadora, se muestra por pantalla una ventana dividida en dos partes.

En la primera parte, se observa el gráfico con el histórico de temperturas.

En la otra fila se observan tres displays, en los cuales se ven las temperaturas mínima, establecida en 0°, la actual, y la temperatura máxima, definida en 45° C.

Este rango de temperaturas se definió simplemente a los fines de mostrar el funcionamiento del sistema. No representa valores significativos.

#### Código

Para el desarrollo del código, se han utilizado al máximo las capacidades de las librerías que provee la suite de desarrollo, por lo que el código es muy compacto, modularizado y de fácil comprensión.

#### Código C del programa del microcontrolador:

```
#ifdef USE CMSIS
    #include "LPC17xx.h"
    #endif
 5
   //ADC
    #include "freq.h"
    #include "adc.h"
    #include "debug.h"
 8
    #include "small systick.h"
 9
10
   //UART
   #include "type.h"
    #include "uart.h"
14
   //Utilidades relacionadas al manejo de cadenas y caracteres.
15
16
   #include <string.h>
    #include <stdlib.h>
18
19
    #include <cr section macros.h>
20
    volatile uint32_t SysTickCount;
                                   /* counts 10ms timeTicks */
    uint8 t cont;
24
    volatile uint16 t adcCount;
25
26
    // InitSysTick() sets systick timer to 10 mS
27
    #define InitSysTick(MHz) SysTick Config(MHz * (1000000/100))
28
    /*-----
30
     SysTick Handler
     Cuando TimerO interrumpe, medimos un valor en el ADC, lo convertimos a
     caracteres y lo enviamos por UART
   void SysTick Handler(void) //interrumpe cada 10 milisegundos
34
35
36
            char mensaje[8];
38
            SysTickCount++; /* provee delay */
            if (SysTickCount < 100) return; //100 = 1 segundo</pre>
40
41
42
            //Tomamos el valor leido por el sensor
            adcCount = ADCORead(0); //Se lee el puerto PO[23]
43
44
45
            //Convierte el valor medido a caracteres (un caracter por cada
46
            //digito decimal)
47
            itoa(adcCount, mensaje, 10);
48
49
            //Agrega un retorno de carro y nueva línea al mensaje
50
            strcat(mensaje, "\r\n");
            //Enviamos por UART el valor:
            UARTSend(3, (uint8 t *)mensaje , strlen(mensaje) );
54
            SysTickCount = 0;
```

```
55
             //Prende y apaga un LED para saber que el sistema está funcionando:
56
             //Sirve como control
             if (cont == 0) {
                     LPC GPIO0->FIOCLR = (1 << 22); // P0[22] = 0
60
                     cont = 1;
             }
62
             else {
                     LPC GPIO0->FIOSET = (1 << 22); // P0[22] = 1
63
                     cont = 0;
64
65
             }
66
    }
69
    int main(void) {
70
        // TODO: insert code here
             adcCount = 1000;
74
             LPC GPIOO->FIODIR \mid= (1 << 22); // P0[22] COMO SALIDA.
75
76
             ADCInit(ADC CLK); //Inicializa el ADC. Entrada ADC por el puerto P0[23].
78
             cont = 0;
79
             InitSysTick(100); //Inicializa el Timer para que interrumpa cada 10 ms.
80
81
             //UART Setting
             UARTInit(3, 9600);
                                      /* baud rate setting */
83
84
        while(1) {
85
86
        return 0 ;
87 }
```

Mencionamos las librerías utilizadas, que se encuentran en el IDE del LPC en caso de que se necesite consultarlas. En el anexo se encuentra el código de las librerías incluidas en el IDE.

```
//ADC
"freq.h"
"adc.h"
"debug.h"
"small_systick.h"

//UART
"type.h"
"uart.h"


//Utilidades relacionadas al manejo de cadenas y caracteres.
<string.h>
<stdlib.h>
```


#### Código Python

#### Lectura del puerto serial

```
import serial
    from Queue import Queue
 4
    for i in range(0, 10):
 5
        try:
            ser = serial.Serial(i) # open first serial port
 6
            print "Conectado a", ser.name # check which port was really used
 8
9
            cola = Queue(10)
10
            while True:
               line = ser.readline()
                                        # read a '\n' terminated line
                valor = int(line)
14
15
                try:
16
                    cola.put_nowait(valor)
18
                except Exception, e:
19
                    cola.get nowait()
20
                    cola.put nowait(valor)
                print "el valor en la cola es:", list(cola.queue)
24
                #print line
25
            ser.close()
                                    # close port
26
        except Exception, e:
            pass
```

### Captura de Pantalla de la Interfaz gráfica





# Conclusión

Este trabajo nos permitió ver ante todo el poder y la sencillez que nos da el trabajar con un LPC, más sumado a la robustez de un lenguaje como Python que nos permitió poder obtener los datos y mostrarlo en formato elegante.

El hecho de haber realizado un trabajo que integre tanto el diseño y conexión del sistema y el desarrollo del software nos da cuenta del poder y versatilidad de los microcontroladores y sistemas embebidos.

#### Anexo. Librerías

#### Uart.c

```
/************************
* $Id::
* Project:
                uart: Simple UART echo for LPCXpresso 1700
* File: uart.c
 * Description:
                         LPCXpresso Baseboard uses pins mapped to UART3 for
                         its USB-to-UART bridge. This application simply echos
                         all characters received.
******************
* Software that is described herein is for illustrative purposes only
^{\star} which provides customers with programming information regarding the
* products. This software is supplied "AS IS" without any warranties.
^{\star} NXP Semiconductors assumes no responsibility or liability \mathbf{for} the
* use of the software, conveys no license or title under any patent,
^{\star} copyright, or mask work right to the product. NXP Semiconductors
\star reserves the right to make changes in the software without
* notification. NXP Semiconductors also make no representation or
* warranty that such application will be suitable for the specified
* use without further testing or modification.
/****************************
* History
    2010.07.01 ver 1.01 Added support for UART3, tested on LPCXpresso 1700 2009.05.27 ver 1.00 Prelimnary version, first Release
************************
#include "LPC17xx.h"
#include "type.h"
#include "uart.h"
volatile uint32 t UARTOStatus, UART1Status, UART3Status;
volatile uint8 t UART0TxEmpty = 1, UART1TxEmpty = 1, UART3TxEmpty=1;
volatile uint8_t UART0Buffer[BUFSIZE], UART1Buffer[BUFSIZE], UART3Buffer[BUFSIZE];
volatile uint32 t UART0Count = 0, UART1Count = 0, UART3Count = 0;
/******************************
** Function name:
                        UARTO IRQHandler
** Descriptions:
                        UARTO interrupt handler
** parameters:
                                  None
** Returned value:
                        None
*******************************
void UARTO IRQHandler (void)
 uint8 t IIRValue, LSRValue;
 uint8 t Dummy = Dummy;
 IIRValue = LPC UARTO->IIR;
 IIRValue >>= 1;
                                  /* skip pending bit in IIR */
                                  /* check bit 1~3, interrupt identification */
 IIRValue &= 0x07;
                                  /* Receive Line Status */
 if ( IIRValue == IIR RLS )
        LSRValue = LPC_UARTO->LSR;
        /* Receive Line Status */
        if ( LSRValue & (LSR_OE|LSR_PE|LSR_FE|LSR_RXFE|LSR BI) )
```

```
/* There are errors or break interrupt */
         /* Read LSR will clear the interrupt */
         UARTOStatus = LSRValue;
         Dummy = LPC UART0->RBR;
                                      /* Dummy read on RX to clear
                                                       interrupt, then bail out */
         return;
       if ( LSRValue & LSR RDR ) /* Receive Data Ready */
         /* If no error on RLS, normal ready, save into the data buffer. */
         /* Note: read RBR will clear the interrupt */
         UARTOBuffer[UARTOCount] = LPC_UARTO->RBR;
         UART0Count++;
         if ( UARTOCount == BUFSIZE )
                               /* buffer overflow */
               UARTOCount = 0;
 else if ( IIRValue == IIR RDA ) /* Receive Data Available */
       /* Receive Data Available */
       UARTOBuffer[UARTOCount] = LPC_UARTO->RBR;
       UART0Count++;
       if ( UARTOCount == BUFSIZE )
        /* Character Time-out indicator */
                                      /* Bit 9 as the CTI error */
       UARTOStatus |= 0x100;
 else if ( IIRValue == IIR_THRE ) /* THRE, transmit holding register empty */
       /* THRE interrupt */
       LSRValue = LPC UARTO->LSR; /* Check status in the LSR to see if
                                                                       valid data in UOTHR
       if ( LSRValue & LSR THRE )
        UARTOTxEmpty = 1;
       else
        UARTOTxEmpty = 0;
** Function name:
                      UART1 IRQHandler
** Descriptions: UART1 interrupt handler
** parameters:
                              None
** Returned value: None
******************************
void UART1 IRQHandler (void)
 uint8 t IIRValue, LSRValue;
 uint8 t Dummy = Dummy;
 IIRValue = LPC UART1->IIR;
                              /* skip pending bit in IIR */
 IIRValue >>= 1;
 IIRValue &= 0x07; /* check bit 1~3, interrupt identification */
if ( IIRValue == IIR_RLS ) /* Receive Line Status */
```

```
LSRValue = LPC UART1->LSR;
        /* Receive Line Status */
        if ( LSRValue & (LSR_OE|LSR_PE|LSR_FE|LSR_RXFE|LSR_BI) )
          /\star There are errors or break interrupt \star/
          /* Read LSR will clear the interrupt */
         UART1Status = LSRValue;
         Dummy = LPC UART1->RBR;
                                          /* Dummy read on RX to clear
                                                                   interrupt, then bail out */
         return;
        if ( LSRValue & LSR RDR ) /* Receive Data Ready */
          /\star If no error on RLS, normal ready, save into the data buffer. \star/
          /* Note: read RBR will clear the interrupt */
          UART1Buffer[UART1Count] = LPC UART1->RBR;
          UART1Count++;
         if ( UART1Count == BUFSIZE )
                                    /* buffer overflow */
                UART1Count = 0;
 else if ( IIRValue == IIR RDA )
                                /* Receive Data Available */
        /* Receive Data Available */
        UART1Buffer[UART1Count] = LPC UART1->RBR;
        UART1Count++;
        if ( UART1Count == BUFSIZE )
         else if ( IIRValue == IIR CTI ) /* Character timeout indicator */
        /* Character Time-out indicator */
        UART1Status \mid = 0 \times 100;
                                         /* Bit 9 as the CTI error */
 else if ( IIRValue == IIR THRE ) /* THRE, transmit holding register empty */
        /* THRE interrupt */
        LSRValue = LPC UART1->LSR; /* Check status in the LSR to see if
                                                                   valid data in UOTHR or not
*/
        if ( LSRValue & LSR THRE )
         UART1TxEmpty = 1;
        else
         UART1TxEmpty = 0;
UARTO IRQHandler
** Function name:
** Descriptions:
                       UARTO interrupt handler
** parameters:
** Returned value: None
************************
void UART3 IRQHandler (void)
 uint8 t IIRValue, LSRValue;
 uint8 t Dummy = Dummy;
 IIRValue = LPC UART3->IIR;
```

```
IIRValue >>= 1;
                                  /* skip pending bit in IIR */
 IIRValue >>= 1;
IIRValue &= 0x07;
if ( IIRValue == IIR_RLS )
                                  /* check bit 1\sim3, interrupt identification */ /* Receive Line Status */
         LSRValue = LPC_UART3->LSR;
         /* Receive Line Status */
         if ( LSRValue & (LSR OE|LSR PE|LSR FE|LSR RXFE|LSR BI) )
          /* There are errors or break interrupt */
/* Read LSR will clear the interrupt */
          UART3Status = LSRValue;
          Dummy = LPC UART3->RBR;
                                         /* Dummy read on RX to clear
                                                              interrupt, then bail out */
          return:
         if ( LSRValue & LSR_RDR ) /* Receive Data Ready */
          /* If no error on RLS, normal ready, save into the data buffer. */
          /* Note: read RBR will clear the interrupt */
          UART3Buffer[UART3Count] = LPC UART3->RBR;
          UART3Count++;
          if ( UART3Count == BUFSIZE )
                 else if ( IIRValue == IIR RDA ) /* Receive Data Available */
         /* Receive Data Available */
         UART3Buffer[UART3Count] = LPC UART3->RBR;
         UART3Count++;
         if ( UART3Count == BUFSIZE )
          else if ( IIRValue == IIR CTI ) /* Character timeout indicator */
         /* Character Time-out indicator */
        UART3Status |= 0x100;
                                            /* Bit 9 as the CTI error */
 else if ( IIRValue == IIR THRE ) /* THRE, transmit holding register empty */
         /* THRE interrupt */
        LSRValue = LPC UART3->LSR;
                                           /* Check status in the LSR to see if
                                                                                 valid data in UOTHR
or not */
        if ( LSRValue & LSR THRE )
          UART3TxEmpty = 1;
         else
         UART3TxEmpty = 0;
}
** Function name:
                         UARTInit
** Descriptions: Initialize UART port, setup pin select,
* *
                                                     clock, parity, stop bits, FIFO, etc.
* *
** parameters:
                                   portNum(0 or 1) and UART baudrate
** Returned value: portnum(0 or 1) and UART baudr
true or false, return false only if the
* *
                                                      interrupt handler can't be installed to the
* *
                                                      VIC table
```

```
*************************
uint32 t UARTInit( uint32 t PortNum, uint32 t baudrate )
 uint32 t Fdiv;
 uint32 t pclkdiv, pclk;
 if ( PortNum == 0 )
        LPC_PINCON->PINSELO &= ~0x000000F0;
         LPC PINCON->PINSELO |= 0x00000050; /* RxD0 is P0.3 and TxD0 is P0.2 */
         /* By default, the PCLKSELx value is zero, thus, the PCLK for
         all the peripherals is 1/4 of the SystemFrequency. */
         /* Bit 6~7 is for UARTO */
         pclkdiv = (LPC SC->PCLKSEL0 >> 6) & 0x03;
         switch ( pclkdiv )
          case 0x00:
          default:
                  pclk = SystemCoreClock/4;
                  break;
          case 0x01:
                  pclk = SystemCoreClock;
                  break;
          case 0x02:
                  pclk = SystemCoreClock/2;
                  break;
          case 0x03:
                  pclk = SystemCoreClock/8;
                 break;
         }
   LPC UARTO->LCR = 0x83;
                                   /* 8 bits, no Parity, 1 Stop bit */
        Fdiv = ( pclk / 16 ) / baudrate ; /*baud rate */
   LPC_UARTO->DLM = Fdiv / 256;
LPC_UARTO->DLL = Fdiv % 256;
        LPC UARTO->LCR = 0x03;
                                             /* DLAB = 0 */
   LPC UARTO->FCR = 0 \times 07;
                                   /\star Enable and reset TX and RX FIFO. \star/
        NVIC EnableIRQ(UARTO IRQn);
   LPC UARTO->IER = IER RBR | IER THRE | IER RLS;
                                                      /* Enable UARTO interrupt */
   return (TRUE);
 else if ( PortNum == 1 )
         LPC PINCON->PINSEL4 &= ~0x0000000F;
         LPC PINCON->PINSEL4 |= 0x0000000A;
                                           /* Enable RxD1 P2.1, TxD1 P2.0 */
         /* By default, the PCLKSELx value is zero, thus, the PCLK for
         all the peripherals is 1/4 of the SystemFrequency. */
         /* Bit 8,9 are for UART1 */
         pclkdiv = (LPC SC->PCLKSEL0 >> 8) & 0x03;
         switch ( pclkdiv )
          case 0x00:
          default:
                  pclk = SystemCoreClock/4;
                  break;
          case 0x01:
                 pclk = SystemCoreClock;
                  break;
          case 0x02:
                  pclk = SystemCoreClock/2;
                  break;
          case 0x03:
                  pclk = SystemCoreClock/8;
                  break;
                            /* 8 bits, no Parity, 1 Stop bit */
   LPC UART1->LCR = 0x83;
```

```
LPC UART1->DLM = Fdiv / 256;
       LPC UART1->DLL = Fdiv % 256;
                                                                              /* DLAB = 0 */
                 LPC UART1->LCR = 0 \times 03;
       LPC UARTI->FCR = 0 \times 07;
                                                                       /st Enable and reset TX and RX FIFO. st/
                 NVIC EnableIRQ(UART1 IRQn);
       LPC UART1->IER = IER RBR | IER THRE | IER RLS; /* Enable UART1 interrupt */
       return (TRUE);
   else if ( PortNum == 3 )
                      LPC PINCON->PINSELO &= ~0x0000000F;
                      LPC PINCON->PINSELO \mid 0x0000000A; /* RxD3 is P0.1 and TxD3 is P0.0 */
                      LPC SC->PCONP |= 1<<4 | 1<<25; //Enable PCUART1
                      /\!\!\!\!\!\!\!^{\star} \overline{\mbox{\ensuremath{B}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensuremath{D}}\mbox{\ensu
                                    all the peripherals is 1/4 of the SystemFrequency. */
                      /* Bit 6~7 is for UART3 */
                      pclkdiv = (LPC SC->PCLKSEL1 >> 18) & 0x03;
                      switch ( pclkdiv )
                      case 0x00:
                      default:
                                        pclk = SystemCoreClock/4;
                                        break;
                      case 0x01:
                                        pclk = SystemCoreClock;
                                        break;
                      case 0x02:
                                        pclk = SystemCoreClock/2;
                                        break;
                      case 0x03:
                                        pclk = SystemCoreClock/8;
                                        break;
                      LPC UART3->LCR = 0x83;
                                                                                           /* 8 bits, no Parity, 1 Stop bit */
                      \overline{\text{Fdiv}} = (\text{pclk} / 16) / \text{baudrate}; /*\text{baud rate} */
                      LPC UART3->DLM = Fdiv / 256;
                      LPC UART3->DLL = Fdiv % 256;
                                                                                             /* DLAB = 0 */
                      LPC UART3->LCR = 0x03;
                      LPC UART3->FCR = 0x07;
                                                                                            /* Enable and reset TX and RX FIFO. */
                      NVIC EnableIRQ(UART3 IRQn);
                      LPC UART3->IER = IER RBR | IER THRE | IER RLS; /* Enable UART3 interrupt */
                      return (TRUE);
   return ( FALSE );
/*****************************
** Function name:
                                                    UARTSend
** Descriptions:
                                                     Send a block of data to the UART 0 port based
                                                                                                               on the data length
** parameters:
                                                                        portNum, buffer pointer, and data length
** Returned value:
                                                     None
void UARTSend( uint32 t portNum, uint8 t *BufferPtr, uint32 t Length )
    if ( portNum == 0 )
       while ( Length != 0 )
                      while ( !(UARTOTxEmpty & 0x01) );
                      LPC UARTO->THR = *BufferPtr;
                      UARTOTxEmpty = 0;/* not empty in the THR until it shifts out */
                      BufferPtr++;
```

```
Length--;
 else if (portNum == 1)
       while ( Length != 0 )
         /* THRE status, contain valid data */
         while ( !(UART1TxEmpty & 0x01) );
         LPC UART1->THR = *BufferPtr;
         UART1TxEmpty = 0;/* not empty in the THR until it shifts out */
         BufferPtr++;
         Length--;
   }
 else if ( portNum == 3 )
   while ( Length != 0 )
         /* THRE status, contain valid data */
         while ( !(UART3TxEmpty & 0x01) );
         LPC UART3->THR = *BufferPtr;
         UART3TxEmpty = 0;/* not empty in the THR until it shifts out */
         BufferPtr++;
         Length--;
 return:
/******************************
                        End Of File
******************************
```

#### Uart.h

```
/*************************
* $Id::
* Project:
              uart: Simple UART echo for LPCXpresso 1700
* File: uarttest.c
* Description:
                      LPCXpresso Baseboard uses pins mapped to UART3 for
                      its USB-to-UART bridge. This application simply echos
                      all characters received.
**************
* Software that is described herein is for illustrative purposes only
* which provides customers with programming information regarding the
* products. This software is supplied "AS IS" without any warranties.
* NXP Semiconductors assumes no responsibility or liability for the
* use of the software, conveys no license or title under any patent,
^{\star} copyright, or mask work right to the product. NXP Semiconductors
* reserves the right to make changes in the software without
* notification. NXP Semiconductors also make no representation or
* warranty that such application will be suitable for the specified
^{\star} use without further testing or modification.
******************
* History
   2010.07.01 ver 1.01
                      Added support for UART3, tested on LPCXpresso 1700
  2009.05.27 ver 1.00 Prelimnary version, first Release
**************************
#ifndef __UART_H
#define __UART_H
```

```
#define IER RBR
                      0x01
#define IER THRE
               0x02
#define IER RLS
                      0x04
#define IIR_PEND
#define IIR RLS
               0x01
                      0x03
#define IIR RDA
                      0x02
                      0x06
#define IIR_CTI
#define IIR THRE 0x01
                      0x01
#define LSR_RDR
#define LSR OE
                       0x02
#define LSR PE
                      0x04
#define LSR FE
                      0x08
#define LSR BI
                      0x10
#define LSR THRE 0x20
#define LSR TEMT 0x40
#define LSR RXFE 0x80
                       0x40
#define BUFSIZE
uint32 t UARTInit( uint32_t portNum, uint32_t Baudrate );
void UARTO IRQHandler( void );
void UART1 IRQHandler( void );
void UARTSend( uint32 t portNum, uint8 t *BufferPtr, uint32 t Length );
End Of File
************************
```

#### Adc.c

```
adc.c: ADC module file for NXP LPC17xx Family Microprocessors
  Copyright (C) 2009, NXP Semiconductor
  All rights reserved.
  History
* 2009.05.25 ver 1.00 Prelimnary version, first Release
*************************
#include "LPC17xx.h"
#include "type.h"
#include "adc.h"
volatile uint32 t ADCOValue[ADC NUM];
volatile uint32 t ADC0IntDone = 0;
#if BURST MODE
volatile uint32_t channel_flag;
#endif
#if ADC INTERRUPT FLAG
/****************************
** Function name:
                   ADC IRQHandler
** Descriptions:
                   ADC interrupt handler
** parameters:
                          None
** Returned value:
                   None
*************************
void ADC IRQHandler (void)
```

```
uint32 t regVal;
                            /* Read ADC will clear the interrupt */
regVal = LPC ADC->ADSTAT;
if ( regVal & 0x0000FF00 ) /* check OVERRUN error first */
       regVal = (regVal & 0x0000FF00) >> 0x08;
       /* if overrun, just read ADDR to clear */
       /* regVal variable has been reused. */
       switch ( regVal )
         case 0x01:
                regVal = LPC_ADC->ADDR0;
         break;
         case 0x02:
                regVal = LPC ADC->ADDR1;
         break:
         case 0x04:
                regVal = LPC_ADC->ADDR2;
         break;
         case 0x08:
                regVal = LPC ADC->ADDR3;
         break;
         case 0x10:
                regVal = LPC ADC->ADDR4;
         break;
         case 0x20:
                regVal = LPC ADC->ADDR5;
         break;
         case 0x40:
                regVal = LPC ADC->ADDR6;
         break;
         case 0x80:
                regVal = LPC ADC->ADDR7;
         break;
         default:
       LPC ADC->ADCR &= 0xF8FFFFFF; /* stop ADC now */
       ADC0IntDone = 1;
       return;
if ( regVal & ADC ADINT )
       switch ( regVal & 0xFF ) /* check DONE bit */
         case 0x01:
                ADCOValue[0] = ( LPC ADC->ADDRO >> 4 ) & 0xFFF;
         case 0x02:
                ADCOValue[1] = ( LPC ADC->ADDR1 >> 4 ) & OxFFF;
         break;
         case 0x04:
                ADCOValue[2] = ( LPC ADC->ADDR2 >> 4 ) & OxFFF;
         break:
         case 0x08:
                 ADCOValue[3] = (LPC ADC->ADDR3 >> 4) & OxFFF;
         break:
         case 0x10:
                ADCOValue[4] = ( LPC_ADC->ADDR4 >> 4 ) & 0xFFF;
         case 0x20:
                ADCOValue[5] = ( LPC ADC->ADDR5 >> 4 ) & 0xFFF;
         break:
         case 0x40:
                ADCOValue[6] = ( LPC ADC->ADDR6 >> 4 ) & 0xFFF;
         case 0x80:
                ADCOValue[7] = ( LPC_ADC->ADDR7 >> 4 ) & 0xfff;
         break;
         default:
```

```
break;
#if BURST MODE
         channel flag \mid = (regVal & 0xFF);
         if ( (channel flag & 0xFF) == 0xFF )
           /\star All the bits in have been set, it indicates all the ADC
           channels have been converted. */
           LPC ADC->ADCR &= 0xF8FFFFF;
                                                /* stop ADC now */
           ADCOIntDone = 1;
#else
         LPC ADC->ADCR &= 0xF8FFFFFF; /* stop ADC now */
         ADC0IntDone = 1;
#endif
  return;
#endif
/******************************
** Function name:
                           ADCInit
** Descriptions:
                           initialize ADC channel
** parameters:
                                      ADC clock rate
** Returned value:
                           true or false
************************
uint32 t ADCInit( uint32 t ADC Clk )
  uint32_t pclkdiv, pclk;
  /* Enable CLOCK into ADC controller */
  LPC SC->PCONP |= (1 << 12);
  /* all the related pins are set to ADC inputs, AD0.0~7 */
  LPC_PINCON->PINSELO |= 0x0F000000; /* P0.12~13, A0.6~7, function 11 */
LPC_PINCON->PINSEL1 &= ~0x003FC000; /* P0.23~26, A0.0~3, function 01 */
  LPC PINCON->PINSEL1 \mid = 0x00154000;
  LPC PINCON->PINSEL3 |= 0xF0000000; /* P1.30~31, A0.4~5, function 11 */
  /* By default, the PCLKSELx value is zero, thus, the PCLK for
  all the peripherals is 1/4 of the SystemFrequency. */
  /* Bit 6~7 is for UARTO */
  pclkdiv = (LPC SC->PCLKSEL0 >> 6) & 0x03;
  switch ( pclkdiv )
         case 0x00:
         default:
          pclk = SystemCoreClock/4;
         break;
         case 0x01:
          pclk = SystemCoreClock;
         break:
         case 0x02:
          pclk = SystemCoreClock/2;
         break;
         case 0x03:
          pclk = SystemCoreClock/8;
         break;
  LPC ADC->ADCR = ( 0x01 << 0 ) | /* SEL=1, select channel 0 on ADCO */
                   ( ( pclk \ / \ ADC_Clk - 1 ) << 8 ) | \ /* \ CLKDIV = Fpclk / \ ADC \ Clk - 1 */
                                              /* BURST = 0, no BURST, software controlled */
                   ( 0 << 16 ) |
                                               /* CLKS = 0, 11 clocks/10 bits */
                   ( 0 << 17 ) |
                                               /* PDN = 1, normal operation */
                   ( 1 << 21 ) |
                                               /* START = 0 A/D conversion stops */
/* EDGE = 0 (CAP/MAT singal falling,trigger A/D
                   ( 0 << 24 ) |
                   ( 0 << 27 );
conversion) */
```

```
/* If POLLING, no need to do the following */
#if ADC INTERRUPT FLAG
LPC ADC->ADINTEN = 0x1FF;
                         /* Enable all interrupts */
 NVIC EnableIRQ(ADC IRQn);
#endif
 return (TRUE);
** Function name:
                   ADC0Read
** Descriptions:
             Read ADC0 channel
** parameters:
                         Channel number
** Returned value: Value read, if interrupt driven, return channel #
uint32 t ADC0Read( uint8 t channelNum )
#if !ADC INTERRUPT FLAG
uint32 t regVal, ADC Data;
#endif
 /* channel number is 0 through 7 */
 if ( channelNum >= ADC_NUM )
     LPC ADC->ADCR &= 0xFFFFFF00;
 LPC ADC->ADCR |= (1 << 24) | (1 << channelNum);
                          /* switch channel, start A/D convert */
#if !ADC INTERRUPT FLAG
                          /* wait until end of A/D convert */
 while (1)
      regVal = *(volatile unsigned long *)(LPC ADC BASE
                   + ADC OFFSET + ADC INDEX * channelNum);
      /* read result of A/D conversion */
      if ( regVal & ADC DONE )
      {
       break;
 }
 return ( 0 );
 ADC Data = ( regVal >> 4 ) & 0xFFF;
 #else
                   /* if it's interrupt driven, the ADC reading is
 return ( channelNum );
                                              done inside the handler. so, return
channel number */
#endif
** Function name:
                   ADC0BurstRead
* *
** Descriptions:
                Use burst mode to convert multiple channels once.
** parameters:
                          None
** Returned value: None
******************************
void ADCBurstRead( void )
 if ( LPC ADC->ADCR & (0x7 << 24) )
```

#### Adc.h

```
/*****************************
* adc.h: Header file for NXP LPC17xx Family Microprocessors
   Copyright(C) 2009, NXP Semiconductor
   All rights reserved.
  History
   2009.05.25 ver 1.00 Prelimnary version, first Release
**********************
#ifndef __ADC_H
#define __ADC_H
/* If Burst mode is enabled, make sure interrupt flag is set. */
#define ADC_INTERRUPT_FLAG 0 /* 1 is interrupt driven, 0 is polling */
#define BURST MODE 0 /* Burst mode works in interrupt driven mode only. */
#define ADC_OFFSET
                   0x10
#define ADC_INDEX
#define ADC_OVERRUN 0x40000000
#define ADC_ADINT 0x40000000
                                           /* for LPCxxxx */
                             8
#define ADC NUM
                             1000000
                                             /* set to 1Mhz */
#define ADC_CLK
extern uint32_t ADCInit( uint32_t ADC_Clk );
extern uint32_t ADCORead( uint8_t channelNum );
extern void ADCBurstRead( void );
End Of File
```