```
% [time wntow,GPSdata,GLNSS,BOTH] = GPSvis(navfilename,ephemtype,...
   gpsvecstart,durationhrs,dt_sec,latgd,lon,alt,topomaskmin,topomaskmax,...
્ટ
   antmask,ant_enu,glnss,tlefilename)
% Predicts the number of GPS and/or Glonass satellites that will be
% visible for a specific observation site and antenna. Either YUMA
 almanacs or broadcast ephemerides can be used to propagate GPS orbits.
  Two Line Elements (TLE) sets are used to propagate Glonass satellites.
  The default Glonass TLE filename that is used is Glonass.tle.
% Author: Ben K. Bradley
% date: 02/20/2011
% Modified to remove calculations for ASEN 5090 Class 9/12
% INPUT:
                   Description
                                                              Units
응
% navfilename
               - filename of IGS broadcast ephemeris file to use
               - ephemeris type of navfilename: 1=YUMA, 2=Broadcast
%
  ephemtype
% gpsvecstart - GPS date/time vector to start analysis [y m d h m s]
% durationhrs - duration of analysis
                                                               hours
               - time step
ક
 dt sec
                                                              seconds
응
  lat qd
               - geodetic latitude of antenna site
                                                        [-90,90] deg
               - longitude of antenna site
% lon
                                                       [-180,180] deg
% alt
               - WGS84 ellipsoidal height (altitude) of antenna
                                                              meters
  topomaskmin
               - topographic minimum elevation (wrt horizon)
                                                                 dea
% topomaskmax - topographic maximum elevation (wrt horizon)
                                                                 deg
 antmask
               - antenna elevation mask (wrt antenna)
 ant_enu
               - boresight direction of antenna in east-north-up unit vector [E;
용
               - boolean: 1=include Glonass, 0=don't include Glonass
용
  glnss
% tlefilename - filename of Glonass TLE file to use
્ટ
% OUTPUT:
9
 NOTE: for outputs with 32 columns, the column number corresponds to
%
         the PRN number of the GPS satellite (i.e. each row is a specific
응
         time and each column is a specific satellite)
읒
               - week number and tow for all computations [WN TOW] (nx2)
% time_wntow
               - structure of GPS results. structure is below
%
  GPSdata
               - structure of Glonass results. structure is below
% GLNSS
               - structure of GPS/Glonass combined results
응
응
```

antmask,ant_enu,junk1,junk2)

1

```
topo_numsats: number of satellites above topomask
                                                    (nx1)
읒
         topo az: topocentric azimuth of satellites
                                                   (nx32)
응
         topo_el: topocentric elevation of satellites
                                                   (nx32)
응
            vis: flag for satellite visible (nx32)
2
      ant numsats: number of satellites above antenna mask
                                                    (nx1)
          ant el: satellite elevation wrt antenna
                                                   (nx32)
2
            DOP: structure containing DOPs: .GDOP .HDOP
                                                each (nx1)
                                     .VDOP .PDOP
읒
                                     .TDOP
응
2
% Coupling:
응
% lla2ecef
              read GPSbroadcast
% qpsvec2qpstow
              broadcast2xva
% ecef2azelrange2 sez2ecef
 gpsvec2utc
              utc2utc
% init_EOP
              get_EOP
% alm2xv
              read TLE
% tle2rv
              teme2ecef
% References:
응
  none
응
r_site = lla2ecef(latgd, lon, alt*0.001);
r_site = r_site' * 1000; % [x y z] meters
ant_ecef = sez2ecef(latgd,lon, [-ant_enu(2) ant_enu(1) ant_enu(3)]);
% Open GPS Ephemeris File and create ephemeris matrix ==========================
if (ephemtype == 1) % YUMA
   ephem_all = read_GPSyuma(navfilename);
elseif (ephemtype == 2) % Broadcast
   ephem_all = read_GPSbroadcast(navfilename);
end
% Convert GPS date/time start to week number and time of week
```

응

```
[WN0, TOW0] = gpsvec2gpstow( gpsvecstart );
   % WNO = week number count from 22Aug99
   % TOWO = time of week, seconds
TOWseries = (TOW0: dt_sec : TOW0+durationhrs*3600)';
      = TOWseries - TOW0;
elapsed
sz = length(TOWseries);
time_wntow = [WN0*ones(sz,1) TOWseries];
   % time_wntow = [WN TOW] % Week numbers and Time of Weeks
prnlist = 1:32;
Xpos = zeros(sz, 32) * NaN;
Ypos = Xpos;
Zpos = Xpos;
GPSdata = struct;
GPSdata.topo_numsats = zeros(sz,1);
GPSdata.topo az = zeros(sz, 32) * NaN;
GPSdata.topo_el = zeros(sz,32) * NaN;
GPSdata.ant_numsats = zeros(sz,1);
GPSdata.ant_el
             = zeros(sz,32) * NaN;
               = zeros(sz,1) * NaN;
GPSdata.DOP.HDOP
                = zeros(sz,1) * NaN;
GPSdata.DOP.VDOP
GPSdata.DOP.PDOP
               = zeros(sz,1) * NaN;
GPSdata.DOP.TDOP
               = zeros(sz,1) * NaN;
             = zeros(sz,1) * NaN;
GPSdata.DOP.GDOP
GLNSS = [];
BOTH = [];
for nn = prnlist % Loop through satellite list ------
   if (ephemtype == 1)
                   % YUMA
      [health,state] = alm2xv(ephem_all,time_wntow,nn);
```

```
elseif (ephemtype == 2) % Broadcast
      [health, state] = broadcast2xva(ephem all, time wntow, nn);
   end
   Xpos(:,nn) = state(:,1); % column number = PRN number
   Ypos(:,nn) = state(:,2); % meters ECEF
   Zpos(:,nn) = state(:,3);
   for tt = 1:sz % loop through all times ------
      if (health(tt) ~= 0) % satellite is unhealthy
          Xpos(tt,nn) = NaN; % get rid of unhealthy states
          Ypos(tt,nn) = NaN;
          Zpos(tt,nn) = NaN;
      else
          % Compute topocentric azimuth and elevation
          [GPSdata.topo_az(tt,nn),GPSdata.topo_el(tt,nn)] = ASEN5090_ecef2azelra
          % az,el = degrees
          % If the satellite is not visible, set the az and el to NaNs or zero h
          % CLOUSE: just NaN stuff with elevations below the min-mask
          GPSdata.topo_az(GPSdata.topo_el < topomaskmin) = NaN;</pre>
          GPSdata.topo_el(GPSdata.topo_el < topomaskmin) = NaN;</pre>
      end % END of satellite health
   end % END of time loop -----
end % END of PRN loop ------
% PUT IN YOUR CALCULATIONS FOR VISIBLE SATELLITES HERE:
% ------
for tt = 1:sz
   % GPS -------
   % Number of Visible GPS Satellites
   % Put in logic here to calculate the number visible
   % GPSdata.ant numsats(tt) = ??;
   GPSdata.ant_numsats(tt) = sum(GPSdata.topo_el(tt, :)>topomaskmin);
```

end %______

CLOUSE: sort the planes the PRNs are on,

```
planes = [];
planes2prns = zeros(32,2);
tol = 0.1;
for prn=1:31
   RAAN = ephem_all(prn,6);
   plane_found = 0;
   for plane = 1:length(planes)
       if planes(plane)-tol < RAAN < planes(plane)+tol</pre>
           plane_found = 1;
          planes2prns(ephem_all(prn,1),1)=RAAN*180/pi;
          planes2prns(ephem_all(prn,1),2)=ephem_all(prn,1);
          break
       end
   end
   if plane_found
       continue
   end
   planes = [planes RAAN];
   planes2prns(ephem_all(prn,1),1)=RAAN*180/pi;
   planes2prns(ephem_all(prn,1),2)=ephem_all(prn,1);
end
planes2prns
sortrows(planes2prns,1)
*-----
```

Published with MATLAB® R2013b