
## THỰC HÀNH KIẾN TRÚC MÁY TÍNH WEEK 11

### **BÙI QUANG HƯNG - 20225849**

# **Assignment 1:** - Code: # col 0x1 col 0x2 col 0x4 col 0x8 # # row 0x1 0 1 2 3 # 0x11 0x21 0x41 0x81 # # row 0x2 4 5 6 7 # 0x12 0x22 0x42 0x82 # # row 0x4 8 9 a b # 0x14 0x24 0x44 0x84 # row 0x8 c d e f # 0x18 0x28 0x48 0x88 # #-----# command row number of hexadecimal keyboard (bit 0 to 3) # Eg. assign 0x1, to get key button 0,1,2,3 # assign 0x2, to get key button 4,5,6,7 # NOTE must reassign value for this address before reading, # eventhough you only want to scan 1 row .eqv IN ADDRESS HEXA KEYBOARD 0xFFFF0012

```
# receive row and column of the key pressed, 0 if not key pressed
# Eg. equal 0x11, means that key button 0 pressed.
# Eg. equal 0x28, means that key button D pressed.
.eqv OUT ADDRESS HEXA KEYBOARD 0xFFFF0014
.data
Msg: .asciiz "\n"
.text
main:
      li $t1, IN ADDRESS HEXA KEYBOARD
      li $t2, OUT ADDRESS HEXA KEYBOARD
      li $s1, 0 # khoi tao gia tri bien kiem tra
start polling 1:
      li $t3, 0x01 #Check row 1 with key 0, 1, 2, 3
      sb $t3, 0($t1) # must reassign expected row
      jal polling
start polling 2:
      li $t3, 0x02 #Check row 2 with key 4, 5, 6, 7
      sb $t3, 0($t1) # must reassign expected row
      jal polling
start polling 3:
      li $t3, 0x04 #Check row 3 with key 8, 9, A, B
      sb $t3, 0($t1) # must reassign expected row
      jal polling
start polling 4:
      li $t3, 0x08 #Check row 4 with key C, D, E, F
      sb $t3, 0($t1) # must reassign expected row
      jal polling
```

```
check_after_polling_4:
      beq $a0, 0x0, print
      j start polling 1
polling:
      sb $t3, 0($t1) # must reassign expected row
      lb $a0, 0($t2) # read scan code of key button
      bne $a0, 0x00, print
      jr $ra
print:
      li $v0, 34 # print integer (hexa)
      syscall
      li $v0, 4 # Print Msg
      la $a0, Msg
      syscall
sleep:
      li $a0, 4000 # sleep 4000ms
      li $v0, 32
      syscall
back to polling:
      j start polling 1 # continue polling
- Kết quả:
+ Nhập lần lượt từ nút 0 đến nút f, kết quả sẽ như thế thế này:
```



→ Kết quả là cột 16 số hexa tương ứng với 16 phím được bấm


## **Assignment 2:**

# Enable the interrupt of Keyboard matrix 4x4 of Digital Lab Sim

```
li $t1, IN_ADDRESS_HEXA_KEYBOARD
    li $t3, 0x80 # bit 7 of = 1 to enable interrupt
    sb $t3, 0($t1)
#-----
# No-end loop, main program, to demo the effective of interrupt
#-----
Loop:
    nop
    nop
    addi $v0, $zero, 32
    li $a0, 200
    syscall
    nop
    nop
    b Loop # Wait for interrupt
end_main:
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
.ktext 0x80000180
#-----
# Processing
#-----
IntSR:
         addi $v0, $zero, 4 # show message
    la $a0, Message
    syscall
```

eret # Return from exception

### - Kết quả chạy:



- + Khi thực hiện chạy từng lệnh của chương trình nhận thấy:
  - Khi ta nhấn một phím bất kỳ thì chương trình xảy ra hiện tượng ngắt khi đó thanh ghi epc sẽ lưu lại giá trị của lệnh được chứa trong thanh ghi pc (lệnh được thực hiện ngay trước khi xảy ra ngắt) và thực hiện chương trình con ngắt.
  - Sau khi thực hiện chương trình con ngắt tăng giá trị thanh ghi epc lên 4 rồi sử dụng lệnh eret để quay về chương trình chính .
  - Thanh ghi epc lưu địa chỉ của lệnh chứa trong pc và sau khi thực hiện xong ngắt tăng giá trị thanh ghi epc lên 4 để quay về lệnh ngay sau khi thực hiện ngắt.

```
Assignment 3:
- Code:
.eqv IN_ADDRESS_HEXA_KEYBOARD 0xFFFF0012
.eqv OUT ADDRESS HEXA KEYBOARD 0xFFFF0014
.data
Message: .asciiz "Key scan code "
# MAIN Procedure
.text
main:
#-----
# Enable interrupts you expect
#-----
# Enable the interrupt of Keyboard matrix 4x4 of Digital Lab Sim
li $t1, IN ADDRESS HEXA KEYBOARD
li $t3, 0x80 \# bit 7 = 1 to enable
sb $t3, 0($t1)
#-----
# Loop an print sequence numbers
#-----
xor \$s0, \$s0, \$s0 \# count = \$s0 = 0
Loop:
addi $s0, $s0, 1 # count = count + 1
prn seq:
```

```
addi $v0,$zero,1
add $a0,$s0,$zero # print auto sequence number
syscall
prn_eol:
addi $v0,$zero,11
li $a0,'\n' # print endofline
syscall
sleep:
addi $v0,$zero,32
li $a0,500 # sleep 0,5 s
syscall
nop # WARNING: nop is mandatory here.
b Loop # Loop
end main:
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
.ktext 0x80000180
#-----
# SAVE the current REG FILE to stack
#-----
IntSR:
addi $sp,$sp,4 # Save $ra because we may change it later
sw $ra,0($sp)
addi $sp,$sp,4 # Save $at because we may change it later
sw $at,0($sp)
```

```
addi $sp,$sp,4 # Save $sp because we may change it later
sw $v0,0($sp)
addi $sp,$sp,4 # Save $a0 because we may change it later
sw $a0,0($sp)
addi $sp,$sp,4 # Save $t1 because we may change it later
sw $t1,0($sp)
addi $sp,$sp,4 # Save $t3 because we may change it later
sw $t3,0($sp)#-----
# Processing
#-----
prn msg:
addi $v0, $zero, 4
la $a0, Message
syscall
get cod:
li $t1, IN ADDRESS HEXA KEYBOARD
li $t3, 0x81 # check row 4 and re-enable bit 7
sb $t3, 0($t1) # must reassign expected row
li $t1, OUT ADDRESS HEXA KEYBOARD
lb $a0, 0($t1)
bne $a0, $zero, prn cod
li $t1, IN ADDRESS HEXA KEYBOARD
li $t3, 0x82 # check row 4 and re-enable bit 7
sb $t3, 0($t1) # must reassign expected row
li $t1, OUT ADDRESS HEXA KEYBOARD
lb $a0, 0($t1)
bne $a0, $zero, prn cod
```

```
li $t1, IN ADDRESS HEXA KEYBOARD
li $t3, 0x84 # check row 4 and re-enable bit 7
sb $t3, 0($t1) # must reassign expected row
li $t1, OUT ADDRESS HEXA KEYBOARD
lb $a0, 0($t1)
bne $a0, $zero, prn cod
li $t1, IN ADDRESS HEXA KEYBOARD
li $t3, 0x88 # check row 4 and re-enable bit 7
sb $t3, 0($t1) # must reassign expected row
li $t1, OUT ADDRESS HEXA KEYBOARD
lb $a0, 0($t1)
bne $a0, $zero, prn cod
prn_cod:
li $v0,34
syscall
li $v0,11
li $a0,'\n' # print endofline
syscall
#-----
# Evaluate the return address of main routine
\# \operatorname{epc} \leq \operatorname{epc} + 4
#-----
next pc:
mfc0 $at, $14 # $at <= Coproc0.$14 = Coproc0.epc
addi at, at, 4 \# at = at + 4 (next instruction)
mtc0 $at, $14 # Coproc0.$14 = Coproc0.epc <= $at
#-----
```

#### # RESTORE the REG FILE from STACK

#-----

#### restore:

lw \$t3, 0(\$sp) # Restore the registers from stackaddi \$sp,\$sp,-4

lw \$t1, 0(\$sp) # Restore the registers from stack

addi \$sp,\$sp,-4

lw \$a0, 0(\$sp) # Restore the registers from stack

addi \$sp,\$sp,-4

lw \$v0, 0(\$sp) # Restore the registers from stack

addi \$sp,\$sp,-4

lw \$ra, 0(\$sp) # Restore the registers from stack

addi \$sp,\$sp,-4


lw \$ra, 0(\$sp) # Restore the registers from stack

addi \$sp,\$sp,-4

return:

eret # Return from exception

- Kết quả chạy: Nhập lần lượt phím 2, 2, 6, 8. Kết quả sẽ như thế này:



- + Chương trình chạy một vòng lặp không dừng để chờ ngắt từ bàn phím . Với mỗi 1 vòng lặp chỉ số đếm tăng dần lên . Khi nhận được lệnh ngắt , chương trình thực hiện in ra key scan code của phím vừa nhập và tiếp tục vòng lặp không dừng .
- + Khi xảy ra hiện tượng ngắt thanh ghi epc lưu lại địa chỉ của lệnh vừa được thực hiện và thực hiện chương trình con ngắt . Sau khi thực hiện xong giá trị epc tăng lên 4 để quay về và thực hiện tiếp tục chương trình chính


#### **Assignment 4:**

# - Code: .eqv IN ADRESS HEXA KEYBOARD 0xFFFF0012 .eqv COUNTER 0xFFFF0013 # Time Counter .eqv MASK CAUSE COUNTER 0x00000400 # Bit 10: Counter interrupt .eqv MASK CAUSE KEYMATRIX 0x00000800 # Bit 11: Key matrix interrupt .data msg keypress: .asciiz "Someone has pressed a key!\n" msg counter: .asciiz "Time inteval!\n" # MAIN Procedure .text main: #-----# Enable interrupts you expect #-----# Enable the interrupt of Keyboard matrix 4x4 of Digital Lab Sim li \$t1, IN ADRESS HEXA KEYBOARD li \$t3, 0x80 # bit 7 = 1 to enablesb \$t3, 0(\$t1) # Enable the interrupt of TimeCounter of Digital Lab Sim

li \$t1, COUNTER
sb \$t1, 0(\$t1)
#
# Loop an print sequence numbers
#
Loop:
nop
nop
nop
sleep:
addi \$v0,\$zero,32 # BUG: must sleep to wait for Time Counter
li \$a0, 400 # sleep 0,4s
syscall
nop # WARNING: nop is mandatory here.
b Loop
end_main:
#
~~
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
#
.ktext 0x80000180
IntSR:
#
# Temporary disable interrupt
#
dis_int:


li \$t1, COUNTER # BUG: must disable with Time Counter

```
sb $zero, 0($t1)
# no need to disable keyboard matrix interrupt
#-----
# Processing
#-----
get_caus:
mfc0 $t1, $13 # $t1 = Coproc0.cause
IsCount:li $t2, MASK CAUSE COUNTER # if Cause value confirm Counter..
and $at, $t1,$t2
beq $at,$t2, Counter Intr
IsKeyMa:
li $t2, MASK CAUSE KEYMATRIX # if Cause value confirm Key..
and $at, $t1,$t2
beq $at,$t2, Keymatrix Intr
others:
j end process # other cases
Keymatrix Intr:
li $v0, 4 # Processing Key Matrix Interrupt
la $a0, msg keypress
syscall
j end process
Counter Intr:
li $v0, 4 # Processing Counter Interrupt
la $a0, msg counter
syscall
j end_process
end process:
```



## - Kết quả:

Nhập lần lượt các phím 2, 6, 8, 4 (tổng số phím bấm là 4). Kết quả sẽ như thế này:



- Time inteval! khi không bấm gì và Someone has pressed a key! khi bấm phím bất kỳ.
- Khi thực hiện chương trình ngắt thanh ghi epc lưu địa chỉ của lệnh vừa được thực hiện và sau khi thực hiện xong chương trình con ngắt giá trị của thanh ghi epc tăng lên 4 để quay về lệnh kế tiếp trong chương trình chính

#### **Assignment 5:**

#### - Code:

.eqv KEY CODE 0xFFFF0004 # ASCII code from keyboard, 1 byte

.eqv KEY READY 0xFFFF0000 # =1 if has a new keycode?

# Auto clear after lw

.eqv DISPLAY CODE 0xFFFF000C # ASCII code to show, 1 byte

.eqv DISPLAY READY 0xFFFF0008 # =1 if the display has already to do

# Auto clear after sw

.eqv MASK CAUSE KEYBOARD 0x0000034 # Keyboard Cause

.text


li \$k0, KEY CODE

li \$k1, KEY READY

li \$s0, DISPLAY CODE

```
li $s1, DISPLAY READY
loop: nop
WaitForKey: lw \$t1, 0(\$k1) \# \$t1 = [\$k1] = KEY READY
beq $t1, $zero, WaitForKey # if $t1 = 0 then Polling
MakeIntR: teqi $t1, 1 # \text{ if } $t1 = 1 \text{ then raise an Interrupt}
j loop
#-----
# Interrupt subroutine
#-----
.ktext 0x80000180
get caus: mfc0 $t1, $13 # $t1 = Coproc0.cause
IsCount: li $t2, MASK CAUSE KEYBOARD# if Cause value confirm Keyboard..
and $at, $t1,$t2
beq $at,$t2, Counter Keyboard
j end process
Counter Keyboard:
ReadKey: lw $t0, 0($k0) # $t0 = [$k0] = KEY CODE
WaitForDis: lw $t2, 0(\$s1) \# \$t2 = [\$s1] = DISPLAY READY
beq $t2, $zero, WaitForDis # if $t2 == 0 then Polling
Encrypt: addi $t0, $t0, 1 # change input key
ShowKey: sw $t0, 0($s0) # show key
nop
end process:
next pc: mfc0 $at, $14 # $at <= Coproc0.$14 = Coproc0.epc
addi at, at, 4 \# at = at + 4 (next instruction)
mtc0 $at, $14 # Coproc0.$14 = Coproc0.epc <= $at
return: eret # Return from exception
```

## - Kết quả chạy:



+ Khi dừng nhập dữ liệu từ bàn phím, chương trình sẽ lặp vô tận để đợi dữ liệu mới được nhập vào và tiếp tục thực hiện.