Carpe Noctum Roadmap

Offline HFC field notebook for maintenance technicians. Goodst3r/Carpe-Noctum. Based on build3 close-out (f467e52) and prior reviews. November 2026.

1. Current state (build 3)

Pinned facts from FINAL_HANDOFF.md on build3:
- 29 screens, 47 features on the f467e52 standalone.
- Test tab has multiple sub-screens (Limits, Calculators, DOCSIS health, Leakage, etc.).
- Files and Help already in the header.
- Power has Load + What-if.
- Station and Readings hold different measurements.
- Company values start as Unknown. 42/54 and 204/258 plants stay separate.
- Offline only. No customer data or PII. No cloud sync.
- No build 3 APK yet. Physical phone testing not done.

2. Immediate (after build 3 merge)

Finish and merge build 3 first. Then change navigation only. No new features in the same change.
Proposed information architecture:
- Home / Plan / Field / Tools / Closeout (five bottom tabs).
- Split the crowded Test tab into Field (live work) and Tools (searchable reference and calculators).
- Persistent context strip for job, asset, split, and measurement plane.
- Exact resume so interrupted work returns to the same place.

Exit criteria: tab counts match guides, 320–430 px layout holds, existing jobs load, no storage-key changes.

3. Near-term (P0 — connect existing screens)

Small items that tie the night's work together. All offline, no company numbers required.

Priority	Item	What it does	Why
P0	Tonight open-items list	Unfinished stations, open temp repairs, unexplained readings in one list.	Pick up tomorrow without digging through notes.
P0	Temporary-repair tracker	Log RG6, pads, terminators by station/span. Show temp repairs still open.	Many temp repairs never get closed.
P0	Plant banner + leakage method	Colored band shows 42/54 or 204/258 and which leakage method (legacy or CCDP).	Prevents mixing plants and mixing leakage methods.
P0	Power-sum / composite calculator	Add/subtract dBmV, N equal carriers, signal + noise. Shows gap, margin.	Quick math for split work.
P0	Upstream headroom card	Convert 1.6 to 6.4 MHz reference and show high-split numbers.	Company limits unknown.
P0	Intermittent-ingress investigation log	One night log: conditions, time, what was tried. Weather and ingress hunting.	Personal only.

4. Medium-term (training alignment and reference)

Cards and calculators that close NCTI System Technician and SCTE BDS gaps. All inputs labeled Spec/Expert/Company/Unknown. No invented procedures.
- Map symbol legend (tech fills company symbols).
- Spectrum analyzer setup card by task (from VIAVI docs only).
- Cascade noise/distortion calculator (inputs from spec sheets).

• Bonding and grounding reminder (follows company policy).
• Generator/standby pre-start checklist (supervisor review).

5. Later / hold

Photo attachments (risk of house numbers/faces). Battery runtime estimator (only with OEM table). Transponder alarm cards (per model only, after OEM manuals). Anything that requires company targets before they are supplied.

6. Constraints and risks

• Offline-first. No sync, no customer data, no live polling.
• Company values stay Unknown until Spencer supplies them.
• Real-phone testing (gloves, night, interrupted work) has not been done. Desktop Chromium checks are not a phone.
• Supervisor review needed for Safety, Outage, and Leakage before coworkers use them.
• Navigation change after build 3 merges. Do not start it while open stretch PRs are landing.

This roadmap is a synthesis of the Claude layout review, the build3 handoff, and public pain-point notes. Facts from the repository win. Items marked not re-verified where phone or field checks are missing.