

# **ANTENA MAGNETYCZNA KF**

### **Schemat:**



# **Schemat zastępczy:**




### Dane techniczne:

- 1. Obwód 3,4 metra
- 2. Kształt ośmiokąt
- 3. Średnica rury 28 mm
- 4. Materiał rury miedź
- 5. Pojemność kondensatora 10 do 50 pF
- 6. Częstotliwość pracy od 13,5 do 26 MHZ
- 7. Sprzężenie anteny z TRX pętla Faradaya
- 8. Sterowanie kondensatora.- silnik prądu stałęgo z przekładnią zębatą oraz elektroniczny regulator PWM (modulacja współczynnika wypełnienia impulsu)


## Efektywność anteny w stosunku do idealnej anteny magnetycznej:

- 1. 14 MHZ około 75% (1,2 dB 0,2 punktu S)
- 18 MHz około 88% (0,6 dB 0,1 punktu S)
   21 MHz około 93% (0,3 dB 0,1 punktu S)
- 4. 24 MHz około 96% (0,2 dB 0,0 punktu S)

Schemat regulatora PWM, do regulacji obrotów silnika obracającego poprzez przekładnie kondensatorem zmiennym:



# Rysunek petli sprzegającej Faradaya:



Wyliczenia anteny wykonane zostały przy pomocy programu komputerowego : RJELOOP1.EXE.

#### Założenia wstępne obliczenia anteny:

- 1. Parametry posiadanego kondensatora zmiennego (10pF 50pF)
- 2. Częstotliwość pracy od 14 MHz w górę, przy efektywności nie mniejszej niż 75% idealnej anteny magnetycznej
- 3. Kształt anteny ośmiokąt
- 4. Materiał anteny rura miedziana hydrauliczna 28 mm oraz kolanka hydrauliczne miedziane 28 mm
- 5. Sprzężenie przy pomocy Faraday loop
- 6. Moc doprowadzona 150 W

<u>Dane anteny wyliczone programem RJEIOOP1.EXE dla pasm 14MHz, 18MHz, 21MHz, 24MHz w postaci zrzutów ekranowych programu:</u>

#### **14MHz:**

```
C:\DOCUME~1\wlodekm\Pulpit\RJELOOP1.EXE
                                                                                                    _ | X
     Shape of loop
Perimeter or circumference of main loop, metres.
Diameter of loop conductor, mm
Height of lowest part of loop above earth, metres
Frequency of operation, megahertz
      Transmitter output power, watts ....
                                                   0.161
    Electrical length of loop ...
                                                              wavelengths at operating freq.
                                                    2.46
0.19
17.8
46.5
30.8
     Inductance of main loop .....
                                                              micro-henrys
    Coupling loop diameter ......
                                                              metres to match to 50-ohm feeder
     Turns ratio on coupling xfmr.
    Tuning capacitor setting ....
Current in main loop ....
                                                              pico-farads at resonance
                                                              amperes rms, opposite capacitor
     Voltage across capacitor ....
                                                              peak volts
    Q when transmitting .....
     Transmitting bandwidth .....
                                                     10.2
                                                              kilo-hertz between 3dB points
    Radiation resistance ......
                                                     1190
                                                              ohms distributed around loop
    Conductor RF loss resistance
Ground proximity losses
Transmission efficiency
                                                              percent of power input
dB = 0.2 "S"-points
    Loss relative to ideal loop .
 Select S,P,D,H,F,T to change input data, R(e-start) or Q(uit program)
```

### 18MHz:

```
C:\DOCUME~1\wlodekm\Pulpit\RJELOOP1.EXE
                                                                                _ O X
    28.0
                                                                3.0
    Frequency of operation, megahertz .....
    Transmitter output power, watts ......
                                                             150.0
   Electrical length of loop ...
                                         0.205
                                                  wavelengths at operating freg.
                                          2.46
0.20
11.8
26.9
20.5
    Inductance of main loop .....
                                                  micro-henrys
   Coupling loop diameter .....
                                                  metres to match to 50-ohm feeder
                                                  to 1 .. .. .. .. pico-farads at resonance
    Turns ratio on coupling xfmr.
    Tuning capacitor setting ....
   Current in main loop ......
                                                  amperes rms, opposite capacitor
                                           7568
    Voltage across capacitor ....
                                                  peak volts
   Q when transmitting ......
Transmitting bandwidth .....
                                        23.1
0.3142
0.0431
0.0004
                                                  kilo-hertz between 3dB points
                                                  ohms distributed around loop
   Radiation resistance ......
   Conductor RF loss resistance
   Ground proximity losses .....
   Transmission efficiency .....
Loss relative to ideal loop .
                                                  percent of power input dB = 0.1 "S"-points
                                         87.84
                                           0.6
<u>Select S,P,D,H,F,T to change input data, R(e-start) or Q(uit program)</u>
```

#### **21MHz:**

```
C:\DOCUME~1\wlodekm\Pulpit\RJELOOP1.EXE
                                                                                          _ | X
     OCTAGON
     28.0
3.0
     Transmitter output power, watts .....
                                               0.161
    Electrical length of loop ...
                                                        wavelengths at operating freq.
                                               2.46
0.19
17.8
46.5
30.8
9188
    Inductance of main loop .....
                                                        micro-henrys
    Coupling loop diameter .....
                                                        metres to match to 50-ohm feeder
                                                        to 1 .. .. .. .. pico-farads at resonance
    Turns ratio on coupling xfmr.
    Tuning capacitor setting ....
Current in main loop .....Voltage across capacitor ....
                                                        amperes rms, opposite capacitor peak volts
                                             1395
10.2
0.1190
0.0381
0.0005
75.48
    Q when transmitting .....
    Transmitting bandwidth .....
                                                        kilo-hertz between 3dB points
    Radiation resistance
Conductor RF loss resistance
Ground proximity losses
Transmission efficiency
Loss relative to ideal loop
                                                        ohms distributed around loop
                                                        percent of power input dB = 0.2 "S"-points
                                                1.2
 Select S,P,D,H,F,T to change input data, R(e-start) or Q(uit program)
```

## **24MHz:**

```
C:\DOCUME~1\wlodekm\Pulpit\RJELOOP1.EXE
                                                                     _ 🗆 X
    OCTAGON
    Frequency of operation, megahertz .....
    Transmitter output power, watts .....
                                    0.283
2.46
0.23
6.5
11.9
   Electrical length of loop ...
                                           wavelengths at operating freq.
   Inductance of main loop .....
                                           micro-henrys
   Coupling loop diameter .....
                                           metres to match to 50-ohm feeder
   Turns ratio on coupling xfmr.
                                           to 1
                                           pico-farads at resonance
   Tuning capacitor setting ....
   Current in main loop ......
                                           amperes rms, opposite capacitor
                                     5370
   Voltage across capacitor ....
                                           peak volts
   O when transmitting .....
                                   76.5
1.1343
0.0505
   Transmitting bandwidth .....
                                           kilo-hertz between 3dB points
   Radiation resistance ......
                                           ohms distributed around loop
   Conductor RF loss resistance
   Ground proximity losses .....
                                   0.0003
   Transmission efficiency .....
                                           percent of power input
   Loss relative to ideal loop .
                                     0.2
                                           dB = 0.0 "S"-points
 Select S.P.D.H.F.T to change input data. R(e-start) or Q(uit program)
```

Parametry elektryczne anteny zestrojonej w odcinku pasma 14 MHz (zrzut ekranu analizatora antenowego) zxfdi:



Antena magnetyczna, znana była już przed drugą wojną światową, aczkolwiek niedoceniana ze względu na brak zrozumienia jej pracy i w związku z tym bardzo często były (i są) popełniane błędy konstrukcyjne – obniżające znacznie skuteczność anteny.

Często stosowana przez wojsko oraz służby profesjonalne jako antena namiernicza (głębokie minima w charakterystyce (w płaszczyźnie horyzontu)

Poprawnie wyliczona i skonstruowana antena w 100% dorównuje antenie dipolowej a w niektórych przypadkach ją przewyższa.

Antena nie wymaga przeciwwag oraz w pozycji pionowej (najbardziej skutecznej) nie wymaga dużej wysokości zainstalowania (wystarczy około dwa razy średnica anteny)

Mało znaną cechą anteny magnetycznej jest jej zmienna charakterystyka promieniowania w zależności od jej kąta promieniowania względem horyzontu. Przy bardzo małych kątach do około 10 stopni antena ma charakterystykę ósemkową z bardzo ostrym minimami, na kierunkach plus i minus 90 stopni od płaszczyzny anteny (dużo głębszymi niż w dipolu).

Przy wznoszącym się kącie, minima powoli zanikają i już przy kącie około 45 stopni, charakterystyka promieniowania przypomina kołową, a przy kącie 90 stopni jest idealnie kołowa.

Jednocześnie ze zmianą kąta promieniowania anteny, zmienia się płynnie jej polaryzacja promieniowania, i tak - przy kącie promieniowania 0 stopni jest idealnie pionowa, przechodząc przez mieszaną polaryzację – a przy kącie promieniowania 90 stopni jest idealnie pozioma.

Przy małych wysokościach zainstalowania antena praktycznie promieniuje w pełnym zakresie od 0 do 90 stopni.- co skutkuje przydatnością tak do łączności dalekich jak i bliskich.

Podnosząc antenę w górę – powyżej jednej dziesiątej długości fali (i wyżej) można kształtować charakterystyką kąta promieniowania anteny zależnie od potrzeb.

Życzę ciekawych łączności, Włodek SP5MAD