简述

• 结束WEA流程;跟进PLMN流程结束;跟进SPN流程中。

PLMN和SPN

- PLMN(Public Land Mobile Network):当前SIM所驻留的网络
- SPN(Service Provider Name): 当前发行SIM卡的运营商的名称

PLMN流程

- 1. TeleService 系统应用加载Telephony业务模型的过程中,同步完成 ServiceStateTracker 对象的创建,同时注册网络变化相关的Registration。
 - o ServiceStateTracker 位于 frameworks/opt/telephony/src/java/com/android/internal/telephony/ServiceStateTrack er.java

2. 当网络发生变化时ServiceStateTracker响应EVENT_NETWORK_STATE_CHANGED消息

```
public void handleMessage(Message msg) {
    AsyncResult ar;
    int[] ints;
    Message message;

    if (VDBG) log("received event " + msg.what);
    switch (msg.what) {
        case EVENT_NETWORK_STATE_CHANGED:
            pollStateInternal(true);
            break;
    }
}

protected void pollStateInternal(boolean modemTriggered) {
// MTK-END
```

```
mPollingContext = new int[1];
    mPollingContext[0] = 0;
    log("pollState: modemTriggered=" + modemTriggered);
    switch (mCi.getRadioState()) {
        case TelephonyManager.RADIO_POWER_UNAVAILABLE:
            mNewSS.setStateOutOfService();
            setSignalStrengthDefaultValues();
            mLastNitzData = null;
            mNitzState.handleNetworkUnavailable();
            pollStateDone();
            break;
        case TelephonyManager.RADIO_POWER_OFF:
            mNewSS.setStateOff();
            setSignalStrengthDefaultValues();
            mLastNitzData = null;
            mNitzState.handleNetworkUnavailable();
            // don't poll when device is shutting down or the poll was
not modemTrigged
           // (they sent us new radio data) and current network is not
IWLAN
            if (mDeviceShuttingDown ||
                    (!modemTriggered &&
ServiceState.RIL_RADIO_TECHNOLOGY_IWLAN
                    != mSS.getRilDataRadioTechnology())) {
                pollStateDone();
                break;
            }
        default:
            // Issue all poll-related commands at once then count down
the responses, which
            // are allowed to arrive out-of-order
            mPollingContext[0]++;
            //获取PLMN信息
            mCi.getOperator(obtainMessage(EVENT_POLL_STATE_OPERATOR,
mPollingContext));
            break;
    }
}
```

o modem侧获取PLMN优先级

- 1. Eons(Enhanced Operator Name String),也就是从SIM的EF_OPL和EF_PNN分区来读取Plmn Name
 - EF:Elementary File
- 2. CPHS ONS(Common PCN Handset Specification Operator Name String) , 该字串也是保存在SIM文件系统中
- 3. NITZ Operator Name
- 4. 配置文件读取
- 5. MCCMNC数字作为Plmn Name

```
public void handleMessage(Message msg) {
    AsyncResult ar;
    int[] ints;
    Message message;
    if (VDBG) log("received event " + msg.what);
    switch (msg.what) {
        case EVENT_POLL_STATE_OPERATOR:
                ar = (AsyncResult) msg.obj;
                handlePollStateResult(msg.what, ar);
                break;
    }
}
protected void handlePollStateResult(int what, AsyncResult ar) {
    // Ignore stale requests from last poll
    if (ar.userObj != mPollingContext) return;
    if (ar.exception != null) {
    } else try {
        handlePollStateResultMessage(what, ar);
}
protected void handlePollStateResultMessage(int what, AsyncResult ar) {
    int ints[];
    switch (what) {
        case EVENT_POLL_STATE_OPERATOR: {
            if (mPhone.isPhoneTypeGsm()) {
                String opNames[] = (String[]) ar.result;
                if (opNames != null && opNames.length >= 3) {
                    //protected ServiceState mNewSS;
                    mNewSS.setOperatorAlphaLongRaw(opNames[0]);
                    mNewSS.setOperatorAlphaShortRaw(opNames[1]);
                    // FIXME: Giving brandOverride higher precedence, is
this desired?
                    String brandOverride = getOperatorBrandOverride();
                    mCdnr.updateEfForBrandOverride(brandOverride);
                    if (brandOverride != null) {
                        log("EVENT_POLL_STATE_OPERATOR: use
brandOverride=" + brandOverride);
                        mNewSS.setOperatorName(brandOverride,
brandOverride, opNames[2]);
                    } else {
                        mNewSS.setOperatorName(opNames[0], opNames[1],
opNames[2]);
                    }
                }
            }
            break;
        }
    }
}
```

```
protected String getOperatorBrandOverride() {
// MTK-END

   UiccCard card = mPhone.getUiccCard();
   if (card == null) return null;
   UiccProfile profile = card.getUiccProfile();
   if (profile == null) return null;
   return profile.getOperatorBrandOverride();
}
```

4. ServiceState的setOperatorName()

```
public void setOperatorName(String longName, String shortName, String
numeric) {
    mOperatorAlphaLong = longName;
    mOperatorAlphaShort = shortName;
    mOperatorNumeric = numeric;
}
```

5. ServiceState提供了三个对应的getXXX()方法获取PLMN

```
//Get current registered operator name in long alphanumeric format.
//In GSM/UMTS, long format can be up to 16 characters long.
//In CDMA, returns the ERI text, if set. Otherwise, returns the ONS.
public String getOperatorAlphaLong() {
    return mOperatorAlphaLong;
}

//Get current registered operator numeric id.
//In GSM/UMTS, numeric format is 3 digit country code plus 2 or 3 digit
//network code.
public String getOperatorNumeric() {
    return mOperatorNumeric;
}
```

SPN流程

从SIM卡读取

从配置文件读取