no		operation	F	ALU-OP	add/sub	reg-dest	REG-WRITI	reg-scr	M-Write
	1	and	00	00000	11	01	1	0	0
	2	or	01	00000	11	01	1	0	0
	3	xor	10	00000	11	01	1	0	0
	4	eqv	11	00000	11	01	1	0	0
	5	add	00	00001	00	01	1	0	0
	6	sub	01	00001	01	01	1	0	0
	7	slt	10	00001	11	01	1	0	0
	8	seq	11	00001	11	01	1	0	0
no		operation	F	ALU-OP	add/sub	reg-dest	REG-WRIT	reg-scr	M-Write
	9	andi	Χ	00100	11	01	1	0	0
	10	ori	Χ	00101	11	01	1	0	0
	11	xori	Χ	00110	11	01	1	0	0
	12		Х	00111	11	01	1	0	0
	13	addi	Χ	01000	11	01	1	0	0
	14		Χ	01001	11	01	1	0	0
	15	seqi	Χ	01010	11	01	1	0	0
	16	sll	Χ	01011	11	01	1	0	0
	17	srl	Χ	01100	11	01	1	0	0
	18	ror	Χ	01101	11	01	1	0	0
	19	beq	Χ	01110	11	XX	0	1	0
	20		Х	01111	11	XX	0	1	0
	21		Χ	10000	11	01	1	Χ	0
	22		Х	10001	11	XX	0	Χ	1
no		operation		ALU-OP	add/sub		REG-WRIT	reg-scr	M-Write
	23		Х	10100	11	XX	0	1	0
	24		Χ	10101	11	XX	0	1	0
	25		Х	10110	11	XX	0	1	0
	26		Х	10111	11	XX	0	1	0
	27	bgtz	X	11000	11	XX	0	1	0
	28		X	11001	11	XX	0	1	0
	29		X	11010	11	XX	0	1	0
	30		X	11011	11	XX	1	1	0
	31		X	11100	11	01	1	X	0
	32		X	11101	11	01	1	1	0
no		operation		ALU-OP	add/sub		REG-WRIT	reg-scr	M-Write
	33		X	XXXXX	11	XX	0	X	0
	34	jal	Χ	XXXXX	11	XX	1	X	0

M-Read	MemToRe	pcnext	branch	b-all	j-src
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
M-Read	MemToRe	pcnext	branch	b-all	j-src
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
0	XX	10	1	000	0
0	XX	10	1	001	0
1	01	00	Х	XXX	0
0	XX	00	Х	XXX	0
M-Read	MemToRe	pcnext	branch	b-all	j-src
0	XX	10	1	010	0
0	XX	10	1	011	0
0	XX	10	1	100	0
0	XX	10	1	101	0
0	XX	10	1	110	0
0	XX	10	1	111	0
0	XX	11	Х	XXX	0
0	10	11	Х	XXX	1
0	00	00	Х	XXX	0
0	00	00	Х	XXX	0
	MemToRe	pcnext	branch	b-all	j-src
0	XX	01	Х	XXX	0
0	10	01	Х	XXX	1

Control Signal
00000110110000000xxxx0
00000110110000000xxxx0
00000110110000000xxxx0
00000110110000000xxxx0
00001000110000000xxxx0
00001000110000000xxxx0
00001000110000000xxxx0
00001000110000000xxxx0
Control Signal
00100110110000000xxxx0
00101110110000000xxxx0
00110110110000000xxxx0
00111110110000000xxxx0
01000110110000000xxxx0
01001110110000000xxxx0
01010110110000000xxxx0
01011110110000000xxxx0
01100110110000000xxxx0
01101110110000000xxxx0
0111011XX0100XX1010000
0111011XX0100XX1010000
1000011011X010100xxxx0
1000111XX0X10XX00xxxx0
Control Signal
1010011XX0100XX1010100
1010111XX0100XX1010110
1011011XX0100XX1011000
10111111XX0100XX1011010
1100011XX0100xx1011100
1100111XX0100XX1011110
1101011XX0100XX11xxxx0
11011111XX11001011xxxx1
1110011011X000000xxxx0
11101110111000000xxxx0
Control Signal
xxxxx11XX0X00XX01xxxx0
xxxxx11XX1X001001xxxx1