```
25-Sep-91 13:23:32 {PELE:MV:ENVOS}<LISPUSERS>MEDLEY>ETHERBOOT.;2
 File created:
  changes to:
               (VARS ETHERBOOTCOMS)
previous date:
               13-Jul-88 17:04:37 {PELE:MV:ENVOS}<LTSPUSERS>MEDLEY>ETHERBOOT.:1
 Read Table:
               INTERLISP
   Package:
               INTERLISP
      Format:
                XCCS
"; Copyright (c) 1985, 1986, 1987, 1988, 1991 by Stanford University. All rights reserved.
(RPAQQ ETHERBOOTCOMS
        ^{(};; Lisp-based Ethernet Boot server, requires ETHERRECORDS and EXPORTS.ALL to compile
         (DECLARE%: EVAL@COMPILE DONTCOPY (FILES (LOADCOMP)
                                                    ETHERRECORDS SPPDECLS))
         (FNS ETHERBOOT SENDSIMPLEDATA SENDSPPDATA CACHE.BOOT.FILES)
         (VARS ETHERBOOTFILES BOOTREQUESTTYPES)
         (ADDVARS (BOOTFILEDIRECTORIES {CORE} {DSK})
                (BOOTFILECACHETYPES DB GERM))
         (INITVARS (BOOTFILECACHEDIRECTORY '(CORE)))
(DECLARE%: DONTCOPY (RECORDS ETHERBOOTPACKET ETHERBOOTFILE BOOTREQUESTTYPE)
                (CONSTANTS (ETHERBOOTPACKETTYPE 9)
                        (BOOTSERVERSOCKET 10)
                        (SIMPLEREQUEST 1)
                        (SIMPLEDATA 2)
                        (SPPREQUEST 3)))
         (GLOBALVARS ETHERBOOTFILES BOOTREQUESTTYPES BOOTFILEDIRECTORIES BOOTFILECACHETYPES
                BOOTFILECACHEDIRECTORY)))
;; Lisp-based Ethernet Boot server, requires ETHERRECORDS and EXPORTS.ALL to compile
(DECLARE%: EVAL@COMPILE DONTCOPY
(FILESLOAD (LOADCOMP)
       ETHERRECORDS SPPDECLS)
(DEFINEO
(ETHERBOOT
  [LAMBDA (LOGFILE) (DECLARE (SPECVARS . T))
                                                                      ; Edited 13-Jul-88 17:03 by cdl
      (XIP NSOCKET BOOTFILE BOOTSTREAM BOOTREQUESTTYPE FILENUMBER ETHERBOOTFILE)
      (DECLARE (SPECVARS . T))
      (RESETLST
          [RESETSAVE NIL '(CLOSENSOCKET , (SETQ NSOCKET (OPENNSOCKET BOOTSERVERSOCKET 'ACCEPT]
          do
           (DISCARDXIPS NSOCKET)
           (if LOGFILE
               then (printout LOGFILE "Listening ... " T))
           (RESETLST
               [RESETSAVE NIL '(RELEASE.XIP , (SETQ XIP (GETXIP NSOCKET T]
               (if (SETQ BOOTREQUESTTYPE (FASSOC (With ETHERBOOTPACKET XIP ETHERBOOTREQUESTTYPE)
                                                  BOOTREQUESTTYPES))
                   then (SETO FILENUMBER (with ETHERBOOTPACKET XIP ETHERBOOTFILENUMBER))
                         (if [SETQ ETHERBOOTFILE (for BOOTFILE in ETHERBOOTFILES thereis (with ETHERBOOTFILE BOOTFILE
                                                                                                 (EQP BOOTFILENUMBER
                                                                                                      FILENUMBER]
                             then (with ETHERBOOTFILE ETHERBOOTFILE
                                        (if LOGFILE
                                            then (printout LOGFILE (DATE)
                                                         (with BOOTREQUESTTYPE BOOTREQUESTTYPE REQUESTDESCRIPTION)
                                                         %, "Request for" %, BOOTFILEDESCRIPTION %, "from" %, (with XIP XIP XIPSOURCENSADDRESS)
                                                         T))
                                        (if (SETQ BOOTFILE (FINDFILE BOOTFILENAME NIL BOOTFILEDIRECTORIES))
                                            then (RESETLST
                                                      [RESETSAVE NIL '(CLOSEF? , (SETQ BOOTSTREAM (OPENSTREAM
                                                                                                      BOOTFILE
                                                                                                      'INPUT]
                                                      (if LOGFILE
                                                          then (printout LOGFILE "Opened" %, (FULLNAME BOOTSTREAM)
                                                                       T))
                                                      [NLSETQ (with XIP XIP (with BOOTREQUESTTYPE BOOTREQUESTTYPE
                                                                                   (APPLY* REQUESTFN BOOTSTREAM XIP
                                                                                          LOGFILE])
                                                 (if LOGFILE
                                                     then (printout LOGFILE T "Closed" %, (FULLNAME BOOTSTREAM)
                                                                  T))
```

```
elseif LOGFILE
                                             then (printout LOGFILE "Error, File Not Found: " %, BOOTFILENAME T)))
                           elseif LOGFILE
                             then (printout LOGFILE "Error, Unknown File Number: " %, FILENUMBER T))
                 elseif LOGFILE
                    then (printout LOGFILE "Error, Unknown Request Type:" %, (with ETHERBOOTPACKET XIP
                                                                                         ETHERBOOTREOUESTTYPE)
                                T)))])])
(SENDSIMPLEDATA
  [LAMBDA (BOOTSTREAM PACKET LOGFILE)
                                                                        ; Edited 13-Jul-88 15:45 by cdl
    (LET (SOCKET)
          (DECLARE (SPECVARS SOCKET))
          (if LOGFILE
              then (printout LOGFILE "Packets"))
          (RESETLST
              [RESETSAVE NIL '(CLOSENSOCKET , (SETQ SOCKET (OPENNSOCKET]
              (bind XIP (BYTECOUNT _ (GETFILEINFO BOOTSTREAM 'LENGTH)) for PACKETNUMBER to (ADD1 (GETFILEINFO BOOTSTREAM 'SIZE)) do (if LOGFILE
                                                                       then (printout LOGFILE %, PACKETNUMBER))
                                                                   (SETQ XIP (with NSADDRESS (with XIP PACKET
                                                                                                    XTPSOURCENSADDRESS)
                                                                                    (\FILLINXIP ETHERBOOTPACKETTYPE
                                                                                           SOCKET NSHOSTNUMBER NSSOCKET
                                                                                           NSNET)))
                                                                   (XIPAPPEND.WORD XIP SIMPLEDATA)
                                                                   (with ETHERBOOTPACKET PACKET (XIPAPPEND.WORD XIP
                                                                                                         ETHERBOOTBFNHI)
                                                                        (XIPAPPEND.WORD XIP ETHERBOOTBFNMID)
(XIPAPPEND.WORD XIP ETHERBOOTBFNLOW))
                                                                   (XIPAPPEND.WORD XIP PACKETNUMBER)
                                                                   (to BYTESPERPAGE as old BYTECOUNT by -1
                                                                      until (ZEROP BYTECOUNT)
                                                                      do (XIPAPPEND.BYTE XIP (BIN BOOTSTREAM)))
                                                                   (SENDXIP SOCKET XIP)
                                                                   (BLOCK)))])
(SENDSPPDATA
  [LAMBDA (BOOTSTREAM PACKET LOGFILE)
                                                                        ; Edited 13-Jul-88 16:56 by cdl
     (DECLARE (SPECVARS . T))
          (INPUTSTREAM OUTPUTSTREAM)
          (DECLARE (SPECVARS . T))
          (RESETLST
              [RESETSAVE NIL '(SPP.CLOSE , (SETO INPUTSTREAM (with NSADDRESS) (with XIP PACKET XIPSOURCENSADDRESS)
                                                                        (SPP.OPEN NSHOSTNUMBER NSSOCKET NIL NIL
                                                                               '(EOM.ON.FORCEOUTPUT T]
               (with SPPSTREAM (SETO OUTPUTSTREAM (SPPOUTPUTSTREAM INPUTSTREAM))
                    (with SPPCON SPP.CONNECTION
                                                                        (* Switch to negotiated connection id)
                          (SETO SPPDESTID (with ETHERBOOTPACKET PACKET ETHERBOOTSPPDESTID)))
                                                                        (* Send SYS packet to establish (Dove fix))
                    (\SPP.SENDPKT SPP.CONNECTION (\SPP.SYSPKT SPP.CONNECTION 0)))
               (if LOGFILE
              then (printout LOGFILE "Packets"))
(for PAGES to (SUB1 (GETFILEINFO BOOTSTREAM 'SIZE)) as COUNTER from 1
                 do (COPYBYTES BOOTSTREAM OUTPUTSTREAM BYTESPERPAGE)
                     (FORCEOUTPUT OUTPUTSTREAM)
                     (if LOGFILE
                         then (if (GEO COUNTER 10)
                                   then (SETQ COUNTER 0)
                                        (printout LOGFILE %, PAGES)))
                 finally (COPYBYTES BOOTSTREAM OUTPUTSTREAM)))
          (if LOGFILE
              then (printout LOGFILE T "SPP Stream closed"])
(CACHE.BOOT.FILES
                                                                        (* cdl "24-Sep-86 15:31")
  [LAMBDA (TYPES)
    (bind file tofile for etherbootfile in etherbootfiles
       do (with etherbootfile etherbootfile (if (and (eqmemb (u-case (filenamefield bootfilename 'extension))
                                                                 (OR TYPES BOOTFILECACHETYPES))
                                                         [NOT (INFILEP (SETQ TOFILE (PACKFILENAME 'NAME BOOTFILENAME
                                                                                               'DIRECTORY
                                                                                               BOOTFILECACHEDIRECTORY1
                                                         (SETQ FILE (FINDFILE BOOTFILENAME NIL BOOTFILEDIRECTORIES)))
                                                     then (COPYFILE FILE TOFILE)
                                                          (PRINTOUT T FILE T])
)
(RPAQO ETHERBOOTFILES
        (("Standard DLion Ethernet Initial Microcode" EtherInitial.db 2852126720)
         ("Standard DLion Diagnostic Microcode" MoonBoot.db 2852126728)
("Standard DLion Mesa Microcode" Mesa.db 2852126736)
         ("Standard DLion Germ" DLion.germ 2852126744)
         ("Standard DLion Boot File" SimpleNetExecDLion.boot 2852126752)
```

```
("Standard DLion Diagnostics Boot File" EIDiskDLion.boot 2852127232) ("Standard DLion Installer Boot File" InstallerNSDLion.boot 2852127234)
           ("Alternate DLion Ethernet Initial Microcode" EtherInitialAlt.db 2852126721)
           ("Alternate DLion Mesa Microcode" Mesa.db 2852126738)
           ("Alternate DLion Germ" DLion.germ 2852126746)
           ("Alternate DLion Boot File" InstallerNSDLion.boot 2852126754)
           ("Standard TriDLion Diagnostic Microcode" Moonboot.db 2852126729)
           ("Standard TriDLion Mesa Microcode" TridentRavenMesa.db 2852126737)
          ("Standard TriDLion Germ" TriDlion.germ 2852126745)
           ("Standard TriDLion Boot File" SimpleNetExecTriDlion.boot 2852126753)
           ("Alternate TriDLion Mesa Microcode" TridentRavenMesa.db 2852126739)
           ("Alternate TriDLion Germ" TriDlion.germ 2852126747)
           ("Alternate TriDLion Boot File" InstallerNSTriDlion.boot 2852126753)
           ("Standard Dove Ethernet Initial Microcode" EtherInitialDove.db 2852128768)
           ("Standard Dove Diagnostic Microcode" MoonRise.db 2852128776)
          ("Standard Dove Mesa Microcode" MoonRise.db 2852128776)
("Standard Dove Mesa Microcode" MesaDove.db 2852128784)
("Standard Dove Germ" Dove.germ 2852128792)
("Standard Dove Boot File" SimpleNetExecDove.boot 2852128800)
("Alternate Dove Ethernet Initial Microcode" EtherInitialDove.db 2852128769)
("Alternate Dove Diagnostic Microcode" MoonRise.db 2852128777)
("Alternate Dove Mesa Microcode" MesaDove.db 2852128785)
          ("Alternate Dove Mesa Microcode" Mesabove.da 2852128783)

("Alternate Dove Germ" Dove.germ 2852128793)

("Alternate Dove Boot File" InstallerNSDove.boot 2852128801)

("Dove Simple Net Exec" SimpleNetExecDove.boot 2852128824)

("Dove Configuration Utility" SysConfigOfflineDove.boot 2852128825)

("Dove Installer" InstallerNSDove.boot 2852128826)

("Dove Diagnostics Utility" DiagnoskUtilDove.boot 2852128828)
           ("Dove Rigid Disk Diagnostics Utility" DiagRDDove.boot 2852128829) ("Dove Ethernet Diagnostics Utility" DiagEtherDove.boot 2852128830)
           ("Dove Keyboard & Display Diagnostics Utility" KDMDove.boot 2852128831)))
(RPAQQ BOOTREQUESTTYPES ((1 Simple SENDSIMPLEDATA)
                                     (3 SPP SENDSPPDATA)))
(ADDTOVAR BOOTFILEDIRECTORIES {CORE} {DSK})
(ADDTOVAR BOOTFILECACHETYPES DB GERM)
(RPAQ? BOOTFILECACHEDIRECTORY '{CORE})
(DECLARE%: DONTCOPY
(DECLARE%: EVAL@COMPILE
[ACCESSFNS ETHERBOOTPACKET [ (ETHERBOOTBASE (with XIP DATUM XIPCONTENTS) )
                                      (ETHERBOOTFILENUMBER (with ETHERBOOTPACKET DATUM (PLUS (LSH ETHERBOOTBFNHI 32)
                                                                                                                (LSH ETHERBOOTBFNMID 16)
                                                                                                                ETHERBOOTBFNLOW]
         (BLOCKRECORD ETHERBOOTBASE ((ETHERBOOTREQUESTTYPE WORD)
                                                (ETHERBOOTBFNHI WORD)
                                                (ETHERBOOTBENMID WORD)
                                                (ETHERBOOTBFNLOW WORD)
                                                (ETHERBOOTSPPDESTID WORD)
(RECORD ETHERBOOTFILE (BOOTFILEDESCRIPTION BOOTFILENAME BOOTFILENUMBER))
(RECORD BOOTREQUESTTYPE (REQUESTTYPE REQUESTDESCRIPTION REQUESTFN))
(DECLARE%: EVAL@COMPILE
(RPAQQ ETHERBOOTPACKETTYPE 9)
(RPAQO BOOTSERVERSOCKET 10)
(RPAQO SIMPLEREQUEST 1)
(RPAQQ SIMPLEDATA 2)
(RPAQQ SPPREQUEST 3)
(CONSTANTS (ETHERBOOTPACKETTYPE 9)
         (BOOTSERVERSOCKET 10)
         (SIMPLEREQUEST 1)
         (SIMPLEDATA 2)
         (SPPREQUEST 3))
(DECLARE%: DOEVAL@COMPILE DONTCOPY
(GLOBALVARS ETHERBOOTFILES BOOTREQUESTTYPES BOOTFILEDIRECTORIES BOOTFILECACHETYPES BOOTFILECACHEDIRECTORY)
(PUTPROPS ETHERBOOT COPYRIGHT ("Stanford University" 1985 1986 1987 1988 1991))
```

{MEDLEY}spusers>ETHERBOOT.;1 28-Jun-2024 18:34:03 -- Listed on 30-Jun-2024 13:14:07 --

FUNCTION INDEX CACHE.BOOT.FILES		
BOOTSERVERSOCKET	SIMPLEDATA	SPPREQUEST3
VARIABLE INDEX		
BOOTFILECACHEDIRECTORY3 BOOTFILECACHETYPES3	BOOTFILEDIRECTORIES	ETHERBOOTFILES
RECORD INDEX		
BOOTREQUESTTYPE3	ETHERBOOTFILE3	ETHERBOOTPACKET