```
16-May-90 16:04:03 {DSK}<usr>local>lde>lispcore>sources>DOVEETHERDECLS.;2
 File created:
  changes to:
               (VARS DOVEETHERDECLSCOMS)
previous date:
               17-Dec-86 18:38:00 {DSK}<usr>local>lde>lispcore>sources>DOVEETHERDECLS.;1
 Read Table:
               INTERLISP
    Package:
               INTERLISP
       Format:
                 XCCS
;; Copyright (c) 1986, 1990 by Venue & Xerox Corporation. All rights reserved.
(RPAQQ DOVEETHERDECLSCOMS
        ((FILES MESATYPES)
         (RECORDS Dove.EtherSCB)
         (RECORDS Dove.EtherAddr Dove.EtherConfigure Dove.EtherDumpStatus Dove.EtherFCB Dove.Etheri586Status Dove.EtherIOCB Dove.EtherCommandIOCB Dove.EtherIOIOCB Dove.EtherMulticastAddr Dove.EtherTransmit
                 Dove.RxBufferDesc Dove.RxFrameDesc Dove.TimeDomainRFL)
         (FUNCTIONS \DoveEther.DoOutput)
         (CONSTANTS \DoveEther.MulticastAddr \DoveEther.QueuePtrSize \DoveEther.ClientConditionSize
                 \DoveEther.IOIOCBLength \DoveEther.RequestON \DoveEther.RequestOFF)
         (CONSTANTS * DoveEther.IOCBTypes)
         (CONSTANTS * DoveEther.ActionCommands)))
(FILESLOAD MESATYPES)
(DECLARE%: EVAL@COMPILE
(MESARECORD Dove.EtherSCB ((stat BITS 4)
                               (NIL BITS 1)
                               (cus BITS 3)
                                                                         (* command unit status)
                               (NIL BITS 1)
                               (rus BITS 3)
                                                                         (* receive unit status)
                               (NIL BITS 4)
                               (ack BITS 4)
                                                                         (* acknowledge int)
                               (NIL BITS 1)
                                                                         (* command unit command)
                               (cuc BITS 3)
                               (reset FLAG)
                                                                         (* receive unit command)
                               (ruc BITS 3)
                               (NIL BITS 4)
                               (cblOffset WORD)
                               (rfaOffset WORD)
                               (crcErrs WORD)
                               (alnErrs WORD)
                               (rscErrs WORD)
                               (ovrnErrs WORD)))
(DECLARE%: EVALGEOMPTLE
(BLOCKRECORD Dove.EtherAddr ((id 3 WORD)))
(MESARECORD Dove. EtherConfigure ((NIL BITS 4)
                                      (ByteCount BITS 4)
                                      (NIL BITS 4)
                                      (FifoLimit BITS 4)
                                      (SaveBadFrames FLAG)
                                      (SyncReady FLAG)
                                      (NIL BITS 6)
                                      (ExternalLoopBack FLAG)
                                      (InternalLoopBack FLAG)
                                      (PreambleLength BITS 2)
                                      (AddrTypeLoc BITS 1)
                                      (AddrLength BITS 3)
                                      (ExpBackoffMethod BITS 1)
                                      (AccContRes BITS 3)
                                      (NIL BITS 1)
                                      (LinearPolarity BITS 3)
                                     (InterframeSpacing BYTE)
(SlotTimeLow BYTE)
                                      (RetryNumber BITS 4)
                                      (NIL BITS 1)
                                      (SlotTimeHigh BITS 3)
                                      (Padding FLAG)
                                      (BitStuffing FLAG)
                                      (CRC16 FLAG)
                                      (NoCRCInsertion FLAG)
                                      (TxNoCRS FLAG)
                                      (NRZEncoding FLAG)
                                      (BroadcastDisable FLAG)
                                      (PromiscuousMode FLAG)
```

(InternalCDT FLAG) (CDTFilter BITS 3)

```
(InternalCRS FLAG)
                                     (CRSFilter BITS 3)
                                     (MinFrameLength BYTE)
                                     (NIL BYTE)))
(BLOCKRECORD Dove.EtherDumpStatus ((Buffer WORD)))
(MESARECORD Dove.EtherFCB ((mesaOutQueue Dove.QueueBlock)
                              (mesaInQueue Dove.QueueBlock)
                              (mesaClientStateRequest WORD)
                              (scb Dove.EtherSCB)
                              (etherOutWorkMask WORD)
                              (etherInWorkMask WORD)
                              (etherLockMask WORD)
                              (mesaInClientState WORD)
                              (mesaOutClientState WORD)))
[BLOCKRECORD Dove.Etheri586Status ((completion FLAG)
                                       (busy FLAG)
                                       (okay FLAG))
       (BLOCKRECORD Dove.Etheri586Status
                                                                        (* receiveframe variant)
                                             ((NIL BITS 3)
                                               (unused FLAG)
                                               (crcErr FLAG)
                                               (alnErr FLAG)
                                               (rscErr FLAG)
                                               (ovrnErr FLAG)
                                               (frameTooShort FLAG)
                                               (noEOFFlag FLAG)
                                               (NIL BITS 6)))
                                                                        (* command variant. Mainly for transmit)
       (BLOCKRECORD Dove.Etheri586Status ((NIL BITS 3)
                                               (aborted FLAG)
                                               (NIL FLAG)
                                               (noCRS FLAG)
                                               (lossOfCTS FLAG)
                                               (underrun FLAG)
                                               (deferred FLAG)
                                               (sqeTest FLAG)
                                               (tooManyCollisions FLAG)
                                               (NIL BITS 1)
                                               (collisions BITS 4]
                                                                        (* Next IOCB in IO queue)
[MESARECORD Dove.EtherIOCB ((next Dove.OpieAddress)
                                                                         Gets notifed in Mesaland when IO is complete)
                               (ClientCondition 3 WORD)
                               (i586Status WORD)
                                                                         Status from the Dove ethernet coprocessor)
                               (Status BYTE)
                                                                         IO status?)
                               (IOCBType BITS 4)
                                                                         What type of IO operation is this?)
                                                                        * Used only for Command variant)
                               (Action BITS 4)
       [ACCESSFNS ((nextIOCB (fetch (Dove.OpieAddress LispPointer) of (fetch (Dove.EtherIOCB next) of DATUM)) (replace (Dove.OpieAddress LispPointer) of (fetch (Dove.EtherIOCB next) of DATUM)
                                with NEWVALUE
       (BLOCKRECORD Dove.EtherIOCB ((NIL 6 WORD)
                                        (done FLAG)
                                        (handled FLAG)
                                        (okay FLAG)
                                        (frameTooLong FLAG)
                                        (interruptTimeout FLAG)
                                        (NIL BITS 2)
                                        (isDequeued FLAG]
(MESARECORD Dove.EtherCommandIOCB ((iocbCommon Dove.EtherIOCB)
                                       (select 7 WORD)))
[MESARECORD Dove.EtherIOIOCB ((iocbCommon Dove.EtherIOCB)
                                 (address Dove.OpieAddress)
                                 (length WORD)
                                 (count WORD))
        (ACCESSFNS ((bufferAddress (fetch (Dove.OpieAddress LispPointer) of (fetch (Dove.EtherIOIOCB address)
                                                                                     of DATUM))
                             (replace (Dove.OpieAddress LispPointer) of (fetch (Dove.EtherIOIOCB address) of DATUM)
                                with Newvalue]
(BLOCKRECORD Dove.EtherMulticastAddr ((ByteCount WORD)
                                          (MulticastID1 3 WORD)
                                          (MulticastID2 3 WORD)))
(BLOCKRECORD Dove.EtherTransmit ((BdPtr WORD)
                                     (DestAddr 3 WORD)
                                     (Type WORD)))
(BLOCKRECORD Dove.RxBufferDesc ((EndOfFrame FLAG)
                                    (Filled FLAG)
                                    (ActualCount BITS 14)
                                    (Next WORD)
                                    (BufAddrIOPReal WORD)
                                    (EndOfList FLAG)
                                    (Unused FLAG)
```

```
(Size BITS 14)))
(BLOCKRECORD Dove.RxFrameDesc ((Status WORD)
                                 (EndOfList FLAG)
                                (Suspend FLAG)
                                (NIL BITS 14)
                                (Link WORD)
                                 (BDPtr WORD)
                                (DestAddr 3 WORD)
                                (SourceAddr 3 WORD)
                                (Type WORD)))
(BLOCKRECORD Dove.TimeDomainRFL ((LinkOK FLAG)
                                   (XcvrProblem FLAG)
                                   (Open FLAG)
                                   (Short FLAG)
                                   (NIL FLAG)
                                   (Time BITS 11)))
(DEFMACRO \DoveEther.DoOutput (IOCB)
   '(PROGN
           (\DoveEther.Initiate , IOCB)
           (until (fetch (Dove.EtherIOCB done) of ,IOCB))
           (\DoveEther.DeQueue (fetch (Dove.EtherFCB mesaOutQueue) of \DoveEther.FCBPointer)
                   IOCB)
           (fetch (Dove.EtherIOCB okay) of ,IOCB)))
(DECLARE%: EVAL@COMPILE
(RPAQQ \DoveEther.MulticastAddr 3)
(RPAQQ \DoveEther.QueuePtrSize 6)
(RPAQQ \DoveEther.ClientConditionSize 3)
(RPAQQ \DoveEther.IOIOCBLength 11)
(RPAQQ \DoveEther.RequestON 1)
(RPAQQ \DoveEther.RequestOFF 0)
(CONSTANTS \DoveEther.MulticastAddr \DoveEther.QueuePtrSize \DoveEther.ClientConditionSize
       \DoveEther.IOIOCBLength \DoveEther.RequestON \DoveEther.RequestOFF)
(RPAQQ DoveEther.IOCBTypes ((DoveEther.commandIOCBType 0)
                            (DoveEther.outputIOCBType 1)
                            (DoveEther.resetIOCBType 2)
                            (DoveEther.startRUIOCBType 3)
                            (DoveEther.inputIOCBType 15)))
(DECLARE%: EVAL@COMPILE
(RPAQQ DoveEther.commandIOCBType 0)
(RPAQQ DoveEther.outputlOCBType 1)
(RPAQQ DoveEther.resetlOCBType 2)
(RPAQQ DoveEther.startRUIOCBType 3)
(RPAQQ DoveEther.inputlOCBType 15)
(CONSTANTS (DoveEther.commandIOCBType 0)
       (DoveEther.outputIOCBType 1)
       (DoveEther.resetIOCBType 2)
       (DoveEther.startRUIOCBType
       (DoveEther.inputIOCBType 15))
(RPAQQ DoveEther.ActionCommands ((DoveEther.actionNop 0)
                                  (DoveEther.actionIndividualAddr 1)
                                  (DoveEther.actionConfigure 2)
                                  (DoveEther.actionMulticastAddr 3)
                                  (DoveEther.actionTransmit 4)
                                  (DoveEther.actionTimeDomainRfl 5)
                                  (DoveEther.actionDumpStatus 6)
                                  (DoveEther.actionDiagnose 7)))
(DECLARE%: EVAL@COMPILE
(RPAQQ DoveEther.actionNop 0)
(RPAQQ DoveEther.actionIndividualAddr 1)
(RPAQQ DoveEther.actionConfigure 2)
```

```
{MEDLEY}<sources>DOVEETHERDECLS.;1
```

{MEDLEY}<sources>DOVEETHERDECLS.;1 28-Jun-2024 18:34:03 -- Listed on 30-Jun-2024 13:15:42 --

CONSTANT INDEX

| | | CONSTA | NTINDEX | | |
|---|---------------|---|--|---|---------------------------------------|
| DoveEther.actionConfigure 4 DoveEther.actionDiagnose 4 DoveEther.actionDumpStatus 4 DoveEther.actionIndividualAddr .4 DoveEther.actionMulticastAddr 4 DoveEther.actionNop 4 DoveEther.actionTimeDomainRfl 4 | | DoveEther.actionTransmit 4 DoveEther.commandIOCBType 3 DoveEther.inputIOCBType 3 DoveEther.outputIOCBType 3 DoveEther.resetIOCBType 3 DoveEther.startRUIOCBType 3 DoveEther.startRUIOCBType 3 \(\) DoveEther.ClientConditionSize 3 | | \DoveEther.IOIOCBLength 3 \DoveEther.MulticastAddr 3 \DoveEther.QueuePtrSize 3 \DoveEther.RequestOFF 3 \DoveEther.RequestON 3 | |
| RECORD INDEX | | | | | |
| Dove.EtherAddr1 Dove.Etheri586Status2 Dove.EtherDumpStatus2 Dove.EtherMulticastAddr .2 | | | Dove.EtherTransmit Dove.RxBufferDesc . | | Dove.RxFrameDesc3 Dove.TimeDomainRFL3 |
| VARIABLE INDEX | | | | | |
| DoveEther.ActionCommands 3 | DoveEther.IOC | CBTypes3 | | | |
| MACRO INDEX | | | | | |
| \DoveEther.DoOutput3 | | | | | |