Rotor Optimization

Joe Spencer

November 5, 2022

Methods

This project will determine the optimal combination of design variables. It will use an optimizer to do this. The optimizer will be confined within these limitations:

- It should obviously increase and hopefully maximize the objective function.
- The root bending moment may not be greater than 110% of the original.
- The torque requirement may not be greater than 110% of the original.

The main purpose of the above requirements is to provide boundaries for safe use of the propellor. Other requirements besides these are more flexible. These can also be modified depending on what is most important to the user.

- The power coefficient.
- The total power produced by the rotor.
- The rotor's efficiency.

There are several variable factors that can be adjusted and several performance measure that can still be used to determine a better propellor design. These include:

- The rotor blade length.
- The rotor width.
- The angle of rotation, ϕ
- The blade count.
- The blade shape.
- The twist distribution.
- The rotational velocity.

To these variables, i will add more constraints. The rotational velocity cannot exceed 10,000 rpm, the camber cannot exceed 100 percent of the chord length, the twist angle cannot exceed 45 degrees, and the airfoil's forward velocity cannot exceed 300 meters per second. These requirements keep the rotor within a real range. Items from these lists can be combined to create a useful objective function. I have decided that in my rotor optimization I want to find the rotor that maximizes the total power produced and the efficiency while minimizing the rotational velocity. Optimizing this relation will allow for a rotor that is as powerful as possible while being the smallest possible.

This relation can be modeled using the following equation. The best rotor is found by minimizing f(x). In this analysis, f(x) represents the ratio of the rotor efficiency to its required power, P,

times its rotational velocity, ω , in radians per second. Optimizing this function should produce a rotor that moves slowly and very efficiently while still producing enough power.

$$f(x) = \frac{\eta P}{\omega} = f(x_1, x_2, x_3...)$$
 (1)

The equations to find power and efficiency are already related. They both contain the power coefficient, C_P , which can be found by blade element momentum theory. In addition, the equation for power contains the cube of the rotational velocity in revolutions per second, n_r , which is related to the rotational velocity ω in radians per second by a simple factor.

$$\eta = J \frac{C_T}{C_P}$$

$$P = \rho n_r^3 D^5 C_P$$

$$\omega = n_r \times \frac{2\pi}{60}$$
(2)

Results and Discussion

This investigation found that given certain constraints, different types of rotors are better suited to different environments. The optimized results for each blade count are shown in table 1.

Table 1: Airfoils Modeled by Program

A link to the graph for each airfoil is in its bottom row

A link to the graph for each anjoin is in its obttom row.									
Profile	1310	2310	3310	1412	2412	3412	2209	2209	2209
Re	$1.0 * 10^5$			$1.0 * 10^5$			$1.0*10^{5}$	$2.0*10^{5}$	$3.0*10^{5}$
Link	??			1			??, ??		
α_{0}	-0.28°	-1.00°	-1.92°	-0.64°	-1.37°	-2.10°	-0.84°	-1.62°	-1.96°
$\alpha_{\mathbf{st}}$	10°	11°	12°	11°	12°	13°	11°	11°	12°
Profile	1115	1115	1115	2208	2213	2218	2114	2214	2314
Re	$1.0 * 10^5$ $2.0 * 10^5$ $3.0 * 10^5$			$1.0 * 10^5$			$1.0*10^{5}$		
Link	??			??			??		??, ??
α_{0}	-0.69°	-0.86°	-0.88°	-0.86°	-1.55°	-1.48°	-1.39°	-1.51°	-1.53°
$\alpha_{\mathbf{st}}$	12°	15°	16°	10°	12°	11°	10°	13°	14°




Figure 1: Testing BEM Output Against Experimental Data. Although there are some differences, Blade Element Momentum code provides a good estimate of the constants experienced by a rotor.

1 Glossary

This is a compilation of the previous two glossaries that I have included in my previous Airfoil Analysis and Rotor Analysis reports.

• Advance Ratio, J - A rotor's Advance Ratio is a non-dimensional term. It describes the ratio how quickly a rotor is moving relative to the fluid flowing past it. A high advance ratio signifies that either the fluid is moving quickly or the rotor is moving slowly. It is described by the following equation, in which V_a is the free stream fluid velocity, n is the rotational velocity, and D is the rotor diameter.

$$J = \frac{V_a}{nD} \tag{3}$$

- Angle of Attack, α The angle of attack, α is the angle between the motion of oncoming fluid and the chord line of the airfoil. a positive α corresponds to a airfoil tilted upwards.
- Angle of Rotation, ϕ The Angle of Rotation, sometimes denoted by the Greek letter ϕ , is the angle between the freest stream velocity and the velocity of the airfoil as it rotates. It is used in Blade Element Momentum Theory calculations.
- Axial Induction Factor, a The Axial Induction Factor is the ratio of the reduction in air velocity at an airfoil to its free stream velocity.
- Bending Moment, M The bending moment a rotor experiences can be defined by the below equation, where M is the moment, S is the shear, and
- Blade Element Momentum Theory The theory used to calculate local forces on a propellor or wind turbine blade. It employs both Blade Element Theory and Momentum Theory. These equations are used to recursively find the Axial Induction Factor, a, Tangential Induction Factor, and Angle of Rotation, ϕ

$$\frac{1}{2}W^2NcC_y = 4\pi U_{\infty}(1-a) \times \Omega a'r^2$$

$$\frac{1}{2}\rho W^2NcC_x = 4\pi\rho[(a'\Omega r)^2 + \Omega_{\infty}^2 a(1-a)]r$$

$$\sin\phi = \frac{U_{\infty}}{W}(1-a)$$
(4)

In these equations, a, a', and ϕ are the previously mentioned axial and tangential induction factors and angle of rotation. The airfoil's apparent speed is represented by the letter W, N is the number of propellers, ρ is the fluid density, c is the chord length, C_x and C_y are obtained by the equation below, U_{∞} is the fluid free velocity, Ω is the blade's angular speed, and r is the radius to the tip of the blade.

$$C_x = c_l \cos \phi + c_d \sin \phi$$

$$C_y = c_l \sin \phi + c_d \cos \phi$$
(5)

• Blade Element Theory - Blade Element Theory calculates the forces on a turbine blade by dividing it into finite pieces and summing the forces on all of these pieces. This theory determines the induced velocity and efficiency of a point along a blade using these equations:

$$v_{i} = \sqrt{\frac{T}{A} \frac{1}{2\rho}}$$

$$\eta = \frac{\tan \phi}{\tan (\phi + \gamma)}$$
(6)

In these equations, v_i is the uniform induced velocity across the disk, T the thrust it experiences, A is its area, ρ is the air density, ϕ is the angle to the airfoil's plane of rotation as it moves forward, and γ is the difference between ϕ and β , what the airfoil's actual angle of rotation would be if it were stationary.

- Camber The Camber of an airfoil is represented by the Camber Line, which runs halfway between its top and bottom surfaces. This line represents the curvature of an airfoil. An airfoil with positive camber is slightly convex on top and slightly concave on its bottom.
- Chord, c An airfoil's Chord is the imaginary line running straight from the leading edge of an airfoil to its trailing edge. The chord line is used to find an airfoil's Angle of Attack. The Chord Length Distribution shows the length of a rotor's chord at different angular positions around itself. An airfoil with a constant angle of attack α as it generates lift has an elliptic chord distribution.
- Drag Coefficient (2D), c_D The drag coefficient determines how much drag force opposing motion will be experienced. It comes from a combination of Pressure Drag, also called Form Drag, and Viscous Drag or Skin Friction. The drag force equation describes it in this way:

$$D = \frac{1}{2}\rho u^2 c_D \tag{7}$$

- ullet Freestream Velocity, V_{∞} The velocity of an oncoming air flow directly upstream from an airfoil, before it interacts with it.
- Hub-to-Tip Ratio A rotor's Hub-to-Tip Ratio divides the distance along the blade that is actually exposed wind by the entire length of the blade. This needs to be taken into account when calculating constants like the airfoil's tip speed ratio.
- Lift Coefficient (2D), c_L The lift coefficient is used in the equation below to define how much lift force acts perpendicular to the direction of the oncoming fluid flow.

$$L = \frac{1}{2}\rho u^2 c_L \tag{8}$$

- Lift Curve Slope The lift curve plots the Lift Coefficient against the Angle of Attack for a single airfoil. This shows the effect that changing the angle of attack will have on the airfoil's total lift force, which can be combined with other airfoils in the case of a wing to find the total lift force experienced by the wing.
- ullet Mach Number, M The Mach number is the velocity of an object in proportion to the speed of sound in its medium. When an airfoil is traveling near the speed of sound, its top portions can have fluid velocity above Mach 1. When an airfoil is traveling above Mach 1, the fluid on both sides of it also have velocities above mach 1 while there are points directly before and after it that are below Mach 1.

$$M = \frac{u}{c} \tag{9}$$

• Momentum Theory - Momentum Theory defines the power required to produce sufficient thrust to maintain momentum in a blade by the following equation, where T is thrust, ρ is density, A is disc area, and P is power:

$$P = \sqrt{\frac{T^3}{2\rho A}} \tag{10}$$

• NACA Airfoil (4-Digit) - A airfoil shape developed by the National Advisory Committee for Aeronautics (NACA). The first digit is the maximum Camber in tenths of the Chord. The second digit is the distance in tenths of the maximum Camber from the leading edge, out of ten. the final two digits are the maximum airfoil thickness as a percentage of the Chord. Descriptions of other NACA numbers can also be found on this Wikipedia Article.

• Pitching Moment Coefficient (2D), c_M - The moment coefficient is used to calculate the pitching moment a airfoil will experience from its dynamic pressure q, area S, and chord length c.

$$M = qSec_M \tag{11}$$

• Power Coefficient, C_P - A propellor's Coefficient of Power signifies how efficient a wind turbine is. It is the ratio of the power generated by a wind turbine to the total power of the wind flowing through it. The power generated or absorbed by an airfoil can be described by the following equation, where P is power, C_P is the coefficient of power, ρ is fluid density, n is the velocity in revolutions per second, and D is the propellor diameter. The Power Coefficient and the Torque Coefficient are proportional to each other by a factor of 2π .

$$P = \rho n^3 D^5 C_P$$

$$C_P = 2\pi C_O$$
(12)

- Polar The Airfoil Polar is a plot displaying the Lift and Drag coefficients corresponding with each Angle of Attack for an airfoil. Examining the ratios of lift to drag is instrumental in choosing the optimal Angle of Attack.
- Potential-Flow Code A potential-flow code calculates the lift, drag, and moment forces an airfoil experiences at many different points along it. Potential-flow theory assumes constant, incompressible, inviscid fluid flow. It calculates the coefficient for each of these small points and then combines them to find the coefficients along the entire airfoil.
- Pressure Drag Pressure Drag, also called Form Drag, comes from the the formation of a vacuum behind an object. The object experiences higher pressure ahead of it than behind it, so the pressure difference pushes it backwards.
- Propellor Identification A Propellor is identified by 2 numbers, which represent its diameter and its pitch, both in inches. For example, an APC 10x7 propellor is made by Advanced Precision Composites. It has a 10-inch diameter and a 7-inch pitch per revolution.
- Reynolds Number, Re The Reynolds Number is a unit-less number for fluid flow described by the equation below. It can be used to predict patterns in the fluid's flow, using its flow speed u, characteristic length L, and kinetic viscosity ν , or else by its density ρ , flow speed u, characteristic length L, and fluid density μ .

$$Re = \frac{uL}{\nu}$$

$$= \frac{\rho uL}{\mu}$$
(13)

• Rotor Solidity, σ - Rotor Solidity describes the ratio of a turbine's chord length, c, to its spacing, s. This is found by the following equation, in which n_b is the number of blades, r_h is the hub radius, and r_t is the tip radius.

$$\sigma = \frac{c}{s} = \frac{cn_b}{2\pi\sqrt{\frac{r_h^2 + r_t^2}{2}}} \tag{14}$$

- Stall Stall occurs when an airfoil's Angle of Attack is too great in magnitude, either positive or negative. When the angle of attack is too dramatic, flow separation occurs, reducing rather than augmenting the airfoil's Lift Coefficient as the Angle of Attack increases.
- Tangential Induction Factor, a' The Tangential Induction Factor is the ratio of the increase in air velocity tangential to the airfoil to its free stream velocity.

- Thickness An airfoil's thickness can be measured in two different ways, either along its Chord Line or along its Camber Line. Thickness measured perpendicular to the Camber Line is also called the American Convention, and thickness measured perpendicular to the Chord Line is also called the British Convention.
- Thrust Coefficient, C_T A rotor's Thrust Coefficient determines how much thrust in the forward direction an airfoil experiences. Thrust force is directly opposite drag. Please note the similarities and differences between the thrust equation and the power equation.

$$T = \rho n^2 D^4 C_T \tag{15}$$

• Tip Speed Ratio, λ - A wind turbine's Tip Speed Ratio is the inverse of its Advance Ratio, J. It represents the ratio of the speed of the tip of a turbine blade, or ωR , to the wind speed, v.

$$\lambda = \frac{\omega R}{v} = \frac{\pi}{J} \tag{16}$$

• Torque Coefficient, C_Q - A rotor's Torque Coefficient defines how much torque it will experience. A propellor's torque is given by the following equation, in which Q represents torque, ρ is the fluid density, n is the velocity in revolutions per second, D is the diameter, and C_Q is the coefficient of torque. The Torque Coefficient and the Power Coefficient are proportional to each other by a factor of 2π .

$$Q = \rho n^2 D^5 C_Q$$

$$C_Q = \frac{C_P}{2\pi}$$
(17)

• Efficiency, η - The Efficiency of a rotor can be described by the following equation, in which J is the rotor's Advance Ratio, C_T is its thrust coefficient, and C_P its power coefficient:

$$\eta = J \frac{C_T}{C_P} \tag{18}$$

- Twist Distribution Twist distribution along a wing redirects where air flows past it. This causes changes in both the magnitude and location lift and drag forces it experienced as air flows past it.
- Viscous Drag Viscous Drag, also called Skin Friction, is drag caused by friction with the fluid particles flowing past an airfoil. Along with Pressure Drag, it contributes to an airfoil's total Drag Coefficient airfoil.