## Wireless LAN access using MAC-based authentication with Mikrotik and FreeRADIUS

## **Tugas Akhir**

<u>Disampaikan Sebagai Bagian Dari Persyaratan Kelulusan Diploma 3</u>

<u>Program Studi Teknik Komputer</u>

#### Oleh:

Hepriyanti Fransiska Siahaan 11106008

Sunardo Panjaitan 11106016

Sanhenra Sinaga 11106071



Politeknik Informatika Del 2009

## Lembar Pengesahan Tugas Akhir Politeknik Informatika Del

# Wireless LAN access using MAC-based authentication with Mikrotik and FreeRADIUS

#### Oleh:

Hepriyanti Fransiska Siahaan 11106008

Sunardo Panjaitan 11106016

Sanhenra Sinaga 11106071

Dinyatakan memenuhi syarat dan karenanya disetujui dan disahkan sebagai Laporan Tugas Akhir Diploma 3 Program Studi Teknik Komputer

Pembimbing

Ramot Lubis, S.T., M.Sc. NIDN. 0130047801

#### **Prakata**

Puji dan syukur kepada Tuhan Yang Maha Esa atas rahmat-Nya yang menyertai penulis selama penulisan naskah ini, sehingga setiap tahapan yang direncanakan untuk penyusunan naskah ini dapat dilalui dengan baik.

Naskah ini ditulis sebagai bagian dari syarat kelulusan Diploma 3 Politeknik Informatika Del. Maksud penulisan naskah ini adalah untuk membantu pembaca mengetahui bagaimana cara yang dapat dilakukan untuk mengatur penggunaan *wireless* LAN yang sifatnya terbuka sehingga hanya ditujukan pada pengguna tertentu yang sudah terdaftar.

Penulis mengucapkan terima kasih kepada Bapak Ramot Lubis sebagai pembimbing, yang telah memberikan arahan dan bimbingan dalam menyelesaikan naskah ini. Terimakasih juga penulis sampaikan kepada Ibu Rosni Lumbantoruan sebagai Koordinator Tugas Akhir atas saran dan waktu yang diberikan selama pengerjaan naskah ini. Ucapan terimakasih juga penulis sampaikan kepada semua pihak atas bantuan yang diberikan kepada penulis selama penyelesaian penulisan naskah ini.

Penulis mengharapkan naskah ini dapat memberikan informasi kepada pembaca mengenai penggunaan Mikrotik dan FreeRADIUS pada *wireless* LAN dengan autentikasi *wireless client* berdasarkan MAC *address*.

Penulis menyadari bahwa naskah ini tidak lepas dari kesalahan, oleh karena itu penulis mengharapkan kritik dan saran yang bersifat membangun untuk perbaikan dokumen ini.

Sitoluama, 28 Agustus 2009

Hepriyanti Fransiska Siahaan Sunardo Panjaitan Sanhenra Sinaga **Abstrak** 

Perkembangan teknologi wireless saat ini sudah semakin pesat karena penggunaan

layanan wireless yang cukup mudah. Salah satu contoh penggunaan teknologi wireless

adalah wireless LAN. Penggunaan wireless LAN yang mudah, menjadi daya tarik

tersendiri bagi para pengguna komputer untuk menggunakan teknologi ini untuk

mengakses suatu jaringan komputer atau internet.

Masalah yang sering dihadapi apabila menerapkan wireless LAN adalah tentang

keamanannya. Hal ini disebabkan oleh wireless LAN yang sifatnya terbuka (open access)

sehingga setiap perangkat yang memiliki kartu wireless (wireless card) dapat mendeteksi

suatu jaringan wireless secara langsung. Sebagian besar penyedia wireless yang tidak

menerapkan sistem keamanan yang memadai, memungkinkan pengguna yang tidak

berhak (ilegal) dapat masuk ke jaringan komputer tersebut. Untuk mengatasi masalah

tersebut, maka perlu dilakukan autentikasi sehingga pengguna wireless LAN hanya

ditujukan pada pengguna tertentu yang sudah terdaftar. Hal ini akan membantu penyedia

layanan tersebut untuk mengamankan sistem jaringan wireless yang dibuatnya. Jenis

autentikasi ada beberapa macam, sebagai contoh yaitu autentikasi dengan menggunakan

username dan password seperti pada layanan email. Dalam kajian ini, autentikasi

dilakukan berdasarkan MAC address (ID perangkat), dimana pengguna yang dapat

mengakses wireless LAN adalah pengguna yang MAC address-nya sudah terdaftar pada

penyedia wireless LAN tersebut.

Pada kajian ini, studi tentang Wireless LAN access using MAC-based authentication with

Mikrotik and FreeRADIUS diharapkan dapat membantu untuk implementasi jaringan

wireless (WLAN) dengan menggunakan autentikasi berdasarkan MAC address.

Kata kunci : Wireless LAN, Mikrotik, FreeRADIUS, MAC Address

## Daftar Isi

Prakata		2
Abstrak.		3
Daftar Is	si	4
Daftar T	abel	6
Daftar G	ambar	7
Bab I	Pendahuluan	8
1.1	Latar Belakang	8
1.2	Tujuan	9
1.3	Lingkup	9
1.4	Pendekatan	9
1.5	Singkatan dan Istilah	10
1.6	Sistematika Penyajian	11
Bab II	Tinjauan Pustaka	13
2.1	Wireless LAN	13
2.1.	1 Keuntungan menggunakan WLAN	14
2.1.	2 Kekurangan menggunakan WLAN	15
2.2	MAC Address	15
2.3	Protokol AAA	18
2.3.	1 Authentication	18
2.3.	2 Authorization	19
2.3.	3 Accounting	20
2.4	Access Point	21
2.4.	1 WEP (Wired Equivalent Privacy)	21
2.4.	2 WPA (Wi-Fi Protected Access)	22
2.4.	3 WPA-Personal	22
2.4.	4 WPA2-Personal	23
2.4.	5 WPA2-Personal Mixed	23
2.4.	6 WPA-Enterprise	23
2.4.	7 WPA2-Enterprise	24
2.4.	8 WPA2-Enterprise Mixed	24

2.5	Remote Authentication Dial-In User Service (RADIUS)				
2.6	FreeRADIUS 2				
2.7	2.7 Mikrotik Router OS				
Bab III	Analisis dan Perancangan	31			
3.1	Analisis	31			
3.1.1	Mekanisme Autentikasi Server RADIUS	31			
3.2	Perancangan	34			
3.2.1	Perancangan perangkat yang akan digunakan	34			
3.2.2	Perancangan toplologi jaringan	35			
Bab IV	Pelaksanaan	38			
4.1	Instalasi	38			
4.1.1	Instalasi Mikrotik Router OS	38			
4.1.2	2 Instalasi FreeRADIUS	39			
4.2	Konfigurasi	40			
4.2.1	Konfigurasi Mikrotik Router OS	41			
Bab V	Pengujian	44			
5.1	Pengujian Koneksi Langsung	44			
5.2 Pengujian Koneksi dengan Menggunakan Autentikasi MAC Address					
Bab VI					
6.1	•				
6.2	6.2 Saran				
Daftar Pu	staka dan Rujukanstaka dan Rujukan	48			
Daftar	Pustaka	48			
Rujuka	n	49			
Lampiran		50			
Lampii	an A	50			
Lampii	an B	95			
•	Lampiran C				
Lampiran D					
•	an E				

## **Daftar Tabel**

Tabel 1 . Daftar Singkatan	10
Tabel 2 . Daftar Istilah	10
Tabel 3 . Kode Paket RADIUS dalam desimal	26
Tabel 4 Fitur-fitur Mikrotik	20

## **Daftar Gambar**

Gambar 1 . Ethernet pada OSI Layer	16
Gambar 2 . MAC Address (Physical Address)	17
Gambar 3 . Struktur MAC Address	18
Gambar 4 . Proses Autentikasi	19
Gambar 5 . Arsitektur jaringan AAA	20
Gambar 6 . Struktur format data RADIUS	26
Gambar 7 . Mekanisme Autentikasi RADIUS Server	32
Gambar 8 . Autentikasi dan Autorisasi RADIUS	32
Gambar 9 . Operasi Filtering Mac Address	33
Gambar 10 . Topologi dasar jaringan 1	36
Gambar 11 . Topologi dasar jaringan 2	37
Gambar 12 . Instalasi Mikrotik	39
Gambar 13 . Instalasi FreeRADIUS	40
Gambar 14. List jaringan wireless	44
Gambar 15 . Alamat IP pengguna	45

### Bab I Pendahuluan

Bab Pendahuluan berisi uraian mengenai latar belakang pemilihan topik, tujuan, dan lingkup pelaksanaan kajian, serta pendekatan yang dilakukan dalam menyelesaikan persoalan yang menjadi kajian Tugas Akhir.

#### 1.1 Latar Belakang

Wireless LAN bersifat terbuka (open access) dimana semua pengguna dapat menggunakan layanan wireless tersebut selama berada dalam jangkauan. Karena sifatnya terbuka dimana setiap perangkat yang memiliki kartu wireless (Wireless Card) dapat mendeteksi suatu jaringan wireless secara langsung, maka perlu dilakukan autentikasi sehingga pengguna wireless LAN hanya ditujukan pada pengguna tertentu yang sudah terdaftar. Autentikasi dilakukan berdasarkan MAC address, dimana pengguna yang dapat melakukan akses terhadap jaringan adalah pengguna yang MAC address-nya sudah terdaftar pada penyedia wireless LAN tersebut.

Alasan menggunakan autentikasi berdasarkan MAC *address* adalah ada kondisi tertentu dimana penggunaan MAC *address* lebih efisien dibanding dengan autentikasi lain, seperti penggunaan *username* dan *password*.

Mikrotik dan FreeRADIUS digunakan sebagai aplikasi yang berperan untuk melakukan autentikasi berdasarkan MAC address. Mikrotik digunakan disebabkan memiliki beberapa fitur yang mendukung untuk studi implementasi pada kajian ini seperti proses routing, DHCP, dan sebagainya, kemudian administrasinya yang mudah dan tidak membutuhkan resources yang besar, seperti pada spesifikasi perangkat yang digunakan. Administrasi Mikrotik bisa dilakukan melalui terminal, SSH, Windows application (WinBox) atau web based. FreeRADIUS merupakan aplikasi Open Source Software yang mendukung protokol RADIUS akan digunakan sebagai sistem yang mengatur proses autentikasi. Penggunaan Mikrotik dan FreeRADIUS diharapkan mampu menyediakan akses terhadap suatu wireless client dengan menggunakan autentikasi berdasarkan MAC address.

#### 1.2 Tujuan

Tujuan dari pelaksanaan Tugas Akhir ini adalah untuk melakukan studi implementasi wireless LAN menggunakan autentikasi berdasarkan MAC address dengan mengintegrasikan Mikrotik dan FreeRADIUS. Autentikasi yang dimaksud adalah autentikasi secara terpusat (centralized authentication) sehingga mempermudah proses administrasi, monitoring, dan maintenance terhadap wireless client.

Pelaksanaan Tugas Akhir ini juga diharapkan dapat menyediakan panduan bagi pembaca agar pembaca dapat mengimplementasikan jaringan *wireless* dengan menggunakan autentikasi berdasarkan MAC *address* dengan mengintegrasikan Mikrotik dan FreeRADIUS.

#### 1.3 Lingkup

Lingkup yang dibahas pada kajian ini yaitu studi implementasi autentikasi berdasarkan MAC address pada wireless LAN dengan mengintegrasikan Mikrotik dan FreeRADIUS. Dalam pelaksanaan studi implementasi ini, Mikrotik digunakan sebagai sistem operasi independen berbasiskan Linux khusus untuk PC Router dan FreeRADIUS sebagai suatu aplikasi yang mendukung protokol RADIUS yang digunakan sebagai sistem yang mengatur proses autentikasi pengguna terhadap suatu jaringan wireless. Pada pelaksanaan kajian ini juga akan menyediakan panduan bagi pembaca, sehingga pembaca dapat mengimplementasikan jaringan wireless dengan menggunakan autentikasi berdasarkan MAC address dengan mengintegrasikan Mikrotik dan FreeRADIUS. Panduan yang dimaksud yaitu hasil akhir dari naskah pelaksanaan kajian ini.

#### 1.4 Pendekatan

Pendekatan yang dilakukan dalam menyelesaikan kajian Tugas Akhir ini, antara lain:

- Melakukan studi literatur dengan mempelajari bahan mengenai wireless LAN, MAC address, Mikrotik Router OS, Protokol RADIUS, dan FreeRADIUS.
- 2. Melakukan analisis mengenai cara kerja Mikrotik Router OS dan FreeRADIUS, yang akan digunakan untuk implementasi *wireless* LAN.
- 3. Melakukan implementasi yang berupa instalasi Mikrotik Router OS dan FreeRADIUS serta melakukan konfigurasi. Tahapan berikutnya adalah mengintegrasikan Mikrotik Router OS dan FreeRADIUS sehingga dapat digunakan untuk implementasi *wireless* LAN dengan autentikasi berdasarkan MAC *address*.

- 4. Melakukan dokumentasi mengenai kegiatan yang dilakukan selama implementasi.
- 5. Melakukan pengujian terhadap *wireless* LAN yang telah diimplementasikan.

### 1.5 Singkatan dan Istilah

Daftar singkatan yang digunakan dalam dokumen diuraikan pada Tabel 1.

Tabel 1. Daftar Singkatan

1. BIA 2. CHAP 3. CSMA/CA 4. DEC 5. DOM 6. EAP 7. FCC 8. IEEE 8. Institute of Electrical and Electronics Engineers 9. ISM 10. IV 11. LAN 12. MAC 13. NAS 14. OFDM 15. OUI 16. PAM 15. OUI 16. PAM 16. PAM 17. PAP 18. PSTN 18. IBIA 18. Burned-in Address 18. Challenge handshake Authentication Protocol 19. Challenge handshake Authentication Protocol 19. Challenge handshake Authentication Protocol 10. IV Extensible Authentication Protocol 11. LAN 12. MAC 13. NAS 14. OFDM 15. OUI 16. PAM 16. PASSWORD Authentication Module 17. PAP 18. PSTN 18. Public Switched Telephone Network 19. Challenge handshake Authentication Protocol 10. Variety Sense Multiple access with Collision Avoidance 10. IV Initialization Vector 11. LAN 12. MAC 13. NAS 14. OFDM 15. OUI 16. PAM 16. PAM 17. PAP 18. PSTN 18. PSTN 19. Public Switched Telephone Network		1	abel I . Daltar Singkatan
2.CHAPChallenge handshake Authentication Protocol3.CSMA/CACarrier Sense Multiple access with Collision Avoidance4.DECDigital Equipment Corporation5.DOMDisk On Module6.EAPExtensible Authentication Protocol7.FCCFederal Communication Commission8.IEEEInstitute of Electrical and Electronics Engineers9.ISMIndustrial, Scientific, and Medical10.IVInitialization Vector11.LANLocal Area Network12.MACMedia Access Control13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	No	Singkatan	Defenisi
3. CSMA/CA  Carrier Sense Multiple access with Collision Avoidance  4. DEC  Digital Equipment Corporation  5. DOM  Disk On Module  Extensible Authentication Protocol  FCC  Federal Communication Commission  IEEE  Institute of Electrical and Electronics Engineers  Industrial, Scientific, and Medical  IO. IV  Initialization Vector  II. LAN  Local Area Network  12. MAC  Media Access Control  NAS  Network Access Server  14. OFDM  Orthogonal Frequency Division Multiplexing  15. OUI  Organizational Unique Identifier  16. PAM  Password Authentication Module  17. PAP  Password Authentication Protocol  18. PSTN  Public Switched Telephone Network	1.	BIA	Burned-in Address
Avoidance  4. DEC Digital Equipment Corporation  5. DOM Disk On Module  6. EAP Extensible Authentication Protocol  7. FCC Federal Communication Commission  8. IEEE Institute of Electrical and Electronics Engineers  9. ISM Industrial, Scientific, and Medical  10. IV Initialization Vector  11. LAN Local Area Network  12. MAC Media Access Control  13. NAS Network Access Server  14. OFDM Orthogonal Frequency Division Multiplexing  15. OUI Organizational Unique Identifier  16. PAM Password Authentication Module  17. PAP Password Authentication Protocol  18. PSTN Public Switched Telephone Network	2.	СНАР	Challenge handshake Authentication Protocol
4.DECDigital Equipment Corporation5.DOMDisk On Module6.EAPExtensible Authentication Protocol7.FCCFederal Communication Commission8.IEEEInstitute of Electrical and Electronics Engineers9.ISMIndustrial, Scientific, and Medical10.IVInitialization Vector11.LANLocal Area Network12.MACMedia Access Control13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	3.	CSMA/CA	Carrier Sense Multiple access with Collision
5. DOM  Disk On Module  Extensible Authentication Protocol  FeCC  Federal Communication Commission  Institute of Electrical and Electronics Engineers  Institute of Electrical and Medical  Industrial, Scientific, and Medical  Initialization Vector  I. LAN  Local Area Network  Local Area Network  Media Access Control  Network Access Server  Access Server  I. OFDM  Orthogonal Frequency Division Multiplexing  Organizational Unique Identifier  OPAM  Password Authentication Module  Password Authentication Protocol  Public Switched Telephone Network			Avoidance
6. EAP  Extensible Authentication Protocol  7. FCC  Federal Communication Commission  8. IEEE  Institute of Electrical and Electronics Engineers  9. ISM  Industrial, Scientific, and Medical  10. IV  Initialization Vector  11. LAN  Local Area Network  12. MAC  Media Access Control  13. NAS  Network Access Server  14. OFDM  Orthogonal Frequency Division Multiplexing  15. OUI  Organizational Unique Identifier  16. PAM  Password Authentication Module  17. PAP  Password Authentication Protocol  18. PSTN  Public Switched Telephone Network	4.	DEC	Digital Equipment Corporation
7.FCCFederal Communication Commission8.IEEEInstitute of Electrical and Electronics Engineers9.ISMIndustrial, Scientific, and Medical10.IVInitialization Vector11.LANLocal Area Network12.MACMedia Access Control13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	5.	DOM	Disk On Module
8. IEEE Institute of Electrical and Electronics Engineers 9. ISM Industrial, Scientific, and Medical 10. IV Initialization Vector 11. LAN Local Area Network 12. MAC Media Access Control 13. NAS Network Access Server 14. OFDM Orthogonal Frequency Division Multiplexing 15. OUI Organizational Unique Identifier 16. PAM Password Authentication Module 17. PAP Password Authentication Protocol 18. PSTN Public Switched Telephone Network	6.	EAP	Extensible Authentication Protocol
9. ISM Industrial, Scientific, and Medical 10. IV Initialization Vector 11. LAN Local Area Network 12. MAC Media Access Control 13. NAS Network Access Server 14. OFDM Orthogonal Frequency Division Multiplexing 15. OUI Organizational Unique Identifier 16. PAM Password Authentication Module 17. PAP Password Authentication Protocol 18. PSTN Public Switched Telephone Network	7.	FCC	Federal Communication Commission
10.IVInitialization Vector11.LANLocal Area Network12.MACMedia Access Control13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	8.	IEEE	Institute of Electrical and Electronics Engineers
11.LANLocal Area Network12.MACMedia Access Control13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	9.	ISM	Industrial, Scientific, and Medical
12.MACMedia Access Control13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	10.	IV	Initialization Vector
13.NASNetwork Access Server14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	11.	LAN	Local Area Network
14.OFDMOrthogonal Frequency Division Multiplexing15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	12.	MAC	Media Access Control
15.OUIOrganizational Unique Identifier16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	13.	NAS	Network Access Server
16.PAMPassword Authentication Module17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	14.	OFDM	Orthogonal Frequency Division Multiplexing
17.PAPPassword Authentication Protocol18.PSTNPublic Switched Telephone Network	15.	OUI	Organizational Unique Identifier
18. PSTN Public Switched Telephone Network	16.	PAM	Password Authentication Module
	17.	PAP	Password Authentication Protocol
10 DADILIS Domoto Authorization Dial La Uran Compies	18.	PSTN	Public Switched Telephone Network
19. KADIUS Remote Authentication Diat-in User Service	19.	RADIUS	Remote Authentication Dial-In User Service
20. RF Radio Frequency	20.	RF	Radio Frequency
21. TKIP Temporal Key Integrity Protocol	21.	TKIP	Temporal Key Integrity Protocol
22. WEP Wired Equivalent Privacy	22.	WEP	Wired Equivalent Privacy
23. WPA Wi-Fi Protected Access	23.	WPA	Wi-Fi Protected Access
24. CA Certificate Authority	24.	CA	Certificate Authority
25. DHCP Dynamic Host Control Protocol	25.	DHCP	Dynamic Host Control Protocol

Daftar istilah yang digunakan dalam dokumen diuraikan pada Tabel 2.

Tabel 2. Daftar Istilah

No	Istilah	Defenisi
1.	Mikrotik	Sistem operasi independen (tidak terbatas pada vendor hardware
		spesifik) berbasiskan Linux khusus untuk komputer yang
		difungsikan sebagai Router.
2.	FreeRADIUS	Aplikasi unix yang memungkinkan seseorang untuk mengatur
		protokol RADIUS, yang dapat digunakan untuk autentikasi,
		autorisasi dan akuntansi berbagai jenis akses jaringan.
3.	MAC address	Sebuah alamat jaringan yang diimplementasikan pada lapisan

No	Istilah	Defenisi
		data-link dalam tujuh lapisan model OSI, yang merepresentasikan
		sebuah <i>node</i> tertentu dalam jaringan.
4.	RADIUS	Suatu protokol yang dikembangkan untuk menyediakan akses
		terpusat untuk melakukan authentication, authorization, dan
		accounting.
5.	PAP	Sebuah protokol yang dalam proses autentikasinya <i>password</i> tidak
		dienkripsi.
6.	CHAP	Sebuah protokol yang dalam proses autentikasinya password
		terlebih dahulu dienkripsi.
7.	WPA	Protokol yang dikembangkan oleh Wi-Fi Alliance sebagai respon
		dari banyaknya kelemahan yang ditemukan pada sistem
		sebelumnya, Wired Equivalent Privacy(WEP).
8.	WEP	Suatu metoda pengamanan jaringan nirkabel, disebut juga dengan
		Shared Key Authentication.
9.	TKIP	Sebuah protokol hasil pengembangan dari WPA.
10.	AES	Sebuah algoritma simetrik blok cipher yang ditujukan untuk
		menggantikan algoritma DES yang menggunakan 128 bit data dan
		menggunakan key 128/192/256 bit
11.	NAS	Sebuah server yang berguna untuk meneruskan informasi
		pengguna ke RADIUS server, kemudian mengembalikan respon
		ke pengguna.
12.	LAN	Jaringan komputer yang jaringannya hanya mencakup wilayah
		kecil; seperti jaringan komputer kampus, gedung, kantor, dalam
		rumah, sekolah atau yang lebih kecil.
13.	DHCP	Pemberian IP <i>address</i> secara dinamis.

#### 1.6 Sistematika Penyajian

Setelah uraian pada bab Pendahuluan yang membahas latar belakang, tujuan, lingkup, pendekatan dan sistematika penyajian, materi pembahasan selanjutnya mengikuti sistematika sebagai berikut.

Bab Tinjauan Pustaka menjelaskan landasan teori mengenai *wireless* LAN, MAC *address*, Protokol AAA, RADIUS, FreeRADIUS, dan Mikrotik Router OS.

Pada bab Analisis dan Desain menjelaskan analisis yang dilakukan selama pelaksanaan kajian ini yang mencakup analisis tentang cara kerja FreeRADIUS serta rancangan topologi jaringan yang akan diimplementasikan pada *wireless* LAN.

Bab Pelaksanaan mendeskripsikan proses yang dilakukan dalam melaksanakan kajian yaitu berupa instalasi dan konfigurasi Mikrotik Router OS dan FreeRADIUS, serta integrasi antara Mikrotik dan FreeRADIUS.

Bab Pengujian berisi penjelasan tentang hasil yang telah dicapai selama pelaksanaan kajian serta pengujian terhadap hasil kajian. Pada bab ini juga akan dijelaskan masalahmasalah yang muncul selama pelaksanaan kajian.

Bab Kesimpulan dan Saran memberikan uraian kesimpulan yang diperoleh dari kajian, dan saran-saran yang dianjurkan untuk pengembangan implementasi selanjutnya.

## Bab II Tinjauan Pustaka

Bab Tinjauan Pustaka mencakup teori mengenai *wireless* LAN, MAC *address*, Protokol AAA, RADIUS, FreeRADIUS dan Mikrotik Router OS.

#### 2.1 Wireless LAN

Local Area Network biasa disingkat LAN adalah jaringan komputer yang jaringannya hanya mencakup wilayah kecil, seperti jaringan komputer kampus, gedung, kantor, dalam rumah, sekolah atau yang lebih kecil [LAN]. Local Area Network menghubungkan dua atau lebih workstation atau perangkat lain pada sebuah bangunan atau daerah yang secara geografis terbatas [CC1]. Dalam menghubungkan workstation atau perangkat tersebut, dibutuhkan media transmisi. Berdasarkan bentuknya, media transmisi memiliki 2 bentuk yaitu:

#### 1. Guided media

Menyediakan jalur transmisi sinyal yang terbatas secara fisik, mencakup *twisted-pair Cable, coaxial cable*, dan kabel *fiber optic. Twisted-pair* dan *coaxial cable* menggunakan konduktor logam yang menerima dan mentransmisikan sinyal dalam bentuk aliran listrik. *Optical fiber*/serat optik menerima dan mentransmisikan sinyal data dalam bentuk cahaya.

#### 2. Unguided media

Unguided media atau komunikasi tanpa kabel (nirkabel), mentransmisikan gelombang elektromagnetik tanpa menggunakan konduktor secara fisik. Sinyal dikirimkan secara broadcast melalui udara (air, dalam beberapa kasus). Media transmisi ini dapat menggunakan wireless (microwave, bluetooth, infrared, radio, dll) atau menggunakan satelit.

Media transmisi *wireless* ada beberapa jenis, yaitu:

1. *Microwave* merupakan *high-end* dari RF (*Radio Frequency*), sekitar 1 – 30 GHz. Transmisi dengan *microwave* memberikan 4 hal yang perlu diperhatikan:

- Alokasi frekuensi
- Interference
- Line-of sight
- Jarak tanpa repeater antara 10 − 100 km

- 2. Radio yaitu media transmisi yang menggunakan gelombang elektromagnetik untuk transmisi data. Gelombang radio ini berada pada jangkauan frekuensi 10 hertz (Hz) sampai beberapa gigahertz (GHz).
- 3. *Infrared* yaitu media transmisi yang menggunakan *transmitter/receiver* yang memodulasikan *no coherent infrared light. Infrared* memiliki data *rate* yang tinggi dan konsumsi dayanya lebih kecil [IRD].
- 4. *Bluetooth* yaitu teknologi *wireless* yang mampu menyediakan layanan komunikasi data dan suara dengan jarak jangkauan yang terbatas. *Bluetooth* beroperasi pada pita frekuensi 2,4 GHz dengan jarak jangkauan layanan yang terbatas (sekitar 10 meter) [TRI].

Penggunaan *wireless* saat ini sangat berperan penting dalam memenuhi kebutuhan komunikasi. Jaringan komputer dengan menggunakan *wireless* (nirkabel) lebih mudah penggunaannya dibandingkan dengan menggunakan kabel, karena dapat diakses dari mana saja selama berada dalam jangkauan *wireless* tersebut. Teknologi *wireless* banyak diterapkan dalam jaringan komputer atau lebih dikenal dangan *wireless* LAN.

Wireless LAN menggunakan gelombang radio sebagai media transmisinya. Wireless LAN didefinisikan oleh IEEE (Institute of Electrical and Electronics Engineers) pada IEEE 802.11. Teknologi WLAN mampu memberikan kecepatan akses yang tinggi hingga 11 Mbps (IEEE 802.11 b) dan 54 Mbps (IEEE 802.11 g) dalam jarak hingga 100 meter.

#### 2.1.1 Keuntungan menggunakan WLAN

Perkembangan WLAN yang sangat pesat tidak terlepaskan dari kelebihannya dibanding LAN. WLAN memiliki beberapa keuntungan, diantaranya[WL1]:

1. *Mobility* 

Mampu menghemat waktu ketika memerlukan fleksibilitas perpindahan tanpa harus memutuskan koneksi yang sudah ada sebelumnnya.

2. *Productivity* 

Jika terjadi perpindahan (*mobile*), dengan WLAN pengguna bisa memanfaatkan waktu yang dibutuhkan selama perpindahan tersebut sehingga pengguna lebih produktif.

3. Expandability

Jika terjadi pertumbuhann jaringan, WLAN tidak membutuhkan banyak perubahan. Jika dibandingkan dengan LAN, maka dibutuhkan penambahan kabel dan *port* bahkan mungkin harus mengganti perangkat seperti *switch* dan *hub*.

#### 4. *Cost*

WLAN mengurangi *cost* (biaya) karena tidak membutuhkan peralatan lain selain *wireless card*, selain itu akan mengurangi biaya pemasangan/penambahan jaringan.

#### 5. Deployment

Deployment pada WLAN lebih mudah dibanding dengan LAN. Dengan menggunakan kabel pada suatu jaringan, akan menambahan biaya dan kerumitan untuk memasang kabel ke berbagai lokasi (yang mungkin sangat sulit untuk mencapai lokasi dalam gedung).

#### 2.1.2 Kekurangan menggunakan WLAN

Selain memiliki kelebihan, WLAN juga mempunyai kekurangan, yaitu [WL1]:

#### 1. Security

Karena WLAN dapat diakses dari mana saja selama berada dalam jangkauan WLAN tersebut. Paket yang dikirimkan oleh seseorang bisa saja diterima oleh orang lain. Hal ini memungkinkan seseorang bisa melakukan "snoping" dengan tujuan yang tidak baik.

#### 2. Reliability (Keandalan)

Kualitas transmisi dan kecepatan WLAN sangat rentan dengan gangguan seperti atenuasi (redaman) dan *noise*. Semakin jauh jaraknya, maka data yang akan sampai semakin sedikit.

#### 3. Speed

Kecepatan WLAN dalam hal transmisi data jauh dibawah LAN. Kecepatan WLAN (1-100 Mbps) cukup lambat dibanding kecepatan LAN (100 Mbps hingga beberapa Gbps). Selain itu semakin banyak *host* yang menggunakan layanan WLAN, maka kecepatan transmisinya akan semakin lambat.

#### 2.2 MAC Address


MAC *address* (*Media Access Control Address*) adalah sebuah alamat jaringan yang diimplementasikan pada lapisan *data-link* dalam tujuh lapisan model OSI, yang merepresentasikan sebuah *node* tertentu dalam jaringan. Dalam sebuah jaringan berbasis *Ethernet*, MAC *address* merupakan alamat yang unik yang memiliki panjang 48-bit (6

byte) yang mengidentifikasikan sebuah komputer, *interface* dalam sebuah *router*, atau *node* lainnya dalam jaringan. MAC *address* juga sering disebut sebagai *Ethernet address*, *physical address*, atau *hardware address* [MAC].

Ethernet merupakan jenis skenario perkabelan dan pemrosesan sinyal untuk data jaringan komputer yang dikembangkan oleh Robert Metcalfe dan David Boggs di Xerox Palo Alto Research Center (PARC) pada tahun 70-an. Standar pertama Ethernet dipublikasikan pada tahun 1980 oleh Digital Equipment Corporation (DEC), Xerox, dan Intel. Dan pada tahun 1985 distandarisasi oleh Institute of Electrical and Electronics Engineers (IEEE) dengan nomor 802 [CC2]. Ada beberapa tipe ethernet, yaitu:

- 10 Mbps *10Base*-T *Ethernet*
- 100 Mbps *Fast* Ethernet
- 1000 Mbps Gigabit *Ethernet*
- 10 Gbps 10 Gigabit *Ethernet*

Perbedaan tersebut yaitu *data rate* tipe *Ethernet* tersebut terjadi di *layer Physical* sehingga sering disebut *Ethernet* PHY). *Ethernet* bekerja pada Data *Link* dan *Physical* OSI *layer*. Data *Link layer* dibagi menjadi dua sublayer yaitu *Logical Link Layer* (LLC) yang didefinisikan pada IEEE 802.2 dan *Media Access Control* (MAC) yang didefinisikan pada IEEE 802.3.




Gambar 1. Ethernet pada OSI Layer

LLC diimpelementasikan pada *software* (*driver*) dan independen terhadap *physical equipment*. MAC diimplementasikan *hardware*, yaitu *Network Interface Card* (NIC) atau lebih dikenal dengan kartu jaringan [CC3].


Masalah utama yang muncul dalam transmisi adalah bagaimana caranya mengidentifikasi setiap *device*. Untuk mengatasi masalah tersebut, sebuah *idenfier* yang unik yang disebut alamat MAC (MAC *address*) dibuat untuk membantu dalam menentukan alamat *source* (pengirim) dan *destination* (penerima) dalam sebuah jaringan. MAC *address* ditambahkan sebagai bagian dari PDU (*Protocol Data Unit*) *Data link layer*.

Untuk melihat nilai MAC *address* bisa dilakukan dengan cara mengetikkan ipconfig /all pada sistem operasi Windows atau *ifconfig* pada sistem operasi Linux.



Gambar 2 . MAC Address (Physical Address)

Nilai MAC address berdasarkan aturan IEEE untuk memastikan alamat global yang unik untuk setiap perangkat Ethernet. MAC address terdiri dari 48 bit dan dinyatakan dalam bentuk 12 digit hexadesimal, enam digit pertama menyatakan vendor pembuat perangkat jaringan tersebut atau menyatakan OUI (Organizational Unique Identifier) dan enam digit lainnya menyatakan serial number interface. Alamat MAC yang sering disebut sebagai burned-in address (BIA) karena di-burned ke dalam ROM (Read-Only Memory) pada NIC. Ini berarti alamat di-encode ke dalam chip ROM secara permanen [CC4]. Untuk lebih jelasnya, perhatikan gambar 3.



Gambar 3. Struktur MAC Address

Ketika komputer hidup (*starts up*), maka NIC menyalin alamat ke dalam RAM. Jika *ethernet* sudah ditentukan menggunakan layanan DHCP sebelumnya (bukan *static* IP *address*), maka MAC sangat berpengaruh dalam proses permintaan dan pemberian IP *address*. *Host* yang bersangkutan mengirimkan *message* dengan menggunakan MAC *address* dan pengirimannya secara *broadcast*. Ketika memeriksa *frame*, adalah alamat di RAM yang digunakan membandingkan alamat *source* dengan alamat *destination*. Alamat MAC yang digunakan oleh NIC untuk menentukan apakah pesan harus disampaikan ke lapisan atas untuk diproses.

#### 2.3 Protokol AAA


Dalam keamanan sistem (computer security), AAA adalah singkatan dari "authentication, authorization and accounting". Protokol AAA kadang-kadang digabungkan dengan auditing (memeriksa) sehingga sering disebut sebagai AAAA. Protokol AAA mengatur mekanisme bagaimana tata cara berkomunikasi, baik antara client ke domain-domain jaringan maupun antar client dengan domain yang berbeda dengan tetap menjaga keamanan pertukaran data.

#### 2.3.1 Authentication

Autentikasi (*Authentication*) yaitu proses pengesahan identitas pengguna (*end user*) untuk mengakses suatu jaringan. Autentikasi menyediakan informasi bagi pengirim dan penerima untuk memvalidasi yang satu dengan yang lainnya sesuai identitasnya. Proses ini diawali dengan pengiriman kode unik (misalnya, *username*, *password*, pin) oleh pengguna kepada *server*. Di sisi *server*, sistem akan menerima kode unik tersebut, selanjutnya membandingkan dengan kode unik yang disimpan dalam *database server*.

Jika hasilnya sama, maka *server* akan mengirimkan hak akses kepada pengguna. Namun jika hasilnya tidak sama, maka *server* akan mengirimkan pesan kegagalan dan menolak hak akses pengguna. Proses ini merupakan salah satu aspek yang sangat penting dalam sistem keamanan jaringan.

Pengertian sederhana dari autentikasi adalah pengiriman *password* antara entitas yang ingin melakukan autentikasi tersebut.



Gambar 4. Proses Autentikasi

Pada gambar 4 menunjukkan salah satu proses autentikasi. Pengguna melakukan autentikasi dengan mengirimkan *username* dan *password* ke *server*. Kemudian *server* akan membandingkan *username* dan *password* tersebut ke *database*. Jika hasilnya sama, maka *server* akan mengambalikan informasi autentikasi kepada pengguna, sehingga pengguna dapat mengakses *server*.


Alasan menggunakan autentikasi yaitu untuk meningkatkan keamanan, memungkinkan *administrator* untuk melacak masalah khusus untuk pengguna, dan memungkinkan pengaturan hak akses pengguna terhadap *server*.

#### 2.3.2 Authorization

Autorisasi (*Authorization*) adalah hak dan izin yang diberikan kepada pengguna atau aplikasi yang memungkinkan untuk mengakses suatu jaringan atau suatu komputer (*computer resource*). Autorisasi merupakan proses pengecekan hak akses pengguna, mana saja hak-hak akses yang diperbolehkan dan mana saja yang tidak. Autorisasi merujuk kepada pemberian hak akses tertentu kepada suatu entitas atau pengguna, berdasarkan proses autentikasi, hak akses apa saja yang dapat mereka minta (*request*) pada sistem yang sedang berjalan. Autorisasi biasanya memiliki batasan-batasan, misalnya batasan waktu, lokasi, atau larangan melakukan proses *login* oleh pengguna.

#### 2.3.3 Accounting

Pencatatan (*Accounting*) merupakan proses pengumpulan data atau informasi mengenai berapa lama pengguna melakukan koneksi terhadap suatu sistem. *Accounting* merujuk kepada pelacakan dari konsumsi sumber daya jaringan oleh pengguna. Informasi ini dapat digunakan untuk pengelolaan (*management*), perencanaan (*planning*), penagihan (*billing*), atau tujuan lainnya. Informasi yang dikumpulkan dalam *accounting* adalah identitas pengguna, sifat dari layanan yang diberikan, saat memulai layanan, dan ketika berakhir.



Gambar 5. Arsitektur jaringan AAA

Gambar 5 menunjukkan komponen-komponen dalam jaringan AAA. Sistem terdiri dari Server AAA, jaringan perantara, Network Access Server (NAS) dan pelanggan (end user). Server AAA dapat dibangun dari beberapa server, yang berisi data pelanggan. Jaringan perantara dapat berbentuk jaringan internet, jaringan PSTN (Public Switched Telephone Network), dan sebagainya. Dalam jaringan ini juga dapat berisikan server AAA lain, yang tersebar sehingga membentuk server perantara. Server perantara ini berperan membantu menyebarkan informasi AAA ke pelanggan yang lokasinya jauh dari server. NAS berperan sebagai pintu gerbang (gateway) pelanggan untuk berhubungan dengan jaringan. Perangkat ini dapat berbentuk router, terminal server atau sebuah host, yang dilengkapi dengan aplikasi AAA client. Pelanggan yaitu pengguna sistem itu sendiri, misalnya, perangkat komputer.

Mekanisme kerja jaringan AAA adalah sebagai berikut :

- Pelanggan melakukan koneksi ke peralatan NAS dan sebagai langkah awal koneksi ke jaringan.
- NAS sebagai *client* AAA kemudian melakukan pengumpulan informasi pelanggan dan melanjutkan data pelanggan ke *server* AAA.
- Server AAA menerima dan memproses data pelanggan, kemudian memberikan balasan ke NAS berupa pesan penerimaan atau penolakan pendaftaran dari pelanggan. Pesan ini mungkin juga disertai dengan data lain jika diperlukan.
- NAS sebagai *client* AAA kemudian menyampaikan pesan *server* AAA itu kepada pelanggan, bahwa pendaftaran ditolak atau diterima beserta layananlayanan yang diperkenankan untuk diakses.

#### 2.4 Access Point

Access Point merupakan perangkat keras yang digunakan dalam jaringan tanpa kabel (wireless) atau jaringan Wi-Fi (Wireless-Fidelity). Access Point berfungsi untuk menghubungkan antara jaringan wireless dengan dengan jaringan lainnya atau internet. Access point juga dapat berfungsi sebagai filtering, firewall, router, yaitu melakukan identifikasi terhadap jaringan dengan memberikan WEP (Wireless Equivalent Privacy) atau WPA wireless. Perangkat access point yang lama bekerja pada standar 802.11b dan kapasitas data yang dapat dikirimkan kecil. Untuk mengirimkan data dalam kapasitas yang besar, hendaknya menggunakan perangkat dengan standar 802.11g dan standar ini kompatibel dengan standar di bawahnya, artinya masih dapat menggunakan perangkat dengan standar 802.11b. Sebuah perangkat access point biasanya mempunyai port ethernet yang biasanya dihubungkan dengan kabel UTP.

Access Point memiliki beberapa security mode yang dapat digunakan. Jenis-jenis security wireless tersebuat yaitu WEP, WPA, WPA-Personal, WPA2-Personal, WPA2-Personal Mixed, WPA-Enterprise, WPA2-Enterprise, dan WPA2-Enterprise Mixed.

#### 2.4.1 WEP (Wired Equivalent Privacy)

(WEP) Wired Equivalent Privacy adalah suatu metoda pengamanan jaringan nirkabel, disebut juga dengan Shared Key Authentication. Shared Key Authentication adalah metoda autentikasi yang membutuhkan penggunaan WEP. Enkripsi WEP menggunakan kunci yang dimasukkan (oleh administrator) ke client maupun access point. Kunci ini

harus sesuai dari yang diberikan akses *point* ke pengguna, dengan yang dimasukkan pengguna untuk authentikasi menuju *access point*.

Proses Shared Key Authentication yaitu sebagai berikut:

- 1. Client meminta asosiasi ke access point, langkah ini sama seperti Open System Authentication.
- 2. Access point mengirimkan text challenge ke client secara transparan.
- 3. *Client* akan memberikan respon dengan mengenkripsi *text challenge* dengan menggunakan kunci WEP dan mengirimkan kembali ke *access point*.
- 4. Access point memberi respon atas tanggapan client, akses point akan melakukan decrypt terhadap respon enkripsi dari client untuk melakukan verifikasi bahwa text challenge dienkripsi dengan menggunakan WEP key yang sesuai. Pada proses ini, access point akan menentukan apakah client sudah memberikan kunci WEP yang sesuai. Apabila kunci WEP yang diberikan oleh client sudah benar, maka access point akan merespon positif dan langsung melakukan autentikasi terhadap client. Namun bila kunci WEP yang dimasukkan client salah, maka access point akan merespon negatif dan client tidak akan diberi autentikasi.

Selain itu, algoritma *Wired Equivalent Privacy* (WEP) digunakan untuk menjaga privasi komunikasi nirkabel (*wireless*) dari *eavesdropping* (pihak penyadap). Kegunaan kedua dari algoritma WEP adalah mengamankan akses tidak sah (*unauthorized access*) ke sebuah jaringan nirkabel (*wireless network*).

#### 2.4.2 WPA (Wi-Fi Protected Access)

Wi-Fi Protected Access (WPA) adalah protocol yang dikembangkan oleh Wi-Fi Alliance sebagai respon dari banyaknya kelemahan yang ditemukan pada sistem sebelumnya, Wired Equivalent Privacy (WEP).

Protokol baru ini mengimplementasikan banyak hal baru dari standar IEEE 802.11i dan telah disiapkan untuk menjadi pengganti WEP ketika 802.11i masih dalam tahap persiapan. Hal paling signifikan dari pengembangan WPA adalah penambahan *Temporal Key Integrity Protocol (TKIP)*.

#### 2.4.3 WPA-Personal

WPA-Personal adalah salah satu jenis wireless security yang menggunakan algoritma TKIP dan AES pada enkripsi datanya. User dapat memilih salah satu algoritma yang

diinginkan dari kedua jenis algoritma tersebut. Secara *default* WPA-*Personal* ini menggunakan algoritma TKIP. WPA-*Personal* ini menggunakan 8 sampai 63 karakter untuk *shared key*-nya. *Mode security wireless* ini juga membutuhkan waktu *timeout* untuk setiap pergantian *key* pada proses enkripsi yang dilakukan. Secara *default* waktu yang dibutuhkan untuk pergantian *key* enkripsi adalah 3600 detik.

#### 2.4.4 WPA2-Personal

WPA2-Personal adalah salah satu jenis wireless security yang menggunakan algoritma AES untuk enkripsi datanya. Selain itu, WPA2-Personal menggunakan Pre-shared Key sepanjang 8 sampai 63 karakter. Mode security wireless ini juga membutuhkan waktu timeout untuk setiap pergantian key pada proses enkripsi yang dilakukan. Secara default waktu yang dibutuhkan untuk pergantian key enkripsi adalah 3600 detik.

#### 2.4.5 WPA2-Personal Mixed

WPA-Personal merupakan gabungan dari WPA-Personal dan WPA2-Personal. Untuk mode gabungan secara otomatis memilih TKIP dan AES sebagai algoritma enkripsi data. Selain itu, WPA2-Personal menggunakan Pre-shared Key sepanjang 8 sampai 63 karakter. Mode keamanan wireless ini juga membutuhkan waktu timeout untuk setiap pergantian key pada proses enkripsi yang dilakukan. Secara default waktu yang dibutuhkan untuk pergantian key enkripsi adalah 3600 detik.

#### 2.4.6 WPA-Enterprise

Fitur wireless security yang ini digunakan pada saat berkordinasi dengan server RADIUS untuk autentikasi client. WPA ini hanya dapat digunakan ketika server RADIUS terhubung dengan access point. WPA ini menggunakan dua metode enkripsi yaitu TKIP dan AES. Secara default algoritma yang digunakan adalah TKIP. Mode security wireless ini juga membutuhkan waktu timeout untuk setiap pergantian key pada proses enkripsi yang dilakukan. Secara default waktu yang dibutuhkan untuk pergantian key enkripsi adalah 3600 detik. Selain itu, WPA-Enterprise memiliki tiga jenis utama proses backup data yaitu:

#### 1. Primary/Backup RADIUS Server

Backup data ini membutuhkan IP address dari server RADIUS. Backup server RADIUS hanya dapat digunakan jika server utama RADIUS tidak tersedia.

2. Primary/Backup RADIUS Server Port

Backup data ini membutuhkan nomor port yang digunakan oleh server RADIUS. Secara default port yang digunakan adalah port 1812 Backup server RADIUS hanya dapat digunakan jika server utama RADIUS tidak tersedia.

#### 3. Primary/Backup Shared Secret

Untuk *backup* ini membutuhkan *shared secret key* yang digunakan oleh *access point* dan *server* RADIUS. Hal ini dilakukan untuk *backup* data pada *server* RADIUS jika *server* RADIUS yang utama tidak tersedia.

#### 2.4.7 WPA2-Enterprise

WPA2-Enterprise ini digunakan pada saat berkoordinasi dengan sebuah server RADIUS untuk autentikasi pengguna. WPA2-Enterprise ini hanya dapat digunakan ketika server RADIUS terhubung dengan access point. WPA2-Enterprise ini selalu menggunakan algoritma AES untuk enkripsi datanya. WPA2-Enterprise memiliki waktu timeout untuk melakukan pergantian terhadap key. Secara default waktu timeoutnya adalah 3600 detik. Ada tiga jenis utama proses backup data pada WPA2-Enterprise yaitu:

#### 1. Primary/Backup RADIUS Server

Backup data ini membutuhkan IP address dari server RADIUS. Backup server RADIUS hanya dapat digunakan jika server utama RADIUS tidak tersedia.

#### 2. Primary/Backup RADIUS Server Port

Backup data ini membutuhkan nomor port yang digunakan oleh server RADIUS. Secara default port yang digunakan adalah port 1812 Backup server RADIUS hanya dapat digunakan jika server utama RADIUS tidak tersedia.

#### 3. Primary/Backup Shared Secret

Untuk *backup* ini membutuhkan *shared secret key* yang digunakan oleh *access point* dan *server* RADIUS. Hal ini dilakukan untuk *backup* data pada *server* RADIUS jika *server* RADIUS yang utama tidak tersedia.

#### 2.4.8 WPA2-Enterprise Mixed

Security mode ini merupakan hasil transisi dari WPA-Enterprise dan WPA2-Enterprise. Secara otomatis access point akan memilih algoritma enkripsi yang digunakan oleh setiap pengguna. Ada tiga jenis utama proses backup data pada WPA2-Enterprise Mixed yaitu:

#### 1. Primary/Backup RADIUS Server

Backup data ini membutuhkan IP address dari server RADIUS. Backup server RADIUS hanya dapat digunakan jika server utama RADIUS tidak tersedia.

#### 2. Primary/Backup RADIUS Server Port

Backup data ini membutuhkan nomor port yang digunakan oleh server RADIUS. Secara default port yang digunakan adalah port 1812 Backup server RADIUS hanya dapat digunakan jika server utama RADIUS tidak tersedia.

#### 3. Primary/Backup Shared Secret

Untuk *backup* ini membutuhkan *shared secret key* yang digunakan oleh *access point* dan *server* RADIUS. Hal ini dilakukan untuk *backup* data pada *server* RADIUS jika *server* RADIUS yang utama tidak tersedia.

#### 2.5 Remote Authentication Dial-In User Service (RADIUS)

Remote Authentication Dial-In User Service (RADIUS) merupakan suatu protokol yang dikembangkan untuk menyediakan akses terpusat untuk melakukan authentication, authorization, dan accounting [AG1]. RADIUS menggunakan AAA konsep untuk mengelola akses jaringan, dikenal dengan istilah "AAA Transaction". RADIUS pada awalnya dikembangkan oleh Livingston untuk jaringan terminal server. RADIUS didefinisikan di dalam RFC 2865, yang pada awalnya digunakan untuk melakukan autentikasi terhadap akses jaringan secara jarak jauh dengan menggunakan koneksi dialup. Karena dukungan yang luas dan sifatnya terbuka, protokol RADIUS sering digunakan oleh ISP, jaringan nirkabel (wireless), layanan email, access point atau web server untuk melakukan autentikasi terhadap akses jaringan.

RADIUS pada umumnya banyak digunakan oleh penyedia layanan internet (*Internet Service Provider*) untuk mengelola akses ke internet atau jaringan internal. RADIUS juga bisa dipakai untuk mengamankan jaringan yang ada.

Beberapa fitur yang disediakan oleh RADIUS adalah sebagai berikut :

#### 1. Client/Server Model

Network Access Server (NAS) beroperasi sebagai pengguna RADIUS. NAS bertanggung jawab untuk meneruskan informasi pengguna ke RADIUS server, kemudian mengembalikan respon ke pengguna. RADIUS server bertanggung jawab untuk menerima permintaan koneksi pengguna, autentikasi, dan mengembalikan semua informasi yang diperlukan kepada pengguna. RADIUS server dapat bertindak sebagai proxy client bagi RADIUS server lainnya atau autentikasi lainnya.

#### 2. Network Security

Transaksi antara pengguna dan server RADIUS adalah dengan melakukan proses autentikasi. Selain itu, setiap *username* dan *password* pengguna dienkripsi diantara pengguna dan server RADIUS, untuk menghapuskan kemungkinan bahwa seseorang melakukan *snooping* pada jaringan sehingga dapat menemukan *username* dan *password*.


#### 3. Flexible Authentication Mechanisms

RADIUS server dapat mendukung berbagai metode untuk melakukan proses autentikasi pengguna.

#### 4. Extensible Protocol

Mendukung autentikasi *Password Authentication Protocol* (PAP) dan *Challenge handshake Authentication Protocol* (CHAP). Atribut nilai-nilai baru dapat ditambahkan tanpa mengganggu yang telah diimplementasi dalam suatu protokol.

Struktur format data pada RADIUS dapat dilihat pada gambar 6. Setiap kolom paket ditransmisikan dari kiri ke kanan.



Gambar 6. Struktur format data RADIUS

Struktur format data RADIUS pada Gambar 6 terdiri dari lima bagian, yaitu:

#### 1. Code

Code memiliki panjang satu oktet, digunakan untuk membedakan tipe pesan RADIUS yang dikirimkan pada paket. Kode-kode tersebut (dalam desimal) adalah:

	de l'aket la loro darani desimai
Kode dalam desimal	Keterangan Kode
1	Access-Request
	1
2	Access-Accept
	1
3	Access-Reject
	,
4	Accounting-Request
-	

Tabel 3 Kode Paket RADIUS dalam desimal

Kode dalam desimal	Keterangan Kode
5	Accounting-Response
11	Access-Challenge
12	Status-Server (experimental)
13	Status-Client (experimental)
255	Reserved

#### 2. Identifier

Memiliki panjang satu oktet, bertujuan untuk mencocokkan permintaan (request) dan balasan (replies).

#### 3. Length

Memiliki panjang dua oktet, memberikan informasi mengenai panjang paket mencakup *Code, Identifier, Length, Authenticator* dan *Attribute fields*.

#### 4. Authenticator

Memiliki panjang 16 oktet, digunakan untuk membuktikan balasan dari RADIUS *server*, selain itu digunakan juga untuk algoritma *password*.

#### 5. Attributes

Field atribut panjangnya bervariasi, dan berisi list atribut yang dibutuhkan.

Protokol RADIUS yang digunakan sebagai salah satu sistem keamanan wireless LAN melalui autentikasi pengguna wireless LAN, ternyata memiliki beberapa celah keamanan. Mekanisme proteksi menggunakan username dan password ternyata tidak cukup aman untuk diterapkan. Hal ini disebabkan oleh penerapan teknik enkripsi dan kriptografi yang tidak benar.

#### 2.6 FreeRADIUS

Server FreeRADIUS adalah aplikasi unix yang memungkinkan seseorang untuk mengatur protokol RADIUS, yang dapat digunakan untuk autentikasi, autorisasi dan akuntansi berbagai jenis akses jaringan. FreeRADIUS dikembangkan oleh Alan DeKok dan Miquel van Smoorenburg pada bulan Agustus 1999. Beberapa aplikasi RADIUS server ada yang berbentuk komersial dan free/open source. Untuk versi komerial contohnya Interlink's Secure.XS, VOP Radius Small Business, Funk Odyssey Server, dan sebagainya. Sedangkan untuk versi free/open source contohnya adalah FreeRADIUS,

Cistron Radius *Server*, ICRADIUS, XtRADIUS, *Open* RADIUS, dan sebagainya. Biasanya harga versi komersialnya sangat mahal. Harga RADIUS *server* komersial tersebut kebanyakan tidak terjangkau para pemilik *hotspot*, terutama bagi kalangan akademis, sehingga sebagian besar memilih menggunakan RADIUS *server* yang bersifat *free/open source*.

Dari sekian banyak *software* RADIUS *server*, FreeRADIUS paling banyak digunakan. Beberapa alasan menggunakan FreeRADIUS server adalah sebagai berikut:

- Free open source RADIUS server
- Terintegrasi dengan LDAP (LightWeight Directory Access Protocol)
- Mendukung berbagai jenis database (MySql, SQL Server, Oracle, dll) bahkan bisa dengan menggunakan teks biasa.
- Dapat berjalan pada berbagai sistem operasi. Pada umumnya FreeRADIUS berjalan pada UNIX dan turunannya (Linux, FreeBSD, NetBSD, Solaris,dll).
- Mendukung berbagai tipe Access Point (AP)/ Network Access Server (NAS).
- Meng-cache semua file konfigurasi di memori.
- Meyimpan log pada UNIX wtmp file format dan RADIUS detail logfiles
- Support Simultaneous-Use = X parameter. Fitur ini mencegah double login.
- Support atribut Vendor-Specific.
- Support proxying
- Mendukung PAM (*Pluggable Authentication Modules*)

#### 2.7 Mikrotik Router OS

Pada prinsipnya router adalah sebuah komputer. Router bekerja pada *layer Network* OSI. Komponen router adalah CPU, RAM, ROM, Flash dan sistem operasi. Router berfungsi:

- Menentukan jalur terbaik (best path) untuk mengirimkan paket.
- Mem-forward paket ke tujuan (destination).

Router bekerja berdasarkan *routing table*-nya. Router adalah *network center* yang menghubungkan *multiple network*. Hal ini berarti router memiliki minimal duah buah *interface* (kartu jaringan), yaitu satu sebagai *input* dan yang lainnya sebagai *output*.

Router memiliki sistem operasi yang berfungsi *Extended Machine - User/Computer Interface dan Rreources Manager*. Contoh sistem operasi router yang terkenal adalah Cisco IOS, Vyatta, dan Mikrotik. Contoh router yang terkenal adalah Cisco2621XM.

Namun harga sebuah router mahal. Alternatif lain yang lebih murah adalah menjadikan sebuah PC (*Personal Computer*) menjadi router.

Mikrotik Router OS adalah sistem operasi independen (tidak terbatas pada *vendor hardware* spesifik) berbasiskan Linux khusus untuk komputer yang difungsikan sebagai Router. Didesain untuk memberikan kemudahan bagi penggunanya. Administrasinya bisa dilakukan melalui *Windows application* (WinBox) atau melalui *web based*. MikroTik Router OS yang berbentuk *software* dan dapat diinstal pada komputer biasa (PC).

Mikrotik Router OS memiliki beberapa jenis, antara lain yaitu :

- Mikrotik RouterOS yang berbentuk software yang apat diinstal pada komputer biasa (Personal Computer).
- Built-in Hardware MikroTik dalam bentuk perangkat keras yang khusus dikemas dalam board router yang didalamnya sudah terinstal MikroTik RouterOS yang disebut DOM (Disk On Module).

Tabel 4 . Fitur-fitur Mikrotik

No	Fitur	Keterangan
1.	Address List	Pengelompokan IP Address berdasarkan nama
2.	Asynchronous	Mendukung serial PPP dial-in / dial-out, dengan
		otentikasi CHAP, PAP, MSCHAPv1 dan MSCHAPv2,
		RADIUS, dial on demand, modem pool hingga 128
		ports.
3.	Bonding	Mendukung dalam pengkombinasian beberapa
		antarmuka ethernet ke dalam 1 pipa pada koneksi cepat.
4.	Bridge	Mendukung fungsi bridge spanning tree, multiple
		bridge interface, bridging firewalling.
5.	Data Rate Management	QoS berbasis HTB dengan penggunaan <i>burst</i> , PCQ,
		RED, SFQ, FIFO queue, CIR, MIR, limit antar peer to
		peer
6.	DHCP	Mendukung DHCP tiap antarmuka; DHCP Relay;
		DHCP Client, multiple network DHCP; static dan
		dynamic DHCP leases.
7.	Firewall dan NAT	Mendukung pemfilteran koneksi <i>peer to peer</i> , source
		NAT dan destination NAT.
8.	Hotspot	Hotspot gateway dengan otentikasi RADIUS.
		Mendukung <i>limit</i> data <i>rate</i> , SSL ,HTTPS.
9.	IPSec	Protokol AH dan ESP untuk IPSec; MODP Diffie-
		Hellmann groups 1, 2, 5; MD5 dan algoritma SHA1
		hashing; algoritma enkirpsi menggunakan DES, 3DES,
		AES-128, AES-192, AES-256; Perfect Forwarding
		Secresy (PFS) MODP groups 1, 2,5

No	Fitur	Keterangan
10.	ISDN	Mendukung ISDN dial-in/dial-out. Dengan otentikasi
		PAP, CHAP, MSCHAPv1 dan MSCHAPv2, RADIUS.
		Mendukung 128K <i>bundle</i> , Cisco HDLC, x751, x75ui,
		x75bui <i>line</i> protokol.
11.	RADIUS	Mendudukung protokol RADIUS.
12.	MNDP	MikroTik <i>Discovery Neighbour</i> Protokol, juga
		mendukung Cisco Discovery Protokol (CDP)
13.	Monitoring/Accounting	Laporan <i>Traffic</i> IP, log, statistik grafik yang dapat
		diakses melalui HTTP
14.	NTP	Network Time Protocol untuk server dan clients;
		sinkronisasi menggunakan sistem GPS
15.	Poin to Point Tunneling	Support PPTP, PPPoE dan L2TP Access Consentrator;
	Protocol	protokol otentikasi menggunakan PAP, CHAP,
		MSCHAPv1, MSCHAPv2; otentikasi dan laporan
		RADIUS; enkripsi MPPE; kompresi untuk PPoE; <i>limit</i>
		data <i>rate</i> .
16.	Proxy	Cache untuk FTP dan HTTP proxy server, HTTPS
		proxy; transparent proxy untuk DNS dan HTTP;
		mendukung protokol SOCKS; mendukung parent
		proxy; static DNS
17.	Routing protocol	Support routing statik dan dinamik; RIP v1/v2, OSPF
		v2, BGP v4
18.	SDSL	Mendukung Single Line DSL; mode pemutusan jalur
- 10		koneksi dan jaringan
	Simple Tunnel	Tunnel IPIP dan EoIP (Ethernet over IP)
20.	SNMP	Simple Network Monitoring Protocol mode akses read-
	~ .	only
21.	Synchronous	Support sinkronisasi V.35, V.24, E1/T1, X21, DS3
		(T3) media ttypes; sync-PPP, Cisco HDLC; Frame
		Relay line protokol; ANSI-617d (ANDI atau annex
		D) dan Q933a (CCITT atau annex A); Frame Relay
	TT. • I • . • / . T	jenis LMI
22.	<i>Utilities/tool</i>	Ping, Traceroute; bandwidth test; ping flood; telnet;
- 22	TIT AND	SSH; packet sniffer; Dinamik DNS update
23.	VLAN	Mendukung Virtual LAN IEEE 802.1q untuk jaringan
	T/ ID	ethernet dan wireless; multiple VLAN; VLAN bridging
24.		Mendukung aplikasi Voice over IP
25.	VRRP	Mendukung Virtual Router Redudant Protocol
26.	WinBox	Aplikasi <i>mode</i> GUI untuk meremote dan
		mengkonfigurasi MikroTik RouterOS.

## Bab III Analisis dan Perancangan

Pada bab Analisis dan Desain akan dijelaskan analisis yang dilakukan selama pelaksanaan kajian ini yang mencakup analisis mekanisme autentikasi *server* RADIUS serta perancangan topologi jaringan yang akan diimplementasikan pada studi implementasi *wireless* LAN.

#### 3.1 Analisis


Pada sub bab ini, akan dijelaskan mengenai mekanisme autentikasi pada FreeRADIUS yang mencakup autentikasi MAC address pada FreeRADIUS dengan menggunakan Mikrotik sebagai *access server* serta autentikasi MAC *address* pada FreeRADIUS dengan menggunakan *access point* sebagai *access server*.

#### 3.1.1 Mekanisme Autentikasi Server RADIUS

Pada server RADIUS, login pengguna terdiri dari permintaan (Access-Request) dari NAS ke server RADIUS dan memberikan respon yang sesuai (Access-Accept atau Access-Reject) dari server. Paket "Access-Request" berisi username, password terenkripsi, alamat IP NAS, dan port.

Ketika server RADIUS menerima Access-Request dari NAS, server RADIUS mencari database untuk pengguna yang di-list (terdaftar). Jika account tidak ada dalam database, default profil di-load atau server RADIUS segera mengirimkan sebuah pesan "Access-Reject". Pesan "Access-Reject" tersebut dapat disertai pesan teks yang menunjukkan alasan penolakan.

Pada RADIUS, autentikasi dan autorisasi digabungkan secara bersamaan. Jika account ditemukan dan password benar, maka server RADIUS mengembalikan respon "Access-Accept", termasuk daftar atribut yang menjelaskan parameter yang akan digunakan untuk sesi ini. Parameter termasuk jenis layanan (frame), alamat IP pengguna yang diberikan (statis atau dinamis), ACL (Access Control List) yang berlaku, atau static route untuk menginstal tabel routing NAS. Informasi konfigurasi dalam RADIUS server mendefinisikan apa yang akan diinstal pada NAS. Gambar 7 menjelaskan urutan autentikasi dan autorisasi.




Gambar 7. Mekanisme Autentikasi RADIUS Server

Pada kajian ini, autentikasi MAC *address* dapat dilakukan dengan beberapa cara, yaitu dengan menggunakan Mikrotik sebagai *access server* atau *access point* sebagai *access server*. Penjelasan untuk tiap-tiap cara yang digunakan yaitu pada sub bab berikut ini.

#### 3.1.1.1 Autentikasi MAC address pada FreeRADIUS dengan Mikrotik

Autentikasi MAC *address* pada FreeRADIUS dengan menggunakan Mikrotik sebagai *access Server* adalah seperti pada gambar 8.




Gambar 8. Autentikasi dan Autorisasi RADIUS

Pada gambar 8, Mikrotik sebagai *access server* akan terhubung langsung dengan FreeRADIUS. Informasi atau atribut-atribut yang diterima dari *access point* akan dilanjutkan (*forward*) oleh Mikrotik kepada *server* FreeRADIUS. Pada bagian ini, Mikrotik akan diatur sebagai *access server* sehingga akan secara langsung yang melakukan *request* terhadap *server* FreeRADIUS.

#### 3.1.1.2 Autentikasi MAC address pada FreeRADIUS dengan Access Point

Autentikasi MAC *address* dapat juga dilakukan dengan dengan menggunakan *Access point* akan digunakan sebagai *access server*, seperti pada gambar 9.



Gambar 9 . Operasi Filtering Mac Address

Pada gambar 9, *Access point* sebagai *access server* akan terhubung langsung dengan FreeRADIUS, sehingga *access point* yang akan mengirimkan informasi atau atributatribut kepada server FreeRADIUS secara langsung. Dalam hal ini, *access point* diasumsikan memiliki fitur yang mendukung protokol RADIUS, sehingga *access point* dapat melakukan autentikasi secara langsung dengan server FreeRADIUS.

#### 3.1.1.3 Filtering MAC Address

Pada gambar 7, hal pertama yang akan dilakukan *access server* adalah melakukan *Access Request*. Ketika melakukan *access request*, *access server* akan mengirimkan beberapa atribut untuk melakukan komunikasi dengan FreeRADIUS. Atribut-atribut yang dikirimkan oleh *access point* untuk melakukan komunikasi ke FreeRADIUS adalah sebagai berikut:

```
Packet-Type = Access-Request
Thu Apr 16 14:12:52 2009

User-Name = "sanhenra"

NAS-IP-Address = 10.1.0.6

NAS-Port = 0

Called-Station-Id = "00-1E-E5-9D-64-B1:TK_03"

Calling-Station-Id = "00-1B-77-48-0A-2B"

Framed-MTU = 1400

NAS-Port-Type = Wireless-802.11

Connect-Info = "CONNECT 11Mbps 802.11b"

Client-IP-Address = 10.1.0.6
```

Dari informasi atribut-atribut tersebut, terdapat beberapa informasi yang akan dikirimkan oleh *access point* kepada FreeRADIUS untuk melakukan komunikasi. Pada kajian ini, informasi yang penting adalah *Calling-Station-ID*. Atribut tersebut merupakan alamat MAC dari *wireless node* (pengguna).

#### **Calling-Station-Id**

Calling-Station-Id merupakan salah satu atribut yang akan dikirimkan oleh access server yaitu yang berisi informasi MAC address wireless node (pengguna) yang mengakses suatu access point. Atribut ini akan digunakan oleh FreeRADIUS sebagai informasi yang unik dari client.

Dalam kasus ini, atribut ini (*Calling-Station-Id*) akan di-*filter* atau diambil nilainya, dan yang akan digunakan sebagai *identity* untuk melakukan autentikasi.

#### 3.2 Perancangan

Tahap perancangan bertujuan untuk mengetahui beberapa kebutuhan yang diperlukan ketika akan melakukan studi implementasi. Perancangan yang dilakukan dalam pelaksanaan kajian ini adalah perancangan perangkat yang akan digunakan sehingga masalah mengenai perangkat yang digunakan saat melakukan studi implementasi dapat diatasi, kemudian perancangan topologi jaringan *wireless* LAN dengan menggunakan Mikrotik dan FreeRADIUS.

#### 3.2.1 Perancangan perangkat yang akan digunakan

Dalam perancangan *wireless* LAN dengan menggunakan Mikrotik dan FreeRADIUS sebagai *authenticator*, memerlukan beberapa perangkat yang dibutuhkan untuk melakukan implementasi. Perancangan perangkat-perangkat yang dibutuhkan adalah sebagai berikut:

- Komputer (*Personal Computer*) untuk instalasi Mikrotik yang akan dijadikan sebagai router OS. Dalam hal ini, PC harus memiliki minimal satu buah NIC *card* yang akan digunakan sebagai *interface* pada Mikrotik.
- Komputer (*Personal Computer*) yang akan diinstal sistem operasi Linux dalam hal ini adalah Fedora Core 6 sebagai sistem operasi untuk melakukan instalasi FreeRADIUS yang digunakan untuk autentikasi.
- Switch yang digunakan untuk menghubungkan semua perangkat.

- Kabel straigth throught yang akan menghubungkan server Mikrotik dengan switch, server FreeRADIUS dengan switch, dan server Mikrotik dengan perangkat wireless (access point).
- Perangkat wireless yang akan digunakan sebagai access point.

Tahap perancangan ini dilakukan untuk mempermudah dalam pelaksanaan tahapan studi implementasi Tugas Akhir ini.

Perencanaan perangkat yang akan digunakan ada beberapa hal yang perlu diketahui mengenai spesifikasi hardware yang akan digunakan untuk instalasi Mikrotik Router OS, yaitu:

- 1. Prosesor Intel Pentium 3, dan akan lebih baik jika menggunakan spesifikasi yang lebih, agar performansinya lebih baik.
- 2. RAM minimal 128 MB, dan dianjurkan untuk menggunakan 64 MB atau lebih.
- 3. *Harddisk* Menggunakan standar ATA/IDE *drive* dengan kapasitas minimal 64 MB atau lebih.

Perencanaan perangkat yang akan digunakan untuk instalasi FreeRADIUS yang dalam hal ini dilakukan pada sistem operasi linux Fedora Core 6 adalah adalah sebagai berikut:

- 1. Prosesor Intel Pentium 4, dan akan lebih baik jika menggunakan spesifikasi yang lebih tingi, agar performansinya lebih baik.
- 2. RAM minimal 256 MB.
- 3. *Harddisk* Menggunakan standar ATA/IDE atau Serial ATA *drive* dengan kapasitas minimal 6GB.


Pada studi ini, perancangan terhadap perangkat pendukung seperti switch yaitu dengan menggunakan switch standar yang biasa digunakan pada suatu jaringan lokal. *Access point* yang akan digunakan adalah Linksys WAP4400N. Perangkat tersebut sudah mendukung *wireless security* yaitu *security* WPA2-*enterprise* yang dapat diintegrasikan langsung dengan *server* RADIUS.

#### 3.2.2 Perancangan toplologi jaringan

Tahapan ini bertujuan untuk merencanakan topologi jaringan ketika akan melakukan studi implementasi pada *wireless* LAN yang memenuhi kebutuhan pengguna saat ini dan dapat


dikembangkan di masa yang akan datang sejalan dengan peningkatan kebutuhan jaringan yang lebih besar. Perancangan mencakup perencanaan secara fisik mencakup media yang digunakan dan infrastruktur *wireless* LAN yakni hubungan antara suatu komponen dengan komponen lain.

Bentuk topologi dasar jaringan untuk implementasi *wireless* LAN pada studi kasus ini terdapat beberapa jenis. Topologi jaringan yang mungkin ketika akan melakukan studi implementasi pada Tugas Akhir ini antara lain adalah seperti gambar 10.



Gambar 10. Topologi dasar jaringan 1

Pada gambar 10, *server* mikrotik harus memiliki 2 buah *interface* dimana salah satu *interface*-nya akan terhubung dengan *switch*, dan satu *interface* akan terhubung dengan *access point*. Pada topologi ini, *access point* akan memiliki *network address* yang berbeda dengan *network address* FreeRADIUS dan *interface* Mikrotik yang terhubung dengan *switch*. Perancangan topologi pada gambar 10, akan digunakan pada pelaksanaan studi ini. Hal ini dilakukan karena dukungan dari perangkat yang digunakan ketika akan melakukan implementasi.



Gambar 11 . Topologi dasar jaringan 2

Pada gambar 11, topologi ini digunakan jika *server* Mikrotik hanya memiliki satu *interface* saja. *Access point* akan dihubungkan langsung dengan *switch*, sehingga semua komponen yang terhubung akan memiliki *network address* yang sama.

## Bab IV Pelaksanaan

Pada bab Pelaksanaan akan dijelaskan cara instalasi *tools* yang akan digunakan seperti Mikrotik Router OS dan FreeRADIUS dan konfigurasi *tools* tersebut, konfigurasi perangkat *wireless* yang digunakan sebagai *access point*, serta integrasi antara Mikrotik Router OS dan FreeRADIUS.

Pada kajian ini, implementasi yang dilakukan adalah autentikasi berdasarkan MAC *address* pada FreeRADIUS dengan menggunakan Mikrotik sebagai *access server*.

#### 4.1 Instalasi

Pada sub bab ini, akan dijelaskan tentang cara-cara instalasi *software* yang digunakan dalam pelaksanaan kajian ini. Adapun *software* yang akan diinstalasi adalah Mikrotik Router OS, dan FreeRADIUS.

#### 4.1.1 Instalasi Mikrotik Router OS

Pada instalasi Mikrotik Router OS, ada beberapa cara yang dapat dilakukan dalam instalasi Mikrotik Ruter OS, misalnya langsung menggunakan CD installer Mikrotik atau melalui jaringan atau lebih dikenal dengan istilah *NetInstall*. Dalam kajian ini, instalasi dilakukan dengan menggunakan CD *installer* Mikrotik. Tahapan yang harus dilakukan dalam instalasi adalah sebagai berikut:

- Booting dengan menggunakan CD installer Mikrotik Router OS.
- Pilih packages yang akan di instalasi sesuai kebutuhan, secara default package
  "system" akan ditandai seperti pada gambar 12. Packages yang dimaksud adalah
  program pendukung yang akan digunakan untuk implementasi wireless LAN, seperti
  system, dhcp, routing, wireless, dan sebagainya.
- Untuk melakukan proses berikutnya, tekan tombol "i" dan ikuti tahapan selanjutnya.
- Saat proses instalasi system dimulai, secara otomatis proses instalasi akan membuat partisi sendiri, termasuk proses *formatting disk*.
- Semua packages akan diinstal, dan setelah proses tersebut selesai Mikrotik perlu direstart.
- Setelah proses instalasi selesai, Mikrotik Router OS sudah dapat digunakan atau dikonfigurasi sesuai kebutuhan.

```
Welcome to MikroTik Router Software installation
Move around menu using 'p' and 'n' or arrow keys, select with 'spacebar'
Select all with 'a', minimum with 'm'. Press 'i' to install locally or '
cancel and reboot.
       system
                                                                               routing-test
                                           isdn
                                           lcd
       ppp
dhcp
                                                                               security
                                                                               stpbridge-legacy
                                           mpls
                                          mpls-test
multicast
        advanced-tools
                                                                               synchronous
        arlan
                                                                               ups
       calea
                                          ntp
radiolan
                                                                             l user-manager
                                                                         [ ] wireless
        hotspot
                                           routerboard
                                           routing
wireless (depends on system):
Provides support for PrismII and Atheros wireless station and AP.
```

Gambar 12. Instalasi Mikrotik

#### 4.1.2 Instalasi FreeRADIUS

Instalasi FreeRADIUS yang dilakukan pada kajian ini dilakukan pada sistem operasi Fedora Core 6. FreeRADIUS yang digunakan adalah versi 1.1.3. Untuk menginstall FreeRADIUS ada beberapa cara, yaitu dengan menggunakan RPM (*Redhat Packages Manager*) yang diinstal secara langsung pada sistem operasi atau menggunakan instalasi melalui jaringan atau *yum.* Pada kajian ini, instalasi dilakukan langsung melalui jaringan. Langkah-langkah untuk instalasi adalah sebagai berikut:

 Konfigurasi file "/etc/yum.repos.d/yum.conf" dengan merujuk pada web repository dari software yang akan diinstal. Contoh konfigurasinya adalah sebagai berikut:

```
[core]
name=Fedora Core $releasever - $basearch
baseurl=http://reponm.nm.del.ac.id/
enabled=1
apacheck=0
```

Pada contoh diatas, software yang akan diinstal berasal dari repository local PI Del.


 Untuk melakukan instalasi, dengan melakukan perintah berikut pada terminal sistem operasi Fedora Core 6.

```
[root@fedora ~]$ yum install freeradius
```

Hasil dari perintah tersebut adalah seperti pada gambar 13.

Ikuti proses instalasi berikutnya sampai hasilnya complete.

Pada gambar 14 menunjukan proses instalasi FreeRADIUS dan beberapa *packages* yang ikut diinstal bersamaan dengan *software* FreeRADIUS.



Gambar 13. Instalasi FreeRADIUS

Untuk menjalankan FreeRADIUS dan untuk melihat proses yang sedang berjalan adalah dengan menggunakan perintah berikut ini:

```
[root@freeradius ~]# service radiusd start
[root@freeradius ~]# radiusd -X
```

Untuk menghentikan proses FreeRADIUS yaitu:

```
[root@freeradius ~]# service radiusd stop
```

#### 4.2 Konfigurasi

Pada sub bab ini, akan dijelaskan tentang cara-cara konfigurasi *software* yang digunakan dalam pelaksanaan kajian ini. Adapun *software* yang akan diinstal adalah Mikrotik Router OS sebagai sistem operasinya dan FreeRADIUS sebagai *server* RADIUS.

## 4.2.1 Konfigurasi Mikrotik Router OS

Konfigurasi Mikrotik yang digunakan sebagai router dapat dilakukan dengan beberapa cara, yaitu dengan menggunakan terminal (*text based*) atau dengan menggunakan *windows application* atau *winbox*. Pada pelaksanaan kajian ini, konfigurasi Mikrotik Router OS dilakukan dengan menggunakan terminal (*text based*).

## 4.2.1.1 Konfigurasi IP address

Setiap perangkat jaringan akan memiliki suatu alamat yang disebut dengan IP *address*. Untuk mengatur ip *address* pada Mikrotik adalah dengan cara berikut ini:

```
[admin@mikrotik] > ip address add address=[address/netmask]
interface=[interface]
```

Perintah "interface" diatas untuk mengatur IP address sesuai yang dibutuhkan interface yang akan diatur IP address-nya. Pada pelaksanaan kajian ini, server Mikrotik memiliki dua buah interface, sehingga cara untuk mengatur ip address untuk setiap interface adalah sbagai berikut:

```
[admin@mikrotik] > ip address add address=172.22.3.10/24
interface=ether1
[admin@mikrotik] > ip address add address=10.1.0.1/24
interface=ether2
```

Untuk melihat hasil konfigurasi ip *address* yaitu dengan menggunakan perintah:

```
[admin@mikrotik] > ip address print
```

## 4.2.1.2 Konfigurasi DHCP Server

Konfigurasi DHCP dilakukan untuk memberikan alamat IP kepada pengguna yang akan menggunakan *wireless* LAN pada saat melakukan pengujian.

## Membuat DHCP server:

1. Membuat sebuah IP *address pool*.

```
[admin@mikrotik] > ip pool add name=client ranges=10.1.0.10-
10.1.0.200
```

2. Konfigurasi DHCP network 10.1.0.0/16

```
[admin@mikrotik] > ip dhcp-server network add address=10.1.0.0 gateway=10.1.0.1 netmask=16 dns-server=172.22.3.10 domain=mikrotik.tk03.net
```

#### 3. Tambahkan DHCP server

```
[admin@mikrotik] > ip dhcp-server add interface=ether2
address-pool=client
```

## 4.2.1.3 Konfigurasi RADIUS

Pada bagian konfigurasi ini adalah untuk menambahkan layanan, alamat dan *secret* RADIUS pada MikroTik.

```
[admin@mikrotik] > radius add service=hotspot,dhcp
address172.22.3.10 secret=tk03
```

## 4.2.1.4 Manambahkan Hotspot

Pada bagian ini akan dijelaskan cara untuk menambahkan layanan *hotspot* baru.

1. Untuk menambahkan layanan hotspot adalah sebagai berikut.

```
[admin@mikrotik] > ip hotspot name=wireless interface=ether2
address-pool=client
```

2. Membuat *profiles* baru yang berisi *hotspot address* dan menggunakan metode autentikasi *login* berdasarkan MAC dengan menggunakan RADIUS.

```
[admin@mikrotik] > ip hotspot profile add name=wireless
login-by=mac use-radius=yes
```

#### 4.2.1.5 Konfigurasi FreeRADIUS

Pada sub bab ini diuraikan mengenai cara konfigurasi FreeRADIUS. Dalam melakukan konfigurasi FreeRADIUS dengan cara mengubah *file* konfigurasi yang ada pada *server* FreeRADIUS. Daftar *file* yang diubah untuk pelaksanaan kajian ini adalah sebagai berikut:

- /etc/raddb/users
- /etc/raddb/clients.conf
- /etc/raddb/radiusd.conf

Konfigurasi untuk tiap-tiap *file* konfigurasi adalah sebagai berikut:

### /etc/raddb/users

File ini digunakan oleh FreeRADIUS untuk menyimpan informasi tentang pengguna. Dalam hal ini, informasi tersebut adalah berupa MAC address dari pengguna yang

melakukan koneksi ke FreeRADIUS *server*. Secara *default*, isi *file* ini adalah kosong. *Format* dari isi file konfigurasi ini adalah sebagai berikut.

```
"MAC address" User-Password == ""
```

## /etc/raddb/clients.conf

Pada *file* ini, konfigurasi yang dilakukan yaitu dengan menambahkan daftar alamat IP pengguna yang melakukan koneksi ke *server* FreeRADIUS. Isi konfigurasi yang di tambah pada *file* ini adalah sebagai berikut.

#### /etc/raddb/radiusd.conf

File ini merupakan file konfigurasi utama pada FreeRADIUS. Adapun isi dari file konfigurasi ini adalah pada Lampiran A.

# Bab V Pengujian

Pada bab Pengujian akan dijelaskan pengujian yang dilakukan selama pelaksanaan kajian ini yang mencakup pengujian koneksi pengguna terhadap *wireless access point* dengan Mikrotik menggunakan autentikasi MAC *address* pada FreeRADIUS.

## 5.1 Pengujian Koneksi Langsung

Pengujian koneksi antara pengguna dengan *wireless acces point* dan Mikrotik dengan menggunakan perangkat berikut ini:

- 1. Laptop yang sudah dilengkapi dengan wireless network card.
- 2. Wireless Access Point Linksys WAP4400N.
- 3. Mikrotik PC *router*.

Pada bagian ini, koneksi dilakukan secara langsung tanpa menggunakan autentikasi. Pengujian dilakukan untuk mengetahui apakah pengguna sudah dapat terhubung dengan wireless access point dan dapat terhubung dengan pengguna lain yang sudah terhubung pada jaringan yang sama. Pada kajian ini, pemberian alamat IP untuk setiap pengguna yang terhubung dengan menggunakan DHCP yang diatur pada Mikrotik dengan menggunakan alamat IP seperti pada penjelasan bab Implementasi.

Penjelasan mengenai pengujian koneksi secara langsung seperti pada penjelasan berikut ini :



Gambar 14. List jaringan wireless

Pada gambar 15, terdapat beberapa daftar jaringan *wireless*. Pada kasus ini, pengujian dilakukan terhadap jaringan *wireless* yang SSID-nya TK\_03. Jika pengguna sudah terhubung dengan *wireless access point*, Mikrotik akan memberikan alamat IP secara dinamis (DHCP) seperti pada gambar 16 berikut ini.

```
Microsoft Windows [Version 6.0.6000]
Copyright (c) 2006 Microsoft Corporation. All rights reserved.

C:\>ipconfig
Windows IP Configuration

Wireless LAN adapter Wireless Network Connection:

Connection-specific DNS Suffix : tk_03.del.ac.id
Link-local IPv6 Address . . : fe80::7082:7bc4:7bc3:bb7f%9
IPv4 Address . . : 10.1.0.200
Subnet Mask . . . : 255.255.0.0
Default Gateway . : 10.1.0.1
```

Gambar 15. Alamat IP pengguna

Pengujian koneksi secara langsung pengguna terhadap *wireless access point* dan Mikrotik telah berhasil dilakukan, sehingga pengguna dapat menggunakan akses *wireless*.

## 5.2 Pengujian Koneksi dengan Menggunakan Autentikasi MAC Address

Pengujian koneksi dengan menggunakan autentikasi MAC address adalah sebagai berikut. Pada pengujian ini, ada beberapa langkah yang dilakukan, yaitu sebagai berikut:

 Menambahkan MAC address pangguna yang akan menggunakan wireless pada file /etc/raddb/users.

```
"00-1B-9E-32-E4-DE" User-Password == ""
```

 Mengakses wireless dengan menggunakan MAC address yang belum terdaftar dan mencoba melakukan akses terhadap jaringan

Pada pengujian ini, terlihat bahwa atribut yang dikirimkan oleh Mikrotik adalah seperti berikut ini.

```
NAS-Port-Type = Wireless-802.11
Calling-Station-Id = "00:13:E8:0C:90:0D"
Called-Station-Id = "wireless"
NAS-Port-Id = "ether2"
User-Name = "00:13:E8:0C:90:0D"
```

```
NAS-Port = 2154823815
Acct-Session-Id = "80700087"
Framed-IP-Address = 10.1.0.169
Mikrotik-Attr-10 = 0x0a010138
CHAP-Challenge = 0x5484b26465b8dfa04e6b8838444f2fc9
CHAP-Password = 0xbcdfae3611a602c1727441b27f18a78e64
Service-Type = Login-User
WISPr-Logoff-URL = "http://10.1.0.1/logout"
NAS-Identifier = "MikroTik"
NAS-IP-Address = 172.22.3.10
```

Pada pengujian ini, atribut yang dikirim mengalami perubahan dari yang telah dikirim oleh access point. Pada kasus ini, Mikrotik mengubah attribut yang diterima dari *access point* sebelum diteruskan ke FreeRADIUS. Hal yang terpenting pada attribut yang diubah oleh Mikrotik adalah attribut MAC *address* pengguna dijadikan sebagai *username*.

Autentikasi dan autorisasi pada study kasus ini berjalan secara paralel. Jika seorang *client* yang memiliki MAC address yang sudah terdaftar, maka autentikasi akan berhasil (FreeRADIUS memberikan balasan bahwa *login ok*). Pengguna tersebut akan mendapatkan koneksi *wireless* dan autorisasi berhasil sehingga pengguna memiliki hak akses terhadap jaringan. *Output* pada FreeRADIUS terdapat pada Lampiran B.

Namun jika MAC *address* yang tidak terdaftar mencoba mengakses WLAN, maka autentikasi gagal (FreeRADIUS memberikan balasan bahwa *login incorrect*). Pengguna tersebut tetap mendapatkan koneksi *wireless*, tetapi tidak bisa melakukan akses apapun terhadap jaringan (autorisasi gagal). *Output* pada FreeRADIUS terdapat pada Lampiran C.

# Bab VI Kesimpulan dan Saran

Pada bab ini diuraikan mengenai kesimpulan dan saran setelah memerhatikan hasil-hasil yang diperoleh selama pelaksanaan Tugas Akhir.

### 6.1 Kesimpulan

Kesimpulan yang diperoleh selama pengerjaan Tugas Akhir ini adalah:

- 1. Mengetahui bahwa autentikasi MAC *address* dapat membatasi pengguna untuk menggunakan layanan *wireless* LAN.
- Dapat mengetahui bagaimana integrasi antara Mikrotik dan FreeRADIUS dalam pengimplementasian akses layanan wireless LAN dengan menggunakan autentikasi MAC address.
- 3. Autentikasi MAC *address* dapat dilakukan dengan dua cara, yaitu dengan menggunakan *access point* sebagai *access Server* dan Mikrotik sebagai *access server*. Pada kajian ini, autentikasi yaitu dengan menggunakan Mikrotik sebagai *access server*.

#### 6.2 Saran

Dalam pengimplementasian *wireless* LAN menggunakan autentikasi berdasarkan MAC *address* dengan mengintegrasikan Mikrotik dan FreeRADIUS sehingga dapat menyediakan akses kepada pengguna terhadap suatu penyedia *wireless* LAN dibutuhkan pemahaman yang cukup untuk dapat mempermudah dalam pengembangannya ke masa yang akan datang.

Selain menggunakan autentikasi berdasarkan MAC *address*, juga perlu ditambahkan autentikasi lainnya seperti autentikasi menggunakan *username* dan *password*, atau sebagai contoh yaitu autentikasi dengan menggunakan layanan LDAP agar tingkat keamanannya menjadi lebih baik.

## Daftar Pustaka dan Rujukan

## **Daftar Pustaka**

- [R1] http://www.freeradius.org, diakses tanggal 30 maret 2009.
- [R2] http://www.mikrotik.com, diakses tanggal 30 maret 2009.
- [R3] http://www.mikrotik.co.id, diakses tanggal 30 maret 2009.
- [R4] http://en.wikipedia.org/wiki/Authentication, diakses 2 april 2009.
- [R5] http://en.wikipedia.org/wiki/Authorization, diakses tanggal 2 april 2009.
- [R6] http://en.wikipedia.org/wiki/AAA protocol, diakses tanggal 2 april 2009.
- [R7] http://en.wikipedia.org/wiki/RADIUS, diakses tanggal 2 april 2009.
- [R8] http://www.mikrotik.com/testdocs/ros/2.9/refman2.9.pdf, diakses tanggal 30 maret 2009.
- [R9] CISCO, "Wireless-N Access Point with Power Over Ethernet User Guide", CISCO, 2008, halaman 25-30.
- [R10] Miranti, 2008. Metode Keamanan Wireless LAN pada Perangkat Komputer dan Handphone. FAKULTAS ILMU KOMPUTER UNIVERSITAS SRIWIJAYA, 2008.

## Rujukan

- [MAC]http://id.wikipedia.org/wiki/MAC address, diakses tanggal 20 agustus 2009.
- [LAN] http://id.wikipedia.org/wiki/Local\_Area\_Network, diakses tanggal 20 agustus 2009.
- [IRD] http://teknik-informatika.com/wireless-lan, diakses tanggal 20 agustus 2009.
- [TRI] http://www.elektroindonesia.com/elektro/khu36.html, diakses tanggal 21 agustus 2009.
- [CC1] CCNA Exploration 4.0 LAN Switching and Wireless, Glossary.
- [WL1] http://en.wikipedia.org/wiki/Wireless\_LAN, diakses tanggal 30 maret 2009.
- [CC2] CCNA Exploration 4.0 Network Fundamental, Chapter 9 Ethernet, "9.1.1 Ethernet-Standards and Implementation".
- [CC3] CCNA Exploration 4.0 Network Fundamental, Chapter 9 Ethernet, "9.1.3 Logical Link Control Connectiong to the Upper Layers".
- [CC4] CCNA Exploration 4.0 Network Fundamental, Chapter 9 Ethernet, "9.3.2.2 MAC Address Structure".
- [RFC] http://tools.ietf.org/html/rfc2865, diakses tanggal 21 agustus 2009.
- [AG1] Agung W. Setiawan, Remote Authentication Dial In User Service (RADIUS) untuk Autentikasi Pengguna Wireless LAN, DEPARTEMEN TEKNIK ELEKTRO FAKULTAS TEKNOLOGI INDUSTRI INSTITUT TEKNOLOGI BANDUNG 2005, BAB III.
- [MIK] MikroTik, MikroTik Router OS v2.9 Reference Manual, 2007.

## Lampiran

#### Lampiran A

## File konfigurasi FreeRADIUS

## /etc/raddb/radiusd.conf

```
##
## radiusd.conf -- FreeRADIUS server configuration file.
     http://www.freeradius.org/
##
     $Id: radiusd.conf.in,v 1.188.2.4.2.12 2006/07/29 19:43:30
##
nbk Exp $
##
     The location of other config files and
#
     logfiles are declared in this file
#
     Also general configuration for modules can be done
#
     in this file, it is exported through the API to
     modules that ask for it.
     The configuration variables defined here are of the form
${foo}
#
     They are local to this file, and do not change from request
to
#
     request.
#
     The per-request variables are of the form %{Attribute-Name},
and
     are taken from the values of the attribute in the incoming
     request. See 'doc/variables.txt' for more information.
prefix = /usr
exec prefix = /usr
sysconfdir = /etc
localstatedir = /var
sbindir = /usr/sbin
logdir = ${localstatedir}/log/radius
raddbdir = ${sysconfdir}/raddb
radacctdir = ${logdir}/radacct
# Location of config and logfiles.
confdir = ${raddbdir}
run dir = ${localstatedir}/run/radiusd
  The logging messages for the server are appended to the
#
  tail of this file.
log file = ${logdir}/radius.log
```

```
# libdir: Where to find the rlm * modules.
    This should be automatically set at configuration time.
#
    If the server builds and installs, but fails at execution
time
    with an 'undefined symbol' error, then you can use the libdir
    directive to work around the problem.
    The cause is usually that a library has been installed on
your
    system in a place where the dynamic linker CANNOT find it.
When
    executing as root (or another user), your personal
environment MAY
   be set up to allow the dynamic linker to find the library.
#
    executing as a daemon, FreeRADIUS MAY NOT have the same
    personalized configuration.
   To work around the problem, find out which library contains
that symbol,
    and add the directory containing that library to the end of
'libdir',
    with a colon separating the directory names. NO spaces are
allowed.
    e.g. libdir = /usr/local/lib:/opt/package/lib
   You can also try setting the LD LIBRARY PATH environment
variable
    in a script which starts the server.
#
    If that does not work, then you can re-configure and re-build
the
   server to NOT use shared libraries, via:
#
#
     ./configure --disable-shared
#
     make
     make install
libdir = /usr/lib
  pidfile: Where to place the PID of the RADIUS server.
  The server may be signalled while it's running by using this
   file.
  This file is written when ONLY running in daemon mode.
   e.g.: kill -HUP `cat /var/run/radiusd/radiusd.pid`
pidfile = ${run dir}/radiusd.pid
```

```
# user/group: The name (or #number) of the user/group to run
radiusd as.
    If these are commented out, the server will run as the
user/group
    that started it. In order to change to a different
user/group, you
    MUST be root ( or have root privleges ) to start the server.
   We STRONGLY recommend that you run the server with as few
permissions
    as possible. That is, if you're not using shadow passwords,
the
   user and group items below should be set to 'nobody'.
#
    On SCO (ODT 3) use "user = nouser" and "group = nogroup".
#
  NOTE that some kernels refuse to setgid(group) when the value
of
   (unsigned) group is above 60000; don't use group nobody on
these systems!
  On systems with shadow passwords, you might have to set 'group
= shadow'
  for the server to be able to read the shadow password file.
If you can
  authenticate users while in debug mode, but not in daemon
mode, it may be
  that the debugging mode server is running as a user that can
   shadow info, and the user listed below can not.
user = radiusd
group = radiusd
  max request time: The maximum time (in seconds) to handle a
request.
  Requests which take more time than this to process may be
killed, and
   a REJECT message is returned.
# WARNING: If you notice that requests take a long time to be
handled,
   then this MAY INDICATE a bug in the server, in one of the
modules
  used to handle a request, OR in your local configuration.
# This problem is most often seen when using an SQL database.
If it takes
  more than a second or two to receive an answer from the SQL
database,
```

```
then it probably means that you haven't indexed the database.
See your
  SOL server documentation for more information.
# Useful range of values: 5 to 120
max request time = 30
  delete blocked requests: If the request takes MORE THAN
'max request time'
  to be handled, then maybe the server should delete it.
# If you're running in threaded, or thread pool mode, this
setting
# should probably be 'no'. Setting it to 'yes' when using a
# server MAY cause the server to crash!
delete blocked requests = no
# cleanup delay: The time to wait (in seconds) before cleaning
up
# a reply which was sent to the NAS.
# The RADIUS request is normally cached internally for a short
period
  of time, after the reply is sent to the NAS. The reply packet
may be
  lost in the network, and the NAS will not see it. The NAS
will then
  re-send the request, and the server will respond quickly with
the
  cached reply.
# If this value is set too low, then duplicate requests from the
  MAY NOT be detected, and will instead be handled as seperate
requests.
  If this value is set too high, then the server will cache too
# requests, and some new requests may get blocked. (See
'max requests'.)
  Useful range of values: 2 to 10
cleanup delay = 5
# max requests: The maximum number of requests which the server
keeps
# track of. This should be 256 multiplied by the number of
clients.
  e.g. With 4 clients, this number should be 1024.
```

```
# If this number is too low, then when the server becomes busy,
  it will not respond to any new requests, until the
'cleanup delay'
# time has passed, and it has removed the old requests.
# If this number is set too high, then the server will use a bit
# memory for no real benefit.
 If you aren't sure what it should be set to, it's better to
  too high than too low. Setting it to 1000 per client is
probably
  the highest it should be.
  Useful range of values: 256 to infinity
max requests = 1024
# bind address: Make the server listen on a particular IP
address, and
  send replies out from that address. This directive is most
  for machines with multiple IP addresses on one interface.
  It can either contain "*", or an IP address, or a fully
qualified
  Internet domain name. The default is "*"
  As of 1.0, you can also use the "listen" directive. See below
for
  more information.
bind address = *
# port: Allows you to bind FreeRADIUS to a specific port.
  The default port that most NAS boxes use is 1645, which is
historical.
# RFC 2138 defines 1812 to be the new port. Many new servers
  NAS boxes use 1812, which can create interoperability
problems.
  The port is defined here to be 0 so that the server will pick
  the machine's local configuration for the radius port, as
defined
  in /etc/services.
# If you want to use the default RADIUS port as defined on your
   (usually through 'grep radius /etc/services') set this to 0
(zero).
```

```
# A port given on the command-line via '-p' over-rides this one.
# As of 1.0, you can also use the "listen" directive. See below
for
# more information.
port = 0
  By default, the server uses "bind address" to listen to all
# on a machine, or just one IP. The "port" configuration is
used
# to select the authentication port used when listening on those
  addresses.
# If you want the server to listen on additional addresses, you
# use the "listen" section. A sample section (commented out) is
included
# below. This "listen" section duplicates the functionality of
  "bind address" and "port" configuration entries, but it only
# for authentication packets.
# If you comment out the "bind address" and "port" configuration
entries,
# then it becomes possible to make the server accept only
accounting,
# or authentication packets. Previously, it always listened for
both
  types of packets, and it was impossible to make it listen for
only
# one type of packet.
#listen {
     # IP address on which to listen.
     # Allowed values are:
          dotted quad (1.2.3.4)
             hostname
                         (radius.example.com)
             wildcard
                         (*)
     ipaddr = *
     # Port on which to listen.
       Allowed values are:
          integer port number (1812)
          0 means "use /etc/services for the proper port"
     port = 0
     # Type of packets to listen for.
     # Allowed values are:
          auth listen for authentication packets
```

```
acct listen for accounting packets
     type = auth
# }
# hostname lookups: Log the names of clients or just their IP
addresses
  e.g., www.freeradius.org (on) or 206.47.27.232 (off).
  The default is 'off' because it would be overall better for
the net
# if people had to knowingly turn this feature on, since
enabling it
# means that each client request will result in AT LEAST one
lookup
# request to the nameserver. Enabling hostname lookups will
  mean that your server may stop randomly for 30 seconds from
time
  to time, if the DNS requests take too long.
# Turning hostname lookups off also means that the server won't
block
# for 30 seconds, if it sees an IP address which has no name
associated
  with it.
#
  allowed values: {no, yes}
hostname lookups = no
  Core dumps are a bad thing. This should only be set to 'yes'
  if you're debugging a problem with the server.
  allowed values: {no, yes}
allow core dumps = no
# Regular expressions
# These items are set at configure time. If they're set to
# then setting them to "no" turns off regular expression
support.
 If they're set to "no" at configure time, then setting them to
# WILL NOT WORK. It will give you an error.
regular expressions
                     = yes
extended expressions = yes
```

```
Log the full User-Name attribute, as it was found in the
request.
# allowed values: {no, yes}
log stripped names = no
# Log authentication requests to the log file.
  allowed values: {no, yes}
log auth = yes
  Log passwords with the authentication requests.
  log auth badpass - logs password if it's rejected
  log auth goodpass - logs password if it's correct
  allowed values: {no, yes}
log auth badpass = no
log auth goodpass = no
# usercollide: Turn "username collision" code on and off. See
the
# "doc/duplicate-users" file
# WARNING
# !!!!!!! Setting this to "yes" may result in the server
behaving
# !!!!!!! strangely. The "username collision" code will ONLY
work
# !!!!!!! with clear-text passwords. Even then, it may not do
what
# !!!!!!! you want, or what you expect.
  !!!!!!!!
# !!!!!!! We STRONGLY RECOMMEND that you do not use this
feature,
  !!!!!!! and that you find another way of acheiving the same
goal.
# !!!!!!!
# !!!!!!! e,q. module fail-over.
'doc/configurable failover'
# WARNING
usercollide = no
# lower user / lower pass:
# Lower case the username/password "before" or "after"
# attempting to authenticate.
# If "before", the server will first modify the request and then
# to auth the user. If "after", the server will first auth
using the
```

```
# values provided by the user. If that fails it will reprocess
the
  request after modifying it as you specify below.
# This is as close as we can get to case insensitivity. It is
the
  admin's job to ensure that the username on the auth db side is
 *also* lowercase to make this work
# Default is 'no' (don't lowercase values)
# Valid values = "before" / "after" / "no"
lower user = no
lower pass = no
# nospace user / nospace pass:
# Some users like to enter spaces in their username or password
# incorrectly. To save yourself the tech support call, you can
  eliminate those spaces here:
# Default is 'no' (don't remove spaces)
# Valid values = "before" / "after" / "no" (explanation above)
nospace user = no
nospace pass = no
# The program to execute to do concurrency checks.
checkrad = ${sbindir}/checkrad
# SECURITY CONFIGURATION
# There may be multiple methods of attacking on the server.
This
  section holds the configuration items which minimize the
impact
  of those attacks
security {
        max attributes: The maximum number of attributes
       permitted in a RADIUS packet. Packets which have MORE
        than this number of attributes in them will be dropped.
       If this number is set too low, then no RADIUS packets
       will be accepted.
     # If this number is set too high, then an attacker may be
     # able to send a small number of packets which will cause
        the server to use all available memory on the machine.
     # Setting this number to 0 means "allow any number of
attributes"
     max attributes = 200
```

```
reject delay: When sending an Access-Reject, it can be
        delayed for a few seconds. This may help slow down a DoS
       attack. It also helps to slow down people trying to
brute-force
     # crack a users password.
        Setting this number to 0 means "send rejects immediately"
       If this number is set higher than 'cleanup delay', then
the
        rejects will be sent at 'cleanup delay' time, when the
request
        is deleted from the internal cache of requests.
       Useful ranges: 1 to 5
     reject delay = 1
        status server: Whether or not the server will respond
        to Status-Server requests.
     # Normally this should be set to "no", because they're
useless.
     # See: http://www.freeradius.org/rfc/rfc2865.html#Keep-
Alives
        However, certain NAS boxes may require them.
     # When sent a Status-Server message, the server responds
with
     # an Access-Accept packet, containing a Reply-Message
attribute,
     # which is a string describing how long the server has been
       running.
     status server = no
}
# PROXY CONFIGURATION
  proxy requests: Turns proxying of RADIUS requests on or off.
  The server has proxying turned on by default. If your system
  set up to proxy requests to another server, then you can turn
proxying
  off here. This will save a small amount of resources on the
  If you have proxying turned off, and your configuration files
say
# to proxy a request, then an error message will be logged.
```

```
To disable proxying, change the "yes" to "no", and comment the
  $INCLUDE line.
  allowed values: {no, yes}
proxy requests = yes
$INCLUDE ${confdir}/proxy.conf
# CLIENTS CONFIGURATION
  Client configuration is defined in "clients.conf".
# The 'clients.conf' file contains all of the information from
the old
  'clients' and 'naslist' configuration files. We recommend
that you
  do NOT use 'client's or 'naslist', although they are still
  supported.
# Anything listed in 'clients.conf' will take precedence over
the
  information from the old-style configuration files.
$INCLUDE ${confdir}/clients.conf
# SNMP CONFIGURATION
  Snmp configuration is only valid if SNMP support was enabled
  at compile time.
  To enable SNMP querying of the server, set the value of the
  'snmp' attribute to 'yes'
snmp = no
$INCLUDE ${confdir}/snmp.conf
# THREAD POOL CONFIGURATION
  The thread pool is a long-lived group of threads which
  take turns (round-robin) handling any incoming requests.
  You probably want to have a few spare threads around,
  so that high-load situations can be handled immediately.
you
  don't have any spare threads, then the request handling will
  be delayed while a new thread is created, and added to the
pool.
  You probably don't want too many spare threads around,
```

```
# otherwise they'll be sitting there taking up resources, and
  not doing anything productive.
# The numbers given below should be adequate for most
situations.
thread pool {
     # Number of servers to start initially --- should be a
reasonable
     # ballpark figure.
     start servers = 5
     # Limit on the total number of servers running.
     # If this limit is ever reached, clients will be LOCKED
OUT, so it
     # should NOT BE SET TOO LOW. It is intended mainly as a
brake to
     # keep a runaway server from taking the system with it as
it spirals
     #
        down...
        You may find that the server is regularly reaching the
        'max servers' number of threads, and that increasing
        'max servers' doesn't seem to make much difference.
     # If this is the case, then the problem is MOST LIKELY that
       your back-end databases are taking too long to respond,
and
       are preventing the server from responding in a timely
manner.
        The solution is NOT do keep increasing the 'max servers'
        value, but instead to fix the underlying cause of the
     # problem: slow database, or 'hostname lookups=yes'.
     # For more information, see 'max request time', above.
     \max \text{ servers} = 32
     # Server-pool size regulation. Rather than making you
guess
     # how many servers you need, FreeRADIUS dynamically adapts
to
       the load it sees, that is, it tries to maintain enough
        servers to handle the current load, plus a few spare
        servers to handle transient load spikes.
     # It does this by periodically checking how many servers
are
        waiting for a request. If there are fewer than
        min spare servers, it creates a new spare. If there are
        more than max spare servers, some of the spares die off.
        The default values are probably OK for most sites.
```

```
min spare servers = 3
     max spare servers = 10
     # There may be memory leaks or resource allocation problems
with
     # the server. If so, set this value to 300 or so, so that
the
        resources will be cleaned up periodically.
     # This should only be necessary if there are serious bugs
in the
     # server which have not yet been fixed.
     # '0' is a special value meaning 'infinity', or 'the
servers never
     # exit'
     max requests per server = 0
}
# MODULE CONFIGURATION
# The names and configuration of each module is located in this
section.
# After the modules are defined here, they may be referred to by
  in other sections of this configuration file.
modules {
       Each module has a configuration as follows:
          name [ instance ] {
                config item = value
     #
          }
        The 'name' is used to load the 'rlm name' library
        which implements the functionality of the module.
     # The 'instance' is optional. To have two different
instances
     # of a module, it first must be referred to by 'name'.
       The different copies of the module are then created by
     # inventing two 'instance' names, e.g. 'instance1' and
'instance2'
       The instance names can then be used in later
configuration
     # INSTEAD of the original 'name'. See the 'radutmp'
configuration
     # below for an example.
```

```
# PAP module to authenticate users based on their stored
password
       Supports multiple encryption schemes
       clear: Clear text
       crypt: Unix crypt
         md5: MD5 ecnryption
        shal: SHA1 encryption.
     # DEFAULT: crypt
     pap {
          encryption scheme = crypt
     # CHAP module
       To authenticate requests containing a CHAP-Password
attribute.
     chap {
          authtype = CHAP
     # Pluggable Authentication Modules
     #
       For Linux, see:
          http://www.kernel.org/pub/linux/libs/pam/index.html
        WARNING: On many systems, the system PAM libraries have
                 memory leaks! We STRONGLY SUGGEST that you do
not
              use PAM for authentication, due to those memory
leaks.
     pam {
             The name to use for PAM authentication.
             PAM looks in /etc/pam.d/${pam auth name}
             for it's configuration. See 'redhat/radiusd-pam'
             for a sample PAM configuration file.
             Note that any Pam-Auth attribute set in the
'authorize'
             section will over-ride this one.
          pam auth = radiusd
     # Unix /etc/passwd style authentication
     unix {
             Cache /etc/passwd, /etc/shadow, and /etc/group
```

```
The default is to NOT cache them.
             For FreeBSD and NetBSD, you do NOT want to enable
             the cache, as it's password lookups are done via a
             database, so set this value to 'no'.
              Some systems (e.g. RedHat Linux with pam pwbd) can
             take *seconds* to check a password, when th passwd
             file containing 1000's of entries. For those
systems,
             you should set the cache value to 'yes', and set
             the locations of the 'passwd', 'shadow', and
'group'
             files, below.
           # allowed values: {no, yes}
           cache = no
           # Reload the cache every 600 seconds (10mins). 0 to
disable.
          cache reload = 600
             Define the locations of the normal passwd, shadow,
and
           #
             group files.
              'shadow' is commented out by default, because not
all
             systems have shadow passwords.
             To force the module to use the system password
functions,
             instead of reading the files, leave the following
entries
             commented out.
             This is required for some systems, like FreeBSD,
             and Mac OSX.
                passwd = /etc/passwd
           shadow = /etc/shadow
                group = /etc/group
             The location of the "wtmp" file.
             This should be moved to it's own module soon.
             The only use for 'radlast'. If you don't use
              'radlast', then you can comment out this item.
          radwtmp = ${logdir}/radwtmp
```

```
# Extensible Authentication Protocol
       For all EAP related authentications.
     # Now in another file, because it is very large.
$INCLUDE ${confdir}/eap.conf
     # Microsoft CHAP authentication
       This module supports MS-CHAP and MS-CHAPv2
authentication.
     # It also enforces the SMB-Account-Ctrl attribute.
     mschap {
             As of 0.9, the mschap module does NOT support
             reading from /etc/smbpasswd.
             If you are using /etc/smbpasswd, see the 'passwd'
          # module for an example of how to use /etc/smbpasswd
           # if use mppe is not set to no mschap will
           # add MS-CHAP-MPPE-Keys for MS-CHAPv1 and
           # MS-MPPE-Recv-Key/MS-MPPE-Send-Key for MS-CHAPv2
          #use mppe = no
          # if mppe is enabled require encryption makes
           # encryption moderate
          #require encryption = yes
           # require strong always requires 128 bit key
          # encryption
          #require strong = yes
          # Windows sends us a username in the form of
          # DOMAIN\user, but sends the challenge response
           # based on only the user portion. This hack
           # corrects for that incorrect behavior.
          #with ntdomain hack = no
          # The module can perform authentication itself, OR
          # use a Windows Domain Controller. This configuration
           # directive tells the module to call the ntlm auth
          # program, which will do the authentication, and
return
          # the NT-Key. Note that you MUST have "winbindd" and
           # "nmbd" running on the local machine for ntlm auth
           # to work. See the ntlm auth program documentation
           # for details.
```

```
# Be VERY careful when editing the following line!
           #ntlm_auth = "/path/to/ntlm auth --request-nt-key --
username=%{Stripped-User-Name:-%{User-Name:-None}} --
challenge=%{mschap:Challenge:-00} --nt-response=%{mschap:NT-
Response: -00}"
     # Lightweight Directory Access Protocol (LDAP)
       This module definition allows you to use LDAP for
       authorization and authentication.
        See doc/rlm ldap for description of configuration options
        and sample authorize{} and authenticate{} blocks
       However, LDAP can be used for authentication ONLY when
the
       Access-Request packet contains a clear-text User-Password
        attribute. LDAP authentication will NOT work for any
other
        authentication method.
       This means that LDAP servers don't understand EAP. If
vou
     # force "Auth-Type = LDAP", and then send the server a
       request containing EAP authentication, then
authentication
     # WILL NOT WORK.
       The solution is to use the default configuration, which
does
       work.
       Setting "Auth-Type = LDAP" is ALMOST ALWAYS WRONG. We
       really can't emphasize this enough.
     ldap {
          server = "ldap.your.domain"
           # identity = "cn=admin,o=My Org,c=UA"
           # password = mypass
          basedn = "o=My Org,c=UA"
           filter = "(uid=%{Stripped-User-Name:-%{User-Name}})"
           # base filter = "(objectclass=radiusprofile)"
           # set this to 'yes' to use TLS encrypted connections
           # to the LDAP database by using the StartTLS extended
           # operation.
           # The StartTLS operation is supposed to be used with
normal
           # ldap connections instead of using ldaps (port 689)
connections
          start tls = no
```

```
# tls cacertfile = /path/to/cacert.pem
          # tls_cacertdir = /path/to/ca/dir/
                               = /path/to/radius.crt
           # tls certfile
           # tls keyfile
                               = /path/to/radius.key
           # tls randfile = /path/to/rnd
           # tls require cert
                                = "demand"
           # default profile = "cn=radprofile,ou=dialup,o=My
Org, c=UA"
           # profile attribute = "radiusProfileDn"
          access attr = "dialupAccess"
           # Mapping of RADIUS dictionary attributes to LDAP
           # directory attributes.
          dictionary mapping = ${raddbdir}/ldap.attrmap
          ldap connections number = 5
          # NOTICE: The password header directive is NOT case
insensitive
           # password header = "{clear}"
                password attribute = nspmPassword
           # to get the user's password from a Novell eDirectory
           # backend. This will work *only if* freeRADIUS is
           # configured to build with --with-edir option.
             The server can usually figure this out on its own,
and pull
             the correct User-Password or NT-Password from the
database.
           #
             Note that NT-Passwords MUST be stored as a 32-digit
hex
             string, and MUST start off with "0x", such as:
                0x000102030405060708090a0b0c0d0e0f
             Without the leading "Ox", NT-Passwords will not
work.
             This goes for NT-Passwords stored in SQL, too.
           # password attribute = userPassword
           # Un-comment the following to disable Novell
eDirectory account
           # policy check and intruder detection. This will work
*only if*
```

```
# FreeRADIUS is configured to build with --with-edir
option.
           # edir account policy check=no
           # groupname attribute = cn
           # groupmembership filter =
"(|(&(objectClass=GroupOfNames)(member=%{Ldap-
UserDn}))(&(objectClass=GroupOfUniqueNames)(uniquemember=%{Ldap-
UserDn})))"
           # groupmembership attribute = radiusGroupName
          timeout = 4
          timelimit = 3
          net timeout = 1
           # compare check items = yes
           # do xlat = yes
           # access attr used for allow = yes
             By default, if the packet contains a User-Password,
             and no other module is configured to handle the
             authentication, the LDAP module sets itself to do
             LDAP bind for authentication.
             You can disable this behavior by setting the
following
             configuration entry to "no".
           # allowed values: {no, yes}
           # set_auth_type = yes
     }
     # passwd module allows to do authorization via any passwd-
like
     # file and to extract any attributes from these modules
     # parameters are:
        filename - path to filename
         format - format for filename record. This parameters
                  correlates record in the passwd file and RADIUS
                  attributes.
                  Field marked as '*' is key field. That is, the
parameter
                  with this name from the request is used to
search for
     #
                  the record from passwd file
                  Attribute marked as '=' is added to reply itmes
     #
instead
                  of default configure itmes
               Attribute marked as '~' is added to request items
                  Field marked as ',' may contain a comma
separated list
```

```
of attributes.
        authtype - if record found this Auth-Type is used to
authenticate
     #
                 user
     #
        hashsize - hashtable size. If 0 or not specified records
are not
                  stored in memory and file is red on every
     #
request.
         allowmultiplekeys - if few records for every key are
allowed
         ignorenislike - ignore NIS-related records
         delimiter - symbol to use as a field separator in passwd
file,
                 for format ':' symbol is always used. '\0',
'\n' are
               not allowed
     # An example configuration for using /etc/smbpasswd.
     #passwd etc smbpasswd {
          filename = /etc/smbpasswd
          format = "*User-Name::LM-Password:NT-Password:SMB-
Account-CTRL-TEXT::"
          authtype = MS-CHAP
     #
          hashsize = 100
          ignorenislike = no
          allowmultiplekeys = no
     # }
     # Similar configuration, for the /etc/group file. Adds a
Group-Name
     # attribute for every group that the user is member of.
     #passwd etc group {
          filename = /etc/group
          format = "=Group-Name:::*,User-Name"
     #
          hashsize = 50
          ignorenislike = yes
     #
          allowmultiplekeys = yes
          delimiter = ":"
     # }
     # Realm module, for proxying.
     # You can have multiple instances of the realm module to
       support multiple realm syntaxs at the same time. The
       search order is defined by the order in the authorize and
       preacct sections.
       Four config options:
          #
     #
          ignore default - set to 'yes' or 'no'
```

```
#
             ignore null - set to 'yes' or 'no'
     #
        ignore default and ignore null can be set to 'yes' to
prevent
        the module from matching against DEFAULT or NULL realms.
This
        may be useful if you have have multiple instances of the
        realm module.
     #
        They both default to 'no'.
     #
        'realm/username'
     # Using this entry, IPASS users have their realm set to
"IPASS".
     realm IPASS {
           format = prefix
           delimiter = "/"
           ignore default = no
           ignore null = no
     }
        'username@realm'
     realm suffix {
           format = suffix
           delimiter = "@"
           ignore default = no
           ignore_null = no
     }
        'username%realm'
     realm realmpercent {
           format = suffix
           delimiter = "%"
           ignore default = no
           ignore null = no
     }
        'domain\user'
     realm ntdomain {
           format = prefix
           delimiter = "\\"
           ignore default = no
           ignore null = no
     }
        A simple value checking module
```

```
It can be used to check if an attribute value in the
request
     # matches a (possibly multi valued) attribute in the check
        items This can be used for example for caller-id
        authentication. For the module to run, both the request
       attribute and the check items attribute must exist
       i.e.
       A user has an ldap entry with 2 radiusCallingStationId
       attributes with values "12345678" and "12345679". If we
       enable rlm checkval, then any request which contains a
       Calling-Station-Id with one of those two values will be
     # accepted. Requests with other values for
        Calling-Station-Id will be rejected.
     # Regular expressions in the check attribute value are
allowed
     # as long as the operator is '=~'
     checkval {
           # The attribute to look for in the request
          item-name = Calling-Station-Id
          # The attribute to look for in check items. Can be
multi valued
          check-name = Calling-Station-Id
           # The data type. Can be
           # string,integer,ipaddr,date,abinary,octets
          data-type = string
          # If set to yes and we dont find the item-name
attribute in the
           # request then we send back a reject
           # DEFAULT is no
          #notfound-reject = no
     }
     # rewrite arbitrary packets. Useful in accounting and
authorization.
        The module can also use the Rewrite-Rule attribute. If it
        is set and matches the name of the module instance, then
     # that module instance will be the only one which runs.
     # Also if new attribute is set to yes then a new attribute
     # will be created containing the value replacewith and it
       will be added to searchin (packet, reply, proxy,
proxy reply or config).
     # searchfor, ignore case and max matches will be ignored in
that case.
```

```
# Backreferences are supported: %{0} will contain the string
the whole match
     \# and %{1} to %{8} will contain the contents of the 1st to
the 8th parentheses
     # If max matches is greater than one the backreferences will
correspond to the
     # first match
     #attr rewrite sanecallerid {
          attribute = Called-Station-Id
           # may be "packet", "reply", "proxy", "proxy reply" or
"config"
          searchin = packet
          searchfor = "[+]"
          replacewith = ""
          ignore case = no
          new attribute = no
          max matches = 10
          ## If set to yes then the replace string will be
appended to the original string
          append = no
     # }
     # Preprocess the incoming RADIUS request, before handing it
off
     # to other modules.
       This module processes the 'huntgroups' and 'hints' files.
     # In addition, it re-writes some weird attributes created
     # by some NASes, and converts the attributes into a form
which
     # is a little more standard.
     preprocess {
          huntgroups = ${confdir}/huntgroups
          hints = ${confdir}/hints
           # This hack changes Ascend's wierd port numberings
           # to standard 0-??? port numbers so that the "+" works
           # for IP address assignments.
          with ascend hack = no
          ascend channels per line = 23
           # Windows NT machines often authenticate themselves as
           # NT DOMAIN\username
           # If this is set to 'yes', then the NT DOMAIN portion
           # of the user-name is silently discarded.
           # This configuration entry SHOULD NOT be used.
           # See the "realms" module for a better way to handle
           # NT domains.
```

```
with ntdomain hack = no
           # Specialix Jetstream 8500 24 port access server.
           # If the user name is 10 characters or longer, a "/"
           # and the excess characters after the 10th are
           # appended to the user name.
           # If you're not running that NAS, you don't need
           # this hack.
          with specialix jetstream hack = no
           # Cisco (and Quintum in Cisco mode) sends it's VSA
attributes
           # with the attribute name *again* in the string, like:
              H323-Attribute = "h323-attribute=value".
           # If this configuration item is set to 'yes', then
           # the redundant data in the the attribute text is
stripped
           # out. The result is:
            H323-Attribute = "value"
           # If you're not running a Cisco or Quintum NAS, you
don't
          # need this hack.
          with cisco vsa hack = no
     # Livingston-style 'users' file
     files {
          usersfile = ${confdir}/users
           acctusersfile = ${confdir}/acct users
          preproxy usersfile = ${confdir}/preproxy users
             If you want to use the old Cistron 'users' file
             with FreeRADIUS, you should change the next line
             to 'compat = cistron'. You can the copy your
'users'
           # file from Cistron.
          compat = no
     # Write a detailed log of all accounting records received.
     detail {
           # Note that we do NOT use NAS-IP-Address here, as
             that attribute MAY BE from the originating NAS, and
             NOT from the proxy which actually sent us the
             request. The Client-IP-Address attribute is ALWAYS
             the address of the client which sent us the
```

```
request.
             The following line creates a new detail file for
             every radius client (by IP address or hostname).
             In addition, a new detail file is created every
             day, so that the detail file doesn't have to go
             through a 'log rotation'
             If your detail files are large, you may also want
             to add a ':%H' (see doc/variables.txt) to the end
             of it, to create a new detail file every hour,
e.g.:
              ..../detail-%Y%m%d:%H
             This will create a new detail file for every hour.
          detailfile = ${radacctdir}/%{Client-IP-
Address}/detail-%Y%m%d
             The Unix-style permissions on the 'detail' file.
             The detail file often contains secret or private
             information about users. So by keeping the file
             permissions restrictive, we can prevent unwanted
           # people from seeing that information.
          detailperm = 0600
           # Certain attributes such as User-Password may be
          # "sensitive", so they should not be printed in the
           # detail file. This section lists the attributes
          # that should be suppressed.
           # The attributes should be listed one to a line.
           #suppress {
                # User-Password
           # }
     }
        Many people want to log authentication requests.
        Rather than modifying the server core to print out more
       messages, we can use a different instance of the 'detail'
        module, to log the authentication requests to a file.
       You will also need to un-comment the 'auth log' line
        in the 'authorize' section, below.
      detail auth log {
           detailfile = ${radacctdir}/%{Client-IP-Address}/auth-
detail-%Y%m%d
```

```
This MUST be 0600, otherwise anyone can read
           # the users passwords!
           # detailperm = 0600
     }
        This module logs authentication reply packets sent
     # to a NAS. Both Access-Accept and Access-Reject packets
       are logged.
     # You will also need to un-comment the 'reply log' line
       in the 'post-auth' section, below.
      detail reply log {
           detailfile = ${radacctdir}/%{Client-IP-
Address \ / reply-detail-\%Y\%m\%d
             This MUST be 0600, otherwise anyone can read
           # the users passwords!
           # detailperm = 0600
     }
        This module logs packets proxied to a home server.
     # You will also need to un-comment the 'pre proxy log' line
       in the 'pre-proxy' section, below.
     # detail pre proxy log {
           # detailfile = ${radacctdir}/%{Client-IP-Address}/pre-
proxy-detail-%Y%m%d
           # This MUST be 0600, otherwise anyone can read
           # the users passwords!
          # detailperm = 0600
     # }
        This module logs response packets from a home server.
     # You will also need to un-comment the 'post proxy log'
line
     # in the 'post-proxy' section, below.
     # detail post proxy log {
           # detailfile = ${radacctdir}/%{Client-IP-
Address}/post-proxy-detail-%Y%m%d
             This MUST be 0600, otherwise anyone can read
```

```
# the users passwords!
           # detailperm = 0600
     # }
        The rlm sql log module appends the SQL queries in a log
        file which is read later by the radsqlrelay program.
        This module only performs the dynamic expansion of the
       variables found in the SQL statements. No operation is
        executed on the database server. (this could be done
       later by an external program) That means the module is
       useful only with non-"SELECT" statements.
     # See rlm sql log(5) manpage.
     sql log {
          path = ${radacctdir}/sql-relay
          acct table = "radacct"
          postauth_table = "radpostauth"
          Start = "INSERT INTO ${acct table} (AcctSessionId,
UserName, \
           NASIPAddress, FramedIPAddress, AcctStartTime,
AcctStopTime, \
           AcctSessionTime, AcctTerminateCause) VALUES
            ('%{Acct-Session-Id}', '%{User-Name}', '%{NAS-IP-
Address}', \
           '%{Framed-IP-Address}', '%S', '0', '0', '');"
          Stop = "INSERT INTO ${acct table} (AcctSessionId,
UserName,
           NASIPAddress, FramedIPAddress, AcctStartTime,
AcctStopTime, \
           AcctSessionTime, AcctTerminateCause) VALUES
            ('%{Acct-Session-Id}', '%{User-Name}', '%{NAS-IP-
Address}', \
           '%{Framed-IP-Address}', '0', '%S', '%{Acct-Session-
Time \ ', \
           '%{Acct-Terminate-Cause}');"
          Alive = "INSERT INTO ${acct table} (AcctSessionId,
UserName, \
           NASIPAddress, FramedIPAddress, AcctStartTime,
AcctStopTime, \
           AcctSessionTime, AcctTerminateCause) VALUES
            ('%{Acct-Session-Id}', '%{User-Name}', '%{NAS-IP-
Address }', \
            '%{Framed-IP-Address}', '0', '0', '%{Acct-Session-
Time } ', '');"
          Post-Auth = "INSERT INTO ${postauth table}
```

```
(user, pass, reply, date) VALUES
            ('%{User-Name}', '%{User-Password:-Chap-Password}',
            '%{reply:Packet-Type}', '%S');"
     }
       Create a unique accounting session Id. Many NASes re-use
       or repeat values for Acct-Session-Id, causing no end of
       confusion.
     # This module will add a (probably) unique session id
       to an accounting packet based on the attributes listed
     # below found in the packet. See doc/rlm acct unique for
       more information.
     acct unique {
          key = "User-Name, Acct-Session-Id, NAS-IP-Address,
Client-IP-Address, NAS-Port"
     # Include another file that has the SQL-related
configuration.
     # This is another file only because it tends to be big.
     # The following configuration file is for use with MySQL.
     # For Postgresql, use:
                                     ${confdir}/postgresql.conf
                                ${confdir}/mssql.conf
     # For MS-SQL, use:
       For Oracle, use:
                                ${confdir}/oraclesql.conf
     $INCLUDE ${confdir}/sql.conf
     # For Cisco VoIP specific accounting with Postgresql,
                     ${confdir}/pgsql-voip.conf
       use:
     # You will also need the sql schema from:
           src/billing/cisco h323 db schema-postgres.sql
     # Note: This config can be use AS WELL AS the standard sql
     # config if you need SQL based Auth
       Write a 'utmp' style file, of which users are currently
       logged in, and where they've logged in from.
       This file is used mainly for Simultaneous-Use checking,
        and also 'radwho', to see who's currently logged in.
     radutmp {
          # Where the file is stored. It's not a log file,
          # so it doesn't need rotating.
```

```
filename = ${logdir}/radutmp
             The field in the packet to key on for the
             'user' name, If you have other fields which you
want
             to use to key on to control Simultaneous-Use,
             then you can use them here.
             Note, however, that the size of the field in the
             'utmp' data structure is small, around 32
             characters, so that will limit the possible choices
             of keys.
             You may want instead: %{Stripped-User-Name:-%{User-
Name } }
          username = %{User-Name}
             Whether or not we want to treat "user" the same
             as "USER", or "User". Some systems have problems
             with case sensitivity, so this should be set to
             'no' to enable the comparisons of the key attribute
             to be case insensitive.
          case sensitive = yes
             Accounting information may be lost, so the user MAY
             have logged off of the NAS, but we haven't noticed.
             If so, we can verify this information with the NAS,
             If we want to believe the 'utmp' file, then this
             configuration entry can be set to 'no'.
          check with nas = yes
           # Set the file permissions, as the contents of this
file
           # are usually private.
          perm = 0600
          callerid = "yes"
     # "Safe" radutmp - does not contain caller ID, so it can be
     # world-readable, and radwho can work for normal users,
without
     # exposing any information that isn't already exposed by
who (1).
     # This is another 'instance' of the radutmp module, but it
is given
     # then name "sradutmp" to identify it later in the
"accounting"
```

```
# section.
     radutmp sradutmp {
           filename = ${logdir}/sradutmp
          perm = 0644
          callerid = "no"
     }
     # attr filter - filters the attributes received in replies
from
     # proxied servers, to make sure we send back to our RADIUS
client
     # only allowed attributes.
     attr filter {
          attrsfile = ${confdir}/attrs
       counter module:
       This module takes an attribute (count-attribute).
       It also takes a key, and creates a counter for each
unique
     # key. The count is incremented when accounting packets
are
        received by the server. The value of the increment
depends
       on the attribute type.
       If the attribute is Acct-Session-Time or of an integer
type we add the
     # value of the attribute. If it is anything else we
increase the
     #
       counter by one.
       The 'reset' parameter defines when the counters are all
reset to
     # zero. It can be hourly, daily, weekly, monthly or never.
     # hourly: Reset on 00:00 of every hour
     # daily: Reset on 00:00:00 every day
     # weekly: Reset on 00:00:00 on sunday
     # monthly: Reset on 00:00:00 of the first day of each month
       It can also be user defined. It should be of the form:
       num[hdwm] where:
        h: hours, d: days, w: weeks, m: months
       If the letter is ommited days will be assumed. In
example:
       reset = 10h (reset every 10 hours)
       reset = 12 (reset every 12 days)
        The check-name attribute defines an attribute which will
be
     # registered by the counter module and can be used to set
the
```

```
maximum allowed value for the counter after which the
user
        is rejected.
     #
     #
        Something like:
        DEFAULT Max-Daily-Session := 36000
                Fall-Through = 1
        You should add the counter module in the instantiate
        section so that it registers check-name before the files
        module reads the users file.
       If check-name is set and the user is to be rejected then
we
        send back a Reply-Message and we log a Failure-Message in
        the radius.log
        If the count attribute is Acct-Session-Time then on each
       we send back the remaining online time as a Session-
Timeout attribute
        The counter-name can also be used instead of using the
check-name
        like below:
     #
        DEFAULT Daily-Session-Time > 3600, Auth-Type = Reject
            Reply-Message = "You've used up more than one hour
today"
        The allowed-servicetype attribute can be used to only
take
        into account specific sessions. For example if a user
first
       logs in through a login menu and then selects ppp there
will
        be two sessions. One for Login-User and one for Framed-
User
     # service type. We only need to take into account the
second one.
        The module should be added in the instantiate, authorize
and
        accounting sections. Make sure that in the authorize
        section it comes after any module which sets the
        'check-name' attribute.
     counter daily {
           filename = ${raddbdir}/db.daily
          key = User-Name
          count-attribute = Acct-Session-Time
          reset = daily
           counter-name = Daily-Session-Time
           check-name = Max-Daily-Session
           allowed-servicetype = Framed-User
```

```
cache-size = 5000
        This module is an SQL enabled version of the counter
module.
        Rather than maintaining seperate (GDBM) databases of
        accounting info for each counter, this module uses the
data
        stored in the raddacct table by the sql modules. This
        module NEVER does any database INSERTs or UPDATEs.
        totally dependent on the SQL module to process Accounting
        packets.
        The 'sqlmod inst' parameter holds the instance of the sql
        module to use when querying the SQL database. Normally it
        is just "sql". If you define more and one SQL module
        instance (usually for failover situations), you can
        specify which module has access to the Accounting Data
        (radacct table).
        The 'reset' parameter defines when the counters are all
        reset to zero. It can be hourly, daily, weekly, monthly
or
        never. It can also be user defined. It should be of the
        form:
          num[hdwm] where:
          h: hours, d: days, w: weeks, m: months
          If the letter is ommited days will be assumed. In
example:
          reset = 10h (reset every 10 hours)
          reset = 12 (reset every 12 days)
       The 'key' parameter specifies the unique identifier for
the
        counter records (usually 'User-Name').
        The 'query' parameter specifies the SQL query used to get
        the current Counter value from the database. There are 3
        parameters that can be used in the query:
                응k
                     'key' parameter
                     unix time value of beginning of reset period
     #
                응b
                     unix time value of end of reset period
        The 'check-name' parameter is the name of the 'check'
        attribute to use to access the counter in the 'users'
file
        or SQL radcheck or radcheckgroup tables.
        DEFAULT Max-Daily-Session > 3600, Auth-Type = Reject
            Reply-Message = "You've used up more than one hour
today"
     #
```

```
sqlcounter dailycounter {
           counter-name = Daily-Session-Time
           check-name = Max-Daily-Session
           sqlmod-inst = sql
           key = User-Name
           reset = daily
           # This query properly handles calls that span from the
           # previous reset period into the current period but
           # involves more work for the SQL server than those
           # below
           # For mysql:
           query = "SELECT SUM(AcctSessionTime - \
                 GREATEST((%b - UNIX TIMESTAMP(AcctStartTime)),
0)) \
                 FROM radacct WHERE UserName='%{%k}' AND \
                 UNIX TIMESTAMP(AcctStartTime) + AcctSessionTime
> '%b'"
           # For postgresql:
           query = "SELECT SUM(AcctSessionTime - \
                 GREATER((%b - AcctStartTime::ABSTIME::INT4), 0))
\
#
                 FROM radacct WHERE UserName='%{%k}' AND \
                 AcctStartTime::ABSTIME::INT4 + AcctSessionTime >
'%b'"
           # This query ignores calls that started in a previous
           # reset period and continue into into this one. But it
           # is a little easier on the SQL server
           # For mysql:
           query = "SELECT SUM(AcctSessionTime) FROM radacct
WHERE \
                 UserName='%{%k}' AND AcctStartTime >
FROM UNIXTIME('%b')"
           # For postgresql:
           query = "SELECT SUM(AcctSessionTime) FROM radacct
WHERE \
                 UserName='%{%k}' AND AND
AcctStartTime::ABSTIME::INT4 > '%b'"
           # This query is the same as above, but demonstrates an
           # additional counter parameter '%e' which is the
           # timestamp for the end of the period
           # For mysql:
           query = "SELECT SUM(AcctSessionTime) FROM radacct \
#
#
                 WHERE UserName='%{%k}' AND AcctStartTime BETWEEN
                 FROM UNIXTIME('%b') AND FROM UNIXTIME('%e')"
           # For postgresql:
#
           query = "SELECT SUM(AcctSessionTime) FROM radacct \
```

```
WHERE UserName='%{%k}' AND
AcctStartTime::ABSTIME::INT4 \
                 BETWEEN '%b' AND '%e'"
     }
     sqlcounter monthlycounter {
           counter-name = Monthly-Session-Time
           check-name = Max-Monthly-Session
           sqlmod-inst = sql
           key = User-Name
           reset = monthly
           # This query properly handles calls that span from the
           # previous reset period into the current period but
           # involves more work for the SQL server than those
           # below
           # The same notes above about the differences between
mysql
           # versus postgres queries apply here.
           query = "SELECT SUM(AcctSessionTime - \
                 GREATEST((%b - UNIX TIMESTAMP(AcctStartTime)),
0)) \
                 FROM radacct WHERE UserName='%{%k}' AND \
                 UNIX TIMESTAMP(AcctStartTime) + AcctSessionTime
> '%b'"
           # This query ignores calls that started in a previous
           # reset period and continue into into this one. But it
           # is a little easier on the SQL server
           query = "SELECT SUM(AcctSessionTime) FROM radacct
WHERE \
                 UserName='%{%k}' AND AcctStartTime >
FROM UNIXTIME ('%b')"
           # This query is the same as above, but demonstrates an
           # additional counter parameter '%e' which is the
           # timestamp for the end of the period
           query = "SELECT SUM(AcctSessionTime) FROM radacct \
#
                 WHERE UserName='%{%k}' AND AcctStartTime BETWEEN
                 FROM UNIXTIME ('%b') AND FROM UNIXTIME ('%e')"
     }
     # The "always" module is here for debugging purposes. Each
     # instance simply returns the same result, always, without
     # doing anything.
     always fail {
           rcode = fail
     always reject {
           rcode = reject
     always ok {
```

```
rcode = ok
                           simulcount = 0
                           mpp = no
              }
                     The 'expression' module currently has no configuration.
                     This module is useful only for 'xlat'. To use it,
                    put 'exec' into the 'instantiate' section. You can then
                     do dynamic translation of attributes like:
                    Attribute-Name = \ensuremath{\ ^\circ}\ensuremath{\ }\ensuremath{\ }
                   The value of the attribute will be replaced with the
output
              # of the program which is executed. Due to RADIUS protocol
                   limitations, any output over 253 bytes will be ignored.
             expr {
             }
                    The 'digest' module currently has no configuration.
                     "Digest" authentication against a Cisco SIP server.
                    See 'doc/rfc/draft-sterman-aaa-sip-00.txt' for details
                    on performing digest authentication for Cisco SIP
servers.
             digest {
              }
                    Execute external programs
                    This module is useful only for 'xlat'. To use it,
                    put 'exec' into the 'instantiate' section. You can then
                    do dynamic translation of attributes like:
                   Attribute-Name = `%{exec:/path/to/program args}`
                   The value of the attribute will be replaced with the
output
                    of the program which is executed. Due to RADIUS protocol
                     limitations, any output over 253 bytes will be ignored.
                   The RADIUS attributes from the user request will be
placed
              # into environment variables of the executed program, as
                     described in 'doc/variables.txt'
             exec {
                           wait = yes
                           input pairs = request
```

```
}
       This is a more general example of the execute module.
        This one is called "echo".
       Attribute-Name = `%{echo:/path/to/program args}`
       If you wish to execute an external program in more than
       one section (e.g. 'authorize', 'pre proxy', etc), then it
        is probably best to define a different instance of the
        'exec' module for every section.
     exec echo {
             Wait for the program to finish.
             If we do NOT wait, then the program is "fire and
             forget", and any output attributes from it are
ignored.
             If we are looking for the program to output
             attributes, and want to add those attributes to the
             request, then we MUST wait for the program to
             finish, and therefore set 'wait=yes'
          # allowed values: {no, yes}
          wait = yes
             The name of the program to execute, and it's
             arguments. Dynamic translation is done on this
             field, so things like the following example will
             work.
          program = "/bin/echo %{User-Name}"
             The attributes which are placed into the
             environment variables for the program.
             Allowed values are:
               request
                                attributes from the request
                                attributes from the configuration
               config
items list
                          attributes from the reply
                reply
                proxy-request attributes from the proxy request
               proxy-reply attributes from the proxy reply
             Note that some attributes may not exist at some
             stages. e.g. There may be no proxy-reply
             attributes if this module is used in the
```

```
'authorize' section.
          input pairs = request
             Where to place the output attributes (if any) from
             the executed program. The values allowed, and the
             restrictions as to availability, are the same as
             for the input pairs.
          output pairs = reply
             When to execute the program. If the packet
             type does NOT match what's listed here, then
             the module does NOT execute the program.
             For a list of allowed packet types, see
             the 'dictionary' file, and look for VALUEs
             of the Packet-Type attribute.
             By default, the module executes on ANY packet.
             Un-comment out the following line to tell the
             module to execute only if an Access-Accept is
             being sent to the NAS.
          #packet type = Access-Accept
     }
     # Do server side ip pool management. Should be added in
post-auth and
        accounting sections.
        The module also requires the existance of the Pool-Name
     # attribute. That way the administrator can add the Pool-
Name
     # attribute in the user profiles and use different pools
       for different users. The Pool-Name attribute is a *check*
item not
     # a reply item.
     # Example:
     # radiusd.conf: ippool students { [...] }
     # users file : DEFAULT Group == students, Pool-Name :=
"students"
     # ****** IF YOU CHANGE THE RANGE PARAMETERS YOU MUST
     # ****** THEN ERASE THE DB FILES
*****
     ippool main pool {
           # range-start, range-stop: The start and end ip
```

```
# addresses for the ip pool
          range-start = 192.168.1.1
          range-stop = 192.168.3.254
           # netmask: The network mask used for the ip's
          netmask = 255.255.255.0
          # cache-size: The gdbm cache size for the db
           # files. Should be equal to the number of ip's
           # available in the ip pool
          cache-size = 800
           # session-db: The main db file used to allocate ip's
to clients
          session-db = ${raddbdir}/db.ippool
           # ip-index: Helper db index file used in multilink
          ip-index = ${raddbdir}/db.ipindex
           # override: Will this ippool override a Framed-IP-
Address already set
          override = no
           # maximum-timeout: If not zero specifies the maximum
time in seconds an
           # entry may be active. Default: 0
          maximum-timeout = 0
     # $INCLUDE ${confdir}/sqlippool.conf
     # OTP token support. Not included by default.
     # $INCLUDE ${confdir}/otp.conf
}
# Instantiation
  This section orders the loading of the modules. Modules
  listed here will get loaded BEFORE the later sections like
  authorize, authenticate, etc. get examined.
  This section is not strictly needed. When a section like
  authorize refers to a module, it's automatically loaded and
  initialized. However, some modules may not be listed in any
  of the following sections, so they can be listed here.
# Also, listing modules here ensures that you have control over
  the order in which they are initalized. If one module needs
  something defined by another module, you can list them in
order
  here, and ensure that the configuration will be OK.
instantiate {
```

```
# Allows the execution of external scripts.
     # The entire command line (and output) must fit into 253
bytes.
     # e.g. Framed-Pool = `%{exec:/bin/echo foo}`
     exec
        The expression module doesn't do authorization,
        authentication, or accounting. It only does dynamic
       translation, of the form:
          Session-Timeout = `%{expr:2 + 3}`
        So the module needs to be instantiated, but CANNOT be
        listed in any other section. See 'doc/rlm expr' for
        more information.
     expr
     # We add the counter module here so that it registers
     # the check-name attribute before any module which sets
     # it
     daily
#
  Authorization. First preprocess (hints and huntgroups files),
  then realms, and finally look in the "users" file.
  The order of the realm modules will determine the order that
  we try to find a matching realm.
# Make *sure* that 'preprocess' comes before any realm if you
  need to setup hints for the remote radius server
authorize {
     #
       The preprocess module takes care of sanitizing some
bizarre
     # attributes in the request, and turning them into
attributes
     # which are more standard.
     # It takes care of processing the 'raddb/hints' and the
       'raddb/huntgroups' files.
     # It also adds the %{Client-IP-Address} attribute to the
request.
     preprocess
     # If you want to have a log of authentication requests,
     # un-comment the following line, and the 'detail auth log'
```

```
# section, above.
     auth log
     attr filter
     # The chap module will set 'Auth-Type := CHAP' if we are
     # handling a CHAP request and Auth-Type has not already
been set
     chap
     # If the users are logging in with an MS-CHAP-Challenge
       attribute for authentication, the mschap module will find
     # the MS-CHAP-Challenge attribute, and add 'Auth-Type :=
MS-CHAP'
     # to the request, which will cause the server to then use
     # the mschap module for authentication.
     mschap
     # If you have a Cisco SIP server authenticating against
     # FreeRADIUS, uncomment the following line, and the
'digest'
     # line in the 'authenticate' section.
     digest
     # Look for IPASS style 'realm/', and if not found, look for
       '@realm', and decide whether or not to proxy, based on
     # that.
     IPASS
     # If you are using multiple kinds of realms, you probably
     # want to set "ignore null = yes" for all of them.
     # Otherwise, when the first style of realm doesn't match,
       the other styles won't be checked.
     suffix
     ntdomain
       This module takes care of EAP-MD5, EAP-TLS, and EAP-LEAP
       authentication.
     # It also sets the EAP-Type attribute in the request
     # attribute list to the EAP type from the packet.
     eap
     # Read the 'users' file
     files
```

```
# Look in an SQL database. The schema of the database
     # is meant to mirror the "users" file.
     # See "Authorization Queries" in sql.conf
     sql
     # If you are using /etc/smbpasswd, and are also doing
     # mschap authentication, the un-comment this line, and
       configure the 'etc smbpasswd' module, above.
     etc smbpasswd
     # The ldap module will set Auth-Type to LDAP if it has not
       already been set
#
     ldap
     # Enforce daily limits on time spent logged in.
     daily
     # Use the checkval module
     checkval
 Authentication.
  This section lists which modules are available for
authentication.
# Note that it does NOT mean 'try each module in order'. It
means
# that a module from the 'authorize' section adds a
configuration
# attribute 'Auth-Type := FOO'. That authentication type is
then
  used to pick the apropriate module from the list below.
# In general, you SHOULD NOT set the Auth-Type attribute. The
server
  will figure it out on its own, and will do the right thing.
The
# most common side effect of erroneously setting the Auth-Type
  attribute is that one authentication method will work, but the
  others will not.
  The common reasons to set the Auth-Type attribute by hand
   is to either forcibly reject the user, or forcibly accept him.
authenticate {
```

```
# PAP authentication, when a back-end database listed
     # in the 'authorize' section supplies a password. The
     # password can be clear-text, or encrypted.
     Auth-Type PAP {
          pap
     # Most people want CHAP authentication
       A back-end database listed in the 'authorize' section
     # MUST supply a CLEAR TEXT password. Encrypted passwords
     # won't work.
     Auth-Type CHAP {
          chap
     # MSCHAP authentication.
     Auth-Type MS-CHAP {
          mschap
     }
     # If you have a Cisco SIP server authenticating against
     # FreeRADIUS, uncomment the following line, and the
'digest'
     # line in the 'authorize' section.
     digest
     # Pluggable Authentication Modules.
#
     pam
     # See 'man getpwent' for information on how the 'unix'
     # module checks the users password. Note that packets
       containing CHAP-Password attributes CANNOT be
authenticated
     # against /etc/passwd! See the FAQ for details.
     unix
     # Uncomment it if you want to use ldap for authentication
     # Note that this means "check plain-text password against
     # the ldap database", which means that EAP won't work,
     # as it does not supply a plain-text password.
     Auth-Type LDAP {
          ldap
       Allow EAP authentication.
```

```
eap
  Pre-accounting. Decide which accounting type to use.
preacct {
     preprocess
     # Ensure that we have a semi-unique identifier for every
       request, and many NAS boxes are broken.
     acct_unique
     # Look for IPASS-style 'realm/', and if not found, look for
        '@realm', and decide whether or not to proxy, based on
     # that.
     # Accounting requests are generally proxied to the same
     # home server as authentication requests.
     IPASS
     suffix
     ntdomain
     # Read the 'acct users' file
     files
}
  Accounting. Log the accounting data.
accounting {
     # Create a 'detail'ed log of the packets.
     # Note that accounting requests which are proxied
     # are also logged in the detail file.
     detail
     daily
     # Update the wtmp file
     # If you don't use "radlast", you can delete this line.
     unix
     # For Simultaneous-Use tracking.
     # Due to packet losses in the network, the data here
     # may be incorrect. There is little we can do about it.
     radutmp
     sradutmp
```

```
# Return an address to the IP Pool when we see a stop
record.
     main pool
       Log traffic to an SQL database.
     # See "Accounting queries" in sql.conf
#
     sql
     # Instead of sending the query to the SQL server,
       write it into a log file.
#
     sql log
     # Cisco VoIP specific bulk accounting
     pgsql-voip
}
# Session database, used for checking Simultaneous-Use. Either
the radutmp
# or rlm sql module can handle this.
  The rlm sql module is *much* faster
session {
     radutmp
     # See "Simultaneous Use Checking Querie" in sql.conf
#
     sql
# Post-Authentication
# Once we KNOW that the user has been authenticated, there are
  additional steps we can take.
post-auth {
     # Get an address from the IP Pool.
     main pool
     # If you want to have a log of authentication replies,
     # un-comment the following line, and the 'detail reply log'
     # section, above.
     reply log
     # After authenticating the user, do another SQL query.
     # See "Authentication Logging Queries" in sql.conf
     sql
```

```
Instead of sending the query to the SQL server,
       write it into a log file.
#
     sql log
       Un-comment the following if you have set
       'edir account policy check = yes' in the ldap module sub-
section of
       the 'modules' section.
     #
     ldap
     # Access-Reject packets are sent through the REJECT sub-
section of the
     # post-auth section.
     # Uncomment the following and set the module name to the
ldap instance
     # name if you have set 'edir account policy check = yes' in
the ldap
     # module sub-section of the 'modules' section.
     Post-Auth-Type REJECT {
          insert-module-name-here
  When the server decides to proxy a request to a home server,
  the proxied request is first passed through the pre-proxy
  stage. This stage can re-write the request, or decide to
  cancel the proxy.
  Only a few modules currently have this method.
pre-proxy {
     attr rewrite
     # Uncomment the following line if you want to change
attributes
     # as defined in the preproxy users file.
     files
     # If you want to have a log of packets proxied to a home
     # server, un-comment the following line, and the
     # 'detail pre proxy log' section, above.
     pre proxy log
  When the server receives a reply to a request it proxied
```

```
to a home server, the request may be massaged here, in the
  post-proxy stage.
post-proxy {
     # If you want to have a log of replies from a home server,
     # un-comment the following line, and the 'detail
post proxy log'
     # section, above.
     post_proxy_log
     attr rewrite
     # Uncomment the following line if you want to filter
replies from
     # remote proxies based on the rules defined in the 'attrs'
file.
     attr filter
     # If you are proxying LEAP, you MUST configure the EAP
       module, and you MUST list it here, in the post-proxy
        stage.
       You MUST also use the 'nostrip' option in the 'realm'
        configuration. Otherwise, the User-Name attribute
       in the proxied request will not match the user name
     # hidden inside of the EAP packet, and the end server will
       reject the EAP request.
     eap
}
```

#### Lampiran B

## Autentikasi FreeRADIUS berhasil

```
rad recv: Access-Request packet from host 172.22.3.10:33420,
id=129, length=205
       NAS-Port-Type = Wireless-802.11
       Calling-Station-Id = "00:13:E8:0C:90:0D"
       Called-Station-Id = "wireless"
       NAS-Port-Id = "ether2"
       User-Name = "00:13:E8:0C:90:0D"
       NAS-Port = 2154823815
       Acct-Session-Id = "80700087"
       Framed-IP-Address = 10.1.0.169
       Mikrotik-Attr-10 = 0x0a010138
       CHAP-Challenge = 0x5484b26465b8dfa04e6b8838444f2fc9
       CHAP-Password = 0xbcdfae3611a602c1727441b27f18a78e64
        Service-Type = Login-User
       WISPr-Logoff-URL = "http://10.1.0.1/logout"
       NAS-Identifier = "MikroTik"
```

```
NAS-IP-Address = 172.22.3.10
  Processing the authorize section of radiusd.conf
modcall: entering group authorize for request 0
 modcall[authorize]: module "preprocess" returns ok for request
radius xlat: '/var/log/radius/radacct/172.22.3.10/auth-detail-
20090819'
rlm detail: /var/log/radius/radacct/%{Client-IP-Address}/auth-
detail-%Y%m%d expands to
/var/log/radius/radacct/172.22.3.10/auth-detail-20090819
 modcall[authorize]: module "auth log" returns ok for request 0
  rlm chap: Setting 'Auth-Type := CHAP'
 modcall[authorize]: module "chap" returns ok for request 0
 modcall[authorize]: module "mschap" returns noop for request 0
    rlm realm: No '@' in User-Name = "00:13:E8:0C:90:0D", looking
up realm NULL
    rlm realm: No such realm "NULL"
 modcall[authorize]: module "suffix" returns noop for request 0
  rlm eap: No EAP-Message, not doing EAP
  modcall[authorize]: module "eap" returns noop for request 0
    users: Matched entry 00:13:E8:0C:90:0D at line 2
 modcall[authorize]: module "files" returns ok for request 0
modcall: leaving group authorize (returns ok) for request 0
  rad check password: Found Auth-Type CHAP
auth: type "CHAP"
  Processing the authenticate section of radiusd.conf
modcall: entering group CHAP for request 0
  rlm chap: login attempt by "00:13:E8:0C:90:0D" with CHAP
password
  rlm chap: Using clear text password for user 00:13:E8:0C:90:0D
authentication.
  rlm chap: chap user 00:13:E8:0C:90:0D authenticated successfully
  modcall[authenticate]: module "chap" returns ok for request 0
modcall: leaving group CHAP (returns ok) for request 0
Login OK: [00:13:E8:0C:90:0D] (from client local port 2154823815
cli 00:13:E8:0C:90:0D)
  Processing the post-auth section of radiusd.conf
modcall: entering group post-auth for request 0
radius xlat: '/var/log/radius/radacct/172.22.3.10/reply-detail-
20090819'
rlm detail: /var/log/radius/radacct/%{Client-IP-Address}/reply-
detail-%Y%m%d expands to
/var/log/radius/radacct/172.22.3.10/reply-detail-20090819
  modcall[post-auth]: module "reply log" returns ok for request 0
modcall: leaving group post-auth (returns ok) for request 0
Sending Access-Accept of id 129 to 172.22.3.10 port 33420
Finished request 0
Going to the next request
--- Walking the entire request list ---
Waking up in 6 seconds...
--- Walking the entire request list ---
Cleaning up request 0 ID 129 with timestamp 4a8bb2c5
Nothing to do. Sleeping until we see a request.
```

### Lampiran C

#### Autentikasi FreeRADIUS gagal

```
rad recv: Access-Request packet from host 172.22.3.10:33420,
id=130, length=205
        NAS-Port-Type = Wireless-802.11
        Calling-Station-Id = "00:1E:E5:9D:64:B2"
        Called-Station-Id = "wireless"
        NAS-Port-Id = "ether2"
        User-Name = "00:1E:E5:9D:64:B2"
        NAS-Port = 2154823816
        Acct-Session-Id = "80700088"
        Framed-IP-Address = 10.1.0.189
        Mikrotik-Attr-10 = 0x0a010006
        CHAP-Challenge = 0x7a424321e7cdade16f36861873bb56c2
        CHAP-Password = 0x907c04346acd2280b8a8f0b2df4458caa7
        Service-Type = Login-User
        WISPr-Logoff-URL = "http://10.1.0.1/logout"
        NAS-Identifier = "MikroTik"
        NAS-IP-Address = 172.22.3.10
  Processing the authorize section of radiusd.conf
modcall: entering group authorize for request 0
  modcall[authorize]: module "preprocess" returns ok for request
radius xlat: '/var/log/radius/radacct/172.22.3.10/auth-detail-
20090819'
rlm detail: /var/log/radius/radacct/%{Client-IP-Address}/auth-
detail-%Y%m%d expands to
/var/log/radius/radacct/172.22.3.10/auth-detail-20090819
 modcall[authorize]: module "auth log" returns ok for request 0
  rlm chap: Setting 'Auth-Type := CHAP'
 modcall[authorize]: module "chap" returns ok for request 0
 modcall[authorize]: module "mschap" returns noop for request 0
    rlm realm: No '@' in User-Name = "00:1E:E5:9D:64:B2", looking
up realm NULL
    rlm realm: No such realm "NULL"
  modcall[authorize]: module "suffix" returns noop for request 0
  rlm eap: No EAP-Message, not doing EAP
  modcall[authorize]: module "eap" returns noop for request 0
    users: Matched entry DEFAULT at line 158
 modcall[authorize]: module "files" returns ok for request 0
modcall: leaving group authorize (returns ok) for request 0
  rad check password: Found Auth-Type CHAP
auth: type "CHAP"
  Processing the authenticate section of radiusd.conf
modcall: entering group CHAP for request 0
  rlm chap: login attempt by "00:1E:E5:9D:64:B2" with CHAP
password
  rlm chap: Could not find clear text password for user
00:1E:E5:9D:64:B2
  modcall[authenticate]: module "chap" returns invalid for
request 0
```

```
modcall: leaving group CHAP (returns invalid) for request 0
auth: Failed to validate the user.
Login incorrect (rlm chap: Clear text password not available):
[00:1E:E5:9D:64:B2] (from client local port 2154823816 cli
00:1E:E5:9D:64:B2)
Delaying request 0 for 1 seconds
Finished request 0
Going to the next request
--- Walking the entire request list ---
Waking up in 1 seconds...
--- Walking the entire request list ---
Waking up in 1 seconds...
rad recv: Access-Request packet from host 172.22.3.10:33420,
id=130, length=205
Sending Access-Reject of id 130 to 172.22.3.10 port 33420
Waking up in 1 seconds...
--- Walking the entire request list ---
Waking up in 4 seconds...
--- Walking the entire request list ---
Cleaning up request 0 ID 130 with timestamp 4a8bb492
Nothing to do. Sleeping until we see a request.
```

### Lampiran D

#### **Daftar File pada FreeRADIUS**

```
-rw-r--r 1 root root 422 Aug 19 05:46 acct users
-rw-r--r-- 1 root root 4074 Aug 19 05:46 attrs
drwxr-xr-x 3 root root 4096 Aug 19 05:46 certs
-rw-r---- 1 root root 189 Aug 19 05:46 clients
-rw-r---- 1 root root 2921 Aug 19 05:46 clients.conf
-rw-r--r-- 1 root root 929 Aug 19 05:46 dictionary
-rw-r--r-- 1 root root 9985 Aug 19 05:46 eap.conf
-rwxr-xr-x 1 root root 4620 Aug 19 05:46 example.pl
-rw-r--r-- 1 root root 2396 Aug 19 05:46 hints
-rw-r--r-- 1 root root 1604 Aug 19 05:46 huntgroups
-rw-r--r-- 1 root root 2439 Aug 19 05:46 ldap.attrmap
-rw-r--r-- 1 root root 1020 Aug 19 06:47 naslist
-rw-r---- 1 root root 856 Aug 19 05:46 naspasswd
-rw-r--r-- 1 root root 3358 Aug 19 05:46 otp.conf
-rw-r--r- 1 root root 1734 Aug 19 05:46 otppasswd.sample
-rw-r--r-- 1 root root 1039 Aug 19 05:46 preproxy users
-rw-r--r-- 1 root root 8834 Aug 19 05:46 proxy.conf
-rw-r--r-- 1 root root 66080 Aug 19 05:46 radiusd.conf
-rw-r--r-- 1 root root 187 Aug 19 05:46 realms
-rw-r--r-- 1 root root 1405 Aug 19 05:46 snmp.conf
-rw-r--r 1 root root 3329 Aug 19 05:46 sqlippool.conf
-rw-r--r-- 1 root root 7210 Aug 19 15:09 users
```

# Lampiran E

# Daftar MAC *address* yang terdaftar pada pengujian /etc/raddb/users

" "	==	User-Password	"00:1B:77:48:0A:2B"
" "	==	User-Password	"00:13:E8:0C:90:0D"
" "	==	User-Password	"00:16:76:39:05:1A"
" "	==	User-Password	"00:1E:E5:9D:64:B2"
" "	==	User-Password	"00:1B:77:55:ED:14"
" "	==	User-Password	"00:1A:73:10:69:E7"
" "	==	User-Password	"00:21:00:68:82:13"
""	==	User-Password	"00:1E:4C:AC:75:8B"