Table a45 Input data, **soccerball.bin**, for continuing to load the shell with Load Set A: the uniform external pressure. This run immediately follows the STAGS run for which the soccerball.bin file is listed in Table a44 (initial pressure load). Note that NSTRAT = -1, NPATH = 0, and NSOL = 0 (Riks continuous solution). The purpose of this "re-start" run is to determine the collapse pressure of the shell with the residual "cos(theta)" dent in it.

```
optimized imperfect shell, nonlinear theory (INDIC=3)
```

- 3, \$ INDIC=1 is bifur.buckling; INDIC=3 is nonlinear BEGIN B-1
- 1, \$ IPOST=1 means save displacements every IPOSTth step
- 0, \$ ILIST = 0 means normal batch-oriented output
- 0, \$ ICOR = 0 means projection in; 1 means not in.
- 1, \$ IMPTHE=index for imperfection theory.
- 0, \$ IOPTIM=0 means bandwith optimization will be performed
- 0, \$ IFLU =0 means no fluid interaction.
- -1 \$ ISOLVR= 0 means original solver; -1 new solver.END B-1 rec
- 0.7, \$ STLD(1) = starting load factor, System A. BEGIN C-1 rec.
- 1.000E-01, \$ STEP(1) = load factor increment, System A
- 1.000, \$ FACM(1) = maximum load factor, System A
- 0., \$ STLD(2) = starting load factor, System B
- 0., \$ STEP(2) = load factor increment, System B
- 0.0, \$ FACM(2) = maximum load factor, System B
- 0 \$ ITEMP = 0 means no thermal loads. END C-1 rec.
- 46, \$ ISTART=restart from ISTARTth load step. BEGIN D-1 rec.
- 300,\$ NSEC= number of CPU seconds before run termination
- 10,\$ NCUT = number of times step size may be cut
- -20, \$ NEWT = number of refactorings allowed
- -1,\$ NSTRAT=-1 means path length used as independent parameter 0.00010,\$ DELX=convergence tolerance
- 0. \$ WUND = 0 means initial relaxation factor =1.END D-1 rec.
- 0, 0, 0 \$ NPATH=0: Riks, NEIGS=no.of eigs, NSOL=1=discontin.ET-1