Table 86 Input file, eqellipse.bin, for STAGS for a nonlinear run in which the shell is being LOADED by uniform external pressure (Load Set A) in a restart run following the run that corresponds to the input data in the previous table. Now we can use the Riks path method (NSTRAT = -1), and the solution is no longer discontinuous, so that NSOL = 0 .

\_\_\_\_\_\_

optimized imperfect shell, nonlinear theory (INDIC=3)

- 3, \$ INDIC=1 is bifur.buckling; INDIC=3 is nonlinear BEGIN B-1
- 1, \$ IPOST=1 means save displacements every IPOSTth step
- 0, \$ ILIST = 0 means normal batch-oriented output
- 0, \$ ICOR = 0 means projection in; 1 means not in.
- 1, \$ IMPTHE=index for imperfection theory.
- 0, \$ IOPTIM=0 means bandwith optimization will be performed
- 0, \$ IFLU =0 means no fluid interaction.
- -1 \$ ISOLVR= 0 means original solver; -1 new solver.END B-1 rec
- 0.7, \$ STLD(1) = starting load factor, System A. BEGIN C-1 rec.
- 1.000E-01, \$ STEP(1) = load factor increment, System A
- 0.900E+00, \$ FACM(1) = maximum load factor, System A
- 00000.0, \$ STLD(2) = starting load factor, System B
- -000.0, \$ STEP(2) = load factor increment, System B
- 0.0, \$ FACM(2) = maximum load factor, System B
- 0 \$ ITEMP = 0 means no thermal loads. END C-1 rec.
- 45, \$ ISTART=restart from ISTARTth load step. BEGIN D-1 rec.
- 300,\$ NSEC= number of CPU seconds before run termination
- 12,\$ NCUT = number of times step size may be cut
- -20, \$ NEWT = number of refactorings allowed
- -1,\$ NSTRAT=-1 means path length used as independent parameter
- 0.00010,\$ DELX=convergence tolerance
- 0. \$ WUND = 0 means initial relaxation factor =1.END D-1 rec.
- 0, 1, 0 \$ NPATH=0: Riks, NEIGS=no.of eigs, NSOL=1 = discontin.ET-1

\_\_\_\_\_\_