Copyright 2016 Microchip Technology Inc. (www.microchip.com)

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at

http://www.apache.org/licenses/LICENSE-2.0

LATDbits.LATD7=1;

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

```
To request to license the code under the MLA license (www.microchip.com/mla license),
please contact mla licensing@microchip.com
#include "system.h"
#include <stdint.h>
#include <string.h>
#include <stddef.h>
#include "usb.h"
#include "drv spi.h"
#include "app led usb status.h"
#include "app device cdc basic.h"
#include "usb config.h"
static bool buttonPressed;
static char buttonMessage[] = "Button pressed.\r\n";
static uint8 t readBuffer[CDC DATA OUT EP SIZE];
static uint8 t writeBuffer[CDC DATA IN EP SIZE];
static char Latch[3];
* Function: void enable latch();
* Overview: Brings the pin related to the LE signal at a high level in
* order to generate a pulse.
* PreCondition: None
* Input: None
* Output: None
************************
void enable latch(){
 LATDbits.LATD7=1; //LE=1
```

```
}
* Function: void disable latch();
* Overview: Brings the pin related to the LE signal at a low level.
* PreCondition: None
* Input: None
* Output: None
*************************
void disable_latch(){
 LATDbits.LATD7=0; //LE=0
 LATDbits.LATD7=0;
* Function: void initialize_SPI();
* Overview: Initializes the SPI communication to send data to the
* PLL (signals LE, DATA and CLK).
* PreCondition: None
* Input: None
* Output: None
************************
void initialize_SPI(){
 TRISBbits.TRISB4=0; //Output. CLK
 TRISCbits.TRISC7=0; //Output. DATA
 TRISDbits.TRISD7=0; //Output. LE (Latch Enable)
 disable latch(); //Default low state for the LE signal
 DRV_SPI_INIT_DATA spiInitData = {1, 0, 1, SPI_BUS_MODE 0, 0}; //The structure that defines
                             //the SPI channel's operation
 DRV SPI Initialize(&spiInitData); //Initializes the SPI instance specified by the channel
                 //of the initialization structure.
}
* Function: void APP DeviceCDCBasicDemoInitialize(void);
* Overview: Initializes the demo code.
* PreCondition: None
* Input: None
* Output: None
       ************************
void APP_DeviceCDCBasicDemoInitialize()
{
 line coding.bCharFormat = 0;
```

```
line coding.bDataBits = 8;
  line coding.bParityType = 0;
  line coding.dwDTERate = 9600;
  buttonPressed = false;
  initialize SPI();
}
* Function: void APP DeviceCDCBasicDemoTasks(void);
* Overview: Keeps the demo running.
* PreCondition: The demo should have been initialized and started via
* the APP DeviceCDCBasicDemoInitialize() and APP DeviceCDCBasicDemoStart() demos
* respectively.
* Input: None
* Output: None
**************************
void APP DeviceCDCBasicDemoTasks()
{
  /* If the USB device isn't configured yet, we can't really do anything
  * else since we don't have a host to talk to. So jump back to the
  * top of the while loop. */
  if( USBGetDeviceState() < CONFIGURED STATE )</pre>
    return;
  /* If we are currently suspended, then we need to see if we need to
  * issue a remote wakeup. In either case, we shouldn't process any
  * keyboard commands since we aren't currently communicating to the host
  * thus just continue back to the start of the while loop. */
  if( USBIsDeviceSuspended()== true )
    return;
  /* If the user has pressed the button associated with this demo, then we
  * are going to send a "Button Pressed" message to the terminal.
  if(BUTTON IsPressed(BUTTON DEVICE CDC BASIC DEMO) == true)
    /* Make sure that we only send the message once per button press and
    * not continuously as the button is held.
    if(buttonPressed == false)
      /* Make sure that the CDC driver is ready for a transmission.
      if(mUSBUSARTIsTxTrfReady() == true)
        putrsUSBUSART(buttonMessage);
        buttonPressed = true;
    }
```

```
else
{
  /* If the button is released, we can then allow a new message to be
  * sent the next time the button is pressed.
  buttonPressed = false;
/* Check to see if there is a transmission in progress, if there isn't, then
* we can see about performing an echo response to data received.
if( USBUSARTIsTxTrfReady() == true)
  uint8 ti;
  uint8 t numBytesRead;
  /* We retrieve the 3 bytes sent on the USB bus.
  * readBuffer: buffer containing the data read on the USBUSART bus.
  * numBytesRead : number of bytes read.
  numBytesRead = getsUSBUSART(readBuffer, 3);
  /* PLL initialization: Initialization Latch Method
  * 1. Apply VDD.
  * 2. Program the Initialization Latch (with COUNTER RESET=0).
  * 3. Do a Function Latch load (with COUNTER RESET=0).
  * 4. Do an R Latch load.
  * 5. Do an AB Latch load.
  disable latch(); //Make sure that the LE signal is low before starting
              //a transfer.
  /* As soon as we receive something ... */
  if(numBytesRead >0){
    for(i=0;i<3;i++)
       Latch[i] = readBuffer[i];
                                   //Store the 3 bytes read in an array
    disable latch();
                                //LE in low state during data transfer
    DRV SPI PutBuffer (1, Latch, 3); //Send data buffer on SPI bus channel 1
    enable latch();
                                //LE in high state to finalize transfer
    disable latch();
                                //Make sure LE goes low again
  }
  /* For every byte that was read... */
  for(i=0; i<numBytesRead; i++)
  {
    switch(readBuffer[i])
       /* If we receive new line or line feed commands, just echo
        * them direct.
       */
       case 0x0A:
       case 0x0D:
         writeBuffer[i] = readBuffer[i];
       /* If we receive something else, then echo it plus one
        * so that if we receive 'a', we echo 'b' so that the
        * user knows that it isn't the echo enabled on their
```

```
* terminal program.
*/
default:
    writeBuffer[i] = readBuffer[i] + 1;
    break;
}

if(numBytesRead > 0)
{
    /* After processing all of the received data, we need to send out
    * the "echo" data now.
    */
    putUSBUSART(writeBuffer,numBytesRead);
}

CDCTxService();
```