EXAPILOT REWORK PROCESS N-1501

จุดประสงค์ในการจัดทำ Exapilot rework process N-1501


- 1.เพื่อลด Work Load BM
- 2.เพื่อความต่อเนื่องของการ Rework
- 3.ลด Loss พลังงานจากการหยุด Rework
- 4.เพื่อให้ Rework ได้ตามแผนงาน







BPA PLANT LAY OUT



Area Equipment
N-1501 Rework


1 พื้นที่ Rework

2 พื้นที่ควบคุม CCR

PROCESS AREA REWORK


ห้องควบคุม











อุปกรณ์














N-1501 REWORK VESSEL

N-1501 Rework vessel คือ อุปกรณ์ที่ทำหน้าที่รับเม็ด BPA จาก Rework Hopper (TK-1551) หลังจากทำการเตรียมสารละลายที่ N-1501 (Rework vessel) แล้วจะต้อง ส่งของไปยัง TK-1251 (Reactor Blowdown Tank) เพื่อนำกลับมาใช้ใน กระบวนการผลิตอีกครั้ง โดยหน้าที่หลักคือ

- นำ BPA ที่ไม่ได้คุณภาพกลับมาเข้ากระบวนการผลิตอีกครั้ง
- ทำหน้าที่ละลายเม็ด BPA เพื่อเตรียม start up การผลิตอีกครั้ง



L-1503

Bigbag

รูปแสดงกระบวนการเตรียม Rework BPA ที่ N-1501

STEP WORKING FOR EXAPILOT REWORK PROCESS N-1501

Item	Task	Status	Date	RP
1	step by step for rework process write down	completed	15-07-19	Team
			09-09-19	Team
2	Find suitable time for last batch condition checking	completed	16-09-19	PW
3	Check SQ-1511 interface	completed	16-09-19	PW
4	Exapilot procedure design	completed	16-09-19	PW
5	Exapilot off line test	completed	16-09-19	PW
6	New DCS tag name define	completed	17-09-19	PW
7	Build DCS graphic	completed	17-09-19	PW
8	Progam review	completed	19-09-19	Team
9	Revise program	completed	20-09-19	PW
10	MOC proposal	completed	17-10-19	Shift B
11	MOC part 2 complete	completed	22-11-19	Shift B
12	Download Exapilot to DCS	completed	02-12-19	Team
13	Test in trial mode	completed	11-05-20	Team
14	Exapilot WI	completed	15-06-20	Shift B
15	Actual test run	completed	18-08-20	Team

STEP FOR ACTUAL TEST RUN

Exapilot BPA rework

Step 1: Phenol make up 34% level of N-1501

Step 2: Condition check before start rework

Step 3: Run sequence SQ-1511 (Load BPA)

Step 4: Level >=44% stop sequence SQ-1511 (Stop load BPA)

Step 5: Transfer rework BPA until level<=10%

Step 6: repeat step 1 until detect last batch


Step 7: Fill Phenol to level 30%

Step 8: Flush line & keep level 25%

Step 9: Alarm finish rework



ACTUAL TEST RUN REPORT



ACTUAL TEST RUN REPORT

Debug program

- -Solve SQ-1511 timer counting lag time by add timer 10 sec Exapilot before checking SQ-1511 running and stopping
- -Remove step to check HS-1511 because valve malfunction and cause Exapilot program pause
- -Add function reset @LB=0 when start new rework

Conclusion


- -Exapilot working normal, the program can complete BPA rework by follow step by step in program
- -Program can detect last batch for rework and go to step 7-8 until finish job
- -Operator can set %level each step via DCS graphic
- -We can reduce operator work load and operate with plant reliability

SEQUENCE REWORK PROCESS N-1501 (Run Sequence)













EXAPILOT REWORK PROCESS N-1501 (USED EXAPILOT)











SEQUENCE REWORK PROCESS N-1501 (Run Sequence)



EXAPILOT REWORK PROCESS N-1501 (Used Exapilot)



สรุปผลในการจัดทำ Exapilot rework process N-1501

จากการเปรียบเทียบการ Start Sequence BM จะต้องเข้าไป action สั่งงาน 18 ครั้ง ครั้งละ 5 นาที รวมได้ 90 นาที ใน 5 Batch (35 ton BPA) ในการ Action ทำงานแต่ละขั้นตอน แต่เมื่อใช้ Exapilot ทำงาน ช่วยทำให้ BM เข้าไป Action สั่งงาน เหลือแค่ 2 ครั้ง รวมได้ 10 นาที ทำให้ Work load BM ลดลง = 80 นาที ต่อการ Re-Process 1 ครั้ง (35 ton BPA)

