

Thesis submitted to obtain the title of Doctor of Philosophy

Doctoral School of Engineering Science Field: Computer Science

# Real-time Soft Tissue Modelling on GPU for Medical Simulation

Prepared by Olivier COMAS at INRIA Lille, SHAMAN Team and CSIRO ICT Brisbane, AEHRC

DRAFT - Thu  $29^{\rm th}$  of July 2010 at 16:01

#### Jury:

Reviewers: Bernard - INRIA (Shaman)

Bornard - INRIA (Shaman)

Bernard - INRIA (Shaman) Stéphane COTIN - INRIA (Shaman)

Advisor:Stéphane COTIN-INRIA (Shaman)President:Bernard-INRIA (Shaman)Examinators:Bernard-INRIA (Shaman)

Bernard - INRIA (Shaman)

Orak Jersjon

# Contents

C	contents							
Ι	Int	roduct	tion	1				
1	Me	Medical simulation						
	1.1	Genera	al context and goal: medical training, patient-specific planning					
		_	er-operative guidance	3				
	1.2	Challe	enges (trade-off between accuracy and real-time)	3				
<b>2</b>	Bac	kgrour	nd in continuum mechanics for soft-tissue modelling	5				
	2.1	Introd	$\operatorname{uction}$	6				
	2.2	Descri	ption of motion	6				
		2.2.1	Lagrangian description	7				
		2.2.2	Eulerian description	7				
		2.2.3	Displacement field	8				
	2.3	Analys	sis of deformation	8				
		2.3.1	Deformation gradient tensor	8				
		2.3.2	Change of volume	9				
		2.3.3	Change of surface	10				
		2.3.4	Volumetric and isochoric components	10				
	2.4	Strain	measures	11				
		2.4.1		11				
		2.4.2	Green strain tensor	11				
		2.4.3	Cauchy and Euler tensor	12				
		2.4.4	Principal strains and invariants	13				
		2.4.5	Infinitesimal strain tensor	13				
	2.5	Stress		14				
		2.5.1	J	14				
		2.5.2		16				
		2.5.3		16				
		2.5.4	1	17				
	2.6		•	17				
		2.6.1	·	18				
		2.6.2	<u> </u>	18				
		2.6.3	1	19				
		2.6.4	1	20				
		2.6.5		20				
		2.6.6		21				
	2.7	Tissue	characterisation	22				

ii Contents

3	Main principles of Finite Element Method (or how to solve equa-					
	tions of continuum mechanics from previous section) 2	٠				
	3.1 Discretisation	) (				
	3.2 Derivation of element equations	) (				
	3.3 Assembly of element equations					
	3.4 Solution of global problem					
	or solution of Stocker broaden					
II	Solid organs modelling 2					
4	State of art: FEM 2	7				
5	$\begin{array}{llllllllllllllllllllllllllllllllllll$	į				
	5.1 Differences with classic FEM and reasons of its efficiency	)(				
	5.2 Visco-elasticity and anisotropy added (MICCAI 2008; MedIA 2009)					
6	GPU implementation of TLED 3	[				
	6.1 What is GPGPU	;				
	6.2 Re-formulation of the algorithm for its Cg implementation 3	[				
	6.3 CUDA implementation/optimisations (ISBMS 2008a)	;]				
7	Implementation in SOFA	:				
	7.1 Presentation of SOFA project and architecture					
	7.2 Implementation in SOFA and TLED released in open-source 3					
II	I Hollow organs modelling 3	1				
8	State of art: hollow structures 3					
	8.1 Non-physic approaches (computer graphics stuff)	, 7				
	8.2 Physically accurate approches (plates/shells)	, ,				
9	Why a shell FEM? Colonoscopy simulator project 3					
	v	36				
	9.2 Mass-spring model for colon implemented on GPU (ISBMS 2008b) . 3	36				
10	More accurate: a co-rotational triangular shell model (ISBMS 2010) $4$	1				
	10.1 Model description					
	10.1 Model description					
	10.3 Application to implant deployment simulation in cataract surgery 4	: J				
11	'Shell meshing' technique (MICCAI 2010)	•				
	11.1 State of art: reconstruction/simplification					
	11.2 Our method	۱:				

Contents		
12 Applications to medical simulation		
12.1 Nice medical stuff to show	45	
12.2 Interaction solid/hollow organs	45	
IV Conclusion	47	
References		

Orall Jersjon

Orak Jersjon

# Part I

Introduction

Otall.

Orak Jersjon

# Chapter 1

## MEDICAL SIMULATION

- 1.1 General context and goal: medical training, patientspecific planning and per-operative guidance
- 1.2 Challenges (trade-off between accuracy and real-time)

Orak Jersjon

# BACKGROUND IN CONTINUUM MECHANICS FOR SOFT-TISSUE MODELLING

As seen in the previous chapter, realistic modelling of organ deformation is a challenging research field that opens the door to new clinical applications including: medical training and rehearsal systems, patient-specific planning of surgical procedures and per-operative guidance based on simulation. In all these cases the clinician needs fast updates of the deformation model to obtain a real-time display of the computed deformations. If for medical training devices the haptic feedback from touching organs merely needs to feel real, the accuracy of the information provided to the clinician in the cases of planning or per-operative guidance is crucial. Therefore, a substantial comprehension of the mechanics involved and a knowledge of the physical properties of anatomical structures are both mandatory in our quest to realistically model the deformation of organs. This chapter will start by introducing the main concepts of continuum mechanics that are fundamental to study the mechanical response of organs. It will then present mathematical models able to describe the different mechanical aspects of materials and briefly discuss the mechanical characterisation of tissues.

#### 2.1 Introduction

In our everyday life, matter appears smooth and continuous: from the wood used to build your desk to the water you drink. But this is just illusion. The concept that matter is composed of discrete units has been around for millennia. In fact, we know with certainty that our world is composed of microscopic atoms and molecules separated by empty space since the beginning of the twentieth century (Lautrup, 2005). However, certain physical phenomena can be predicted with theories that pay no attention to the molecular structure of materials. Consider for instance the deformation of the horizontal board of a bookshelf under the weight of books. The bending of the shelf can be modelled without considering its molecular composition. The branch of physics in which materials are treated as continuous is known as continuum mechanics. Continuum mechanics studies the response of materials to different loading conditions. In this theory, matter is assumed to exist as a continuum, meaning that the matter in the body is continuously distributed and fills the entire region of space it occupies (Lai et al., 1996). This assumption is generally valid if the length scales of interest are large compared with the length scales of discrete molecular structure, but whether the approximation of continuum mechanics is actually justified in a given situation is merely a matter of experimental test.

Modelling anatomical structures requires an understanding of the deformation and stresses caused by the different interactions that occur during medical procedures. A sufficient knowledge of continuum mechanics is therefore essential to follow the rest of this manuscript. Continuum mechanics can be divided into two main parts: general principles common to all media (analysis of deformation, strain and stress concepts) and constitutive equations defining idealised materials. This chapter will not only deal with those two aspects but will also discuss the different aspects of the mechanical behaviour that we find in anatomical structures. Note that this chapter will mostly follow the notation used by Bonnet and Wood (1997) and Reddy (2007). The interested reader may refer to these books for more details.

#### 2.2 Description of motion

Let us consider a body  $\boldsymbol{B}$  of known geometry in a three-dimensional Euclidian space  $\mathbb{R}^3$ . For a given geometry and loading,  $\boldsymbol{B}$  will undergo a set of macroscopic changes which is called *deformation*. The region of space occupied by the body at a given time t is termed a *configuration*. A change in the configuration of a continuum body results in a displacement. The displacement of a body has two components: a rigid-body displacement and a deformation. A rigid-body displacement consists of a simultaneous translation and rotation of the body without changing its shape or size. Deformation implies the change in shape and/or size of the body from an initial configuration noted  $\kappa_0$  to a new configuration  $\kappa$  called the *current* or *deformed configuration*.

Let us now consider a given particle of the body that we call X. What we will call particle in the following is in fact an infinitesimal volume of material. We denote

the position it occupies in the initial configuration  $\mathbf{X}$  and note its position in the deformed configuration  $\mathbf{x}$ , both expressed in the chosen frame of reference. The mapping  $\chi$  defined as the following:

$$\chi: \mathbf{B}_{\kappa_0} \to \mathbf{B}_{\kappa} \tag{2.1}$$

is called the deforming mapping of the body B from  $\kappa_0$  to  $\kappa$ . When analysing the deformation of a continuous body, it is necessary to describe the evolution of configurations through time. Its mathematical description follows one of the two approaches: the material description or the spatial description. The material description is known as Lagrangian description whereas the spatial description is called Eulerian description. These two approaches are detailed next.

#### 2.2.1 Lagrangian description

In the Lagrangian description, the position and physical properties of the particles are referred to a reference configuration  $\kappa_R$ , often chosen to be the undeformed configuration  $\kappa_0$ . Thus, the current coordinates ( $\mathbf{x} \in \kappa$ ) are expressed in terms of the reference coordinates ( $\mathbf{X} \in \kappa_0$ ):

$$\mathbf{x} = \chi(\mathbf{X}, t), \quad \chi(\mathbf{X}, 0) = \mathbf{X}, \tag{2.2}$$

and the variation of a typical variable  $\phi$  over the body is described with respect to the coordinates **X** and time t:

$$\phi = \phi(\mathbf{X}, t). \tag{2.3}$$

For a fixed value of  $\mathbf{X} \in \kappa_0$ ,  $\phi(\mathbf{X}, t)$  gives the value of  $\phi$  at time t associated with the fixed particle X whose position in the reference configuration is  $\mathbf{X}$ . We note that a change in time t implies that the same particle X has a different value  $\phi$ . Thus, the Lagrangian description focuses its attention on the particles of the continuous body and it is usually used in solid mechanics.

#### 2.2.2 Eulerian description

Rather than following the particles, the Eulerian description observes the changes at fixed locations. In the Eulerian description, the motion is this time referred to the current configuration  $\kappa$  and  $\phi$  is described with respect to the current position  $(\mathbf{x} \in \kappa)$ :

$$\phi = \phi(\mathbf{x}, t), \quad \mathbf{X} = \mathbf{X}(\mathbf{x}, t). \tag{2.4}$$

For a fixed value of  $\mathbf{x} \in \kappa$ ,  $\phi(\mathbf{x}, t)$  gives the value of  $\phi$  associated with the particle occupying the position  $\mathbf{x} \in \kappa$ , which may very well be a different particle for each new time t. Because a change in time t implies that a different value  $\phi$  is observed at the same spatial location  $\mathbf{x} \in \kappa$ , now probably occupied by a different particle, the Eulerian description is focused on a spatial position. This approach is convenient for the study of fluid flow where the kinematic property of greatest interest is the

rate at which change is taking place rather than the shape of the body of fluid at a reference time (Spencer, 1980). Because we are only interested in the study of solid bodies, the Lagrangian description will be used in the rest of the text.

#### 2.2.3 Displacement field

The displacement  $\mathbf{u}$  of a particle X is called *displacement vector* and its expression in the Lagrangian description is given by the following:

$$\mathbf{u}(\mathbf{X},t) = \mathbf{x}(\mathbf{X},t) - \mathbf{X}.\tag{2.5}$$

A displacement field is a vector field of all displacement vectors for all particles in the body, which relates the deformed configuration  $\kappa$  with the undeformed configuration  $\kappa_0$ . Indeed if the displacement field is known, we can construct the current configuration  $\kappa$  from the undeformed configuration  $\kappa_0$ :  $\chi(\mathbf{X},t) = \mathbf{X} + \mathbf{u}(\mathbf{X})$ .

#### 2.3 Analysis of deformation

#### 2.3.1 Deformation gradient tensor

The displacement field tells us how a point displaces from the reference to the deformed configuration. However, we would also like to know how a piece of material is stretched and rotated as the body moves from the reference to the deformed configuration. Since the length of a material line  $d\mathbf{X}$  can change when going to the deformed configuration as well as its orientation, we can say that  $d\mathbf{X}$  deforms into  $d\mathbf{x}$ . The question then becomes how to relate  $d\mathbf{x}$  in the deformed configuration with  $d\mathbf{X}$  of the reference configuration.

Consider two particles  $P_1$  and  $P_2$  in a continuous body separated by an infinitesimal distance  $d\mathbf{X}$ :

$$d\mathbf{X} = \mathbf{X}_{P_2} - \mathbf{X}_{P_1}. (2.6)$$

After deformation, the two particles have deformed to their current positions given by the mapping  $\chi$  (2.1) as:

$$\mathbf{x}_{P_1} = \chi(\mathbf{X}_{P_1}, t) \quad \text{and} \quad \mathbf{x}_{P_2} = \chi(\mathbf{X}_{P_2}, t). \tag{2.7}$$

Using (2.6) the distance  $d\mathbf{x}$  between  $P_1$  and  $P_2$  can then be expressed as:

$$d\mathbf{x} = \mathbf{x}_{P_2} - \mathbf{x}_{P_1} = \chi(\mathbf{X}_{P_1} + d\mathbf{X}, t) - \chi(\mathbf{X}_{P_1}, t). \tag{2.8}$$

The deformation gradient  $\mathbf{F}$  can be defined as:

$$\mathbf{F} = \frac{\partial \chi}{\partial \mathbf{X}} \tag{2.9}$$

and the vector  $d\mathbf{x}$  can then be obtained in terms of  $d\mathbf{X}$  as:

$$d\mathbf{x} = \mathbf{F} \, d\mathbf{X}.\tag{2.10}$$

Note that **F** transforms vectors from the reference configuration into vectors in the current configuration and is therefore a second-order tensor.

Knowing that  $\chi(\mathbf{X}, t)$  is of course  $\mathbf{x}$ , the deformation gradient may also be written as:

$$\mathbf{F} = \frac{\partial \mathbf{x}}{\partial \mathbf{X}} = \nabla_0 \mathbf{x} = \nabla_0 \mathbf{u} + \mathbf{I}, \tag{2.11}$$

where  $\nabla_0$  is the gradient operator with respect to **X** and **u** the displacement vector. In indicial notation in a Cartesian coordinate system, (2.11) can be explicited as:

$$[F] = \begin{bmatrix} \frac{\partial \mathbf{x}_1}{\partial \mathbf{X}_1} & \frac{\partial \mathbf{x}_1}{\partial \mathbf{X}_2} & \frac{\partial \mathbf{x}_1}{\partial \mathbf{X}_3} \\ \frac{\partial \mathbf{x}_2}{\partial \mathbf{X}_1} & \frac{\partial \mathbf{x}_2}{\partial \mathbf{X}_2} & \frac{\partial \mathbf{x}_2}{\partial \mathbf{X}_3} \\ \frac{\partial \mathbf{x}_3}{\partial \mathbf{X}_1} & \frac{\partial \mathbf{x}_3}{\partial \mathbf{X}_2} & \frac{\partial \mathbf{x}_3}{\partial \mathbf{X}_3} \end{bmatrix}.$$
 (2.12)

#### 2.3.2 Change of volume

At this point, we have seen how a deformation can affect a vector. We will now look into its effect on volumes. Our motivation comes from the need to write global equilibrium statements that involve integrals over volumes. We can define volume elements in the reference and deformed configurations. Consider three non-coplanar line elements  $d\mathbf{X}^{(1)}$ ,  $d\mathbf{X}^{(2)}$  and  $d\mathbf{X}^{(3)}$  forming a parallelepiped in the reference configuration TODO: Add figure with all notations . The three vectors after deformation  $d\mathbf{x}^{(1)}$ ,  $d\mathbf{x}^{(2)}$  and  $d\mathbf{x}^{(3)}$  can be obtained with:

$$d\mathbf{x}^{(i)} = \mathbf{F} d\mathbf{X}^{(i)}, \quad i = 1, 2, 3.$$
 (2.13)

The volume of the parallelepiped that we will note dV can be calculated using the triple product between the three vectors:

$$dV = d\mathbf{X}^{(1)} \cdot d\mathbf{X}^{(2)} \times d\mathbf{X}^{(3)} = (\hat{\mathbf{N}}_1 \cdot \hat{\mathbf{N}}_2 \times \hat{\mathbf{N}}_3) dX^{(1)} dX^{(2)} dX^{(3)}$$
  
=  $dX^{(1)} dX^{(2)} dX^{(3)}$ , (2.14)

where  $\hat{\mathbf{N}}_i$  denote the unit vector along  $d\mathbf{X}^i$ . The corresponding volume in the deformed configuration is given by:

$$dv = d\mathbf{x}^{(1)} \cdot d\mathbf{x}^{(2)} \times d\mathbf{x}^{(3)}$$

$$= (\mathbf{F} \cdot \hat{\mathbf{N}}_1) \cdot (\mathbf{F} \cdot \hat{\mathbf{N}}_2) \times (\mathbf{F} \cdot \hat{\mathbf{N}}_3) dX^{(1)} dX^{(2)} dX^{(3)} \quad \text{by (2.13)}$$

$$= \det \mathbf{F} dX^{(1)} dX^{(2)} dX^{(3)}. \tag{2.15}$$

The determinant of **F** is called the *Jacobian* and it is denoted by  $J = \det \mathbf{F}$ . And we have:

$$dv = JdV. (2.16)$$

Thus, J has the physical meaning of being the local ratio of current to reference volume of a material volume element.

#### 2.3.3 Change of surface

For similar reasons, let us find the relation between an element of area in the reference configuration  $d\mathbf{A}$  which becomes  $d\mathbf{a}$  in the deformed configuration. Considering an arbitrary material line  $d\mathbf{L}$  in the reference configuration and noting  $d\mathbf{l}$  the same line after deformation TODO: Add figure with all notations , the corresponding reference and current volumes are given respectively by:

$$d\mathbf{V} = d\mathbf{L} \cdot d\mathbf{A} \tag{2.17}$$

and 
$$d\mathbf{v} = d\mathbf{l} \cdot d\mathbf{a}$$
. (2.18)

Using (2.16) which relates the reference and deformed volumes and recalling that  $d\mathbf{l} = \mathbf{F} d\mathbf{L}$ , we have:

$$J d\mathbf{L} \cdot d\mathbf{A} = (\mathbf{F} d\mathbf{L}) \cdot d\mathbf{a}. \tag{2.19}$$

The fact that this expression is valid for any vector  $d\mathbf{L}$  and using the property  $\mathbf{a} \cdot \mathbf{b} = \mathbf{a}^T \mathbf{b}$  yields:

$$d\mathbf{a} = J \mathbf{F}^{-T} d\mathbf{A}. \tag{2.20}$$

#### 2.3.4 Volumetric and isochoric components

We recall that the Jacobian J has the physical meaning of being the local ratio of current to reference volume of a material volume element. Therefore, if J=1 the volume does not change locally during the deformation and the latter is qualified as isochoric at this given particle P. If J=1 everywhere in the body, the deformation of the body is isochoric.

When dealing with incompressible and nearly incompressible materials it is necessary to separate the volumetric from the isochoric components of the deformation. Such a separation must ensure that the isochoric component  $\hat{\mathbf{F}}$  does not imply any change in volume. This condition can be achieved by choosing  $\hat{\mathbf{F}}$  as:

$$\mathbf{\hat{F}} = J^{-1/3}\mathbf{F}.\tag{2.21}$$

Indeed,

$$\det \hat{\mathbf{F}} = \det(J^{-1/3}\mathbf{F})$$

$$= (J^{-1/3})^3 \det \mathbf{F}$$

$$= J^{-1}J$$

$$= 1. \tag{2.22}$$

The deformation gradient  $\mathbf{F}$  can now be expressed in terms of the volumetric and isochoric component J and  $\hat{\mathbf{F}}$  as:

$$\mathbf{F} = J^{1/3}\hat{\mathbf{F}}.\tag{2.23}$$

2.4. Strain measures 11

#### 2.4 Strain measures

The length of a material curve from the reference configuration can change when displaced to a curve in the deformed configuration. If all the curves do not change length, it is said that a rigid body displacement occurred. The concept of strain is used to evaluate how much a given displacement differs locally from a rigid body displacement. Therefore, although we know how to transform vectors from the reference configuration into vectors in the current configuration using the deformation gradient, it is more useful to find a measure of the change in length of  $d\mathbf{X}$ . Many measures of strains can be defined and the most common ones will now be introduced.

#### 2.4.1 Cauchy-Green deformation tensors

Let us consider two particles  $P_1$  and  $P_2$  in the neighbourhood of each other, separated by  $d\mathbf{X}$  in the reference configuration. In the deformed configuration  $P_1$  and  $P_2$ occupy the positions  $\tilde{P}_1$  and  $\tilde{P}_2$  and they are separated by  $d\mathbf{x}$ . We are interested in the change of distance between the two points  $P_1$  and  $P_2$  as the body deforms.

The squared distances between  $P_1$  and  $P_2$  and  $\tilde{P}_1$  and  $\tilde{P}_2$  are respectively given by:

$$(dS)^{2} = d\mathbf{X} \cdot d\mathbf{X}$$

$$(ds)^{2} = d\mathbf{x} \cdot d\mathbf{x} = (\mathbf{F} d\mathbf{X}) \cdot (\mathbf{F} d\mathbf{X})$$

$$= (\mathbf{F} d\mathbf{X})^{T} (\mathbf{F} d\mathbf{X}) = (d\mathbf{X}^{T} \mathbf{F}^{T}) (\mathbf{F} d\mathbf{X}) = d\mathbf{X}^{T} (\mathbf{F}^{T} \mathbf{F} d\mathbf{X})$$

$$= d\mathbf{X} \cdot (\mathbf{F}^{T} \mathbf{F} d\mathbf{X}).$$
(2.24)
$$(2.24)$$

using the property that the dot product between two vectors a and b can also be expressed as the simple product between the transpose of a and b ( $a \cdot b = a^T b$ ). We define the right Cauchy-Green deformation tensor  $\mathbb{C}$  as:

$$\mathbf{C} = \mathbf{F}^T \mathbf{F}.\tag{2.26}$$

Thus, the change of distance between the two points  $P_1$  and  $P_2$  after deformation of the continuous body may be written as:

$$(ds)^2 = d\mathbf{X} \cdot (\mathbf{C} \, d\mathbf{X}). \tag{2.27}$$

By definition, C is a symmetric second-order tensor. The transpose of C is denoted B and is called the *left Cauchy-Green deformation tensor*:

$$\mathbf{B} = \mathbf{F}\mathbf{F}^T. \tag{2.28}$$

#### 2.4.2 Green strain tensor

Using (2.24) and (2.27), the change in the squared lengths due to the body deformation between the reference and the current configuration can be expressed as:

$$(ds)^{2} - (dS)^{2} = d\mathbf{X} \cdot (\mathbf{C} d\mathbf{X}) - d\mathbf{X} \cdot d\mathbf{X}$$

$$= d\mathbf{X} \cdot (\mathbf{C} - \mathbf{I}) d\mathbf{X}.$$
(2.29)

Let us define the Green-St. Venant strain tensor E as:

$$\mathbf{E} = \frac{1}{2}(\mathbf{C} - \mathbf{I}) \tag{2.30}$$

so we can write:

$$(ds)^{2} - (dS)^{2} = 2 d\mathbf{X} \cdot \mathbf{E} d\mathbf{X}. \tag{2.31}$$

By definition, the Green strain tensor is a symmetric second-order tensor. Also, the change in squared lengths is zero if and only if  $\mathbf{E} = \mathbf{0}$ . Using (2.11), the Green strain tensor may be expanded as the following:

$$\mathbf{E} = \frac{1}{2} (\mathbf{F}^T \mathbf{F} - \mathbf{I})$$

$$= \frac{1}{2} [(\nabla_0 \mathbf{u} + \mathbf{I})^T (\nabla_0 \mathbf{u} + \mathbf{I}) - \mathbf{I}]$$

$$= \frac{1}{2} [(\nabla_0 \mathbf{u})^T + \nabla_0 \mathbf{u} + (\nabla_0 \mathbf{u})^T (\nabla_0 \mathbf{u})].$$
(2.32)

The Green strain tensor can be expressed in terms of its components in any coordinate system. In particular, in the Cartesian coordinate system  $(X_1, X_2, X_3)$  the components  $E_{ij}$  of  $\mathbf{E}$  are the following:

$$E_{i,j} = \frac{1}{2} \left( \frac{\partial u_i}{\partial X_j} + \frac{\partial u_j}{\partial X_i} + \frac{\partial u_k}{\partial X_i} \frac{\partial u_k}{\partial X_j} \right), \quad i = 1, 2, 3.$$
 (2.33)

The components  $E_{11}$ ,  $E_{22}$  and  $E_{33}$  are called *normal strains* and it can be shown that they are in fact the ratio of the change in length to the original length along each of the three unit vectors. The components  $E_{12}$ ,  $E_{23}$  and  $E_{13}$  are called *shear strains* and they can be interpreted as a measure of the change in angle between line elements that were perpendicular to each other in the undeformed configuration.

#### 2.4.3 Cauchy and Euler tensor

The change in the squared lengths during the body deformation can also be expressed relative to the current length. The length dS can be written in terms of  $d\mathbf{x}$  as:

$$(dS)^{2} = d\mathbf{X} \cdot d\mathbf{X} = d\mathbf{x} \cdot (\mathbf{F}^{-T}\mathbf{F}^{-1})d\mathbf{x} = d\mathbf{x} \cdot \tilde{\mathbf{B}}d\mathbf{x}$$
(2.34)

where  $\tilde{\mathbf{B}} = \mathbf{F}^{-T}\mathbf{F}^{-1}$  is called the *Cauchy strain tensor*.  $\tilde{\mathbf{B}}$  is in fact the inverse of the left Cauchy-Green tensor  $\mathbf{B}$  introduced previously.

In a similar way we defined the Green strain tensor, we can write the change in the squared lengths but relative to the current length:

$$(ds)^2 - (dS)^2 = 2 d\mathbf{x} \cdot \mathbf{e} d\mathbf{x}.$$
 (2.35)

where **e** is called Almansi-Hamel strain tensor or simply Euler strain tensor.

2.4. Strain measures 13

#### 2.4.4 Principal strains and invariants

The components  $\varepsilon_{ij}$  of the strain tensor depend on the coordinate system at the point under consideration. However, the strain tensor itself is a physical quantity and as such, it is independent of the coordinate system chosen to represent it. Certain operations on strain tensors give the same result independently of the coordinate system chosen to represent the components of strain. As an example, a vector is a simple tensor of rank one. In three dimensions, it has three components. The value of these components will depend on the coordinate system chosen to represent the vector, but the length of the vector is a physical quantity (a scalar) and is independent of the coordinate system chosen to represent the vector. Similarly, every second rank tensor (such as the strain tensors) has three independent invariant quantities associated with it. One set of such invariants are the principal strains of the strain tensor, which are just the eigenvalues of the strain tensor. Because they are independent of any coordinate system, they are very convenient to define strain energy density functions (see section 2.6.5). The most commonly used invariants are:

$$I_{1} = tr(\varepsilon)$$

$$I_{2} = \frac{1}{2} \left\{ tr(\varepsilon^{2}) - [tr(\varepsilon)]^{2} \right\}$$

$$I_{3} = det(\varepsilon).$$
(2.36)

It can be shown that in the coordinate system  $(\mathbf{p}_1, \mathbf{p}_2, \mathbf{p}_3)$  formed by the three eigenvectors, the expression of the strain tensor is:

$$\boldsymbol{\varepsilon} = \begin{bmatrix} \varepsilon_1 & 0 & 0 \\ 0 & \varepsilon_2 & 0 \\ 0 & 0 & \varepsilon_3 \end{bmatrix}. \tag{2.37}$$

Since there are no shear strain components in this particular coordinate system, the principal strains represent the maximum and minimum stretches of an elemental volume. Because of the obvious simplicity of the strain tensor's expression, this coordinate system is often used in mechanics to derive and solve equations.

#### 2.4.5 Infinitesimal strain tensor

In some cases, it is possible to simplify the expression of the Green strain tensor defined in (2.32). Indeed, when the displacement gradients are small (that is,  $|\nabla \mathbf{u}| \ll 1$ ) we can neglect the non-linear terms in the definition. In the case of infinitesimal strains, the Green-Lagrange strain tensor and the Eulerian strain tensor are approximately the same and can be approximated by the infinitesimal strain tensor denoted  $\varepsilon$  and is given by:

$$\varepsilon = \frac{1}{2} \left[ \nabla \mathbf{u} + (\nabla \mathbf{u})^T \right]. \tag{2.38}$$

Its Cartesian components  $\varepsilon_{ij}$  are the following:

$$\varepsilon_{ij} = \frac{1}{2} \left( \frac{\partial u_i}{\partial X_j} + \frac{\partial u_j}{\partial X_i} \right). \tag{2.39}$$

The strain quantities defined in the previous sections are non-linear expressions in terms of the mapping  $\chi$  and will lead to non-linear governing equations. In solid mechanics, whenever the hypothesis is acceptable, it is common practice to assume that the displacements are small and the infinitesimal strain tensor is then used as a measure of the deformation.

#### 2.5 Stress

Stress is a measure of the intensity of the internal forces acting between particles of a deformable body across imaginary internal surfaces. These internal forces are produced between the particles in the body as a reaction to external forces applied on the body. The SI unit for stress is pascal (symbol Pa), which is equivalent to one newton (force) per square metre (unit area). As with strain, different measures of stress can be defined. For instance, stress can be measured per unit of deformed area (section 2.5.1) or undeformed area (sections 2.5.2 and 2.5.3). In general, the stress is not uniformly distributed over the cross section of a material body, and consequently the stress at a point on a given area is different from the average stress over this entire area. Therefore, it is necessary to define the stress not over a given area but at a specific point in the body. Stress at a point in a three-dimensional continuum can be measured in terms of nine quantities, three per plane, on three mutually perpendicular planes at the point. These nine quantities may be viewed as the components of a second-order tensor that we call stress tensor.

#### 2.5.1 Cauchy stress

The Euler-Cauchy's stress principle states that on any surface (real or imaginary) that divides the body, the action of one part of the body on the other is equivalent to the system of distributed forces and couples on the surface dividing the body. With that consideration in mind, let us consider a plane S that passes through an arbitrary internal point P which has a unit normal vector  $\mathbf{n}$ . This plane separates the body into two regions and we are interested in the forces applied by one region onto the other. First we will introduce the true stress, defined as the stress in the deformed configuration  $\chi$  measured per unit area of the deformed configuration. The force  $\Delta \mathbf{f}(\mathbf{n})$  acting on a small element of area  $\Delta a$  in a continuous medium depends not only on the size of the area but also depends on the orientation of this area  $\mathbf{n}$ . The Cauchy stress vector at P on S can be defined as:

$$\mathbf{t}(\mathbf{n}) = \lim_{\Delta a \to 0} \frac{\Delta \mathbf{f}(\mathbf{n})}{\Delta a}.$$
 (2.40)

This equation means that the stress vector depends on its location in the body and the orientation of the plane on which it is acting. In general, the stress vector is 2.5. Stress 15

not perpendicular to that plane and it can be separated into two components: one component normal to the plane called *normal stress* and one component tangent to the plane named *shear stress*. Since  $\mathbf{t}$  depends on  $\mathbf{n}$  but is not in the direction of  $\mathbf{n}$ , it may be interesting to look into the relationship between  $\mathbf{t}$  and  $\mathbf{n}$ .

To establish this relationship, let us consider an infinitesimal tetrahedron in a Cartesian coordinate system. TODO: Add figure of a tetrahedron with all notations. We note  $-\mathbf{t}_1$ ,  $-\mathbf{t}_2$ ,  $-\mathbf{t}_3$  and  $\mathbf{t}$  the stress vectors in the outwards directions on the faces of the tetrahedron whose areas are respectively  $\Delta a_1$ ,  $\Delta a_2$ ,  $\Delta a_3$  and  $\Delta a$ . For the mass m inside the tetrahedron, we have by Newton's second law:

$$\sum \mathbf{F} = \mathbf{t}\Delta a - \mathbf{t}_1 \Delta a_1 - \mathbf{t}_2 \Delta a_2 - \mathbf{t}_3 \Delta a_3 + \Delta v \mathbf{f} = m\mathbf{a}, \tag{2.41}$$

where **f** is the force per unit volume acting on the body,  $\Delta v$  the volume of the tetrahedron and **a** the acceleration. The areas  $\Delta a_1$ ,  $\Delta a_2$  and  $\Delta a_3$  being the projections of  $\Delta a$ , they are related to  $\Delta a$  in the Cartesian coordinate system (**e**<sub>1</sub>, **e**<sub>2</sub>, **e**<sub>3</sub>) by:

$$\Delta a_i = (\mathbf{n} \cdot \mathbf{e}_i) \Delta a, \quad i = 1, 2, 3.$$
 (2.42)

Dividing (2.41) by  $\Delta a$ , using (2.42) and noting that  $\Delta v/\Delta a \to 0$  when the tetrahedron shrinks to a point yields:

$$\mathbf{t} = (\mathbf{n} \cdot \mathbf{e}_1)\mathbf{t}_1 + (\mathbf{n} \cdot \mathbf{e}_2)\mathbf{t}_2 + (\mathbf{n} \cdot \mathbf{e}_3)\mathbf{t}_3$$
  
=  $\mathbf{n} \cdot (\mathbf{e}_1\mathbf{t}_1 + \mathbf{e}_2\mathbf{t}_2 + \mathbf{e}_3\mathbf{t}_3).$  (2.43)

We define the Cauchy stress tensor  $\sigma = \mathbf{e}_1 \mathbf{t}_1 + \mathbf{e}_2 \mathbf{t}_2 + \mathbf{e}_3 \mathbf{t}_3$  and we have:

$$\mathbf{t}(\mathbf{n}) = \mathbf{n} \cdot \sigma. \tag{2.44}$$

The stress vector  $\mathbf{t}$  represents the vectorial stress on a plane whose normal is  $\mathbf{n}$ . As we demonstrated, the stress tensor is a property of the medium that is independent of  $\mathbf{n}$ . It represents the current force per unit of deformed area:  $d\mathbf{f} = \mathbf{t}da = \sigma \cdot d\mathbf{a}$ .

The matrix form of (2.44) in a Cartesian coordinate system is given by:

$$\begin{bmatrix} t_1 \\ t_2 \\ t_3 \end{bmatrix} = \begin{bmatrix} \sigma_{11} & \sigma_{21} & \sigma_{31} \\ \sigma_{12} & \sigma_{22} & \sigma_{32} \\ \sigma_{13} & \sigma_{23} & \sigma_{33} \end{bmatrix} \begin{bmatrix} n_1 \\ n_2 \\ n_3 \end{bmatrix}. \tag{2.45}$$

The Cauchy stress tensor is used for stress analysis of material bodies experiencing small deformations. This stress is basically defined as force/(unit deformed area). The strain measure that is appropriate to use with the Cauchy stress tensor is the infinitesimal strain tensor (see section 2.4.5). The problem with using the Cauchy stress tensor for analysing materials undergoing large deformation is that we generally do not know the area in the deformed configuration. Therefore, we need to develop alternative stress tensors that we can use in the reference configuration. We will introduce two new stress measures: the first Piola-Kirchhoff stress tensor and the second Piola-Kirchhoff stress tensor.

#### 2.5.2 First Piola-Kirchhoff stress tensor

We know that the Cauchy stress tensor represents the current force per unit of deformed area:  $d\mathbf{f} = \mathbf{t}(\mathbf{n})da = \sigma \cdot d\mathbf{a}$ . We define a stress vector  $\mathbf{T}$  over the area element dA with normal  $\mathbf{N}$  in the underformed configuration such that it results in the same total force

$$d\mathbf{f} = \mathbf{t}(\mathbf{n})da = \mathbf{T}(\mathbf{N})dA. \tag{2.46}$$

The two stress vectors have the obviously the same direction but different magnitudes since they are not applied to the same area.

In a similar way we defined the Cauchy stress  $\sigma$  with  $\mathbf{t}(\mathbf{n}) = \sigma \cdot \mathbf{n}$ , we introduce a stress tensor  $\mathbf{P}$  called the *first Piola-Kirchhoff stress tensor* such that  $\mathbf{T}(\mathbf{n}) = \mathbf{P} \cdot \mathbf{N}$ . The first Piola-Kirchhoff stress tensor gives the current force per unit undeformed area.

The relation between the first Piola-Kirchhoff stress tensor and the Cauchy stress tensor can be obtained as follows. From (2.46) we have:

$$\mathbf{T} = \frac{da}{dA}\mathbf{t}.\tag{2.47}$$

Using  $d\mathbf{f} = \mathbf{t} da$  and the relation (2.20) between  $d\mathbf{A}$  and  $d\mathbf{a}$ , we have:

$$\mathbf{T} = J \mathbf{t} \mathbf{F}^{-T}. \tag{2.48}$$

Finally we can express the first Piola-Kirchhoff stress tensor  ${f P}$  as

$$\mathbf{P} = J \,\sigma \,\mathbf{F}^{-T}.\tag{2.49}$$

#### 2.5.3 Second Piola-Kirchhoff stress tensor

The second Piola-Kirchhoff stress tensor **S** is introduced as the stress tensor associated with the force  $d\mathbf{F}$  in the undeformed area  $d\mathbf{A}$  that corresponds to the force  $d\mathbf{f}$  in the deformed area  $d\mathbf{a}$ :

$$d\mathbf{F} = \mathbf{S} \, d\mathbf{A}.\tag{2.50}$$

Thus, the second Piola-Kirchhoff stress tensor gives the transformed current force per unit undeformed area. Similar to the relationship (2.13) between  $d\mathbf{x}$  and  $d\mathbf{X}$ , the force  $d\mathbf{f}$  is related to the force  $d\mathbf{F}$  by:

$$d\mathbf{F} = \mathbf{F}^{-1} d\mathbf{f}$$

$$= \mathbf{F}^{-1} (\mathbf{P} d\mathbf{A})$$

$$= \mathbf{S} d\mathbf{A}.$$
(2.51)

Therefore, the second Piola-Kirchhoff stress tensor is related to the first Piola-Kirchhoff stress tensor as follows:

$$\mathbf{S} = \mathbf{F}^{-1}\mathbf{P} = J\,\mathbf{F}^{-1}\,\sigma\,\mathbf{F}^{-T}.\tag{2.52}$$

#### 2.5.4 Principal stresses and invariants

In the same way that we defined principal strains in section 2.4.4 and like any second-rank tensor, the stress tensor has at least three invariants and we can find a coordinate system  $(\mathbf{n}_1, \mathbf{n}_2, \mathbf{n}_3)$  in which the expression of the stress tensor is:

$$\boldsymbol{\sigma} = \begin{bmatrix} \sigma_1 & 0 & 0 \\ 0 & \sigma_2 & 0 \\ 0 & 0 & \sigma_3 \end{bmatrix} . \tag{2.53}$$

This result means that at every point in a stressed body there are at least three planes called *principal planes*, with normal vectors  $\mathbf{n}_1$ ,  $\mathbf{n}_2$  and  $\mathbf{n}_3$  called *principal directions* (in fact, the eigenvectors), where the corresponding stress vector is perpendicular to the plane and where there are no normal shear stresses. The three stresses normal  $\sigma_1$ ,  $\sigma_2$  and  $\sigma_3$  to these principal planes are called *principal stresses*.

#### 2.6 Constitutive equations

So far, all the relations that we have established are valid for every continuum. Indeed, no mention was made of any material in the derivations. Therefore, these relations are not sufficient to describe the response of a material to a given loading. We know that the stresses result from the deformation of the material and it is now necessary to express them in terms of some measure of this deformation such as, for instance, the strain. These relationships, known as *constitutive equations*, obviously depend on the type of material under consideration and may be dependent on time or not. Constitutive equations are not derived from any physical principles, although they are subject to obeying certain rules and the entropy inequality. In essence, constitutive equations are mathematical models of the behaviour of materials that are validated against experimental results.

The relationship between stress and strain depends on the nature, or constitution of the particular material that we are studying. Of course, any material mechanics, and especially tissue mechanics, can be quite complex, and many assumptions must be made when deriving a constitutive equation. It is basically impossible to derive a particular constitutive equation that would accurately model all aspects of tissue behaviour under any type of loading. This is because tissues may behave very differently under small loads as compared to large loads. For instance, we may expect damage under large loads. Also, under different loading rates different tissues may behave differently. Therefore, whenever we develop a constitutive equation to model a tissue, we need to balance the need to accurately model tissue behaviour under the range of loadings with the need to have a constitutive equation that is simple enough to:

- 1. be computed in a numerical model
- 2. experimentally measure all the material constants used in the constitutive equation

This section will now introduce the most common constitutive models relevant to soft-tissue modelling.

#### 2.6.1 Elasticity

If under applied loads a material stores but does not dissipate energy, and it returns to its original shape when the loads are removed, we call that material *elastic*. The work done by the stress is generally dependent on the deformation path. However, for elastic materials the stress does not depend on the path of deformation and therefore the state of stress in the deformed configuration is determined only by the state of deformation. It means that the stress does not depend on the time taken to achieve the deformation or the rate at which the state of deformation is reached.

One special case of elastic materials are hyperelastic materials. A material is said to be hyperelastic if there exists a strain energy density function  $U_0(\varepsilon)$  such that

$$\sigma = \frac{\partial U_0}{\partial \varepsilon}.\tag{2.54}$$

However, for *imcompressible* materials the stress tensor is not completely determined by the deformation. The hydrostatic pressure<sup>1</sup> affects the stress and the above equation is then written as:

$$\boldsymbol{\sigma} = -p\mathbf{I} + \frac{\partial U_0}{\partial \varepsilon},\tag{2.55}$$

where p is the hydrostatic pressure. In order to develop a mathematical model of an hyperelastic material,  $U_0$  is expanded in Taylor's series about  $\varepsilon = 0$ :

$$U_0 = C_0 + C_{ij}\varepsilon_{ij} + \frac{1}{2!}\hat{C}_{ijkl}\varepsilon_{ij}\varepsilon_{kl} + \frac{1}{3!}\hat{C}_{ijklmn}\varepsilon_{ij}\varepsilon_{kl}\varepsilon_{mn} + \dots, \qquad (2.56)$$

where  $C_0$ ,  $C_{ij}$  and  $\hat{C}$  are material stiffnesses. The form of  $U_0$  may varied for different materials. A material is said to be *linear* if the relationship between strain and stress is also linear. Based on this definition,  $U_0$  is a cubic or higher-order function of the strains for non-linear materials whereas  $U_0$  is a quadratic function of strain for linear materials. We will start by discussing linear materials for the case of infinitesimal deformations (sections 2.6.2 to 2.6.4). Consequently, we will not make any distinction between the various measures of stress and strain and use  $\sigma$  and  $\varepsilon$  for stress and strain tensors respectively.

#### 2.6.2 Linear materials: generalised Hooke's law

The linear constitutive model for infinitesimal deformations is called the generalised Hooke's law. To derive the relation between stress and strain for a linear material, we assume the quadratic form of  $U_0$ :

$$U_0 = C_0 + C_{ij}\varepsilon_{ij} + \frac{1}{2!}\hat{C}_{ijkl}\varepsilon_{ij}\varepsilon_{kl}. \tag{2.57}$$

<sup>&</sup>lt;sup>1</sup>pressure exerted by a fluid at equilibrium due to the force of gravity

From there and using (2.54) it can be shown that there exists some coefficients  $C_{ijkl}$  such as:

$$\sigma_{ij} = C_{ijkl} \varepsilon_{kl}. \tag{2.58}$$

The  $C_{ijkl}$  are the coefficients of the fourth-order tensor  $\mathbf{C}$  that relates the second-order tensors of strain and stress. The 81 scalar components of this fourth-order tensor (=  $3^4$ ) can be reduced to 21 independent coefficients using existing symmetries. Recalling that both strain and stress tensors are symmetric yields:

$$\begin{bmatrix} \sigma_{11} \\ \sigma_{22} \\ \sigma_{33} \\ \sigma_{23} \\ \sigma_{13} \\ \sigma_{12} \end{bmatrix} = \begin{bmatrix} C_{1111} & C_{1122} & C_{1133} & C_{1123} & C_{1113} & C_{1112} \\ C_{1122} & C_{2222} & C_{2233} & C_{2223} & C_{2213} & C_{2212} \\ C_{1133} & C_{2233} & C_{3333} & C_{3323} & C_{3313} & C_{3312} \\ C_{1123} & C_{2223} & C_{3323} & C_{2323} & C_{2313} & C_{2312} \\ C_{1113} & C_{2213} & C_{3313} & C_{2313} & C_{1312} & C_{1312} \\ C_{1112} & C_{2212} & C_{3312} & C_{2312} & C_{1312} & C_{1212} \end{bmatrix} \begin{bmatrix} \varepsilon_{11} \\ \varepsilon_{22} \\ \varepsilon_{33} \\ \varepsilon_{23} \\ \varepsilon_{13} \\ \varepsilon_{13} \\ \varepsilon_{12} \end{bmatrix}.$$

$$(2.59)$$

#### 2.6.3 Orthotropic materials

Further reduction in the number of independent stiffness parameters can be achieved using the so-called material symmetry. This symmetry is due to the internal structure of the material, that is the arrangement of molecules (crystallographic form). We note that the symmetry under discussion is a directional property and not a positional property. Thus, a material may have certain elastic symmetry at every point of a material body and the properties may vary from point to point. Positional dependence of material properties is what we called the inhomogeneity of the material.

Orthotropic materials are characterised by three mutually orthogonal planes of material symmetry, that is, three mutually orthogonal preferred directions. In this case, the number of coefficients is reduced to 9 and the stress-strain relation for an orthotropic material is the following:

$$\begin{bmatrix} \sigma_{11} \\ \sigma_{22} \\ \sigma_{33} \\ \sigma_{23} \\ \sigma_{13} \\ \sigma_{12} \end{bmatrix} = \begin{bmatrix} C_{1111} & C_{1122} & C_{1133} & 0 & 0 & 0 \\ C_{1122} & C_{2222} & C_{2233} & 0 & 0 & 0 \\ C_{1133} & C_{2233} & C_{3333} & 0 & 0 & 0 \\ 0 & 0 & 0 & C_{2323} & 0 & 0 \\ 0 & 0 & 0 & 0 & C_{1313} & 0 \\ 0 & 0 & 0 & 0 & 0 & C_{1212} \end{bmatrix} \begin{bmatrix} \varepsilon_{11} \\ \varepsilon_{22} \\ \varepsilon_{33} \\ \varepsilon_{23} \\ \varepsilon_{13} \\ \varepsilon_{12} \end{bmatrix}.$$
 (2.60)

Most often, the material properties are determined in a laboratory in terms of the engineering constants such as Young's modulus, shear modulus, and so on. These constants are measured using simple tests like uniaxial tension test or pure shear test. Because of their direct and obvious physical meaning, engineering constants are used in place of the more abstract stiffness coefficients  $C_{ijkl}$ . Therefore, we will now reformulate (2.60) with respect to those engineering constants. Noting  $E_i$  the

Young's modulus in the direction  $x_i$  and  $G_{ij}$  the shear moduli in the  $x_i - x_j$  plane, it can be shown that:

$$\begin{bmatrix} \varepsilon_{11} \\ \varepsilon_{22} \\ \varepsilon_{33} \\ \varepsilon_{23} \\ \varepsilon_{12} \end{bmatrix} = \begin{bmatrix} \frac{1}{E_1} & -\frac{\nu_{21}}{E_2} & -\frac{\nu_{31}}{E_3} & 0 & 0 & 0 \\ -\frac{\nu_{12}}{E_1} & \frac{1}{E_2} & -\frac{\nu_{32}}{E_3} & 0 & 0 & 0 \\ -\frac{\nu_{13}}{E_1} & -\frac{\nu_{23}}{E_2} & \frac{1}{E_3} & 0 & 0 & 0 \\ -\frac{\nu_{13}}{E_1} & -\frac{\nu_{23}}{E_2} & \frac{1}{E_3} & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1}{G_{23}} & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1}{G_{13}} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1}{G_{12}} \end{bmatrix} \begin{bmatrix} \sigma_{11} \\ \sigma_{22} \\ \sigma_{33} \\ \sigma_{23} \\ \sigma_{13} \\ \sigma_{12} \end{bmatrix}.$$
 (2.61)

#### 2.6.4 Isotropic materials

A material is said *isotropic* if its properties are independent of directions. Therefore, we have the following relations:

$$E_1 = E_2 = E_3 = E, \quad G_{12} = G_{13} = G_{23} = G, \quad \nu_{12} = \nu_{23} = \nu_{13} = \nu.$$
 (2.62)

The stress-strain relations may be written:

$$\sigma_{ij} = \frac{E}{1+\nu} \varepsilon_{ij} + \frac{\nu E}{(1+\nu)(1-2\nu)} \varepsilon_{kk} \delta_{ij}. \tag{2.63}$$

where the summation of repeated indices is implied (Einstein's notation). The inverse relations are:

$$\varepsilon_{ij} = \frac{1+\nu}{E}\sigma_{ij} - \frac{\nu}{E}\sigma_{kk}\delta_{ij},\tag{2.64}$$

recalling that  $G = E/[2(1+\nu)]$ .

#### 2.6.5 Non-linear materials

For most materials, the linear relation between stress and strain is only valid for small deformation. Beyond a certain threshold, Hooke's law is no longer valid. Note that it does mean that the material is not elastic, it may well recover all its deformation after removal of the loads. However, materials often exibit an elastic threshold in the non-linear range after which permanent deformation occurs. This range of deformation is qualified of *plastic*.

The strain energy density function takes different forms for different materials. It is often expressed as a linar combination of unknown coefficients (determined experimentally) and principal invariants of Green strain tensor  $\mathbf{E}$ , left Cauchy-Green strain tensor  $\mathbf{B}$  and deformation gradient tensor  $\mathbf{F}$  (see section 2.4.4 for more information on invariants). The constitutive equations of two well-known non-linear elastic materials (Mooney-Rivlin and neo-Hookean) will now be introduced.

#### Mooney-Rivlin

The Mooney-Rivlin model was proposed by Melvin Mooney and Ronald Rivlin in two independent papers in 1952. For an incompressible Mooney-Rivlin material, the strain energy density function  $U_0$  is taken as a linear function of the principal invariants of the left Cauchy-Green strain tensor **B** and is written as:

$$U_0 = C_1(I_B - 3) + C_2(II_B - 3), (2.65)$$

where  $C_1$  and  $C_2$  are two constants and  $I_B$  and  $II_B$  are the two principal invariants of **B**. For those materials, it can be shown that the stress tensor has the form

$$\sigma = -p\mathbf{I} + \alpha \mathbf{B} + \beta \mathbf{B}^{-1}, \tag{2.66}$$

where  $\rho$  is the material density and  $\alpha$  and  $\beta$  are given by

$$\alpha = 2\rho \frac{\partial U_0}{\partial I_B} = 2\rho C_1, \quad \beta = -2\rho \frac{\partial U_0}{\partial II_B} = -2\rho C_2. \tag{2.67}$$

The Mooney-Rivlin incompressible model is often used to represent the behaviour of rubber-like materials.

#### Neo-Hookean

The neo-Hookean model was proposed by Ronald Rivlin in 1948. It can be derived from the Mooney-Rivlin model in the special case where  $C_2 = 0$  in the strain energy density function. Therefore, we have:

$$U_0 = C_1(I_B - 3). (2.68)$$

and the constitutive equation for the stress may be written as:

$$\sigma = -p\mathbf{I} + 2\rho C_1 \mathbf{B}. \tag{2.69}$$

The neo-Hookean model provides a reasonable approximation of rubber-like material for moderate strains. It is typically accurate for strains less than 20% (Gent, 2001).

#### 2.6.6 Viscoelastic materials

Viscoelasticity is the property of materials that exhibit both viscous and elastic characteristics when undergoing deformation. Viscous materials, like honey, resist shear flow and strain linearly with time when a stress is applied. Elastic materials strain instantaneously when stretched and just as quickly return to their original state once the stress is removed. Viscoelastic materials have elements of both of these properties and, as such, exhibit time dependent strain. Depending on the change of strain rate versus stress inside a material the viscosity can be categorised as having a linear or non-linear response. When a material exhibits a linear response it is categorised as a Newtonian material. In this case the stress is linearly proportional to the strain rate. If the material exhibits a non-linear response to the strain rate, it is categorised as a Non-Newtonian material.

Viscoelastic materials present a few characteristics:

- 1. if the stress is held constant, the strain increases with time (creep)
- 2. if the strain is held constant, the stress decreases with time (relaxation)
- 3. the effective stiffness depends on the rate of application of the load
- 4. if cyclic loading is applied, hysteresis occurs, leading to a dissipation of mechanical energy

TODO: Add details on constitutive equations? Level of details to be determined later (depending on TLED needs)

#### 2.7 Tissue characterisation

One of the main obstacles in developing realistic organ models is the lack of data on the material properties of live organ tissues. Measuring and characterising in vivo organ properties is a highly challenging task, but is a requirement for realistic organ modelling. Indeed, as we have seen in sections 2.60 and 2.6.5, constitutive equations require the experimental determination of material constants. Organ models with incorrect material properties will affect training in surgical simulator systems (Sedef et al., 2006).

The constitutive equations are used to define idealised materials, which represent different aspects of the mechanical behaviour of natural materials. However, no real material is known to behave exactly as one of these mathematical models. In particular, few biological tissues obey Hooke's law. If because of their high stiffness (and therefore small deformations) cortical bones are accurately described by a linear model, Hooke's law becomes insufficient to describe the mechanical behaviour of the liver with precision for instance. In fact, in vivo experiments conducted by Melvin et al. (1973) suggest that mechanical behaviour of liver is non-linear and viscoelastic. The brain also appears to be non-linear and viscoelastic (Miller and Chinzei, 1997). The liver has the additional property of anisotropy, more precisely, it is transversely isotropic according to Chui et al. (2007).

TODO: Transition with next chapter (complexity of models => FEM to solve them)

# MAIN PRINCIPLES OF FINITE ELEMENT METHOD (OR HOW TO SOLVE EQUATIONS OF CONTINUUM MECHANICS FROM PREVIOUS SECTION)

- 3.1 Discretisation
- 3.2 Derivation of element equations
- 3.3 Assembly of element equations
- 3.4 Solution of global problem

Ordit Jersjot

# Part II

Solid organs modelling

Ordit Jersjot

# Chapter 4

# STATE OF ART: FEM

Orall Jersjon

Ordit Jersjot

### Chapter 5

# LINEAR NOT ACCURATE => NON-LINEAR FEM => INTRODUCTION OF TLED

- 5.1 Differences with classic FEM and reasons of its efficiency
- 5.2 Visco-elasticity and anisotropy added (MICCAI 2008; MedIA 2009)

Ordit Jersjot

### GPU IMPLEMENTATION OF TLED

- 6.1 What is GPGPU
- 6.2 Re-formulation of the algorithm for its Cg implementation
- 6.3 CUDA implementation/optimisations (ISBMS 2008a)

#### IMPLEMENTATION IN SOFA

- 7.1 Presentation of SOFA project and architecture
- 7.2 Implementation in SOFA and TLED released in open-source

Dr. alt Jerejon

## Part III

Hollow organs modelling

# STATE OF ART: HOLLOW STRUCTURES

- 8.1 Non-physic approaches (computer graphics stuff)
- 8.2 Physically accurate approches (plates/shells)

#### $_{\text{CHAPTER}}\,9$

# WHY A SHELL FEM? COLONOSCOPY SIMULATOR PROJECT

- 9.1 Project introduction
- 9.2 Mass-spring model for colon implemented on GPU (ISBMS 2008b)

# MORE ACCURATE: A CO-ROTATIONAL TRIANGULAR SHELL MODEL (ISBMS 2010)

- 10.1 Model description
- 10.2 Validation
- 10.3 Application to implant deployment simulation in cataract surgery

# 'SHELL MESHING' TECHNIQUE

(MICCAI 2010)

- 11.1 State of art: reconstruction/simplification
- 11.2 Our method

Orall Jersjoth

Ordit Jersjot

# APPLICATIONS TO MEDICAL SIMULATION

- 12.1 Nice medical stuff to show
- 12.2 Interaction solid/hollow organs

Orall Jersjoth

Ordit Jersjot

# Part IV

Conclusion

Orall.

Ordit Jersjot

#### References

- [Bonnet and Wood, 1997] J. Bonnet and R. D. Wood. *Nonlinear Continuum Mechanics For Finite Element Analysis*. Cambridge University Press, 1997.
- [Chui et al., 2007] C. Chui, E. Kobayashi, X. Chen, T. Hisada and I. Sakuma. Transversely isotropic properties of porcine liver tissue: experiments and constitutive modelling. Medical and Biological Engineering and Computing, vol. 45, no. 1, pages 99–106, 2007.

  URL http://dx.doi.org/10.1007/s11517-006-0137-y
- [Gent, 2001] A. N. Gent. Engineering With Rubber: How to Design Rubber Components. Hanser Gardner Publications, 2001.
- [Lai et al., 1996] W. Lai, D. Rubin and E. Krempl. *Introduction to Continuum Mechanics*. Butterworth-Heinemann, third ed., 1996.
- [Lautrup, 2005] B. Lautrup. Physics of continuous matter: exotic and everyday phenomena in the macroscopic world. Institute of Physics Publishing, 2005.
- [Melvin et al., 1973] J. Melvin, R. Stalnaker and V. Roberts. *Impact injury mechanisms in abdominal organs*. SAE Transactions, , no. 730968, pages 115–126, 1973.
- [Miller and Chinzei, 1997] K. Miller and K. Chinzei. Constitutive modelling of brain tissue: Experiment and theory. Journal of Biomechanics, vol. 30, no. 11-12, pages 1115 1121, 1997, ISSN 0021-9290.

  URL http://www.sciencedirect.com/science/article/B6T82-3S3N065-6/2/4b459f2cc2d21298e07478f8cbfe3ae7
- [Reddy, 2007] J. N. Reddy. An Introduction to Continuum Mechanics. Cambridge University Press, 2007.
- [Sedef et al., 2006] M. Sedef, E. Samur and C. Basdogan. Real-Time Finite-Element Simulation of Linear Viscoelastic Tissue Behavior Based on Experimental Data. IEEE Comput. Graph. Appl., vol. 26, no. 6, pages 58–68, 2006, ISSN 0272-1716.
- [Spencer, 1980] A. Spencer. Continuum Mechanics. Longman Group Limited, 1980.