# Министерство образования Республики Беларусь

## Учреждение образования

«Белорусский государственный университет информатики и радиоэлектроники»

Кафедра электронных вычислительных машин

# Лабораторная работа №2 «Программирование контроллера прерываний» Вариант 14

Выполнил: Проверил:

Студент группы 150504 Желубовский С.В.

Преподаватель Одинец Д.Н.

### 1. Постановка задачи

Написать резидентную программу выполняющую перенос всех векторов аппаратных прерываний ведущего и ведомого контроллера на пользовательские прерывания. При этом необходимо написать обработчики аппаратных прерываний, которые будут установлены на используемые пользовательские прерывания и будут выполнять следующие функции:

- 1. Выводить на экран в двоичной форме следующие регистры контроллеров прерывания (как ведущего, так и ведомого):
  - регистр запросов на прерывания;
  - регистр обслуживаемых прерываний;
  - регистр масок.

При этом значения регистров должны выводиться всегда в одно и то же место экрана.

2. Осуществлять переход на стандартные обработчики аппаратных прерываний, для обеспечения нормальной работы компьютера.

## 2. Алгоритм

- Все векторы аппаратных прерываний ведущего и ведомого контроллера переносятся на пользовательские прерывания с помощью функций getvect и setvect.
- Производится инициализация контроллеров, заключающаяся в последовательности команд: ICW1, ICW2, ICW3 и ICW4.
- С помощью функции \_dos\_keep осуществляется выход в DOS, при этом программа остаётся резидентной.
- В каждом обработчике выводятся в видеопамять в двоичной форме значения регистров запросов на прерывания, обслуживаемых прерываний, масок. Затем вызываются стандартные обработчики прерываний.

## 3. Листинг программы

Далее приведен листинг резидентной программы, выполняющей перенос всех векторов аппаратных прерываний ведущего и ведомого контроллера на пользовательские прерывания.

```
#include <dos.h>
#include <time.h>
#include <stdio.h>
#include <stdlib.h>

#define COLORS 7 // amount of counts for colors
struct VIDEO
{
```

```
unsigned char symbol;
         unsigned char attribute;
     };
     // array of counts for video buffer:
    unsigned char colors[COLORS] = { 0x71, 0x62, 0x43, 0x54, 0x35,
0x26, 0x17 };
    char color = 0x89; // default color (blue);
    void changeColor() // change color randomly
     {
         color = colors[rand() % COLORS];
         return;
     }
    void print()
         char temp; // current bit
         int i, val;
         VIDEO far* screen = (VIDEO far*)MK FP(0xB800, 0);  // get
video card buffer
         //----MASK-----
         val = inp(0x21);
                                                             // get
mask MASTER register
                                                             // find
         for (i = 0; i < 8; i++)
bits
         {
             temp = val % 2;
                                                              // get
last bit
              val = val >> 1;
                                                              // move
bits on right
              screen->symbol = temp + '0';
                                                              // save
bit as a char ('0' or '1')
              screen->attribute = color;
                                                              // set
color of print symbol by video card
              screen++;
                                                              // get
to next symbol
         screen++;
                                                             // space
between master and slave
         val = inp(0xA1);
                                                             // get
mask SLAVE register
         for (i = 0; i < 8; i++)
// find bits
             temp = val % 2;
     // get last bit
              val = val >> 1;
      // move bits on right
                                                               //
              screen->symbol = temp + '0';
save bit as a char ('0' or '1')
```

```
screen->attribute = color;
// set color of print symbol by video card
            screen++;
// get to next symbol
        screen += 63;
// next line
        //----MASK-----
       //-----REQUEST-----
_____
        outp(0x20, 0x0A);
                                                       //
switch to MASTERS's request register
        val = inp(0x20);
                                                       // get
MASTERS's request register
        for (i = 0; i < 8; i++)
// find bits
            temp = val % 2;
     // get last bit
            val = val >> 1;
     // move bits on right
                                                         //
            screen->symbol = temp + '0';
save bit as a char ('0' or '1')
            screen->attribute = color;
// set color of print symbol by video card
            screen++;
// get to next symbol
        screen++;
                                                       // space
        outp(0xA0, 0x0A);
                                                       //
switch to SLAVE's request register
        val = inp(0xA0);
                                                       // get
SLAVE's request register
        for (i = 0; i < 8; i++)
// find bits
            temp = val % 2;
     // get last bit
            val = val >> 1;
     // move bits on right
                                                         //
             screen->symbol = temp + '0';
save bit as a char ('0' or '1')
            screen->attribute = color;
// set color of print symbol by video card
             screen++;
// get to next symbol
        screen += 63;
                                                       // go to
next line
        //-----REQUEST-----
```

```
//----SERVICE-----
        outp(0x20, 0x0B);
                                                       //
switch to MASTER's service register
        val = inp(0x20);
                                                       // get
MASTER's service register
        for (i = 0; i < 8; i++)
                                                       // find
bits
            temp = val % 2;
     // get last bit
            val = val >> 1;
     // move bits on right
            screen->symbol = temp + '0';
                                                         //
save bit as a char
            screen->attribute = color;
// set color of print
            screen++;
// get to next symbol
                                                       // space
        screen++;
        outp(0xA0, 0x0B);
switch to SLAVE's service register
        val = inp(0xA0);
                                                       // get-
ting SLAVES's service register
        for (i = 0; i < 8; i++)
                                                       // find
bits
            temp = val % 2;
// get last bit
            val = val >> 1;
     // move bits on right
                                                         //
             screen->symbol = temp + '0';
save bit as a char
            screen->attribute = color;
// set color of print
            screen++;
// get to next symbol
        //----SERVICE-----
._____
    //----IRQ 0-7-----
 -----
    void interrupt(*oldint8) (...);
// IRQ 0 - interrupt of timer (18,2 times per second) oldint8 -
переменная, являющаяся дальним указателем на функцию таймера
    void interrupt(*oldint9) (...);
// IRQ 1 - interrupt of keypad (press and release key)
    void interrupt(*oldint10) (...);
                                                         //
IRQ 2 - interrupt for cascade interruptions in AT machines
    void interrupt(*oldint11) (...);
                                                         //
IRQ 3 - interrupt of async port COM 2
```

```
void interrupt(*oldint12) (...);
                                                         //
IRQ 4 - interrupt of async port COM 1
    void interrupt(*oldint13) (...);
                                                         //
IRQ 5 - interrupt of hard disk controller (for XT)
    void interrupt(*oldint14) (...);
                                                         //
IRQ 6 - interrupt of floppy disk controller (when finish operation
with floppy disk)
    void interrupt(*oldint15) (...);
                                                         //
IRQ 7 - interrupt of printer (when printer is ready to work)
   //----IRO 0-7-----
 -----
   //----IRQ 8-15-----
_____
    void interrupt(*oldint70) (...);
                                                         //
IRQ 8 - interrupt of real time clock
    void interrupt(*oldint71) (...);
                                                         //
IRQ 9 - interrupt of EGA controller
    void interrupt(*oldint72) (...);
                                                         //
IRQ 10 - reserved interrupt
    void interrupt(*oldint73) (...);
                                                         //
IRQ 11 - reserved interrupt
    void interrupt(*oldint74) (...);
IRQ 12 - reserved interrupt
    void interrupt(*oldint75) (...);
IRQ 13 - interrupt of mathematic soprocessor
    void interrupt(*oldint76) (...);
                                                         //
IRQ 14 - interrupt of hard disk
   void interrupt(*oldint77) (...);
                                                         //
IRQ 15 - reserved interrupt
   //----IRQ 8-15-----
   //----NEW INTERRUPTIONS-----
_____
   void interrupt newint08(...) { print(); oldint8(); }
// set function for service interrupt int8
    void interrupt newint09(...) { changeColor(); print();
oldint9(); } // set function for service interruptint9
    void interrupt newintOA(...) { changeColor(); print();
oldint10(); } // set function for service interruptint10
    void interrupt newintOB(...) { changeColor(); print();
oldint11(); } // set function for service interruptint11
    void interrupt newintOC(...) { changeColor(); print();
oldint12(); } // set function for service interruptint12
    void interrupt newintOD(...) { changeColor(); print();
oldint13(); } // set function for service interruptint13
    void interrupt newintOE(...) { changeColor(); print();
oldint14(); } // set function for service interruptint14
    void interrupt newintOF(...) { changeColor(); print();
oldint15(); } // set function for service interruptint15
    void interrupt newintC8(...) { changeColor(); print();
oldint70(); } // set function for service interruptint70
```

```
void interrupt newintC9(...) { changeColor(); print();
oldint71(); } // set function for service interruptint71
    void interrupt newintCA(...) { changeColor(); print();
oldint72(); } // set function for service interruptint72
    void interrupt newintCB(...) { changeColor(); print();
oldint73(); } // set function for service interruptint73
    void interrupt newintCC(...) { changeColor(); print();
oldint74(); } // set function for service interruptint74
    void interrupt newintCD(...) { changeColor(); print();
oldint75(); } // set function for service interruptint75
    void interrupt newintCE(...) { changeColor(); print();
oldint76(); } // set function for service interruptint76
    void interrupt newintCF(...) { changeColor(); print();
oldint77(); } // set function for service interruptint77
    //----NEW INTERRUPTIONS-----
    void initialize()
         //IRQ 0-7
         oldint8 = getvect(0x08); // IRQ 0 - system timer oldint9 = getvect(0x09); // IRQ 1 - keyboard controller oldint10 = getvect(0x0A); // IRQ 2 - cascaded sig-
nals from IRQs 8-15 (any devices configured to use IRQ2 will actually
be using IRQ9)
         oldint11 = qetvect(0x0B); // IRQ 3 - serial port
controller for serial port 2 (shared with serial port 4, if present)
         oldint12 = getvect(0x0C); // IRQ 4 - serial port
controller for serial port 1 (shared with serial port 3, if present)
         oldint13 = getvect(0x0D); // IRQ 5 - parallel port
2 and 3 or sound card
                                          // IRQ 6 - floppy disk
         oldint14 = getvect(0x0E);
controller
         oldint15 = getvect(0x0F); // IRQ 7 - parallel port
1. It is used for printers or for any parallel port if a printer is
not present
         //IRQ 8-15
         oldint70 = getvect(0x70); // IRQ 8 - real-time
clock (RTC)
         oldint71 = getvect(0x71); // IRQ 9 - Advanced Con-
figuration and Power Interface (ACPI) system control interrupt
   oldint72 = getvect(0x72); // IRQ 10 - the interrupt
is left open for the use of peripherals (open interrupt/available,
SCSI or NIC)
         oldint73 = getvect(0x73);
                                     // IRQ 11 - the interrupt
is left open for the use of peripherals (open interrupt/available,
SCSI or NIC)
         oldint74 = getvect(0x74); // IRQ 12 - mouse on PS/2
         oldint75 = getvect(0x75);
                                          // IRQ 13 - CPU co-proces-
sor or integrated floating point unit or inter-processor interrupt
(use depends on OS)
         oldint76 = getvect(0x76); // IRQ 14 - primary ATA
channel (ATA interface usually serves hard disk drives and CD drives)
```

```
oldint77 = getvect(0x77); // IRQ 15 - secondary ATA
channel
           //----NEW HANDLERS-----
_____
           //set new handlers for IRQ 0-7
           setvect(0xC8, newint08);  // set new handler for IRQ 0 setvect(0xC9, newint09);  // set new handler for IRQ 1 setvect(0xCA, newint0A);  // set new handler for IRQ 2 setvect(0xCB, newint0B);  // set new handler for IRQ 3 setvect(0xCC, newint0C);  // set new handler for IRQ 4 setvect(0xCD, newint0D);  // set new handler for IRQ 5 setvect(0xCE, newint0E);  // set new handler for IRQ 6 setvect(0xCF, newint0F);  // set new handler for IRQ 7
           //set new handlers for IRQ 8-15
           _____
           disable(); // CLI
           // interrupt initializtion for Master
           outp (0x20, 0x11);
                                          // ICW1 - initialize MAS-
TER
           outp(0x21, 0xC8);
                                                   // ICW2 - base vector for
MASTER (COH)
           outp(0x21, 0x04);
                                          // ICW3 - the port bit of
SLAVE (in binary format)
           outp (0x21, 0x01);
                                                   // ICW4 - default
           // interrupt initialization for Slave
           outp(0xA0, 0x11); // ICW1 - initialize SLAVE outp(0xA1, 0x08): // ICW2 - base vector for
           outp(0xA1, 0x08);
                                                   // ICW2 - base vector for
SLAVE (08H)
           outp(0xA1, 0x02);
                                             // ICW3 - the port number
of connected port on MASTER
                                                  // ICW4 - default
           outp(0xA1, 0x01);
           enable(); // STI
      }
     int main()
          unsigned far* p;
                                                                 // declare
pointer that can link to other segment
           initialize();
                                                                  // execute in-
itialization
```

```
system("cls");
                                                         // clear con-
sole
                                    - MASK\n");
         printf("
                                                        // the mask of
Master and Slave
         printf("
                                     - REQUEST\n"); // the request
of Master and Slave
        printf("
                                    - SERVICE\n"); // the service
of Master and Slave
         printf(" MASTER SLAVE\n");
         // resident
         FP\_SEG(p) = \_psp;

FP\_OFF(p) = 0x2c;
                                                        // get segment
                                                        // get data
segment offset with environment variables
                                                         // free for
         _dos_freemem(*p);
DOS
         _dos_keep(0, (_DS - _CS) + (_SP / 16) + 1); // left pro-
gram resident, 1st param - ending code,
         // 2nd param - volume of memory, that must be reserved for
program after ending
         return 0;
     }
```

## 4. Тестирование программы




Рисунок 4.1 – Результат работы программы при запуске.




Рисунок 4.2 – Результат работы программы при нажатии клавиши.

#### 5. Заключение

В ходе лабораторной удалось выполнить перенос всех векторов аппаратных прерываний ведущего и ведомого контроллера на пользовательские прерывания. Использование контроллера прерываний позволяет ускорить взаимодействие процессора с внешними устройствами. Недостатком программы является клонирование программы в памяти при повторном запуске.

Программа компилировалась в Turbo C++ и запускалась в DOS, который эмулировался с помощью DosBox.