Αναφορά 8ης Εργαστηριακής Άσκησης Εργαστηρίου Μικροϋπολογιστών

ΞΈΝΟΣ ΕΜΜΑΝΟΥΗΛ 03120850ΠΑΠΑΔΟΠΟΥΛΟΣ ΣΠΥΡΙΔΩΝ 03120033

[Επωνυμία εταιρείας] |[Διεύθυνση εταιρείας]

Προτού προχωρήσουμε στην ανάλυση της του προγράμματος για την επικοινωνία του ntuAboard με τον server θα πρέπει να αρχικά να δώσουμε μία σύντομη περιγραφή των συναρτήσεων που χρησιμοποιήσαμε ώστε να επιτευχθεί αυτή η επικοινωνία.

```
void usart_init(unsigned int ubrr){
    UCSR0A=0;
    UCSR0B=(1<<RXEN0)|(1<<TXEN0);
    UBRR0H=(unsigned char)(ubrr>>8);
    UBRR0L=(unsigned char)ubrr;
    UCSR0C=(3 << UCSZ00);
    return;
}</pre>
```

Αρχικά έχουμε την συνάρτηση usart_init η οποία παίρνει ως argument το UBRR και ουσιαστικά μας επιτρέπει να έχουμε ασύγχρονη επικοινωνία με τον server, πραγματοποιώντας αποστολή και λήψη μηνυμάτων των 8bit. Το argument UBRR μας βοηθάει να ρυθμίσουμε το επιθυμητό BAUD χρησιμοποιώντας την εξίσωση:

$$UBRR = \frac{f_{osc}}{16 BAUD} - 1$$

Όπου f_{osc} είναι η συχνότητα λειτουργίας στον μικροελεγκτή που χρησιμοποιούμε.

Στην συνέχεια έχουμε την συνάρτηση που μας επιτρέπει να στέλνουμε δεδομένα στον server.

```
void usart_transmit(uint8_t data){
    while(!(UCSR0A&(1<<UDRE0)));
    UDR0=data;
}

void usart_transmit_string(const char str[]){
    int i;
    for(i=0; str[i]!='\0'; i++) usart_transmit(str[i]);
}</pre>
```

Η συνάρτηση usart_transmit_string παίρνει ως όρισμα ένα string και μέσα σε αυτή στέλνουμε έναν-έναν τους χαρακτήρες του μέχρι το end of string που συμβολίζεται στην C με \0. Η συνάρτηση usart_transmit αποθηκεύει τα bytes δεδομένων στον καταχωρητή UDRO από τον οποίο στέλνονται τα δεδομένα από το UART. Ουσιαστικά σε αυτή την συνάρτηση περιμένουμε μέχρι ο καταχωρητής αποστολής δεδομένων UDRO να είναι έτοιμος να δεχθεί νέα δεδομένα, που σηματοδοτείται με το όταν η σημαία UDREO είναι 1.

Η συνάρτηση που χρησιμοποιούμε για να λάβουμε ένα string από δεδομένα από τον server είναι:

```
uint8_t usart_receive(){
    while(!(UCSR0A&(1<<RXC0)));
    return UDR0;
}</pre>
```

```
void usart_receive_string(char string[]) {
   int i = 0;
   char received;
   while((received = usart_receive()) != '\n') {
      string[i++] = received;
   }
   string[i] = '\0';
}
```

Στην συνάρτηση usart_receive_string γράφουμε την πληροφορία που λάβαμε σε ένα string που το παίρνουμε ως όρισμα. Σε αυτό γράφουμε έως ότου ο χαρακτήρας που λαμβάνουμε είναι το \n, όπου στην επικοινωνία μας σε αυτή την άσκηση σημαίνει ότι τελείωσε το μήνυμα. Για να μπορέσουμε αυτό το string να το χρησιμοποιήσουμε σωστά στην C προσθέτουμε μετά το \n και το \0 που σημαίνει ότι εδώ τελειώνει το string. Η συνάρτηση usart_receive που χρησιμοποιείται στην usart_receive_string περιμένει μέχρι να υπάρχουν δεδομένα προς ανάγνωση και στην συνέχεια επιστρέφει το περιεχόμενο του καταχωρητή UDR0. Το ότι υπάρχουν δεδομένα προς ανάγνωση σηματοδοτείται από το όταν η σημαία RXC0 είναι 1.

Για την κατασκευή του payload που θα σταλθεί στον server χρησιμοποιείται η ακόλουθη συνάρτηση που το κατασκευάζει σταδιακά.

```
char payload[168];

void append_to_payload(const char *key, const char *value) {
    strcat(payload, "{\"name\": \"");
    strcat(payload, key);
    strcat(payload, "\",\"value\": \"");
    strcat(payload, value);
    strcat(payload, "\"},");
}
```

Έχουμε λοιπόν αναλύσει όλες τις συναρτήσεις που χρειαζόμαστε για την επικοινωνία με τον server καθώς και όποιες άλλες χρειαζόμαστε, επομένως μπορούμε να προχωρήσουμε στην υλοποίηση της εργασίας. Συναρτήσεις που δεν έχουν αναφερθεί παραπάνω έχουν υλοποιηθεί σε προηγούμενες εργαστηριακές ασκήσεις και θα παρατεθούν στο τέλος της αναφοράς ώστε το κείμενο να είναι πιο ευανάγνωστο, αλλά ταυτόχρονα να υπάρχει η υλοποίησή τους σε περίπτωση που χρειαστεί.

Η συνάρτηση main είναι η ακόλουθη:

```
int main(){
    twi_init();

PCA9555_0_write(REG_CONFIGURATION_0, 0x00);

PCA9555_0_write(REG_CONFIGURATION_1, 0xF0); //Set EXT_PORT1[7:4] as input and EXT_PORT[3:0] as output

ADMUX |= 0b01000000; //Right adjusted, ADC0
```

```
ADCSRA |= 0b10000111; //128 Prescaler
    char recMes[20];
    lcd init();
    usart_init(103);
    usart transmit string("ESP:restart\n");
    usart receive string(recMes);
    int nurse call=0;
    uint8 t failed, first;
    first=0;
   while(1){
        lcd_clear_display();
        do {
            char receivedMessage[30];
            failed=0;
            lcd clear display();
            usart transmit string("ESP:connect\n");
            usart receive string(receivedMessage);
            if(strcmp(receivedMessage, "\"Success\"")==0){
              lcd_string("1.Success");
            }else {
                lcd string("1.Fail");
                failed=1;
           delay ms(1000);
        } while(failed);
        do {
            char receivedMessage2[30];
            failed=0:
            lcd clear display();
            if(!first) {
                usart receive string(receivedMessage2);
                first=1;
            }
usart transmit string("ESP:url:\"http://192.168.1.250:5000/data\"\n");
            usart receive string(receivedMessage2);
            if(strcmp(receivedMessage2, "\"Success\"")==0){
              lcd string("2.Success");
            }else {
                lcd_string("2.Fail");
                failed=1:
```

```
delay ms(1000);
        } while(failed);
        lcd clear display();
        //Temperature calculation
        char temperature[6];
        calculateTemp(temperature);
        //Calculate Pressure
        ADCSRA|= (1<<ADSC);
                              //Start ADC
        while(ADCSRA & (1<<ADSC)); //Wait until ADC is finished</pre>
        uint8 t pressureNum=ADC/50;
        char pressureStr[2];
        dtostrf(pressureNum, 3, 2, pressureStr);
        //Checking status
        char *status;
        lcd string("Checking status...");
        delay ms(1500);
        lcd clear display();
        status="OK";
        if(keypad_to_ascii()=='5' || nurse_call==1){
            status="NURSECALL";
            nurse call=1;
            _delay_ms(1500);
        if(keypad to ascii()=='#'){
            status="OK";
            nurse call=0;
        if((pressureNum>12 || pressureNum<4) && !nurse call)</pre>
status="CHECKPRESSURE";
        if((temp_num>37 || temp_num<34) && !nurse_call)</pre>
status="CHECKTEMP";
        //writing status, temp and pressure in lcd
        lcd string(temperature);
        lcd data(0xDF);
        lcd string("C ");
```

```
lcd string(pressureStr);
lcd string("cm H20");
lcd command(0 \times C0);
lcd string(status);
_delay_ms(2500);
lcd clear display();
strcpy(payload, "ESP:payload:[");
append_to_payload("temperature", temperature);
append_to_payload("pressure", pressureStr);
append to payload("team", "45");
append to payload("status", status);
payload[strlen(payload) - 1] = ' \ 0';
strcat(payload, "]\n");
*/
do{
    failed=0;
    char receivedMessage2[30];
    lcd clear display();
    usart_transmit_string(payload);
    usart receive string(receivedMessage2);
    if(strcmp(receivedMessage2, "\"Success\"")==0){
        lcd string("3.Success");
    }else {
          lcd string("3.Fail");
          failed=1;
    delay ms(2000);
}while(failed);
lcd clear display();
char end[30];
usart_transmit_string("ESP:transmit\n");
usart receive string(end);
lcd string("4.");
lcd string(end);
delay ms(2000);
lcd clear display();
```

Στην αρχή γίνεται αρχικοποίηση του πρωτοκόλλου TWI και θέτουμε την θύρα επέκτασης 0 του PCA9555 ως έξοδο, ενώ στην θύρα επέκτασης 1 του PCA9555 θέτουμε τα 4 MSB ως είσοδο και το 4 LSB ως έξοδο. Αυτές οι τιμές επιλέχθηκαν καθώς στην θύρα επέκτασης 0 είναι συνδεδεμένη η LCD οθόνη και στην θύρα

επέκτασης 1 το 4x4 πληκτρολόγιο. Έπειτα ρυθμίζουμε κατάλληλα το ADC0 της πλακέτας, αρχικοποιούμε την οθόνη και το UART και του κάνουμε επανεκκίνηση. Η τιμή 103 στην αρχικοποίηση του UART προκύπτει από το ότι έχουμε μικροελεγκτή συχνότητας 16MHz και θέλουμε BAUD 9600.

Μετά από τις απαραίτητες αρχικοποιήσεις μπαίνουμε σε έναν ατέρμονα βρόχο ο οποίος αποτελείται από 4 στάδια. Σε κάθε στάδιο εκτός από το τελευταίο επιμένουμε έως ότου λάβουμε "Success" από τον server.

Στο πρώτο στάδιο προσπαθούμε να συνδεθούμε στον server στέλνοντας το μήνυμα "ESP:connect\n". Μέχρι να λάβουμε "Success" παραμένουμε σε αυτό το στάδιο. Αν λάβουμε "Success" εκτυπώνουμε στην οθόνη "1.Success" και στάδιο πηγαίνουμε στο δεύτερο όπου στέλνουμε ESP:url:"http://192.168.1.250:5000/data" και επαναλαμβάνουμε λάβουμε "Success" από τον server. Σε περίπτωση που λάβουμε "Fail" στο στάδιο 1 εκτυπώνουμε στην οθόνη "1.Fail", ενώ αν λάβουμε "Fail" στο στάδιο 2 εκτυπώνουμε "2.Fail". Αξίζει να σημειωθεί εδώ ότι παρατηρήθηκε κατά την διάρκεια που κάναμε την εργασία ότι ο server στην πρώτη φορά που συνδεόμασταν σε αυτόν μετά το "Success" που στέλνει στο πρώτο στάδιο φαίνεται να στέλνει άλλο ένα dummy μήνυμα και για αυτό την πρώτη μόνο φορά που μπαίνουμε στο δεύτερο στάδιο κάνουμε ένα dummy receive string.

Αφού λοιπόν λάβαμε "Success" και στο δεύτερο στάδιο έχουμε συνδεθεί στον server και πρέπει να κατασκευάσουμε το payload που πρόκειται να στείλουμε. Για αυτό μετράμε την θερμοκρασία μέσω της calculateTemp και παίρνουμε την πίεση από το POT0 κάνοντας ADC και διαιρώντας την τιμή που λάβαμε με 50. Το 50 προκύπτει από το ότι έχουμε 10bit ADC, άρα μέγιστη τιμή 1024, και η μέγιστη τιμή της πίεσης είναι 20 cm H_2 0 και $\frac{1024}{20} \cong 50$, και μετατρέπουμε την

τιμή της πίεσης σε string. Στην συνέχεια ελέγχουμε το status του ασθενή. Αν ο ασθενής πατήσει το πλήκτρο 5 (το τελευταίο ψηφίο του αριθμού της ομάδος μας) εκείνη την στιγμή ή έχει πατήσει το 5 σε προηγούμενη επανάληψη του βρόχου τότε το status του γίνεται "NURSECALL". Αν πατήσει την δίεση τότε το status του από NURSECALL γίνεται ΟΚ. Αν η πίεση δεν είναι μεταξύ των τιμών 4 με 12 και δεν έχει πατηθεί το NURSECALL τότε το status του γίνεται CHECKPRESSURE. Αν η θερμοκρασία του δεν είναι ανάμεσα σε 34 με 37 βαθμούς και δεν έχει πατηθεί το NURSECALL τότε το status γίνεται CHECKTEMP. Αν δεν έχει πατηθεί NURSECALL (ή πατήθηκε προηγουμένως και τώρα ακυρώθηκε) και η θερμοκρασία και η πίεση του ασθενή είναι «καλή» τότε το status του γίνεται ΟΚ. Επειδή η εκφώνηση δεν επιτρέπει να υπάρχει status που να ειδοποιεί και για έλεγχο της θερμοκρασίας και της πίεσης, σε περίπτωση που χρειάζονται να γίνουν και τα δύο το status που μένει είναι η τελευταία τιμή του status, δηλαδή το CHECKTEMP, επειδή ο έλεγχος φυσιολογικής τιμής της θερμοκρασίας γίνεται μετά της πίεση. Αφού έχουμε όλες τις αναγκαίες πληροφορίες για το payload τις δείχνουμε την οθόνη και κατασκευάζουμε το payload. Όταν το payload κατασκευαστεί το στέλνουμε συνεχώς στον server μέχρι να λάβουμε το μήνυμα "Success" από αυτόν.

Στο τέταρτο στάδιο αφού έχουμε στείλει το payload στέλνουμε το μήνυμα " ESP:transmit" στον server και εκτυπώνουμε την απάντηση του server στην οθόνη. Αν όλα έχουν πάει καλά με το payload λαμβάνουμε απάντηση 200 OK.

Ακολουθεί ο πλήρης κώδικας της υλοποίησής μας:

```
#define F CPU 16000000UL
#include<avr/io.h>
#include<avr/interrupt.h>
#include<util/delay.h>
#include <stdlib.h>
#include <string.h>
#include <stdio.h>
#include <avr/pgmspace.h>
#define PCA9555 0 ADDRESS 0x40
#define TWI READ 1
#define TWI WRITE 0
#define SCL CLOCK 100000L
//A0=A1=A2=0 by hardware
// reading from twi device
// writing to twi device
// twi clock in Hz
//Fscl=Fcpu/(16+2*TWBR0 VALUE*PRESCALER VALUE)
#define TWBR0 VALUE ((F CPU/SCL CLOCK)-16)/2
// PCA9555 REGISTERS
typedef enum {
REG INPUT 0 = 0,
REG INPUT 1 = 1,
REG OUTPUT 0 = 2,
REG OUTPUT 1 = 3,
REG POLARITY INV 0 = 4,
REG POLARITY INV 1 = 5,
REG CONFIGURATION 0 = 6,
REG CONFIGURATION 1 =7
} PCA9555 REGISTERS;
//----- Master Transmitter/Receiver ------
#define TW START 0x08
#define TW_REP_START 0x10
//-------Master Transmitter ------
#define TW MT SLA ACK 0x18
#define TW MT SLA NACK 0x20
#define TW MT DATA ACK 0x28
#define TW MR SLA ACK 0x40
#define TW MR SLA NACK 0x48
#define TW MR DATA NACK 0x58
#define TW STATUS MASK 0b11111000
#define TW STATUS (TWSR0 & TW STATUS MASK)
```

```
//initialize TWI clock
void twi init(void){
    TWSR0 = 0; // PRESCALER VALUE=1
    TWBR0 = TWBR0 VALUE; // SCL CLOCK 100KHz
// Read one byte from the twi device (request more data from device)
unsigned char twi readAck(void){
    TWCR0 = (1 << TWINT) | (1 << TWEN) | (1 << TWEA);
    while(!(TWCR0 & (1<<TWINT)));</pre>
    return TWDR0;
//Read one byte from the twi device, read is followed by a stop
condition
unsigned char twi readNak(void){
    TWCR0 = (1 << TWINT) | (1 << TWEN);
   while(!(TWCR0 & (1<<TWINT)));</pre>
    return TWDR0;
// Issues a start condition and sends address and transfer direction.
// return 0 = device accessible, 1= failed to access device
unsigned char twi start(unsigned char address){
    uint8 t twi status; // send START condition
    TWCR0 = (1 << TWINT) | (1 << TWSTA) | (1 << TWEN);
    // wait until transmission completed
    while(!(TWCR0 & (1<<TWINT)));
    // check value of TWI Status Register.
    twi status = TW STATUS & 0xF8;
    if ( (twi status != TW START) && (twi status != TW REP START))
return 1;
    // send device address
    TWDR0 = address;
    TWCR0 = (1 << TWINT) \mid (1 << TWEN);
    // wail until transmission completed and ACK/NACK has been received
    while(!(TWCR0 & (1<<TWINT)));
    // wail until transmission completed and ACK/NACK has been received
   while(!(TWCR0 & (1<<TWINT)));
```

```
// check value of TWI Status Register.
    twi status = TW STATUS & 0xF8;
    if ( (twi_status != TW_MT_SLA_ACK) && (twi_status != TW_MR_SLA_ACK)
 return 1;
    return 0:
// Send start condition, address, transfer direction.
// Use ack polling to wait until device is ready
void twi start wait(unsigned char address){
    uint8 t twi status;
    while (1){
        // send START condition
        TWCR0 = (1 << TWINT) | (1 << TWSTA) | (1 << TWEN);
        // wait until transmission completed
        while(!(TWCR0 & (1<<TWINT)));</pre>
        // check value of TWI Status Register.
        twi_status = TW_STATUS & 0xF8;
        if ( (twi_status != TW_START) && (twi_status != TW REP_START))
continue:
        // send device address
        TWDR0 = address;
        TWCR0 = (1 << TWINT) | (1 << TWEN);
        // wail until transmission completed
        while(!(TWCR0 & (1<<TWINT)));</pre>
        // check value of TWI Status Register.
        twi status = TW STATUS & 0xF8;
        if ( (twi status == TW MT SLA NACK )||(twi status
==TW MR DATA NACK) ){
            /* device busy, send stop condition to terminate write
operation */
            TWCR0 = (1 << TWINT) | (1 << TWEN) | (1 << TWST0);
            // wait until stop condition is executed and bus released
            while(TWCR0 & (1<<TWST0));</pre>
            continue;
        break;
    }
// Send one byte to twi device, Return 0 if write successful or 1 if
```

```
unsigned char twi write( unsigned char data ){
    // send data to the previously addressed device
   TWDR0 = data;
   TWCR0 = (1 << TWINT) \mid (1 << TWEN);
   // wait until transmission completed
   while(!(TWCR0 & (1<<TWINT)));</pre>
   if( (TW STATUS & 0xF8) != TW MT DATA ACK) return 1;
    return 0:
// Send repeated start condition, address, transfer direction
//Return: 0 device accessible
         1 failed to access device
unsigned char twi rep start(unsigned char address)
return twi start( address );
// Terminates the data transfer and releases the twi bus
void twi stop(void){
   // send stop condition
   TWCR0 = (1 << TWINT) | (1 << TWEN) | (1 << TWST0);
   while(TWCR0 & (1<<TWST0));</pre>
void PCA9555 0 write(PCA9555 REGISTERS reg, uint8 t value){
    twi start wait(PCA9555 0 ADDRESS + TWI WRITE);
    twi write(reg);
    twi write(value);
    twi stop();
uint8 t PCA9555 0 read(PCA9555 REGISTERS reg){
    uint8 t ret val;
    twi start wait(PCA9555 0 ADDRESS + TWI WRITE);
    twi write(reg);
    twi rep start(PCA9555 0 ADDRESS + TWI READ);
    ret val = twi readNak();
    twi stop();
    return ret val;
```

```
//function to get the number of row to check if a button is pressed.
Returns an 8 bit int with the buttons that were pressed.
uint8 t scan row(uint8 t row){
    uint8_t check=1;
    check = check << row;</pre>
    PCA9555_0_write(REG_OUTPUT_1, ~check);
    uint8 t result = PCA9555 0 read(REG INPUT 1)>>4;
    return result;
//function to check the entire 4x4 keypad. Returns an 16 bit int with
the buttons that were pressed.
//The formation of the result is r0 r1 r2 r3 where its r0 is 4 bits
IO1 7, IO1 6, IO 5, IO 4
uint16 t scan keypad(){
    uint16 t result;
    result= (scan row(0) << 12) + (scan row(1) << 8) + (scan row(2) << 4)
+scan row(3);
    return result;
uint8 t previous call=0;
uint16 t scan keyboard rising edge(){
    uint16 t result0 = scan keypad();
    delay ms(15);
    uint16 t result1 = scan keypad();
    uint16 t same = (~result0 & ~result1);
    previous call=~same;
    return same;
uint8 t keypad to ascii(){
        switch(scan keyboard rising edge()) {
        case 0: return 0;
        case 1: return '1';
        case 2: return '2';
        case 4: return '3';
        case 8: return 'A';
        case 16: return '4';
        case 32: return '5';
        case 64: return '6';
        case 128: return 'B';
        case 256: return '7';
        case 512: return '8';
        case 1024: return '9';
        case 2048: return 'C';
```

```
case 4096: return '*';
        case 8192: return '0';
        case 16384: return '#';
        case 32768: return 'D';
        return 0:
void write 2 nibbles(uint8 t c);
void lcd clear display();
void lcd command(uint8 t com);
void lcd data(unsigned char data);
void lcd init();
void lcd string(const char *str);
void write 2 nibbles(uint8 t c){
    uint8 t temp= c;
    PCA9555 0 write(REG OUTPUT 0, (PCA9555 0 read(REG INPUT 0) & 0x0f)
 (temp & 0xf0)); //LCD Data High Bytes
    PCA9555_0_write(REG_OUTPUT_0, PCA9555_0_read(REG_INPUT_0) | 0x08);
    asm("nop");
    asm("nop");
    PCA9555 0 write(REG OUTPUT 0, PCA9555 0 read(REG INPUT 0) &
(\sim 0 \times 08)):
    c=(c<<4) | (c>>4);
    PCA9555 0 write(REG OUTPUT 0, (PCA9555 0 read(REG INPUT 0) & 0x0f)
+ (c & 0xf0)); //LCD Data Low Bytes
    PCA9555 0 write(REG OUTPUT 0, PCA9555 0 read(REG INPUT 0) | 0x08);
    asm("nop");
    asm("nop");
    PCA9555 0 write(REG OUTPUT 0, PCA9555 0 read(REG INPUT 0) &
(\sim 0 \times 08));
void lcd clear display(){
    lcd command(0 \times 01);
    delay ms(5);
void lcd command(uint8 t com){
    PCA9555 0 write(REG OUTPUT 0, PCA9555 0 read(REG INPUT 0) &
(\sim 0 \times 04)); //LCD RS=0 => Instruction
    write_2_nibbles(com);
    delay us(250);
```

```
void lcd data(uint8 t data){
    PCA9555_0_write(REG_OUTPUT_0, PCA9555_0_read(REG_INPUT_0) |
0x04); //LCD RS=1 => Data
    write_2_nibbles(data);
    _delay_us(250);
void lcd init(){
    _delay_ms(200);
    int i=0;
    while(i<3){
                     //command to switch to 8 bit mode
        PCA9555 0 write(REG OUTPUT 0, 0x030);
        PCA9555_0_write(REG_OUTPUT_0, PCA9555_0 read(REG_INPUT_0) |
0x08);
        asm("nop");
        asm("nop");
        PCA9555 0 write(REG OUTPUT 0, PCA9555 0 read(REG INPUT 0) &
(\sim 0 \times 08));
        _delay_us(250);
        ++i;
    }
    PCA9555_0_write(REG_OUTPUT_0, 0x20); //command to switch to 4 bit
mode
    PCA9555 0 write(REG OUTPUT 0, PCA9555 0 read(REG INPUT 0) | 0x08);
    _delay_us(2);
    PCA9555_0_write(REG_OUTPUT_0, PCA9555_0 read(REG_INPUT_0) &
(~0x08));
    delay us(250);
    lcd command(0x28); //5*8 dots, 2 lines
    lcd command(0x0c); //display on, cursor off
    lcd clear display();
void lcd string(const char *str){
    int i:
    for(i=0; str[i]!=0; i++) lcd data(str[i]);
uint8 t one wire reset() {
 DDRD |= (1 << PD4);
 PORTD &= \sim(1 << PD4);
```

```
_delay_us(480);
  DDRD &= \sim (1 << PD4);
  PORTD &= \sim (1 << PD4);
  delay us(100);
  uint8_t input = PIND;
  delay us(380);
  return input & (1 << PD4) ? 0 : 1;
uint8 t one wire receive bit() {
  DDRD |= (1 << PD4);
 PORTD &= \sim(1 << PD4);
 delay us(2);
  DDRD &= \sim (1 << PD4);
  PORTD &= \sim (1 << PD4);
  delay us(10);
 uint8 t input = PIND;
 _delay_us(49);
  return input & (1 << PD4) ? 1 : 0;
void one wire transmit bit(uint8 t data){
  DDRD |= (1 << PD4);
 PORTD &= \sim(1 << PD4);
 _delay_us(2);
  PORTD | = (data < < PD4);
 _delay_us(58);
 DDRD &= \sim (1 << PD4);
 PORTD &= \sim(1 << PD4);
 _delay_us(1);
uint8_t one_wire_receive_byte(){
  uint8_t i=0;
 uint8 t receive result=0;
 while(i<8){
    receive_result+= (one_wire_receive_bit()<<i);</pre>
    i++;
  return receive_result;
```

```
void one_wire_transmit_byte(uint8_t data){
  uint8 t i=0;
 while(i<8){</pre>
    one_wire_transmit_bit(data & 0x01);
    data=data>>1;
    i++;
  }
uint8_t low, high;
void measureTemp(){
  if(!one wire reset()){
    high=0x080;
    low=0x00;
    __asm__ __volatile__(
    "mov r24, %1" "\n\\overline{t}"
    "mov r25, %0" "\n\t"
    : "r" (high), "r" (low)
    );
    return;
  }
  one_wire_transmit_byte(0xCC);
  one wire transmit byte(0x44);
  while(one wire receive bit()!=1);
  if(!one_wire_reset()){
    high=0x80;
    low=0x00;
    __asm__ __volatile__(
    "mov r24, %1" "\n\t"
    "mov r25, %0" "\n\t"
    : "r" (high), "r" (low)
    );
    return;
  one_wire_transmit_byte(0xCC);
  one wire transmit byte(0xBE);
```

```
low=one wire receive byte();
  high=one wire receive byte();
  __asm__ __volatile__(
    "mov r24, %1" "\n\t"
    "mov r25, %0" "\n\t"
    : "r" (high), "r" (low)
    );
float temp num;
void calculateTemp(char temp[]){
  measureTemp();
  lcd clear display();
  if(high==0x80 \&\& low==0x00){
    lcd string("No Device");
    return;
  uint16_t temperature = (uint16_t)((high << 8) | low);</pre>
  if(high & 0xF8){ //if temperature is negative
    temperature=~temperature+1;
    lcd data('-');
  float num = temperature *0.0625*1.55;
  temp num=num;
  dtostrf(num, 3, 2, temp);
void usart init(unsigned int ubrr){
    UCSR0A=0;
    UCSR0B=(1<<RXEN0)|(1<<TXEN0);
    UBRROH=(unsigned char)(ubrr>>8);
    UBRR0L=(unsigned char)ubrr;
    UCSR0C=(3 << UCSZ00);
    return;
void usart transmit(uint8 t data){
    while(!(UCSR0A&(1<<UDRE0)));</pre>
    UDR0=data;
```

```
void usart transmit string(const char str[]){
    for(i=0; str[i]!='\0'; i++) usart_transmit(str[i]);
uint8_t usart_receive(){
   while(!(UCSR0A&(1<<RXC0)));
    return UDR0;
void usart receive string(char string[]) {
    int i = 0;
    char received;
   while((received = usart receive()) != '\n') {
        string[i++] = received;
    string[i] = ' \ 0';
char payload[168];
void append to payload(const char *key, const char *value) {
    strcat(payload, "{\"name\": \"");
   strcat(payload, key);
   strcat(payload, "\",\"value\": \"");
    strcat(payload, value);
    strcat(payload, "\"},");
int main(){
    twi init();
    PCA9555 0 write(REG CONFIGURATION 0, 0x00);
    PCA9555 0 write(REG CONFIGURATION 1, 0xF0); //Set EXT PORT1[7:4] as
input and EXT_PORT[3:0] as output
    ADMUX |= 0b01000000; //Right adjusted, ADC0
    ADCSRA |= 0b10000111; //128 Prescaler
    char recMes[20];
    lcd init();
   usart init(103);
```

```
usart transmit string("ESP:restart\n");
    usart receive string(recMes);
    int nurse_call=0;
    uint8_t failed, first;
    first=0;
   while(1){
        lcd clear display();
        do {
            char receivedMessage[30];
            failed=0;
            lcd clear display();
            usart transmit string("ESP:connect\n");
            usart receive string(receivedMessage);
            if(strcmp(receivedMessage, "\"Success\"")==0){
              lcd string("1.Success");
            }else {
                lcd_string("1.Fail");
                failed=1;
           delay ms(1000);
        } while(failed);
        do {
            char receivedMessage2[30];
            failed=0;
            lcd clear display();
            if(!first) {
                usart_receive_string(receivedMessage2);
                first=1:
usart transmit string("ESP:url:\"http://192.168.1.250:5000/data\"\n");
            usart receive string(receivedMessage2);
            if(strcmp(receivedMessage2, "\"Success\"")==0){
              lcd string("2.Success");
            }else {
                lcd string("2.Fail");
                failed=1;
           delay ms(1000);
        } while(failed);
        lcd clear display();
        //Temperature calculation
```

```
char temperature[6];
        calculateTemp(temperature);
        //Calculate Pressure
        ADCSRA|= (1<<ADSC);
                              //Start ADC
        while(ADCSRA & (1<<ADSC)); //Wait until ADC is finished</pre>
        uint8 t pressureNum=ADC/50;
        char pressureStr[2];
        dtostrf(pressureNum, 3, 2, pressureStr);
        //Checking status
        char *status;
        lcd_string("Checking status...");
        \overline{\text{delay ms}(1500)};
        lcd clear display();
        status="OK";
        if(keypad_to_ascii()=='5' || nurse_call==1){
            status="NURSECALL";
            nurse call=1;
            delay ms(1500);
        if(keypad to ascii()=='#'){
            status="OK";
            nurse call=0;
        if((pressureNum>12 || pressureNum<4) && !nurse call)</pre>
status="CHECKPRESSURE";
        if((temp_num>37 || temp_num<34) && !nurse_call)</pre>
status="CHECKTEMP";
        //writing status, temp and pressure in lcd
        lcd string(temperature);
        lcd data(0xDF);
        lcd string("C ");
        lcd string(pressureStr);
        lcd string("cm H20");
        lcd command(0 \times C0);
        lcd string(status);
        delay ms(2500);
        lcd_clear_display();
```

```
strcpy(payload, "ESP:payload:[");
    append to payload("temperature", temperature);
    append to payload("pressure", pressureStr);
    append_to_payload("team", "45");
    append to payload("status", status);
    payload[strlen(payload) - 1] = ' \setminus 0';
    strcat(payload, "]\n");
    */
    do{
        failed=0:
        char receivedMessage2[30];
        lcd clear display();
        usart transmit string(payload);
        usart receive string(receivedMessage2);
        if(strcmp(receivedMessage2, "\"Success\"")==0){
            lcd_string("3.Success");
        }else {
              lcd string("3.Fail");
              failed=1;
        }
        delay ms(2000);
    }while(failed);
    lcd_clear_display();
    char end[30];
    usart transmit string("ESP:transmit\n");
    usart receive string(end);
    lcd string("4.");
    lcd string(end);
    delay ms(2000);
    lcd_clear_display();
}
```