# PRÁCTICA 6 - Implementación de un cliente GATT

# Tarea previa

```
static const char remote_device_name[] = "ESP_GATTS_CLIENT_NOCONNECT";
```

#### Tarea 1

Configura los parámetros de escaneo para que éste se produzca con menos frecuencia (e.g. 1 segundo o un valor superior). Para ello, adapta el valor del campo <a href="mailto:scan\_interval">scan\_interval</a> con el valor apropiado.

Para configurar el varlo de scan\_interval a 4 segundos consultamos la documentación oficial en este enlace.

En este caso 4 segundos = 4000 ms = 6400 \* 0.625. Convirtiendo este valor a hexadecimal obtenemos 0x1900, estableciendolo como valor por defecto en el parámetro BLE SCAN INTERVAL en sdkconfig.

## Tarea 2

El valor de duración del proceso de escaneado es configurable. En esta primera parte de la práctica, auméntalo para que el proceso sea más largo y así tengas más tiempo para analizar la salida producida. Comprueba que efectivamente el tiempo en el que el dispositivo se encuentra en fase de escaneo es el seleccionado.

Aumentamos el valor por defecto a 60 segundos para poder analizar la salida:

#### Tarea 3

Analiza el código y modifícalo para que el proceso de escaneo se produzca cíclicamente, con un parámetro de separación entre fases de escaneado definido a través de los menús de configuración. De la misma manera, añade a dichos menús un parámetro adicional que indique el inervalo entre eventos de escaneo.

Para conseguir que el proceso sea cíclico se han definido los siguientes parámetros en el fichero Kconfig.projbuild:

```
config BLE_SCAN_LE_INTERVAL
        hex "Ble scan interval (Time = N * 0.625 msec Time Range: 2.5 msec to
10240 msec)"
        range 0x0004 0x4000
        default 0x1900
    config BLE SCAN LE WINDOW
        hex "The duration of the LE scan. LE_Scan_Window shall be less than or
equal to LE_Scan_Interval (Time = N * 0.625 msec Time Range: 2.5 msec to 10240
msec)"
        range 0x0004 0x4000
        default 0x0010
    config BLE SCAN DURATION
        int "Duration of a scan (s)"
        range 60 300
        default 60
    config BLE_SCAN_DELAY
        int "Delay before starting new scan (s)"
        range 10 600
        default 30
```

Los parámetros BLE\_SCAN\_LE\_INTERVAL y BLE\_SCAN\_LE\_WINDOW se han definido como 4s y 1s respectivamente en la estructura esp\_ble\_scan\_params\_t.

```
static esp_ble_scan_params_t ble_scan_params = {
    .scan_type = BLE_SCAN_TYPE_ACTIVE,
    .own_addr_type = BLE_ADDR_TYPE_PUBLIC,
    .scan_filter_policy = BLE_SCAN_FILTER_ALLOW_ALL,
    .scan_interval = BLE_SCAN_LE_INTERVAL,
    .scan_window = BLE_SCAN_LE_WINDOW,
    .scan_duplicate = BLE_SCAN_DUPLICATE_DISABLE};
```

Por otro lado utilizamos BLE SCAN DURATION a la hora de iniciar un nuevo escaneo:

```
uint32_t duration = BLE_SCAN_DURATION; // the unit of the duration is second
esp_ble_gap_start_scanning(duration);
```

Una vez finalizado el escaneo, dentro del tratamiento del evento ESP\_GAP\_SEARCH\_INQ\_CMPL\_EVT esperamos 30s segundos establecidos por defecto en el parámetro BLE\_SCAN\_DELAY:

```
case ESP_GAP_SEARCH_INQ_CMPL_EVT:
    // Wait BLE_SCAN_DELAY seconds
    ESP_LOGI(GATTC_TAG, "Waiting %d seconds before starting a new scan",
BLE_SCAN_DELAY);
    vTaskDelay(BLE_SCAN_DELAY * 1000 / portTICK_PERIOD_MS);
    // Initiate new scan
    ESP_LOGI(GATTC_TAG, "Starting a new %d seconds duration scan",
BLE_SCAN_DURATION);
    uint32_t duration = BLE_SCAN_DURATION; // the unit of the duration is second
    esp_ble_gap_start_scanning(duration);
    break;
```

Resumiendo, los valores establecidos para los parámetros son los siguientes:

• BLE\_SCAN\_LE\_INTERVAL: 4s

• BLE\_SCAN\_LE\_WINDOW: 10ms

• BLE SCAN\_DURATION: 60s

• BLE SCAN DELAY: 30s

#### Tarea 4

Muestra por pantalla el valor de RSSI de cada dispositivo BLE encontrado. Para ello, busca en laestructura de parámetros recibidos el campo correspondiente.

Examinamos los parámetros de la estructura esp\_ble\_gap\_cb\_param\_t recibida dentro del tratamiento del evento ESP\_GAP\_BLE\_SCAN\_RESULT\_EVT en la documentación oficial mostrando su valor:

Verificamos como el valor es distinto para cada dispositivo detectado en el escaneo:

```
I (237932) GATTC CLIENT: Device found
I (237932) GATTC_CLIENT: bc 14 85 ea 9c 18
I (237932) GATTC_CLIENT: searched Adv Data Len 28, Scan Response Len 0
I (237932) GATTC_CLIENT: searched Device Name Len 0
I (237942) GATTC_CLIENT: searched Device RSSI -74
I (237942) GATTC_CLIENT:
I (237952) GATTC_CLIENT: Device found
I (237952) GATTC_CLIENT: 88 0f 10 8d df 4e
I (237962) GATTC_CLIENT: searched Adv Data Len 31, Scan Response Len 0
I (237962) GATTC CLIENT: searched Device Name Len 0
I (237972) GATTC_CLIENT: searched Device RSSI -77
I (237982) GATTC_CLIENT:
I (238052) GATTC_CLIENT: Device found
I (238052) GATTC_CLIENT: bc 14 85 ea 9c 18
I (238052) GATTC_CLIENT: searched Adv Data Len 28, Scan Response Len 0
I (238062) GATTC_CLIENT: searched Device Name Len 0
I (238062) GATTC_CLIENT: searched Device RSSI -75
I (238072) GATTC_CLIENT:
I (241052) GATTC_CLIENT: Waiting 30 seconds before starting a new scan
```

## Tarea 5

Añade a los menús de configuración un campo que indique la dirección MAC BLE de un dispositivo(conocido) que esté en fase de anuncio. Puedes utilizar los códigos de servidor de la práctica anterior.

Para obtener la MAC podemos examinar la salida del servidor:

```
I (572) main_task: Calling app_main()
I (622) BTDM_INIT: BT controller compile version [946b762]
I (622) BTDM_INIT: Bluetooth MAC: 24:0a:c4:ea:28:c2
I (632) phy_init: phy_version 4670,719f9f6,Feb 18 2021,17:07:07
I (1042) main_task: Returned from app_main()
I (1042) GATTS_TABLE_DEMO: create attribute table successfully, the number handle = 8

I (1052) GATTS_TABLE_DEMO: SERVICE_START_EVT, status 0, service_handle 40
I (1062) GATTS_TABLE_DEMO: advertising start successfully
```

Configuramos por tanto un nuevo parámetro en el fichero Kconfig.projbuild del cliente:

```
config MAC_KNOWN_DEVICE
  string "MAC for a known device on advertising state"
  default "24:0a:c4:ea:28:c2"
  help
     Specify a MAC address for the ethernet interface in the form of
     six hex 8-bit chars separated by colons (e.g.:
     aa:33:cc:22:e2:c0). The default is an empty string, which
     means the code will make 00:00:5E:00:53:XX, where XX will be
     random.
```

Añadiendo su definición en el fichero gattc\_demo.c para poder ser utilizada más adelante:

```
#define MAC_KNOWN_DEVICE CONFIG_MAC_KNOWN_DEVICE
```

### Tarea 6

Modifica la fase de escaneado para que únicamente se muestre información (al menos nombre y RSSI) sobre el dispositivo cuya dirección MAC se haya configurado.

Para ello añadimos un nuevo filtro dentro del tratamiento del evento ESP\_GAP\_SEARCH\_INQ\_RES\_EVT:

Podemos ver en la salida la información filtrada por la MAC introducida como parámetro:

```
I (6885072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-50
I (6889072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-48
I (6893092) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-45
```

```
I (6897082) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-50
I (6901062) GATTC_CLIENT: Waiting 30 seconds before starting a new scan
I (6931062) GATTC_CLIENT: Starting a new 60 seconds duration scan
I (6931062) GATTC_CLIENT: scan start success
I (6931092) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
I (6935082) GATTC CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP GATTS SERVER | RSSI:
-45
I (6939082) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-50
I (6943072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-48
I (6947072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-46
I (6951072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-49
I (6955072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-46
I (6959092) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-46
I (6963092) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-49
I (6967072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
I (6971072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-45
I (6975072) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
I (6983082) GATTC_CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP_GATTS_SERVER | RSSI:
-46
I (6987072) GATTC CLIENT: MAC: 24:0a:c4:ea:28:c2 | NAME: ESP GATTS SERVER | RSSI:
I (6991062) GATTC_CLIENT: Waiting 30 seconds before starting a new scan
```

## Tarea 7

Modifica el firmware básico para que, en función del valor de RSSI obtenido para el dispositivo deinterés, el cliente reporte con más o menos frecuencia por pantalla un valor proporcional a la distancia supuesta para dicho dispositivo. Si dispones de un LED conectado a la placa, puedes hacer que la frecuencia de parpadeo del mismo sea proporcional a dicha distancia.

En este caso hemos bajado el valor del parámetro BLE\_SCAN\_LE\_INTERVAL a 1s es decir 0x640 en hexadecimal.

Al final de la función app\_main hemos inicializado el led:

```
// Configure led for blinking
ESP_LOGI(GATTC_TAG, "Configure blinking led!");
gpio_reset_pin(BLINK_GPIO);
```

```
/* Set the GPIO as a push/pull output */
gpio_set_direction(BLINK_GPIO, GPIO_MODE_OUTPUT);
```

Se ha establecido un parámetro estático static int delay\_blinking = 0; y una función que realiza la operación de parpadeo y espera el tiempo establecido:

Este parámetro se calcula automáticamente en funcion del RSSI multiplicándolo por 4 para ver las diferencias en milisegundos:

```
delay_blinking = abs(scan_result->scan_rst.rssi) * 4;
esp_log_buffer_char(GATTC_TAG, adv_name, adv_name_len);
ESP_LOGI(GATTC_TAG, "MAC: %s", macdetected);
ESP_LOGI(GATTC_TAG, "RSSI: %d | Blinking delay %d ms", scan_result->scan_rst.rssi, delay_blinking);
ESP_LOGI(GATTC_TAG, "------");
```

Por último la salida sería como la siguiente:

```
I (7065) GATTC_CLIENT: ------
I (8065) GATTC_CLIENT: ESP_GATTS_SERV
I (8065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (8065) GATTC_CLIENT: RSSI: -45 | Blinking delay 180 ms
I (8065) GATTC_CLIENT: -----
I (12065) GATTC_CLIENT: ESP_GATTS_SERV
I (12065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (12065) GATTC_CLIENT: RSSI: -44 | Blinking delay 176 ms
I (12065) GATTC_CLIENT: -----
I (14065) GATTC_CLIENT: ESP_GATTS_SERV
I (14065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (14065) GATTC_CLIENT: RSSI: -47 | Blinking delay 188 ms
I (14075) GATTC_CLIENT: -----
I (16075) GATTC_CLIENT: ESP_GATTS_SERV
I (16075) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (16075) GATTC_CLIENT: RSSI: -48 | Blinking delay 192 ms
I (16075) GATTC_CLIENT: -----
I (17055) GATTC CLIENT: ESP GATTS SERV
I (17065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (17065) GATTC_CLIENT: RSSI: -49 | Blinking delay 196 ms
I (17065) GATTC_CLIENT: ------
I (18055) GATTC_CLIENT: ESP_GATTS_SERV
I (18055) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (18055) GATTC_CLIENT: RSSI: -51 | Blinking delay 204 ms
I (18055) GATTC_CLIENT: ------
I (20065) GATTC_CLIENT: ESP_GATTS_SERV
I (20065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (20065) GATTC_CLIENT: RSSI: -50 | Blinking delay 200 ms
I (20065) GATTC_CLIENT: ------
I (21065) GATTC_CLIENT: ESP_GATTS_SERV
I (21065) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (21065) GATTC_CLIENT: RSSI: -50 | Blinking delay 200 ms
I (21065) GATTC_CLIENT: ------
I (24075) GATTC_CLIENT: ESP_GATTS_SERV
I (24075) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (24075) GATTC_CLIENT: RSSI: -51 | Blinking delay 204 ms
I (24085) GATTC_CLIENT: ------
I (25065) GATTC CLIENT: ESP GATTS SERV
I (25065) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (25065) GATTC_CLIENT: RSSI: -47 | Blinking delay 188 ms
I (25065) GATTC CLIENT: ------
I (26045) GATTC CLIENT: ESP GATTS SERV
I (26055) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (26055) GATTC_CLIENT: RSSI: -43 | Blinking delay 172 ms
I (26055) GATTC CLIENT: -----
I (29065) GATTC_CLIENT: ESP_GATTS_SERV
I (29065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (29065) GATTC_CLIENT: RSSI: -42 | Blinking delay 168 ms
I (29075) GATTC_CLIENT: -----
I (31055) GATTC_CLIENT: ESP_GATTS_SERV
I (31055) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (31055) GATTC_CLIENT: RSSI: -27 | Blinking delay 108 ms
I (31055) GATTC_CLIENT: ------
I (32055) GATTC CLIENT: ESP GATTS SERV
```

```
I (32065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (32065) GATTC_CLIENT: RSSI: -23 | Blinking delay 92 ms
I (32065) GATTC_CLIENT: -----
I (33065) GATTC_CLIENT: ESP_GATTS_SERV
I (33065) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (33065) GATTC_CLIENT: RSSI: -18 | Blinking delay 72 ms
I (33065) GATTC_CLIENT: ------
I (35075) GATTC CLIENT: ESP GATTS SERV
I (35075) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (35075) GATTC_CLIENT: RSSI: -23 | Blinking delay 92 ms
I (35085) GATTC_CLIENT: ------
I (36065) GATTC_CLIENT: ESP_GATTS_SERV
I (36065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (36065) GATTC_CLIENT: RSSI: -18 | Blinking delay 72 ms
I (36075) GATTC CLIENT: ------
I (38065) GATTC_CLIENT: ESP_GATTS_SERV
I (38065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (38065) GATTC CLIENT: RSSI: -24 | Blinking delay 96 ms
I (38065) GATTC CLIENT: ------
I (40055) GATTC_CLIENT: ESP_GATTS_SERV
I (40055) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (40055) GATTC_CLIENT: RSSI: -28 | Blinking delay 112 ms
I (40055) GATTC_CLIENT: ------
I (41065) GATTC_CLIENT: ESP_GATTS_SERV
I (41065) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (41065) GATTC_CLIENT: RSSI: -34 | Blinking delay 136 ms
I (41065) GATTC_CLIENT: -----
I (42055) GATTC CLIENT: ESP GATTS SERV
I (42055) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (42055) GATTC_CLIENT: RSSI: -61 | Blinking delay 244 ms
I (42065) GATTC CLIENT: ------
I (47075) GATTC CLIENT: ESP GATTS SERV
I (47075) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (47075) GATTC_CLIENT: RSSI: -81 | Blinking delay 324 ms
I (47075) GATTC CLIENT: -----
I (50055) GATTC_CLIENT: ESP_GATTS_SERV
I (50055) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (50055) GATTC_CLIENT: RSSI: -80 | Blinking delay 320 ms
I (50065) GATTC CLIENT: -----
I (52075) GATTC_CLIENT: ESP_GATTS_SERV
I (52075) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (52075) GATTC_CLIENT: RSSI: -79 | Blinking delay 316 ms
I (52075) GATTC CLIENT: ------
I (55065) GATTC CLIENT: ESP GATTS SERV
I (55065) GATTC CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (55065) GATTC_CLIENT: RSSI: -80 | Blinking delay 320 ms
I (55065) GATTC_CLIENT: -----
I (59075) GATTC_CLIENT: ESP_GATTS_SERV
I (59075) GATTC_CLIENT: MAC: 8c:aa:b5:b8:bf:f6
I (59075) GATTC_CLIENT: RSSI: -28 | Blinking delay 112 ms
I (59085) GATTC CLIENT: ------
I (61045) GATTC_CLIENT: Waiting 30 seconds before starting a new scan
```

## Tarea previa

```
static const char remote_device_name[] = "ESP_GATTS_SERV";
```

### Tarea 8

Modifica el cliente para que las notificaciones enviadas por tu servidor GATT modificado en la práctica anterior sean recibidas y monitorizadas por parte del cliente GATT.

Tras cambiar el nombre de remote\_device\_name para que coincida con el nombre del servidor observamos los siguientes pasos en los logs del servidor:

- Conexión establecida
- Creación de la tarea de generación de valores aleatorios
- Confirmación de escritura del valor 0x10 en IDX\_CHAR\_CFG\_A
- Envio de valores aleatorios al cliente suscrito a notificaciones de la caracteristica IDX\_CHAR\_VAL\_A

#### Salida Servidor:

```
I (624902) GATTS_TABLE_DEMO: advertising start successfully
I (625082) GATTS_TABLE_DEMO: ESP_GATTS_CONNECT_EVT, conn_id = 0
I (625082) GATTS TABLE DEMO: 24 0a c4 ea 28 c2
I (625082) GATTS_TABLE_DEMO: Creating publish_data_task...
I (625092) APP: Update value for IDX_CHAR_VAL_A: 11 E1 33 44
I (625102) APP: Notifications disabled, not sending data...
I (625262) GATTS_TABLE_DEMO: update connection params status = 0, min_int = 16,
max_int = 32,conn_int = 32,latency = 0, timeout = 400
I (626062) GATTS TABLE DEMO: ESP GATTS MTU EVT, MTU 500
I (626102) APP: Update value for IDX CHAR VAL A: 11 F6 33 44
I (626102) APP: Notifications disabled, not sending data...
I (626222) GATTS_TABLE_DEMO: GATT_WRITE_EVT, handle = 43, value len = 2, value :
I (626222) GATTS TABLE DEMO: 01 00
I (626232) GATTS TABLE DEMO: notify enable
I (626232) APP: IDX_CHAR_CFG_A written value: 01 00
I (626242) GATTS TABLE DEMO: ESP GATTS CONF EVT, status = 0, attr handle 42
I (627102) APP: Update value for IDX_CHAR_VAL_A: 11 F4 33 44
I (627102) APP: Notifications enabled, sending data...
I (627102) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (627102) APP: Data sent successfully: 11 F4 33 44
I (628112) APP: Update value for IDX_CHAR_VAL_A: 11 8A 33 44
I (628112) APP: Notifications enabled, sending data...
I (628112) GATTS TABLE DEMO: ESP GATTS CONF EVT, status = 0, attr handle 42
I (628112) APP: Data sent successfully: 11 8A 33 44
I (629122) APP: Update value for IDX_CHAR_VAL_A: 11 C9 33 44
I (629122) APP: Notifications enabled, sending data...
I (629122) GATTS TABLE DEMO: ESP GATTS CONF EVT, status = 0, attr handle 42
I (629122) APP: Data sent successfully: 11 C9 33 44
I (630132) APP: Update value for IDX CHAR VAL A: 11 A4 33 44
I (630132) APP: Notifications enabled, sending data...
```

```
I (630132) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (630132) APP: Data sent successfully: 11 A4 33 44
I (631142) APP: Update value for IDX_CHAR_VAL_A: 11 1E 33 44
I (631142) APP: Notifications enabled, sending data...
I (631142) GATTS TABLE DEMO: ESP GATTS CONF EVT, status = 0, attr handle 42
I (631142) APP: Data sent successfully: 11 1E 33 44
I (632152) APP: Update value for IDX_CHAR_VAL_A: 11 E9 33 44
I (632152) APP: Notifications enabled, sending data...
I (632152) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (632152) APP: Data sent successfully: 11 E9 33 44
I (633162) APP: Update value for IDX_CHAR_VAL_A: 11 96 33 44
I (633162) APP: Notifications enabled, sending data...
I (633162) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (633162) APP: Data sent successfully: 11 96 33 44
I (634172) APP: Update value for IDX_CHAR_VAL_A: 11 29 33 44
I (634172) APP: Notifications enabled, sending data...
I (634172) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (634172) APP: Data sent successfully: 11 29 33 44
I (635182) APP: Update value for IDX_CHAR_VAL_A: 11 6E 33 44
I (635182) APP: Notifications enabled, sending data...
I (635182) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (635182) APP: Data sent successfully: 11 6E 33 44
I (636192) APP: Update value for IDX_CHAR_VAL_A: 11 6F 33 44
I (636192) APP: Notifications enabled, sending data...
I (636192) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (636192) APP: Data sent successfully: 11 6F 33 44
I (637202) APP: Update value for IDX_CHAR_VAL_A: 11 0F 33 44
I (637202) APP: Notifications enabled, sending data...
I (637202) GATTS_TABLE_DEMO: ESP_GATTS_CONF_EVT, status = 0, attr_handle 42
I (637202) APP: Data sent successfully: 11 0F 33 44
```

Por otro lado, en el cliente se ejecutan las siguientes acciones:

- Conexión al servidor
- Configuración de MTU de la conexión
- Descubrimiento de servicios
- Suscripción a notificaciones

#### Salida Cliente:

```
I (4095) GATTC_CLIENT: searched device ESP_GATTS_SERV

I (4105) GATTC_CLIENT: connect to the remote device.
I (4115) GATTC_CLIENT: stop scan successfully
I (4175) GATTC_CLIENT: ESP_GATTC_CONNECT_EVT conn_id 0, if 3
I (4175) GATTC_CLIENT: REMOTE BDA:
I (4175) GATTC_CLIENT: 8c aa b5 b8 bf f6
I (4185) GATTC_CLIENT: open success
I (4385) GATTC_CLIENT: update connection params status = 0, min_int = 16, max_int = 32,conn_int = 32,latency = 0, timeout = 400
I (5105) GATTC_CLIENT: discover service complete conn_id 0
```

```
I (5105) GATTC_CLIENT: SEARCH RES: conn_id = 0 is primary service 1
I (5105) GATTC CLIENT: start handle 40 end handle 65535 current handle value 40
I (5115) GATTC_CLIENT: service found
I (5125) GATTC_CLIENT: UUID16: ff
I (5125) GATTC CLIENT: Get service information from remote device
I (5135) GATTC_CLIENT: ESP_GATTC_SEARCH_CMPL_EVT
I (5135) GATTC_CLIENT: ESP_GATTC_REG_FOR_NOTIFY_EVT
I (5185) GATTC_CLIENT: ESP_GATTC_CFG_MTU_EVT, Status 0, MTU 500, conn_id 0
I (5345) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (5345) GATTC_CLIENT: 00 01 02 03 04 05 06 07 08 09 0a 0b 0c 0d 0e
I (5345) GATTC_CLIENT: write descr success
I (6225) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (6225) GATTC_CLIENT: 11 f4 33 44
I (7225) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (7225) GATTC CLIENT: 11 8a 33 44
I (8225) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (8225) GATTC_CLIENT: 11 c9 33 44
I (9225) GATTC CLIENT: ESP GATTC NOTIFY EVT, receive notify value:
I (9225) GATTC_CLIENT: 11 a4 33 44
I (10265) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (10265) GATTC_CLIENT: 11 1e 33 44
I (11265) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (11265) GATTC_CLIENT: 11 e9 33 44
I (12265) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (12265) GATTC_CLIENT: 11 96 33 44
I (13265) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (13265) GATTC_CLIENT: 11 29 33 44
I (14305) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (14305) GATTC_CLIENT: 11 6e 33 44
I (15305) GATTC_CLIENT: ESP_GATTC_NOTIFY_EVT, receive notify value:
I (15305) GATTC CLIENT: 11 6f 33 44
I (16305) GATTC CLIENT: ESP GATTC NOTIFY EVT, receive notify value:
I (16305) GATTC_CLIENT: 11 Of 33 44
```