


Optimal Placement of Inertia and Primary Droop Control

vs.

Slow Network Modes in High Voltage Power Grids



Philippe Jacquod
CISS19 - Baltimore 20.03.2019
(with L. Pagnier)





UNIVERSITÉ
DE GENÈVE



Hes-SO // VALAIS
WALLIS
School of
Engineering π

Today's (and yesterday's) AC power grids



- Built around rotating synchronous machines
- Coupling between power balance and frequency



figs. Taken from <http://northernutilities.co.uk>

Today's (and yesterday's) AC power grids

- Built around rotating synchronous machines
- Coupling between power balance and frequency





figs. Taken from <http://northernutilities.co.uk>

- Dynamics given by swing equations
~ conservation of energy/power

$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$

Today's (and yesterday's) AC power grids

- Built around rotating synchronous machines
- Coupling between power balance and frequency



figs. Taken from <http://northernutilities.co.uk>


- Dynamics given by swing equations
~ conservation of energy/power

$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$

Change in kinetic energy = balance of power

Frequency vs. Electric Power Quality


$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$



- Frequency transient as indicator of fault magnitude

Frequency vs. Electric Power Quality


$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$



- Frequency transient as indicator of fault magnitude

Frequency vs. Electric Power Quality


$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$



- Frequency transient as indicator of fault magnitude

Frequency vs. Electric Power Quality


$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$



- Frequency transient as indicator of fault magnitude

Frequency vs. Electric Power Quality

$$M \frac{d\omega}{dt} = P_{\text{gen}} - P_{\text{cons}}$$



- Frequency transient as indicator of fault magnitude
- Frequency fluctuations need to be minimized
... but how ?

The swing equations (linearized)

- Frequency vs. voltage angles $\omega(t) = \dot{\varphi}(t)$

$$M\ddot{\varphi} = -D\dot{\varphi} - L\varphi + p(t)$$

The swing equations (linearized)

- Frequency vs. voltage angles $\omega(t) = \dot{\varphi}(t)$

$$M\ddot{\varphi} = -D\dot{\varphi} - L\varphi + p(t)$$

Change in kinetic
Energy (inertia)

The swing equations (linearized)

- Frequency vs. voltage angles $\omega(t) = \dot{\varphi}(t)$

$$M\ddot{\varphi} = -D\dot{\varphi} - L\varphi + p(t)$$

Change in kinetic Energy (inertia)	Damping (droop control)
---------------------------------------	----------------------------

The swing equations (linearized)

- Frequency vs. voltage angles $\omega(t) = \dot{\varphi}(t)$

$$M\ddot{\varphi} = -D\dot{\varphi} - L\varphi + p(t)$$

Change in kinetic Energy (inertia)	Damping (droop control)	Power out (to consumers)
---------------------------------------	----------------------------	-----------------------------

The swing equations (linearized)

- Frequency vs. voltage angles $\omega(t) = \dot{\varphi}(t)$

$$M\ddot{\varphi} = -D\dot{\varphi} - L\varphi + p(t)$$

Power in
(generation)

Change in kinetic
Energy (inertia)

Damping
(droop control)

Power out
(to consumers)

The swing equations (linearized)

- Frequency vs. voltage angles $\omega(t) = \dot{\varphi}(t)$




$$M\ddot{\varphi} = -D\dot{\varphi} - L\varphi + p(t)$$

Power in
(generation)



Change in kinetic
Energy (inertia)

Damping
(droop control)


Power out
(to consumers)




Old vs. new productions



Old vs. new productions




- Centralized




- Decentralized
 - issues at distribution level
 - easier at transmission level
(=reduction in load) up to some level...

Old vs. new productions




- Centralized
- Dispatchable/predictable




- Decentralized
 - issues at distribution level
 - easier at transmission level
(=reduction in load) up to some level...
- Uncertain
 - power / energy reserve

Variability and uncertainty are nothing new for grid operators


England Vs Germany 1990, World Cup Semi-Final, Kick Off 19:00



Old vs. new productions





- Rotating machine with inertia
 - frequency definition
 - grid stability :
 - *energy reserve
 - *droop control



- No inertia
(But : converters
 - +local storage
 - = synthetic inertia)

Old vs. new productions





?? Where is it problematic to substitute
• Old productions with new renewables ??

inertia

- frequency definition
- grid stability :
 - *energy reserve
 - *droop control

(But : converters
+local storage
= synthetic inertia)

Old vs. new productions



- ?? Where is it problematic to substitute old productions with new renewables ??
 - inertia
 - frequency definition
 - grid stability
 - *energy reserve
 - *droop control
- (But : converters
+local storage
+synthetic inertia)
 - ?? Where is it not ??

Content

- Disturbance propagation
 - vs. inertia
 - vs. Laplacian eigenmodes
- Optimal placement of inertia and droop control


Content

- Disturbance propagation
 - vs. inertia
 - vs. Laplacian eigenmodes
- Optimal placement of inertia and droop control

Disturbance propagation : (i) definition of the problem

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



- Power injected/extracted @ bus #i :

$$P_i^e = \sum_{j \in \mathcal{V}} B_{ij} V_i V_j \sin(\theta_i - \theta_j)$$

- Dynamics given by swing equations :


$$m_i \dot{\omega}_i + d_i \omega_i = P_i^{(0)} - P_i^e, \text{ if } i \in \mathcal{V}_{\text{gen}}$$

$$d_i \omega_i = P_i^{(0)} - P_i^e, \text{ if } i \in \mathcal{V}_{\text{load}}$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



Assume $m_i=m$, $d_i=d$


Linearize dynamics about steady-state solution

$$M\dot{\omega} + D\omega = P - L\theta$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



Assume $m_i=m$, $d_i=d$


Linearize dynamics about steady-state solution

$$M\dot{\omega} + D\omega = P - L\theta$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



Assume $m_i=m$, $d_i=d$

Linearize dynamics about steady-state solution

$$M\dot{\omega} + D\omega = P - L\theta$$

Network Laplacian


$$(L)_{ij} = -B_{ij} V_i^{(0)} V_j^{(0)}$$

$$(L)_{ii} = \sum_k B_{ik} V_i^{(0)} V_k^{(0)}$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



Assume $m_i = m$, $d_i = d$

Linearize dynamics about steady-state solution

$$M\dot{\omega} + D\omega = P - L\theta$$

Network Laplacian

$$(L)_{ij} = -B_{ij} V_i^{(0)} V_j^{(0)}$$

$$(L)_{ii} = \sum_k B_{ik} V_i^{(0)} V_k^{(0)}$$

With eigenvectors and -values


$$\{u_1, \dots, u_N\}$$

$$\{\lambda_1, \dots, \lambda_N\}$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



Assume $m_i = m$, $d_i = d$

Linearize dynamics about steady-state solution

$$M\dot{\omega} + D\omega = P - L\theta$$

Network Laplacian

$$(L)_{ij} = -B_{ij} V_i^{(0)} V_j^{(0)}$$

$$(L)_{ii} = \sum_k B_{ik} V_i^{(0)} V_k^{(0)}$$

Zero mode


$$(u_1)^\top = (1, \dots, 1)/\sqrt{N}$$

$$\lambda_1 = 0$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$
 $\Delta P = 900 \text{ MW}$



Assume $m_i = m$, $d_i = d$

Linearize dynamics about steady-state solution

$$M\dot{\omega} + D\omega = P - L\theta$$

Network Laplacian

$$(L)_{ij} = -B_{ij} V_i^{(0)} V_j^{(0)}$$

$$(L)_{ii} = \sum_k B_{ik} V_i^{(0)} V_k^{(0)}$$

Higher modes


$$\sum_i u_{\alpha i} = 0 \quad (\text{orthog. to zero mode})$$
$$\lambda_{\alpha} > 0 \quad (\text{stability})$$

Disturbance propagation : (ii) analytics

Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$

$$\Delta P = 900 \text{ MW}$$



$$M\dot{\omega} + D\omega = P - L\theta$$

Spectral decomposition over modes of network Laplacian $(\gamma = d/m)$

$$\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin \left(\sqrt{\lambda_\alpha/m - \gamma^2/4} t \right)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$$



Average over i or b

$$\langle \delta\omega_i \rangle = \frac{2\Delta P e^{-\gamma t/2}}{m N \gamma} \sinh(\gamma t/2) \quad \langle \delta\omega_i \rangle (t \rightarrow \infty) = \frac{\Delta P}{d N}$$

Disturbance propagation : (ii) analytics


Fault : sudden power loss

 $P_b = P_b^{(0)} - \Delta P$




Disturbance propagation : (iii) numerics

Today's Europe




Disturbance propagation : (iii) numerics

Today's Europe




Inertia in France reduced to 50%




Disturbance propagation : (iii) numerics


Today's Europe



Inertia in France reduced to 50%




Inertia in Balkans doubled




Disturbance propagation : (iii) numerics


Today's Europe



Inertia in France



Inertia in Balkans doubled




Disturbance propagation : (ii) analytics

Fault : sudden power loss

⚡ $P_b = P_b^{(0)} - \Delta P$

$\Delta P = 900 \text{ MW}$




$$\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin \left(\sqrt{\lambda_\alpha/m - \gamma^2/4} t \right)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$$

Wave-propagation from higher modes $\alpha > 1$

Oscillations + denominator

→ only few, low modes matter ?



Disturbance propagation : (iii) numerics

Disturbance magnitude :

I) RoCoF at bus #i

$$r_i(t) = \frac{\delta\omega_i(t + \Delta t) - \delta\omega_i(t)}{2\pi\Delta t}$$

2) Performance measure
vs. Disturbance location #b

$$\mathcal{M}_b = \sum_{k=1}^{N_{\text{sim}}} \sum_i |r_i(k\Delta t)|$$

Disturbance propagation : (iii) numerics


Disturbance magnitude :

I) RoCoF at bus #i


$$r_i(t) = \frac{\delta\omega_i(t + \Delta t) - \delta\omega_i(t)}{2\pi\Delta t}$$

2) Performance measure
vs. Disturbance location #b


$$\mathcal{M}_b = \sum_{k=1}^{N_{\text{sim}}} \sum_i |r_i(k\Delta t)|$$



~amplitude of slowest, nonzero mode
(a.k.a. Fiedler mode) on disturbance location




Disturbance propagation : (iii) numerics



Conclusion 1

- Inertia absorbs disturbances
 - locally (close to the disturbance)
 - on short times
- Inertia outside slow modes has very little effect on disturbances inside slow modes
- Inertia inside slow modes is key to mitigate RoCoF's




Content

- Disturbance propagation
 - vs. inertia
 - vs. Laplacian eigenmodes
- Optimal placement of inertia and droop control

Context (i)


- Increased penetration of new renewables
- Decrease of inertia (+time dependent)
- Inertia can be replaced by
 - *synthetic inertia (power electronics+storage)
 - *flywheels
 - *synchronous condensers



(see e.g.: Poola, Bolognani, Dörfler '17)

Context (i)

- Increased penetration of new renewables
- Decrease of inertia (+time dependent)
- Inertia can be replaced by
 - *synthetic inertia (power electronics+storage)
 - *flywheels
 - *synchronous condensers



Where is it best to deploy substitution inertia ?

(see e.g.: Poola, Bolognani, Dörfler '17)

Context (ii)

- Frequency disturbance $\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin(\sqrt{\lambda_\alpha/m - \gamma^2/4} t)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$
- Quadratic performance measures / H_2 -norms

$$\|\tilde{w}\|_2^2 = \sum_{k=1}^{n-1} \frac{(v_k^T u_0)^2}{2d\lambda_k}$$

$$E[\|\tilde{w}\|_2^2] = \frac{1}{2d} \sum_k \frac{1}{\lambda_k}$$

From : Paganini and Mallada '17

Context (ii)

- Frequency disturbance $\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin(\sqrt{\lambda_\alpha/m - \gamma^2/4} t)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$
- Quadratic performance measures / H_2 -norms

vs. disturbance
vector

$$\|\tilde{w}\|_2^2 = \sum_{k=1}^{n-1} \frac{(v_k^T u_0)^2}{2d\lambda_k}$$

$$E[\|\tilde{w}\|_2^2] = \frac{1}{2d} \sum_k \frac{1}{\lambda_k}$$

From : Paganini and Mallada '17

Context (ii)

- Frequency disturbance $\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin(\sqrt{\lambda_\alpha/m - \gamma^2/4} t)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$
- Quadratic performance measures / H_2 -norms

vs. disturbance
vector

$$\|\tilde{w}\|_2^2 = \sum_{k=1}^{n-1} \frac{(v_k^T u_0)^2}{2d\lambda_k}$$

Averaged over
disturbance locations

$$E[\|\tilde{w}\|_2^2] = \frac{1}{2d} \sum_k \frac{1}{\lambda_k}$$

From : Paganini and Mallada '17

Context (ii)

- Frequency disturbance $\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin(\sqrt{\lambda_\alpha/m - \gamma^2/4} t)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$
- Quadratic performance measures / H_2 -norms

vs. disturbance
vector

$$\|\tilde{w}\|_2^2 = \sum_{k=1}^{n-1} \frac{(v_k^T u_0)^2}{2d\lambda_k}$$

Averaged over
disturbance locations

$$E[\|\tilde{w}\|_2^2] = \frac{1}{2d} \sum_k \frac{1}{\lambda_k}$$

From : Paganini and Mallada '17

Other works (list not complete) :

Bamieh, Jovanovic, Mitra, Patterson '12
 Bamieh and Gayme '13
 Siami and Mottee '14
 Grunberg and Gayme '16

Poolla, Bolognani, Dörfler '17
 Paganini and Mallada '17
 Tyloo, Coletta, PJ '18
 Coletta, Bamieh, PJ '18

Context (ii)

- Frequency disturbance $\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin(\sqrt{\lambda_\alpha/m - \gamma^2/4} t)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$
- Quadratic performance measures / H_2 -norms

vs. disturbance
vector

Averaged over
disturbance locations

**Performance measures vs. modes and
spectrum of the network Laplacian**

$$\|\tilde{w}\|_2^2 = \sum_{k=1}^{\text{rank } \kappa} \frac{1}{\lambda_k}$$

From : Paganini and Mallada '17

Other works (list not complete) :

Bamieh, Jovanovic, Mitra, Patterson '12

Bamieh and Gayme '13

Siami and Motte '14

Grunberg and Gayme '16

Poolla, Bolognani, Dörfler '17

Paganini and Mallada '17

Tyloo, Coletta, PJ '18

Coletta, Bamieh, PJ '18

Context (ii)

- Frequency disturbance $\delta\omega_i(t) = \frac{\Delta P e^{-\gamma t/2}}{m} \sum_{\alpha=1}^N u_{\alpha i} u_{\alpha b} \frac{\sin(\sqrt{\lambda_\alpha/m - \gamma^2/4} t)}{\sqrt{\lambda_\alpha/m - \gamma^2/4}}$
- Quadratic performance measures / H_2 -norms

vs. disturbance
vector

Averaged over
disturbance locations

$\|\tilde{w}\|_2^2 = \sum_{k=1}^{\text{rank } \kappa}$ Performance measures vs. modes and spectrum of the network Laplacian $\sum_k \frac{1}{\lambda_k}$

From : Paganini and Mallada '17

All these works considered either

$$m_i = m, d_i = d$$

$$d_i/m_i = \text{constant}$$

Other works (list)

Bamieh, Jovanović '12

Bamieh and Gayme '13

Siami and Mottee '14

Grunberg and Gayme '16

17

Paganini and Mallada '17

Tyloo, Coletta, PJ '18

Coletta, Bamieh, PJ '18

Matrix perturbation theory (a.k.a. Rayleigh-Schrödinger)

- Starting point : known, diagonalized matrix

$\textcolor{brown}{L}$ with eigenvalues $\lambda_{\alpha}^{(0)}$ and eigenvectors $\textcolor{brown}{u}_{\alpha}^{(0)}$

Matrix perturbation theory (a.k.a. Rayleigh-Schrödinger)

- Starting point : known, diagonalized matrix

$\textcolor{brown}{L}$ with eigenvalues $\lambda_\alpha^{(0)}$ and eigenvectors $\textcolor{teal}{u}_\alpha^{(0)}$

- Can we give estimates for the eigenvectors $\textcolor{teal}{u}_\alpha$ and eigenvalues λ_α of a slightly different matrix $\textcolor{teal}{L} + \mu V_1$?

Matrix perturbation theory (a.k.a. Rayleigh-Schrödinger)

- Starting point : known, diagonalized matrix

$\textcolor{brown}{L}$ with eigenvalues $\lambda_\alpha^{(0)}$ and eigenvectors $\textcolor{brown}{u}_\alpha^{(0)}$

- Can we give estimates for the eigenvectors $\textcolor{teal}{u}_\alpha$ and eigenvalues λ_α of a slightly different matrix $\textcolor{teal}{L} + \mu V_1$?

Answer : yes ! In a controlled power expansion in $\mu \ll 1$:

Matrix perturbation theory (a.k.a. Rayleigh-Schrödinger)

- Starting point : known, diagonalized matrix

$\textcolor{brown}{L}$ with eigenvalues $\lambda_\alpha^{(0)}$ and eigenvectors $\textcolor{brown}{u}_\alpha^{(0)}$

- Can we give estimates for the eigenvectors $\textcolor{teal}{u}_\alpha$ and eigenvalues λ_α of a slightly different matrix $\textcolor{teal}{L} + \mu V_1$?

Answer : yes ! In a controlled power expansion in $\mu \ll 1$:

$$\lambda_\alpha = \lambda_\alpha^{(0)} + \mu \lambda_\alpha^{(1)} + \mathcal{O}(\mu^2)$$

$$\textcolor{brown}{u}_\alpha = \textcolor{brown}{u}_\alpha^{(0)} + \mu \textcolor{brown}{u}_\alpha^{(1)} + \mathcal{O}(\mu^2)$$

Matrix perturbation theory (a.k.a. Rayleigh-Schrödinger)

- Starting point : known, diagonalized matrix

\mathbf{L} with eigenvalues $\lambda_\alpha^{(0)}$ and eigenvectors $\mathbf{u}_\alpha^{(0)}$

- Can we give estimates for the eigenvectors \mathbf{u}_α and eigenvalues λ_α of a slightly different matrix $\mathbf{L} + \mu \mathbf{V}_1$?

Answer : yes ! In a controlled power expansion in $\mu \ll 1$:

$$\lambda_\alpha = \lambda_\alpha^{(0)} + \mu \lambda_\alpha^{(1)} + \mathcal{O}(\mu^2)$$

$$\mathbf{u}_\alpha = \mathbf{u}_\alpha^{(0)} + \mu \mathbf{u}_\alpha^{(1)} + \mathcal{O}(\mu^2)$$

$$\lambda_\alpha^{(1)} = \mathbf{u}_\alpha^{(0)\top} \mathbf{V}_1 \mathbf{u}_\alpha^{(0)}$$
$$\mathbf{u}_\alpha^{(1)} = \sum_{\beta \neq \alpha} \frac{\mathbf{u}_\beta^{(0)\top} \mathbf{V}_1 \mathbf{u}_\alpha^{(0)}}{\lambda_\alpha^{(0)} - \lambda_\beta^{(0)}} \mathbf{u}_\beta^{(0)}$$

Matrix perturbation theory (a.k.a. Rayleigh-Schrödinger)

- Starting point : known, diagonalized matrix

L with eigenvalues $\lambda_\alpha^{(0)}$ and eigenvectors $u_\alpha^{(0)}$

We use matrix perturbation theory to free
ourselves from the homogeneity assumption
and calculate optimal distribution of m_i and d_i

$$\lambda_\alpha = \lambda_\alpha^{(0)} + \mu \lambda_\alpha^{(1)} + \mathcal{O}(\mu^2)$$

$$u_\alpha = u_\alpha^{(0)} + \mu u_\alpha^{(1)} + \mathcal{O}(\mu^2)$$

$$u_\alpha^{(1)} = \sum_{\beta \neq \alpha} \frac{u_\beta^{(0)\top} V_1 u_\alpha^{(0)}}{\lambda_\alpha^{(0)} - \lambda_\beta^{(0)}} u_\beta^{(0)}$$

Optimal placement of inertia and droop

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state)

(Paganini and Mallada '17)

$$M\dot{\omega} + D\omega = \delta P - L\delta\theta$$

$$M = \text{diag}(\{m_i\})$$

$$D = \text{diag}(\{d_i\})$$

Optimal placement of inertia and droop

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state) (Paganini and Mallada '17)

$$M\dot{\omega} + D\omega = \delta P - L\delta\theta$$

$$M = \text{diag}(\{m_i\})$$
$$D = \text{diag}(\{d_i\})$$

$$\delta\theta = M^{-1/2}\delta\theta_M$$



Optimal placement of inertia and droop

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state) (Paganini and Mallada '17)

$$M\dot{\omega} + D\omega = \delta P - L\delta\theta$$

$$M = \text{diag}(\{m_i\})$$
$$D = \text{diag}(\{d_i\})$$

$$\delta\theta = M^{-1/2}\delta\theta_M$$

$$\dot{\omega}_M + \underbrace{M^{-1}D}_{\Gamma}\omega_M + \underbrace{M^{-1/2}LM^{-1/2}}_{L_M}\delta\theta_M = M^{-1/2}\delta P$$

Optimal placement of inertia and droop

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state) (Paganini and Mallada '17)

$$M\dot{\omega} + D\omega = \delta P - L\delta\theta$$

$$M = \text{diag}(\{m_i\})$$
$$D = \text{diag}(\{d_i\})$$

$$\delta\theta = M^{-1/2}\delta\theta_M$$

$$\dot{\omega}_M + \underbrace{M^{-1}D}_{\Gamma}\omega_M + \underbrace{M^{-1/2}LM^{-1/2}}_{L_M}\delta\theta_M = M^{-1/2}\delta P$$

$$\Gamma = \text{diag}(\{d_i/m_i\})$$

Optimal placement of inertia and droop

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state) (Paganini and Mallada '17)

$$M\dot{\omega} + D\omega = \delta P - L\delta\theta$$

$$M = \text{diag}(\{m_i\})$$
$$D = \text{diag}(\{d_i\})$$

$$\delta\theta = M^{-1/2}\delta\theta_M$$

$$\dot{\omega}_M + \underbrace{M^{-1}D}_{\Gamma}\omega_M + \underbrace{M^{-1/2}LM^{-1/2}}_{L_M}\delta\theta_M = M^{-1/2}\delta P$$

$$\Gamma = \text{diag}(\{d_i/m_i\})$$

When can this eq. be reduced to a set of scalar eps. ?

Optimal placement of inertia and droop

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state) (Paganini and Mallada '17)

$$M\dot{\omega} + D\omega = \delta P - L\delta\theta$$

$$M = \text{diag}(\{m_i\})$$
$$D = \text{diag}(\{d_i\})$$

$$\delta\theta = M^{-1/2}\delta\theta_M$$

$$\dot{\omega}_M + \underbrace{M^{-1}D}_{\Gamma}\omega_M + \underbrace{M^{-1/2}LM^{-1/2}}_{L_M}\delta\theta_M = M^{-1/2}\delta P$$

$$\Gamma = \text{diag}(\{d_i/m_i\})$$

A.: when $d_i/m_i=\text{constant}$

Diagonalized solution - starting point

- Starting point : when can one diagonalize the swing eqs. ? (linearized about steady-state) (Paganini and Mallada '17)

$$\dot{\omega}_M + \underbrace{M^{-1}D}_{\Gamma} \omega_M + \underbrace{M^{-1/2}LM^{-1/2}}_{L_M} \delta\theta_M = M^{-1/2} \delta P$$

$$\Gamma = \gamma \mathbf{1}$$

$$\ddot{\xi} + \gamma \dot{\xi} + \Lambda \xi = UM^{-1/2} \delta P$$

$$\Lambda = \text{diag}(\{\lambda_1 = 0, \lambda_2, \dots, \lambda_N\})$$

~diagonal/scalar linear differential equation

Optimal placement of inertia and droop - problem formulation

- Performance measure (to be minimized)

$$\mathcal{M} = \int_0^{\infty} (\omega^T - \bar{\omega}^T) M (\omega - \bar{\omega}) dt$$

- Power loss at bus #b

$$\mathcal{M}_b = \frac{\delta P^2}{2\gamma m_b} \sum_{\alpha > 1} \frac{u_{\alpha b}^2}{\lambda_\alpha}$$

(Similar expressions in :
Bamieh and Gayme '13, Siami and Mottee '14
Grunberg and Gayme '16, Paganini and Mallada '17
Pagnier and PJ '18)

Optimal placement of inertia and droop - problem formulation

- Performance measure (to be minimized)

$$\mathcal{M} = \int_0^{\infty} (\omega^\top - \bar{\omega}^\top) M (\omega - \bar{\omega}) dt$$

- Power loss at bus #b

$$\mathcal{M}_b = \frac{\delta P^2}{2\gamma m_b} \sum_{\alpha > 1} \frac{u_{\alpha b}^2}{\lambda_\alpha}$$

(Similar expressions in :
Bamieh and Gayme '13, Siami and Mottee '14
Grunberg and Gayme '16, Paganini and Mallada '17
Pagnier and PJ '18)

- Deviation from homogeneity

$$m_i = m + \delta m r_i ,$$

$$d_i = m_i \gamma_i = (m + \delta m r_i)(\gamma + \delta \gamma a_i)$$

$$-1 \leq a_i, r_i \leq 1$$

Optimal placement of inertia and droop - problem formulation

- Performance measure (to be minimized)

$$\mathcal{M} = \int_0^{\infty} (\omega^T - \bar{\omega}^T) M (\omega - \bar{\omega}) dt$$

- Power loss at bus #b

$$\mathcal{M}_b = \frac{\delta P^2}{2\gamma m_b} \sum_{\alpha > 1} \frac{u_{\alpha b}^2}{\lambda_\alpha}$$

(Similar expressions in :
Bamieh and Gayme '13, Siami and Mottee '14
Grunberg and Gayme '16, Paganini and Mallada '17
Pagnier and PJ '18)

- Deviation from homogeneity

$$m_i = m + \delta m r_i,$$

$$d_i = m_i \gamma_i = (m + \delta m r_i)(\gamma + \delta \gamma a_i)$$

$$-1 \leq a_i, r_i \leq 1$$

Do perturbation theory with
small parameters

$$\mu \equiv \delta m / m \ll 1$$

$$g \equiv \delta \gamma / \gamma \ll 1$$

Optimal placement of inertia and droop - problem formulation

- Perturbative performance measure - to be minimized

$$\mathcal{M}_b = \mathcal{M}_b^{(0)} + r_i \rho_i + a_i \alpha_i + \mathcal{O}(\delta m^2, \delta \gamma^2)$$

with susceptibilities (this is what we calculate)

$$\rho_i \equiv \partial \mathcal{M}_b / \partial r_i \quad \alpha_i \equiv \partial \mathcal{M}_b / \partial a_i$$

Optimal placement of inertia and droop - problem formulation

- Perturbative performance measure - to be minimized

$$\mathcal{M}_b = \mathcal{M}_b^{(0)} + r_i \rho_i + a_i \alpha_i + \mathcal{O}(\delta m^2, \delta \gamma^2)$$

with susceptibilities (this is what we calculate)

$$\rho_i \equiv \partial \mathcal{M}_b / \partial r_i \quad \alpha_i \equiv \partial \mathcal{M}_b / \partial a_i$$

- Goal : determine optimal distribution of r_i and a_i with constraints

$$-1 \leq a_i, r_i \leq 1 \quad \text{Local reduction/increase}$$

$$\sum_i r_i = \sum_i a_i = 0 \quad \text{Total limited resources}$$

$$\mu \equiv \delta m / m \ll 1$$

$$g \equiv \delta \gamma / \gamma \ll 1$$

Optimal placement of inertia and droop - algorithmic solution

- Susceptibilities

- I) inhomogeneities in inertia

$$\rho_i = \frac{\partial \mathcal{M}_b}{\partial r_i} = -\frac{\mu \delta P^2}{\gamma} \sum_{\substack{\alpha > 1 \\ \beta \neq \alpha}} \frac{u_{\alpha b}^{(0)} u_{\beta b}^{(0)} u_{\alpha i}^{(0)} u_{\beta i}^{(0)}}{\lambda_\alpha^{(0)} - \lambda_\beta^{(0)}}$$

- 2) inhomogeneities in damping

$$\alpha_i \equiv \partial \mathcal{M}_b / \partial a_i = -\frac{g \delta P^2}{2\gamma m_b} \left[\sum_{\alpha > 1} \frac{u_{\alpha i}^2 u_{\alpha b}^2}{\lambda_\alpha} + \sum_{\alpha > 1, \beta \neq \alpha} \frac{u_{\alpha i} u_{\alpha b} u_{\beta i} u_{\beta b}}{(\lambda_\alpha - \lambda_\beta)^2 + 2\gamma^2(\lambda_\alpha + \lambda_\beta)} \right]$$

Optimal placement of inertia and droop - algorithmic solution

- Susceptibilities

- I) inhomogeneities in inertia

$$\rho_i = \frac{\partial \mathcal{M}_b}{\partial r_i} = -\frac{\mu \delta P^2}{\gamma} \sum_{\substack{\alpha > 1 \\ \beta \neq \alpha}} \frac{u_{\alpha b}^{(0)} u_{\beta b}^{(0)} u_{\alpha i}^{(0)} u_{\beta i}^{(0)}}{\lambda_\alpha^{(0)} - \lambda_\beta^{(0)}}$$

- 2) inhomogeneities in damping

$$\alpha_i \equiv \partial \mathcal{M}_b / \partial a_i = -\frac{g \delta P^2}{2\gamma m_b} \left[\sum_{\alpha > 1} \frac{u_{\alpha i}^2 u_{\alpha b}^2}{\lambda_\alpha} + \sum_{\alpha > 1, \beta \neq \alpha} \frac{u_{\alpha i} u_{\alpha b} u_{\beta i} u_{\beta b}}{(\lambda_\alpha - \lambda_\beta)^2 + 2\gamma^2(\lambda_\alpha + \lambda_\beta)} \right]$$

Algorithm for optimal placement

- *rank susceptibilities in ascending order

- * $a_i, r_i = -1$ for the $N/2$ smallest susceptibilities

- * $a_i, r_i = +1$ for the $N/2$ largest susceptibilities

- *for simultaneous optimal inertia and damping placement,

- include constraint $\sum_i r_i a_i = 0$

- *if all susceptibilities equal : $a_i, r_i = 0$

Optimal placement of inertia and droop - solution



Inertia. : $r_i = 0$

Wants to keep it homogeneous

$$m_i = m + \delta m r_i ,$$

$$d_i = m_i \gamma_i = (m + \delta m r_i)(\gamma + \delta \gamma a_i)$$

Optimal placement of inertia and droop - solution



Inertia. : $r_i = 0$

Wants to keep it homogeneous




Damping/droop : $r_i = 1$ (blue) $r_i = -1$ (red)

Wants to keep it homogeneous

$$m_i = m + \delta m r_i ,$$

$$d_i = m_i \gamma_i = (m + \delta m r_i)(\gamma + \delta \gamma a_i)$$


Optimal placement of inertia and droop - solution



- Performance strongly increased especially at most sensitive buses


Conclusion 2

- Short time effect of inertia → keep it homogeneous !
- Optimal droop / damping placement
Seems correlated with location of few slow modes



Conclusion 2

- Short time effect of inertia → keep it homogeneous !
- Optimal droop / damping placement
Seems correlated with location of few slow modes



Conclusions - work in progress

- Need to unify both approaches - vs. different perf. measures ?
- Beyond first order perturbation theory ?

Conclusions - work in progress

- Need to unify both approaches - vs. different perf. measures ?
- Beyond first order perturbation theory ?



Laurent Pagnier