# Waves

## KDSMIL001 PHY2004W PHYLAB2

## 26 October 2020

## Contents

1	Introduction	1
<b>2</b>	Aim	1
3	Theory	1
4	Apparatus	3
5	Method         5.1 Propagation Speed of the Wave	<b>3</b> 3

#### 1 Introduction

Electromagnetic waves can propagate on a transmission line as well as in free space. One example of such a transmission line is the coaxial cable, most commonly known as the cable that connects a TV set to an aerial.

### 2 Aim

The standard for propagating electromagnetic (EM) waves is those propagating in a vacuum, the speed of which is well established as  $c = 299792458 \,\mathrm{m/s}$ , but in this experiment we are more interested in the speed of propagation for EM waves in the coaxial cable. We will also determine the characteristic impedance of the cable.

## 3 Theory

Coaxial cables are a special type of Transmission Line, with an inner and outer conductor separated by some dielectric. These cables have some intrinsic properties, namely a capacitance and inductance per unit length, which are

$$C = \frac{2\pi\epsilon}{\ln(r_{out}/r_{in})}$$
 and  $L = \frac{\mu}{2\pi} \ln \frac{r_{out}}{r_{in}}$ 

where we have  $\epsilon$  and  $\mu$  are the permittivity and permeability of the dielectric in the cable respectively. For our case, we will actually take  $\mu = \mu_0 = 4\pi \times 10^{-7} \,\mathrm{H/m}$ . Finally  $r_{out}$  and  $r_{in}$  are the outer and inner radius of the cable, that is the outer radius of the outer and inner conductor respectively. For and EM wave in the cable, the electric and magnetic energy densities are equal, given by

$$E_E = \frac{1}{2}CV^2$$
 and  $E_B = \frac{1}{2}LI^2$ 

where V and I are the potential and current at a point in the cable.

**Exercise 1:** We want to find an expression for the characteristic impedance  $Z_0$  of the cable, so we have

$$Z_0 = \frac{V}{I} = \sqrt{\frac{E_E 2}{C}} \sqrt{\frac{L}{2E_B}}$$

$$E_E = E_B$$

$$\implies Z_0 = \sqrt{\frac{L}{C}} = \sqrt{\frac{\mu}{2\pi} \ln \frac{r_{out} \ln(r_{out}/r_{in})}{2\pi\epsilon}}$$

$$= \frac{1}{2\pi} \sqrt{\frac{\mu}{\epsilon}} \ln \frac{r_{out}}{r_{in}}$$

Another characteristic of the coaxial cable is that EM waves will propagate through it at a speed

 $v = \frac{c}{\sqrt{\epsilon \mu}} = \frac{c}{n} \tag{3.1}$ 

where we call n the refractive index of the dielectric (at the specific frequency of propagation).

For these cables, if the characteristic impedance changes at some point, the propagation of the wave will be affected, namely the wave will be partially reflected. The reflection coefficient for a purely resistive load R is given by

$$\mathcal{R} = \frac{R - Z_0}{R + Z_0} \tag{3.2}$$

Note that Exercise 2: We want to show that  $\lim_{R\to\infty} \mathcal{R} = 1$ :

$$\mathcal{R} = \frac{R - Z_0}{R + Z_0}$$

$$\lim_{R \to \infty} \frac{R - Z_0}{R + Z_0} = \lim_{R \to \infty} \frac{1 - \frac{Z_0}{R}}{1 + \frac{Z_0}{R}}$$

$$= \frac{1 - 0}{1 + 0} = 1$$

By measuring the time it takes for reflections of pulses to return to the start of the cable, we will be able to determine the speed of propagation for the waves in the cable with a known length. A similar technique can be used for more extended waves, such as sine waves.

For the pulses we would expect that, depending on the conditions at the end of the cable, we will have different types of reflection. For an open circuit, that is the cable is not connected to anything on the other side, as we have shown in Exercise 2,  $\mathcal{R}=1$ , so there will be perfect reflection of the pulse. For a short circuit, R=0, so we will have  $\mathcal{R}=-1$ , resulting in a perfectly reflected wave, but with negative voltage.

For the extended sine wave, we expect to see particular resonant frequencies depending on the length of the cable, resulting in standing waves. Again these frequencies depend on the condition at the end of the cable. For an open circuit, the resonant frequencies will be

$$f_n = n \frac{v}{4L}, \quad n = 1, 3, 5 \dots$$
 (3.3)

For a short circuit, we expect

$$f_n = n \frac{v}{2L}, \quad n = 1, 2, 3 \dots$$
 (3.4)

With both of these, we obviously expect a fundamental frequency with harmonics on top of that, hence the multiple nodes.

## 4 Apparatus

- Signal generator (with duty cycle control).
- Oscilloscope.
- Digital multimeter.
- Coaxial cable of length  $(55.845 \pm 0.005)$  m with switch to switch termination end between short circuit, open circuit, and variable resistance.

We set up the signal generator to feed into the coaxial cable, measuring the voltage at that point with the oscilloscope.

#### 5 Method

#### 5.1 Propagation Speed of the Wave

In this section we aimed to determine the speed at which EM waves propagate through the coaxial cable. We did this by two methods.

Firstly we looked at the pulses. We know the length of the cable, so all we needed to do was time how long it took for the pulse to travel from the start of the cable to the end, be reflected, and return to the start. The velocity will simply be given by

$$v = \frac{2L}{\Delta t} \tag{5.1}$$

To measure measure this  $\Delta t$  we set the signal generator to a square wave with the duty cycle to a minimum (20%), and set the frequency to 1MHz. We measured  $\Delta t$  for both the open and short circuit by looking at the oscilloscope. Using these values we could find v for each.

The second method we used to find v was by using Equation 3.3 and Equation 3.4, varying the frequency of a sine wave supplied by the signal generator to try find the first and second resonant frequencies of both the open and closed circuit. We could then find v for both.

## 5.2 Characteristic Impedance $Z_0$

In this section we aimed to find the characteristic impedance  $Z_0$  of the coaxial cable. For this we use the variable resistance setting for the termination end of the cable. We know from Equation 3.2 that  $\mathcal{R} = 0$  when  $R = Z_0$ , and we can find this resistance by looking at the oscilloscope for when the reflections vanish completely while varying the resistance.