mass_properties.py | lines 157-169

```
157     inertia = np.zeros((3, 3))
158     inertia_rate = np.zeros((3, 3))
159     for c in components:
160         distance = c.center_axial_m - center
161         distance_rate = c.center_rate_mps - center_rate
162         parallel = np.diag([0.0, distance**2, distance**2])
163         parallel_rate = np.diag([0.0] + [2 * distance * distance_rate] * 2)
164         inertia += c.inertia_at_center_kgm2 + c.mass_kg * parallel
165         inertia_rate += (
166             c.inertia_rate_at_center_kgm2ps
167             + c.mass_rate_kgps * parallel
168             + c.mass_kg * parallel_rate
169         )
```