INSULATION ADDENDUM

by William

80 Lamb Ave, Toronto | North Arrow Limited | Framing package

Quantities for the insulation, the same as the insulation lines on the framing order, for the insulation supplier. Wall types from the wall schedule on A004. Square feet are wall face area with window and door openings deducted; the order column adds waste and rounds up. Budget prices are on the order summaries.

EXTERIOR MINERAL WOOL, 3" (75 MM) PINNED SEMI-RIGID, R12ci (W1 AND W2 PARAPETS)

ELEVATION	PHASE 1 SQ FT	PHASE 2 SQ FT	NET SQ FT	ORDER SQ FT +10%	BOARDS 2'x4'
North	220	498	718	790	99
South	220	370	590	650	82
East	65	156	221	245	31
Stair enclosure, south faces above the roof		111	111	125	16
Stair enclosure, west face above the roof		26	26	30	4
Total 3"	**505**	**1,162**	**1,667**	**1,840**	**232**

EXTERIOR MINERAL WOOL, 5" (125 MM) STICK-PINNED SEMI-RIGID (W1a, WEST WALL)

AREA	PHASE 1 SQ FT	PHASE 2 SQ FT	NET SQ FT	ORDER SQ FT +10%	BOARDS 2'x4'
West: the two infill panels beside the curtain wall, and the band up to the parapet top	46	91	138	**155**	**20**

INTERIOR BATTS, R19 MINERAL FIBRE, 140 MM (5 1/2"), 2x6 STUDS AT 16" (W1)

PHASE	WHAT IS IN IT	NET SQ FT	ORDER SQ FT +5%	
Phase 1	1st floor exterior walls, from the top of the curb	474	500	
Phase 2	2nd floor exterior walls and the stair enclosure walls	978	1,030	
Total		**1,452**	**1,530**	

HOW IT WAS MEASURED

- Exterior mineral wool runs continuous over the DensGlass from the top of the concrete curb to the top of the parapets and the stair enclosure roof, including the floor and roof bands and the parapet faces.
- Phase 1 is the curb up to the top of the 2nd floor subfloor; Phase 2 is everything above, the same split as the framing order.
- Batts fill the stud cavities of the exterior walls only; bag count depends on the brand bought (R19 to suit 2x6 at 16").
- Boards counted as 2' x 4' (8 sq ft). Adjust if the yard stocks another size.

NOT INCLUDED / TO CONFIRM

- Thickness: the wall schedule on A004 says 75 mm (3"); a detail in the set notes 4" exterior Rockwool. Quantities are at 75 mm. Marek to confirm with Kunaal.
- Pins (3 per board) and the furring screws through the wool are on the framing order: #10 x 6" exterior coated wood screws through 3", #14 x 8" at the west wall.
- Parapet cavities, floor and roof assembly insulation (R32 mineral wool), and sound batts in interior partitions.
- DensGlass, air barrier and furring at the floor and roof bands are on the framing order (T 1.06A in the print set).

ISSUED FOR BUDGET AND COORDINATION, REV T4, 23 OCT 2026

80 Lamb Ave – Laneway House
Oct 23, 2026

Insulation Addendum – T 1.07-IA