### STANDARD ARRIVAL CHART -INSTRUMENT

## RJGG / CHUBU CENTRAIR

STAR RWY36

## SOUTH ARC ARRIVAL

From over CARDS, via CBE R224, turn right ,via CBE 21.0DME counterclockwise ARC, turn left....

From over CHESS, via CBE R339, turn right ,via CBE 21.0DME counterclockwise ARC, turn left....

From over SWING, via CBE R042, turn left ,via CBE 21.0DME clockwise ARC, turn right....

From over SLIDE, via CBE R055, turn left, via CBE 21.0DME clockwise ARC, turn right....

From over TRIKE, via CBE R105, turn left ,via CBE 21.0DME clockwise ARC, turn right....

From over BIWWA, via CBE R307, turn right ,via CBE 21.0DME counterclockwise ARC, turn left....

## for ILS Z RWY36 and LOC Z RWY36:

....to intercept and proceed via ICX-LOC to PROBE.

Cross CBE R208 at or above 6000FT, cross CBE R195 at or above 5000FT(when started from CARDS or BIWWA or CHESS).

Cross CBE R124 at or above 5000FT(when started from SWING or SLIDE or TRIKE).

Cross PROBE at or above 4000FT.

# for VOR RWY36:

....to intercept and proceed via CBE R174 to PIXIE.

Cross CBE R208 at or above 6000FT, cross CBE R195 at or above 5000FT(when started from CARDS or BIWWA or CHESS ).

Cross CBE R124 at or above 5000FT(when started from SWING or SLIDE or TRIKE).

