


NOTE: REPRINTING DOD FLIP



ENKAI TWO DEPARTURE RJSM / MISAWA 180 Rwy Knots 60 120 240 300 360 ATIS ★ 128.4 315.35 CLNC DEL 10 V/V(fpm) 350 700 1050 1400 1750 2100 118.65 275.8 TOWER ATC Climb Rate to 3500 118.1 315.8 DEP CON 125.3 363.8 ENKAI 3 3500 -105°-- R-105 — 10) MISAWA 115.4 MIS ... Chan 101 •3802 TA 14,000 V DEPARTURE ROUTE DESCRIPTION TAKE-OFF RWY 10: Climb on MIS VORTAC R-105 to ENKAI. Cross ENKAI at or above 3500. CHANGE: Update.

RJSM / MISAWA KOSUI TWO DEPARTURE Knots 60 180 240 300 360 ATIS ★128.4 315.35 1218 2030 CLNC DEL 28 V/V(fpm) 406 812 1624 2436 118.65 275.8 TOWER ATC Climb Rate to 3600 118.1 315.8 DEP CON 125.3 363.8 KOSUI 3 3600 **←** R-282 **←** ▲ -282°**--▼**10 MISAWA 115.4 MIS ... Chan 101 • 3802 TA 14,000 V DEPARTURE ROUTE DESCRIPTION TAKE-OFF RWY 28: Climb on MIS VORTAC R-282 to KOSUI. Cross KOSUI at or above 3600.



RJSM / MISAWA

MISAWA SIX DEPARTURE



DEPARTURE ROUTE DESCRIPTION (Continued)

HANAMAKI TRANSITION:

TAKE-OFF RWY 10: ...turn right to intercept MIS TACAN R-196 (HPE VOR/DME R-017) to HANAMAKI VOR/DME. Cross OMBOE at or above 10,000. Maintain ATC assigned altitude. TAKE-OFF RWY 28: ...turn left to intercept MIS R-196 (HPE R-017) to HANAMAKI VOR/DME. Cross OMBOE at or above 10,000. Maintain ATC assigned altitude.

JYONA TRANSITION:

TAKE-OFF RWY 10: ...continue climb to 2000, then turn right and climb via MIS VORTAC to intercept MIS R-310 direct to JYONA. Cross JYONA at or above 3500. Maintain ATC assigned altitude.

TAKE-OFF RWY 28: ...then turn right to intercept MIS R-310 to JYONA. Cross JYONA at or above 3500. Maintain ATC assigned altitude.

MIYAKO TRANSITION:

TAKE-OFF RWY 10: ...turn right to intercept MIS R-161 (MQE VOR/DME R-340) to MIYAKO VOR/DME. Cross the SESEA at or above 8000. Maintain ATC assigned altitude.

TAKE-OFF RWY 28: ...turn left to intercept MIS R-161 (MQE R-340) to MIYAKO VOR/DME. Cross the SESEA at or above 8000. Maintain ATC assigned altitude.

OLSAE TRANSITION:

TAKE-OFF RWY 10: ...turn right to intercept MIS R-233 to OLSAE (MIS R-233/40 DME). Cross OLSAE at or above 9000.

Maintain ATC assigned altitude.

TAKE-OFF RWY 28: ...turn left to intercept MIS R-233 to OLSAE (MIS R-233/40 DME). Cross OLSAE at or above 9000.


Maintain ATC assigned altitude.

SAMBO TRANSITION:

TAKE-OFF RWY 10: ...turn right to intercept MIS R-221 to SAMBO (MIS R-221/36.7 DME). Cross SAMBO at or above 13,000. Maintain ATC assigned altitude.


TAKE-OFF RWY 28: ...turn left to intercept MIS R-221 to SAMBO (MIS R-221/36.7 DME). Cross SAMBO at or above 13,000. Maintain ATC assigned altitude.


CHANGE: Update.






RJSM / MISAWA







RJSM / MISAWA VORTAC MIS Rwy ldg TDZE APCH CRS 115.4 290°

9999

VOR Z or TACAN Z RWY28

