

- 4. PTW sends the PTE address to the PFA.
- 5. PFA assembles a **load command** in memory.
- 6. PFA signals NIC to send the command and provides the first free page (from the freeQ) as a receive buffer.
- 7. NIC reads request from memory, sends request to memory blade.
- 8. NIC gets new page, DMAs page to destination frame.
- 9. NIC signals PFA done.
- 10. PFA updates page table.
- 11. PFA adds pageID to NewQ.
- 12. The application is restarted with the new mapping.