指令	opcode	funct	RT	REGorM		NPCo	EXTO	Alo	A2	A3o	REGo	RegWri	ALU_A	ALU_Bo
311 (1			EM	rite	p	p	p	op	p	p	te	op	p
and	000000	100100		0	0	000	0	00	0	00	000	1	0	00
or	000000	100101		0	0	000	0	00	0	00	000	1	0	00
xor	000000	100110		0	0	000	0	00	0	00	000	1	0	00
nor	000000	100111		0	0	000	0	00	0	00	000	1	0	00
add	000000	100000		0	0	000	0	00	0	00	000	1	0	00
addu	000000	100001		0	0	000		00	0	00	000	1	0	00
sub	000000	100010		0	0	000	0	00	0	00	000	1	0	00
subu	000000	100011		0	0	000	0	00	0	00	000	1	0	00
addi	001000			0	0	000	0	00	0	01	000	1	0	01
addiu	001001			0	0	000	0	00	0	01	000	1	0	01
andi	001100			0	0	000	1	00	0	01	000	1	0	01
ori	001101			0	0	000	1	00	0	01	000	1	0	01
xori	001110			0	0	000	1	00	0	01	000	1	0	01
slti	001010			0	0	000	0	00	0	01	000	1	0	01
sltiu	001011			0	0	000	0	00	0	01	000	1	0	01
指令	opcode	funct	RT	REGorM	MemW	NPCo	EXTO	A1o	A2	A3o	REGo	RegWri	ALU_A	ALU_Bo
1日.스	opcode	Tunct	KI	EM	rite	p	p	p	op	p	p	te	op	p
lw	100011			1	0	000	0	00	0	01	000	1	0	01
lb	100000			1	0	000	0	00	0	01	000	1	0	01
lbu	100100			1	0	000	0	00	0	01	000	1	0	01
lh	100001			1	0	000	0	00	0	01	000	1	0	01
lhu	101001			1	0	000	0	00	0	01	000	1	0	01
SW	101011			0	1	000	0	00	0	00	000	0	0	01
sb	101000			0	1	000	0	00	0	00	000	0	0	01
sh	101001			0	1	000	0	00	0	00	000	0	0	01
beq	000100			0	0	001	0	00	0	00	000	0	0	00
bne	000101			0	0	001	0	00	0	00	000	0	0	00
blez	000110			0	0	001	0	00	0	00	000	0	0	00
bgtz	000111			0	0	001	0	00	0	00	000	0	0	00
bltz	000001		00000	0	0	001	0	00	0	00	000	0	0	00
bgez	000001		00001	0	0	001	0	00	0	00	000	0	0	00
lui	001111			0	0	000	0	00	0	01	000	1	0	01
sll	000000	000000		0	0	000	0	00	0	00	000	1	0	00
srl	000000	000010		0	0	000	0	00	0	00	000	1	0	00
sra	000000	000011		0	0	000	0	00	0	00	000	1	0	00
sllv	000000	000100		0	0	000	0	00	0	00	000	1	0	00
srlv	000000	000110		0	0	000	0	00	0	00	000	1	0	00
srav	000000	000111		0	0	000	0	00	0	00	000	1	0	00
slt	000000	101010		0	0	000	0	00	0	00	000	1	0	00
sltu	000000	101011		0	0	000	0	00	0	00	000	1	0	00
j	000010			0	0	010	0	00	0	00	000	0	0	00
jal	000011			0	0	010	0	00	0	10	001	1	0	00
jalr	000000	001001		0	0	011	0	00	0	00	001	1	0	00
jr	000000	001000		0	0	011	0	00	0	00	000	0	0	00
				REGorM	MemW	NPCo	EXTO	Alo	A2	A30	REGo	RegWri	AIII A	ALU_Bo
指令	opcode	funct	RT	EM	rite	p	p	p	op	p	p	te	op	p
14	000000	011000							-				1	•
mult	000000	011000		0	0	000	000	00	0	00	000	0		
multu	000000	011001		0	0	000	000	00	0	00	000	0		
div	000000	011010		0	0	000	000	00	0	00	000	0		
divu	000000	011011		0	0	000	000	00	0	00	000	0		
mfhi	000000	010000		0	0	000	000	00	0	00	010	1		
mflo	000000	010010		0	0	000	000	00	0	00	011	1		

mthi	000000	010001	0	0	000	000	00	0	00	000	0	
mtlo	000000	010011	0	0	000	000	00	0	00	000	0	

0000		
ALUO p	MDUOp	start
	0000	1
	0001	1
	0010	1
	0011	1
	1111	0
	1111	0

0100	0
0101	0