
# Structure Registration Memory (Tyros 3)

### 1 STRUCTURE



# 2 SpfF Chunk (Header)

• SpfF chunk: 22 bytes

53 70 66 46	SpfF (ASCII coded)
00 10	number of following data bytes in this chunk
OC 12	
52 47 53 54	RGST (ASCII coded)
00 02	could be: (according to SysEx messages)
	Sub-ID #2 = General MIDI Off
	type 1
	Maj 7
	Internal Clock Substatus
	Lyrics Indication On/Off
00 02	
00 00 03 66	number of bytes in the whole document;
	here: 870 bytes
00 70	

# 3 BHD CHUNKS (SEQUENCE OR REGISTRATION)

- Sequence chunk: 42 bytes
- thus: SpfF and sequence chunk take up 64 bytes (bytes 0x000 to 0x030)

42 48 64	BHd (ASCII coded)	
00 / 01	type: Registration or Sequence	
00 24	number of bytes in this chunk 752	
	Data	

#### 3.1 ... DATA FOR SEQUENCE

Sequence occurs only one time in the whole file

FF	- all data bytes filled up with FF: Registration
FF	Sequence disabled → end byte doesn't
FF FF FF FF	matter
	- last byte: code for Sequence End
	→ 00: Sequence End Stop
	→ 01: Sequence End Top
	→ 02: Sequence End Next Bank

## 3.2 ... DATA FOR REGISTRATION (GPM)

#### 3.2.1 GPm Header

47 50 6D	GPm (ASCII coded)		
OB	type		
<b>00 2A</b> (42 Bytes following)	number of following data bytes in this chunk		

#### 3.2.2 GPm Data

### Drehregler:

- Tyros: -64 bis 63

Dezimal: 0 bis 127 (Mitte: 64)Hex: 00 bis 7F (Mitte: 40)

Funktion	Data- Byte	Wertebereich	Erklärung bzw. Wertbereich am Tyros
	<del></del>	Title 01	
Registration name	1	ASCII coded	
		02	-
	1	7F	aus / an ?
	2	03	
	3	04	
	4	02	
	5	06	
	6	06	
	7	07	
	8	02	
	9	05	
	10	06	
		Standard Style 07	
	1		
	2		
	3		
	4		
	5		
	6		
	7		
Style-Nummer	8		
Style-Nummer wiederholt	9		
	10		
Sync Start	11	00 / 7F	aus / ein
	12		
	13		
	14		
	15		
		Style Attributes 08	
		Voice global 0A	
		Voices 0B / 0F / 17 (13 Left	
Aktiviert?	1	00 / 7F	aus / ein
MSB	2	00	

LSB	3	73 (Dez: 115)	
Programm	4	00	
Portamento Time	5	00 - 7F	0 - 127
	6		
Volume	7	00 - 7F	0 - 127
Panpot	8	00 und 01 / 40 / 7F	links / mittig / rechts
•		00 - 7F	L63 - R63 (L63 = L64)
Mono	9/10	00 / 7F	aus / an
Harmonic Content	11	00 - 7F	-64 - +63
	12		
Brightness	13	00 - 7F	-64 - +63
Reverb	14	00 - 7F	0 - 127
Chorus	15	00 - 7F	0 - 127
	16		
	17		
	18		
	19		
EQ Low	20	00 - 7F	-64 - +63
	21		
EQ High	22	00 - 7F	-64 - +63
	23		
	24		
	25		
Pitch Bend Range	26	00 – 0 <mark>C</mark>	0 - 12
Tuning	27	00 - 7F	-64 - +63
	28		
	29		
	30		
Octave	31	3E (62) / 3F (63) / 40 (64) / 41 (65) / 42 (66)	-2/-1/0/1/2
	32		
	33		
	34		
	35		
	36		
	37		
	38		
	39		
	40		
	41		
	42		
		Basic 1B Reverb	
	1	FF	00 bei Änderung allgemein
	2	FB	FF wenn anderer Reverb
			02 bei Änderung allgemein
	3	FF	
	4	FF	
	5	01	MSB
	6	13	LSB
	7	40	
	1.	Basic 1C Chorus	1
1 FF 00 bei Änderung allgemein			

		00 wenn anderer Reverb
2	FB	02 bei Änderung allgemein
		02 wenn anderer Reverb
		FF wenn anderer Chorus
3	FF	
4	FF	
5	41	MSB
6	00	LSB
7	40	
	Basic 20	
1	00	
2	<b>7F</b>	
3	00	
4	00	
5	00	
6	01	
7	FF	
8	FF	
9	63	
10	10	
11	00	
12	00	
13	03	
14	FF	
15	FA	FF bei Änderung allgemein
		bei Änderung des Tempos
	Basic 21	
1	00	
2	7F	
3	00	
4	00	
5	00	
6	09	
7	FF	
8	FF	
9	15	
10	00	
11	00	
12	00	
13	01	
14	FF	EE hat Xaada aa aa Uu
15	FA	FF bei Änderung allgemein
	Basic 22	bei Änderung des Tempos
1	00	
2	7F	
3	00	
4	00	
5	00	
6	15	
7	FF	
8	FF	
	• •	<u> </u>

	9	42	
	10	10	
	11	00	
	12	00	
	13	02	
	14	FF	
	15	FA	FF bei Änderung allgemein
		Tempo 29	
Tempo?	1/2	00 05 - 01 F4	5- 500
Tempo Song	3/4	00 05 - 01 F4	5 - 500
Tempo Style	5/6	00 05 - 01 F4	5-500
	7	00 / 7F	aus / ein
			Vermutung: nur ein, wenn
			Tempo Song nicht gleich Tempo
			Style

### scheint immer bei Änderung einzutreten

Pos. 537 von FF auf 00 538 von FB auf 02 550 von FF auf 00 551 von FB auf 02

682 von FA auf FF