

# Arquitetura de Computadores Trabalho Prático 3

Data de entrega e discussão: 24-05-2024

Faculdade de Ciências Exatas e da Engenharia

Ano letivo 2023/2024

2º Ano 2º Semestre

#### Índice

Introdução	2
Objetivos	4
Desenvolvimento	4
Interrupções	5
Conclusão	5
Anexo A – Fluxogramas	6
Start Program	6
Init Routine	7
Countdown Routine	8
Answer Routine	10
Timer 0 Interruption	11
Timer 1 Interruption	12
External Interruption 0	13
External Interruption 1	14
Display Routine	15
Anexo B1: Código em linguagem Assembly	16
Anexo B2: Código em Linguagem C	44

### Introdução

Este relatório foi realizado no âmbito de descrever o trabalho realizado para o 3º trabalho prático de Arquitetura de Computadores. Este trabalho teve como principal objetivo implementar um programa em assembly e C que é capaz de realizar uma contagem de tempo e também é capaz de registar as respostas do utilizador. Este sistema seria desenvolvido no âmbito de, por exemplo, um concurso de respostas. Para isto foi utilizado o software Keil Uvision 5 para produzir o código do programa e consequente simulação do mesmo.

Foi desenvolvimento pelo grupo docente um circuito que trava de realizar as ligações entre o microcontrolador, os displays de 7 segmentos e os botões necessários. Este circuito está representado na figura 1.

O botão B1 é responsável por iniciar a contagem de 5 segundos até 0 segundos. Caso não haja nenhuma interrupção através dos botões de resposta BA, BB, BC e BD é apresentado, alternadamente em 1 segundo, o tempo "0.0" e a resposta "-.-". Para reiniciar o programa o utilizador clica novamente no botão B1 onde é mostrado os 5 segundos novamente. Caso o utilizador clique nalgum botão de respostas durante a contagem, inicia-se a alternação entre resposta/tempo com 1 segundo em que a resposta corresponde ao botão clicado e o tempo corresponde ao tempo restante que o utilizador

tinha para responder, ou seja, corresponde ao tempo que estava representado no display aquando da seleção de resposta.




Figura 1 - Esquema de ligações do microcontrolador

Tabela 1 - Mapeamento dos Pinos do microcontrolador para o Display

Objeto	Pino do microcontrolador			
DISPLAY 1				
A	P1.0			
В	P1.1			
С	P1.2			
D	P1.3			
E	P1.4			
F	P1.5			
G	P1.6			
DP	P1.7			
DISPLAY 2				
A	P2.0			
В	P2.1			
С	P2.2			
D	P2.3			
E	P2.4			
F	P2.5			
G	P2.6			
DP	P2.7			

#### **Objetivos**

- Breve estudo dos requisitos de software para a elaboração do projeto
- Desenho dos principais fluxogramas do controlo e das rotinas secundárias
- Programação em linguagem assembly e linguagem C
- Verificação experimental do programa

#### **Desenvolvimento**

Este projeto foi desenvolvimento baseado numa noção de estados. Assim definiuse 3 estados fundamentais:

- Estado waiting: corresponde ao programa estar com o display "5.0" e à espera que o utilizador carregue no botão B1 para iniciar a contagem
- Estado time: corresponde ao programa estar a realizar a contagem desde os 5 segundos até aos 0 segundos. Este estado pode ser interrompido através do utilizador quando este carrega num botão corresponde a uma das quatro respostas, passo para o estado de resposta.
- Estado answer: corresponde ao programa estar a mostrar a resposta (ou resposta nula ("-.-")) alternadamente com o tempo restante de 1 em 1 segundos. Este estado é interrompido quando o utilizador carrega no botão B1, voltando ao estado waiting.

Assim, como é percebido, é necessário utilizar expressões condicionais para saber se o estado está ativo ou desativo para poder executar as instruções correspondentes.

Depois, foi necessário corresponder os bits dos segmentos para um valor em hexadecimal. Assim, esta correspondência é descrita na tabela 2.

Tabela 2 - Valores em binário e hexadecimal dos símbolos do Display

Símbolo	Valor em Binário	Valor em Hexadecimal
0.	01000000	40
1.	01111001	79
2.	00100100	24
3.	00110000	30
4.	00011001	19
5.	00010010	12
	00111111	3F
0	11000000	C0
1	11111001	F9
2	10100100	A4
3	10110000	В0
4	10011001	99
5	10010010	92
6	10000010	82

7	11111000	F8
8	1000000	80
9	10010000	90
-	10111111	BF
А	10001000	88
В	10000011	83
С	11000110	C6
d	10100001	A1

#### Interrupções

As interrupções foram uma funcionalidade bastante importante neste trabalho. Assim, decidiu-se ativar 4 interrupções (2 timer e 2 externas). Para fazer isto, foi necessário ativar as interrupções globalmente, ativar cada interrupção e de seguida configurar essas interrupções.

As interrupções timers foram configuradas com um debounce de 50ms para evitar o ruído quando o utilizador pressiona os botões. Assim, como sabe-se que os timers estiveram no modo 1 com 16 bits:

$$65536 - 50000 = 15536 (3CB0h)$$

Logo, TH = 0x3C e TL = 0xB0.

A interrupção Timer 0 foi responsável por fazer contagens de segundos e por ativar a mudança do display 1 (correspondente aos segundos). Também foi responsável por verificar se a contagem tinha excedido os 5 segundos no estado time de modo a dar reset no timer, ativar o estado answer e mostrar no display do tempo restante "0.0".

A interrupção Timer 1 foi responsável por fazer contagens de 0.1 segundos e por ativar a mudança do display 2 (correspondente às decimas de segundo).

A interrupção externa 0 (ativada quando o utilizador carrega no botão B1) tem 2 funções. Caso o estado ativo seja o estado waiting (estado inicial com "5.0" no display), muda-se para o estado time (inicia-se a contagem). Caso o estado ativo seja o estado answer (alternância de resposta/tempo restante), muda-se para o estado waiting (estado inicial com "5.0" no display).

A interrupção externa 1 (ativada quando o utilizador carrega num dos botões de resposta BA, BB, BC ou BD) verifica e ativa a flag desse botão de resposta.

#### Conclusão


Este trabalho permitiu ter uma melhor noção de como trabalhar e gerir interrupções. Permitiu, embora com mais dificuldade, compreender melhor a linguagem assembly e como gerir registos e memória. A linguagem C é, sem dúvida, mais fácil de trabalhar do que a linguagem Assembly. No entanto, percebe-se que com Assembly o programador tem muito mais controlo sobre a memória e o próprio programa.

## Anexo A – Fluxogramas


### **Start Program**


## START PROGRAM **BEGIN** Init routine NO waitingState == 0 ? YES YES timeState Countdown Routine YES -NO answerState B1 is YES -Answer Routine

#### **Init Routine**




#### **Countdown Routine**






#### **Answer Routine**




### **Timer 0 Interruption**




#### **Timer 1 Interruption**


## **Timer 1 Interruption**



#### **External Interruption 0**




## **External Interruption 1**



## **Display Routine**

## **Display Routine**



## Anexo B1: Código em linguagem Assembly

		•	``	
tenthSecond	EQU		2	;time to count 0,1 seconds (2 x 50ms)
twoTenthSeconds	EQU		4	
threeTenthSeconds E	QU	6		
fourTenthSeconds	EQU 8			
fiveTenthSeconds EQ	U	10		
sixTenthSeconds	EQU		12	
sevenTenthSeconds E	QU	14		
eightTenthSeconds E	QU	16		
nineTenthSeconds EQ	QU	18		
second 50ms)		EQU		20 ;time to count 1 second (20 x
twoSeconds	EQU	40		
threeSeconds EQU		60		
fourSeconds EQU	80			
fiveSeconds EQU	100			
THtimer 50000(3E8h) = 15536	(3CB0h	EQU ))	0x3C	;Timer 0 - 50ms -> (65536(10000h) -
TLtimer 15536(3CB0h))	EQU	0xB0	;Timer	0 - 50ms -> (65536(10000h) - 50000(3E8h) =
; values for display				
null	EQU		0xFF	
zeroDot		EQU		0x40
oneDot	EQU		0x79	
twoDot	EQU		0x24	
threeDot	EQU		0x30	
fourDot		EQU		0x19
fiveDot	EQU	0x12		
hifenDot	EQU		0x3F	
zero	EQU		0xC0	
one		EQU		0xF9

two		EQU		0xA4
three	EQU		0xB0	
four	EQU		0x99	
five	EQU		0x92	
six		EQU		0x82
seven	EQU		0xF8	
eight	EQU		08x0	
nine	EQU		0x90	
hifen	EQU		0xBF	
aLetter	EQU		88x0	
bLetter	EQU		0x83	
cLetter	EQU		0xC6	
dLetter	EQU		0xA1	
; Buttons definition				
BA EQU	P3^4	;		
ВВ		EQU	P3^5	;
ВС		EQU	P3^6	;
BD		EQU	P3^7	;
; states				
waitingState EQU	1		; R0 b	ank 0
timeState	EQU	0		; R1 bank 0
answerState EQU	0		; R2 ba	
D1changed	EQU	0		; R3 bank 0
D2changed	EQU	0		; R4 bank 0
counter	EQU	0		; R5 bank 0
counter1	EQU	0		; R6 bank 0

D1 EQU 0 ; R0 bank 1 D2 EQU 0 ; R1 bank 1 0 EQU ; R2 bank 1 pressA EQU 0 ; R3 bank 1 pressB EQU 0 pressC ; R4 bank 1 pressD EQU 0 ; R5 bank 1 StackPointer EQU 0x0F; need to point to a new location because of the usage of 2 banks CSEG AT 0000H JMP Main CSEG AT 0003H JMP ExternalInterruption0 CSEG AT 000BH JMP TimerInterruption0 CSEG AT 0013H JMP ExternalInterruption1

CSEG AT 001BH

JMP TimerInterruption1

CSEG AT 1000H

Main:

MOV SP, #StackPointer

CALL Initializations ; routine to set registers

```
CALL EnableInterruptions ; routine to enable interruptions and set priorities
CALL ConfigureInterruptions; routine to configure tmod, timers and tcon
; select bank 1
SETB PSW.3
MOV R0, #fiveDot
MOV R1, #zero
; select bank 0
CLR PSW.3
CALL Display
For:
CJNE R0, #0, CheckAnswerState1; waitingState == 0
CJNE R1, #1, CheckAnswerState1; timeState == 1
CJNE R3, #0, OneSecondR; D1Changed == 0
MOV A, R5
                                                               ; A = counter
CJNE A, #fourSeconds, OneSecondR
                                         ; counter == 4 * seconds
      ; select bank 1
      SETB PSW.3
      MOV R0, #zeroDot
      ; select bank 0
```

```
CLR PSW.3
      MOV R3, #1
      CALL Display
      JMP ZeroTenthSecondsR
OneSecondR:
CJNE R3, #0, TwoSecondsR; D1Changed == 0
MOV A, R5
                                                           ; A = counter
CJNE A, #threeSeconds, TwoSecondsR
                                             ; counter == 3 * seconds
      ; select bank 1
      SETB PSW.3
      MOV R0, #oneDot
      ; select bank 0
      CLR PSW.3
      MOV R3, #1
      CALL Display
      JMP ZeroTenthSecondsR
TwoSecondsR:
CJNE R3, #0, ThreeSecondsR; D1Changed == 0
MOV A, R5
                                                           ; A = counter
CJNE A, #twoSeconds, ThreeSecondsR
                                             ; counter == 2 * seconds
```

```
; select bank 1
      SETB PSW.3
      MOV R0, #twoDot
      ; select bank 0
      CLR PSW.3
      MOV R3, #1
      CALL Display
      JMP ZeroTenthSecondsR
ThreeSecondsR:
CJNE R3, #0, FourSecondsR; D1Changed == 0
CJNE R5, #second, FourSecondsR; counter == second
      ; select bank 1
      SETB PSW.3
      MOV R0, #threeDot
      ; select bank 0
      CLR PSW.3
      MOV R3, #1; D1changed = 1
      CALL Display
      JMP ZeroTenthSecondsR
```

```
FourSecondsR:
      CJNE R3, #0, ZeroTenthSecondsR ; D1Changed == 0
      CJNE R1, #1, ZeroTenthSecondsR ; timeState == 1
      CJNE R5, #0, ZeroTenthSecondsR
                                       ; counter == 0
             ; select bank 1
             SETB PSW.3
             MOV R0, #fourDot
             ; select bank 0
             CLR PSW.3
             MOV R3, #1
             CALL Display
             JMP ZeroTenthSecondsR
      CheckAnswerState1:
             JMP CheckAnswerState
      ZeroTenthSecondsR:
             CJNE R4, #0, OneTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, #nineTenthSeconds, OneTenthSecondsR; counter1 == 9 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
```

```
MOV R1, #zero
             ; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      OneTenthSecondsR:
             CJNE R4, #0, TwoTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, #eightTenthSeconds, TwoTenthSecondsR; counter1 == 8 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #one
             ; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
```

```
TwoTenthSecondsR:
             CJNE R4, #0, ThreeTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, \#sevenTenthSeconds, ThreeTenthSecondsR; counter1 == 7 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #two
             ; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      ThreeTenthSecondsR:
             CJNE R4, #0, FourTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, #sixTenthSeconds, FourTenthSecondsR; counter1 == 6 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #three
```

```
; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      FourTenthSecondsR:
             CJNE R4, #0, FiveTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, #fiveTenthSeconds, FiveTenthSecondsR; counter1 == 5 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #four
             ; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      FiveTenthSecondsR:
             CJNE R4, #0, SixTenthSecondsR; D2Changed == 0
```

```
MOV A, R6
             CJNE A, #fourTenthSeconds, SixTenthSecondsR; counter1 == 4
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #five
             ; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      SixTenthSecondsR:
             CJNE R4, #0, SevenTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, #threeTenthSeconds, SevenTenthSecondsR; counter1 == 3 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #six
             ; select bank 0
```

```
CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      SevenTenthSecondsR:
             CJNE R4, #0, EightTenthSecondsR; D2Changed == 0
             MOV A, R6
             CJNE A, #twoTenthSeconds, EightTenthSecondsR; counter1 == 2 *
tenthSeconds
             ; select bank 1
             SETB PSW.3
             MOV R1, #seven
             ; select bank 0
             CLR PSW.3
             MOV R4, #1
             CALL Display
             JMP CheckAnswerState
      EightTenthSecondsR:
             CJNE R4, #0, NineTenthSecondsR; D2Changed == 0
             CJNE R6, #tenthSecond, NineTenthSecondsR; counter == tenthSeconds
             ; select bank 1
```

```
SETB PSW.3
      MOV R1, #eight
      ; select bank 0
      CLR PSW.3
      MOV R4, #1
      CALL Display
      JMP CheckAnswerState
NineTenthSecondsR:
      CJNE R4, #0, CheckAnswerState; D2Changed == 0
      CJNE R6, #0, CheckAnswerState; counter == 0
      CJNE R1, #1, CheckAnswerState; timeState == 1
      ; select bank 1
      SETB PSW.3
      MOV R1, #nine
      ; select bank 0
      CLR PSW.3
      MOV R4, #1 ; D2changed = 1
      CALL Display
```

```
JMP CheckAnswerState
CheckAnswerState:
      CJNE R2, #1, EndCycle1; answerState == 1
      CJNE R3, #0, OneSecondAnswer; D1Changed == 0
      MOV A, R5
      CJNE A, #twoSeconds, OneSecondAnswer; counter == 2 * seconds
      CALL Display
      MOV R5, #0
                                       ; reset counter
      JMP EndCycle
      EndCycle1:
             JMP EndCycle
      OneSecondAnswer:
             CJNE R3, #0, EndCycle; D1Changed == 0
             CJNE R5, #second, EndCycle; counter == second
             ; select bank 1
             SETB PSW.3
             CJNE R2, #1, CheckB ; pressA == 1
             ; select bank 1
             SETB PSW.3
```

```
MOV A, R0
      MOV R0, #hifenDot
      MOV B, R1
      MOV R1, #aLetter
      CLR PSW.3
      CALL Display
      ; select bank 1
      SETB PSW.3
      MOV R0, A
      MOV R1, B
      ; select bank 0
      CLR PSW.3
      JMP EndCycle
CheckB:
      CJNE R3, #1, CheckC ; pressB == 1
      ; select bank 1
      SETB PSW.3
      MOV A, R0
      MOV R0, #hifenDot
      MOVB, R1
      MOV R1, #bLetter
```

```
CLR PSW.3
      CALL Display
      ; select bank 1
      SETB PSW.3
      MOV R0, A
      MOV R1, B
      ; select bank 0
      CLR PSW.3
      JMP EndCycle
CheckC:
      CJNE R4, #1, CheckD ; pressC == 1
      ; select bank 1
      SETB PSW.3
      MOV A, R0
      MOV R0, #hifenDot
      MOV B, R1
      MOV R1, #cLetter
      CLR PSW.3
      CALL Display
      ; select bank 1
      SETB PSW.3
```

```
MOV R0, A
      MOV R1, B
      ; select bank 0
      CLR PSW.3
      JMP EndCycle
CheckD:
      CJNE R5, #1, CheckNone ; pressD == 1
      ; select bank 1
      SETB PSW.3
      MOV A, R0
      MOV R0, #hifenDot
      MOV B, R1
      MOV R1, #dLetter
      CLR PSW.3
      CALL Display
      ; select bank 1
      SETB PSW.3
      MOV R0, A
      MOV R1, B
      ; select bank 0
      CLR PSW.3
      JMP EndCycle
```

```
CheckNone:
                    ; select bank 1
                    SETB PSW.3
                    MOV A, R0
                    MOV R0, #hifenDot
                    MOVB, R1
                    MOV R1, #hifen
                    CLR PSW.3
                    CALL Display
                    ; select bank 1
                    SETB PSW.3
                    MOV R0, A
                    MOV R1, B
                    ; select bank 0
                    CLR PSW.3
                    JMP EndCycle
      EndCycle:
             CLR PSW.3
             JMP For
                                               ; begin again
Initializations:
      MOV R0, #waitingState
```

```
MOV R1, #timeState
      MOV R2, #answerState
      MOV R3, #D1changed
      MOV R4, #D2changed
      MOV R5, #counter
      MOV R6, #counter1
      ; select bank 1
      SETB PSW.3
      MOV R0, #D1
      MOV R1, #D2
      MOV R2, #pressA
      MOV R3, #pressB
      MOV R4, #pressC
      MOV R5, #pressD
      ; select bank 0
      CLR PSW.3
      RET
EnableInterruptions:
      MOV IE, #8FH
                                        ; EA=1, ET1=1, EX1=1, ET0=1 e EX0=1 ->
IE=10001111
      MOV IP, #00H
                                        ; Don't change priorities
      RET
ConfigureInterruptions:
```


```
; TMOD Config
       MOV A, TMOD
                                                    ; copy tmod to A
       ANL A,#0x00
                                                    ; set all bits of tmod to 0
       ORL A,#0x11
                                                    ; set timer mods to 1 (16 bits)
       MOV TMOD, A
                                                    ; set tmod
       ; timer 0 config
       MOV TH0, #THtimer
                                            ; set th0
       MOV TL0, #THtimer
                                            ; set tl0
       ; timer 1 config
       MOV TH1, #THtimer
                                            ; set th1
       MOV TL1, #THtimer
                                            ; set tl1
       ; TCON config
       CLR TR0
                                                           ; timer 0 is turned off
       CLR TR1
                                                           ; timer 1 is turned off
       SETB ITO
                                                    ; external interruption 0 is activated on
falling edge
       SETB IT1
                                                    ; external interruption 1 is activated on
falling edge
       RET
Display:
       ; select bank 1
       SETB PSW.3
       MOV P1, R0
```

```
MOV P2, R1
      ; select bank 0
      CLR PSW.3
      RET
ExternalInterruption0:
      PUSH PSW
      ; select bank 0
      CLR PSW.3
      CJNE R0, #1, NotWaiting ; skip if the wainting state is 1
      CJNE R2, #0, ExternalInterruption0End; skip if answer state is 0
      ; change states
      MOV R0, #0
                                                 ; change to non waiting state
      MOV R1, #1
                                                 ; change to start counting time state
      ; enable timers
      SETB TR0
      SETB TR1
      ; Reload timers
      MOV TH0, #THtimer
                                          ; set th0
      MOV TL0, #THtimer
                                          ; set tl0
```

```
MOV TH1, #THtimer
                                   ; set th1
MOV TL1, #THtimer
                                   ; set tl1
; reset counters
MOV R5, #0
MOV R6, #0
JMP ExternalInterruption0End
NotWaiting:
       CJNE R2, #1, ExternalInterruption0End; answerState == 1
       ; change states
       MOV R0, #1
                                          ; change to waiting state
       MOV R2, #0
                                          ; change to non answer state
       ; select bank 1
       SETB PSW.3
       MOV R2, #0
                      ; Reset button press flags
       MOV R3, #0
       MOV R4, #0
       MOV R5, #0
       MOV R0, #fiveDot
       MOV R1, #zero
       ; select bank 0
```

```
CLR PSW.3
             CALL Display
             ; reset counters
             MOV R5, #0
             MOV R6, #0
             // stop timers
             CLR TR0
             CLR TR1
      ExternalInterruption0End:
             POP PSW
             RETI
TimerInterruption0:
      PUSH PSW
      ; select bank 0
      CLR PSW.3
      ; timer 0 config
      MOV TH0, #THtimer
                                        ; set th0
      MOV TL0, #THtimer
                                         ; set tl0
      INC R5
                                                ; Increment counter
      MOV R3, #0
                                                ; D1changed = 0
```

```
CJNE R5, #fiveSeconds, TimerInterruption0End; counter == 5*second
CJNE R0, #0, TimerInterruption0End; waitingState == 0
CJNE R1, #1, TimerInterruption0End; timeState == 1
; reset counter
MOV R5, #0
                                          ; counter = 0
; change states
MOV R1, #0
                                          ; timeState = 0
MOV R2, #1
                                          ; answerState = 1
; display
; select bank 1
SETB PSW.3
MOV R0, #zeroDot
MOV R1, #zero
; select bank 0
CLR PSW.3
CALL Display
TimerInterruption0End:
       POP PSW
       RETI
```



```
; select bank 1
       SETB PSW.3
       MOV R3, #1
       ; select bank 0
       CLR PSW.3
       ; change states
       MOV R1, #0
                                                 ; timeState = 0
       MOV R2, #1
                                                 ; answerState = 1
       JMP ExternalInterruption1End
AnswerC:
       JB BC, AnswerD
                                          ; BC == 0
       ; select bank 1
       SETB PSW.3
       MOV R4, #1
       ; select bank 0
       CLR PSW.3
       ; change states
       MOV R1, #0
                                                 ; timeState = 0
```

```
MOV R2, #1
                                                         ; answerState = 1
              {\sf JMP\ ExternalInterruption 1End}
       AnswerD:
              JB BD, ExternalInterruption1End; BD == 0
              ; select bank 1
              SETB PSW.3
              MOV R5, #1
              ; select bank 0
              CLR PSW.3
              ; change states
              MOV R1, #0
                                                         ; timeState = 0
              MOV R2, #1
                                                         ; answerState = 1
              JMP ExternalInterruption1End
       ExternalInterruption1End:
              POP PSW
              RETI
TimerInterruption1:
       PUSH PSW
       ; select bank 0
       CLR PSW.3
```

; timer 1 config

MOV TH1, #THtimer ; set th1

MOV TL1, #THtimer ; set tl1

INC R6 ; counter1++

MOV R4, #0 ; D2changed = 0

CJNE R6, #second, TimerInterruption1End; counter1 == second

MOV R6, #0 ; counter1 = 0

TimerInterruption1End:

**POP PSW** 

RETI

END

## Anexo B2: Código em Linguagem C

```
#include <reg51.h>
#define tenthSecond
                                     2 //time to count 0,1 seconds (2 x
50ms)
#define second
                                         20 // time to count 1 second (20
// values for display
#define null
                                             0xFF
#define zeroDot
                                         0x40
#define oneDot
                                         0x79
#define twoDot
                                         0x24
#define threeDot
                                         0x30
#define fourDot
                                         0x19
#define fiveDot
                                         0x12
#define hifenDot
                                         0x3F
#define zero
                                             0xC0
#define one
                                             0xF9
#define two
                                             0xA4
#define three
                                             0xB0
#define four
                                             0x99
#define five
                                             0x92
#define six
                                             0x82
#define seven
                                             0xF8
#define eight
                                             0x80
#define nine
                                             0x90
#define hifen
                                             0xBF
#define aLetter
                                         0x88
#define bLetter
                                         0x83
#define cLetter
                                         0xC6
#define dLetter
                                         0xA1
// Buttons definition
sbit BA = P3^4;
sbit BB = P3^5;
sbit BC = P3^6;
sbit BD = P3^7;
bit pressA = 0;
bit pressB = 0;
bit pressC = 0;
bit pressD = 0;
bit waitingState = 1;
bit timeState = 0;
bit answerState = 0;
bit D1changed = 0;
```

```
bit D2changed = 0;
unsigned int counter = 0;
unsigned int counter1 = 0;
unsigned char D1;
unsigned char D2;
//Function declarations
void Init(void);
void display(unsigned char Display1, unsigned char Display2);
void main (void)
    Init();
    while(1) {
            if (waitingState == 0) {
                // button has been pressed to start counting
                if (timeState == 1) {
                    if (counter == (4*second) && D1changed == 0) {
                        D1 = zeroDot;
                        D1changed = 1;
                    } else if (counter == (3*second) && D1changed == 0) {
                        D1 = oneDot;
                        D1changed = 1;
                    } else if (counter == (2*second) && D1changed == 0) {
                        D1 = twoDot;
                        D1changed = 1;
                    } else if (counter == second && D1changed == 0) {
                        D1 = threeDot;
                        D1changed = 1;
                    } else if (counter == 0 && D1changed == 0 &&
timeState == 1) {
                        D1 = fourDot;
```

```
D1changed = 1;
                    if (counter1 == (9*tenthSecond) && D2changed == 0) {
                        D2 = zero;
                        D2changed = 1;
                    } else if (counter1 == (8*tenthSecond) && D2changed
== 0) {
                        D2 = one;
                        D2changed = 1;
                    } else if (counter1 == (7*tenthSecond) && D2changed
== 0) {
                        D2 = two;
                        D2changed = 1;
                    } else if (counter1 == (6*tenthSecond) && D2changed
== 0) {
                        D2 = three;
                        D2changed = 1;
                    } else if (counter1 == (5*tenthSecond) && D2changed
== 0) {
                        D2 = four;
                        D2changed = 1;
                    } else if (counter1 == (4*tenthSecond) && D2changed
== 0) {
                        D2 = five;
                        D2changed = 1;
                    } else if (counter1 == (3*tenthSecond) && D2changed
== 0) {
                        D2 = six;
                        D2changed = 1;
                    } else if (counter1 == (2*tenthSecond) && D2changed
== 0) {
                        D2 = seven;
```

```
D2changed = 1;
                    } else if (counter1 == tenthSecond && D2changed == 0)
                        D2 = eight;
                        D2changed = 1;
                    } else if (counter1 == 0 && D2changed == 0 &&
timeState == 1) {
                        D2 = nine;
                        D2changed = 1;
                    if (D2changed == 1 || D2changed == 1) {
                        display(D1, D2);
                // answer state
                if (answerState == 1) {
                    if (counter == (2*second) && D2changed == 0) {
                            display(D1, D2);
                            counter = 0; // repeat the cycle
                    } else if (counter == second && D2changed == 0) {
                        if (pressA == 1) {
                            display(hifenDot, aLetter);
                        } else if (pressB == 1) {
                            display(hifenDot, bLetter);
                        } else if (pressC == 1) {
                            display(hifenDot, cLetter);
                        } else if (pressD == 1) {
```

```
display(hifenDot, dLetter);
                          } else {
                              display(hifenDot, hifen);
void Init(void){
    //Configuration of interruptions
    EA = 1; //ativate global interruptions
    ET0 = 1; // activate timer interruption 0
    ET1 = 1; // activate timer interruption 1
    EX0 = 1; // activate external interruption 0
    EX1 = 1, // activate external interruption 1
    TMOD &= 0x00; //Clean initial 4 bits of timer 0 and 1
    TMOD \mid = 0x11; //Set timer 0 and 1 with 16 bits
    //\text{Timer 0} - 50\text{ms} \rightarrow (65536(10000\text{h}) - 50000(3E8\text{h}) = 15536(3CB0\text{h}))
    TH0 = 0x3C;
    TL0 = 0xB0;
    //\text{Timer 1 - 50ms} \rightarrow (65536(10000h) - 50000(3E8h) = 15536(3CB0h))
    TH1 = 0x3C;
    TL1 = 0xB0;
    //Configure TCON
    ITO = 1; //specify falling edge trigger on external interruption 0
    IT1 = 1; //specify falling edge trigger on external interruption 1
    display(fiveDot, zero);
void Timer0_ISR (void) interrupt 1 {
    //Configure timer 0
```

```
//Timer 0 - 50ms -> (65536(10000h) - 50000(C350h)= 15536(3CB0h))
    TH0 = 0x3C;
    TL0 = 0xB0;
    counter++;
    if (counter % second == 0) {
        D1changed = 0;
    // start showing answer state with no answer
    if(counter >= (5*second) && waitingState == 0 && timeState == 1){
        counter = 0;
        // change stats
        timeState = 0;
        answerState = 1;
        D1 = zeroDot;
        D2 = zero;
void Timer1_ISR (void) interrupt 3 {
    //\text{Timer 1 - 50ms} \rightarrow (65536(10000h) - 50000(3E8h) = 15536(3CB0h))
    TH1 = 0x3C;
    TL1 = 0xB0;
    counter1++;
    if (counter1 % tenthSecond == 0) {
        D2changed = 0;
    if (counter1 >= second) {
```

```
counter1 = 0;
void External0_ISR (void) interrupt 0 {
   // change for non waiting state and start counting timer
   if (waitingState == 1 && answerState == 0) {
       waitingState = 0;
       timeState = 1;
       TR0 = 1;
       TR1 = 1;
       //Timer 0 - 50ms -> (65536(10000h) - 50000(3E8h) = 15536(3CB0h))
       TH0 = 0x3C;
       TL0 = 0xB0;
       //Timer 1 - 50ms -> (65536(10000h) - 50000(3E8h) = 15536(3CB0h))
       TH1 = 0x3C;
       TL1 = 0xB0;
        counter = 0;
        counter1 = 0;
   // beginning state with 5.0s
   if (answerState == 1) {
        answerState = 0;
       waitingState = 1;
        pressA = 0;
        pressB = 0;
        pressC = 0;
        pressD = 0;
        counter = 0;
        counter1 =0;
       // bug fix
       D1 = fiveDot;
       D2 = zero;
```

```
display(D1, D2);
       TR0 = 0;
       TR1 = 0;
void External1_ISR (void) interrupt 2 {
   if (waitingState == 0 && answerState == 0) {
       if (~BA) {
            pressA = 1;
           // change states
            timeState = 0;
            answerState = 1;
        } else if (~BB) {
           pressB = 1;
           // change states
           timeState = 0;
            answerState = 1;
        } else if (~BC) {
            pressC = 1;
           // change states
            timeState = 0;
            answerState = 1;
        } else if (~BD) {
            pressD = 1;
            // change states
            timeState = 0;
            answerState = 1;
```

```
counter = 0;
  counter1 = 0;
}

void display(unsigned char Display1, unsigned char Display2)
{
  P1 = Display1;
  P2 = Display2;
}
```