



BATTERY PACK 6-CELL

21.6V

2100 mAh

**BATTERY BMS (STANDARD | ECO)****OPERATIONAL & CHARGING**

- **SOLID BLUE** Vacuum is ON
- **BREATHING BLUE** Battery is Charging
- **FLASHING BLUE 3×3** Battery Low
- **SOLID GREEN** Charging Complete

DIAGNOSTICS & SAFETY

- **SOLID WHITE** Charging Pause / Cell Stabilization
- **SOLID YELLOW** Temp Normalization Lock
- **FLASHING RED** **FAULT / ERROR CODE**

BATTERY CAPACITY (After Trigger Release)

- **1 FLASH** 0% - 33%
- **2 FLASHES** 33% - 66%
- **3 FLASHES** 66% - 100%

ON CHARGER CONNECT / DISCONNECT (Dual-Function)

- **FLASHING BLUE** Cell Balance in **STANDARD mode** (1 Flash = 50mV)
- **FLASHING GREEN** Cell Balance in **ECO mode** (1 Flash = 50mV)

TO CHANGE MODE: Hold trigger down while connecting charger

- **10 × WHITE + 2 × BLUE** → **STANDARD MODE** (4.15V max.)
- **10 × WHITE + 2 × GREEN** → **ECO MODE** (4.00V max.)

For the Error codes and more information about custom firmware, please scan QR code.