

No Thing There: Control, Readout, and Self-Referential Metrology in Engineered Quantum Systems

QNFO Research Collective

2026-07-20

Abstract

“The Qubit Delusion” argued that the quantum computing industry’s failure to deliver commercially viable machines is an epistemic crisis — the qubit-gate-circuit model imports a particle ontology inconsistent with quantum field theory and relational quantum mechanics. “Beyond the Qubit” surveyed alternative paradigms more faithful to quantum reality. But neither paper answered a practical question: if no working quantum engineer actually believes a qubit is a billiard-ball particle, then what ARE control pulses manipulating, and what does readout actually measure? This paper provides the pedagogical bridge. We explain, in accessible yet rigorous terms, the physical ontology of qubits across three major platforms (superconducting transmon, trapped ion, spin qubit), the physics of control pulses and dispersive readout, and the self-referential metrology (tomography) problem that sits at the heart of quantum characterization. We introduce a consistent analogy family — the “electrical seesaw” — to make the physics intuitive without sacrificing accuracy. We then formalize the calibration bootstrapping problem: how gate set tomography, randomized benchmarking, and bare Hamiltonian spectroscopy together anchor the self-consistent calibration circle. We conclude that the particle-qubit “delusion” is primarily pedagogical, not operational — working engineers already think in terms of modes, collective excitations, and relational observables — but that the self-referential metrology challenge becomes genuinely acute at the fault-tolerance threshold. A calibration register of eight dated, falsifiable predictions is provided to prevent post-hoc rationalization.

Author: QNFO Research Collective | **Date:** 2026-07-20 | **License:** QNFO-ULA: <https://legal.qnfo.org/>

1. Introduction

1.1 The Question Behind the Critique

In 2026, the global quantum computing industry has absorbed an estimated \$35 billion in combined public and private investment. No commercially viable quantum computer exists [QubitDelusion2026]. The standard narrative attributes this to engineering difficulty: qubits are fragile, decoherence is relentless, error correction is expensive, and scaling is hard. This is undoubtedly true. But the QNFO research program has advanced a deeper diagnosis: the qubit-gate-circuit model imports a particle ontology into quantum mechanics that is inconsistent with what we have learned about quantum reality since the development of relativistic quantum field theory [QubitDelusion2026; BeyondQubit2026].

“The Qubit Delusion” systematically deconstructed four scaffolds of the incumbent paradigm — qubit-as-particle, gate-as-discrete-operation, decoherence-as-enemy, and error-correction-as-classical-coding — and identified the invariants that survive scaffold removal (superposition, entanglement, correlation structure, phase coherence). “Beyond the Qubit” surveyed alternative computational paradigms — measurement-based, continuous-variable, topological, field-theoretic — that are more faithful to quantum reality.

But diagnosis without a constructive bridge is incomplete. The QNFO critique, while powerful, has left a practical question unanswered: **if no working quantum engineer actually believes a qubit is a tiny billiard ball, then what ARE control pulses manipulating? What does readout actually measure? And how does the self-referential character of quantum state tomography affect our confidence in gate fidelities and error correction thresholds?**

This paper provides that bridge. It explains, in accessible yet rigorous terms, the actual working physics of engineered qubits — what control pulses couple to, what readout amplifiers amplify, and where the calibration circle finds its anchor. We call this project “No Thing There” — a reference both to the absence of a localized “qubit particle” and to the relational, mode-based reality that quantum engineers work with every day.

1.2 What This Paper Is and Is Not

This paper IS: - A pedagogical bridge connecting ontological critique to working physics - A multi-platform explanation of qubit physical implementation - A formal treatment of the self-referential metrology problem - A calibration register with dated, falsifiable predictions

This paper IS NOT: - A repetition of the QNFO critique (see QubitDelusion2026 for the full argument) - A survey of alternative paradigms (see BeyondQubit2026) - An empirical forensics exercise (see QubitDelusion2026 §3) - A defense of the \$35B investment

1.3 Structure

Section 2 answers “what is a qubit physically?” across three platforms. Section 3 explains control pulses. Section 4 explains readout. Section 5 formalizes the self-referential metrology problem. Section 6 explains why quantum error correction is necessary. Section 7 synthesizes the calibration circle and its anchor — the paper’s core argument. Section 8 extends the analysis to logical qubits as “relations of relations.” Section 9 concludes with the calibration register.

2. What Is a Qubit Physically?

2.1 The Two Answers (Both Correct)

If you ask a quantum engineer “what is a qubit?”, you will get two answers, both correct at different levels of abstraction:

1. **The mathematical answer:** A qubit is a two-level quantum system — a vector $|\psi\rangle = \alpha|0\rangle + \beta|1\rangle$ in a complex Hilbert space $\mathbb{C}^2$, subject to unitary evolution and projective measurement.
2. **The physical answer:** A qubit is a carefully isolated two-level subspace of a much richer physical object — a collective mode of a superconducting circuit, an electronic state of a trapped ion, the spin of a confined electron, or a photon’s polarization.

The mathematical answer is sufficient for writing quantum algorithms. But it obscures the physical reality — and it is this obscuration that creates the “billiard-ball” misconception the QNFO critique targets. Let us examine the physical answer in detail.

2.2 Platform 1: The Superconducting Transmon Qubit

A transmon qubit [Koch2007] is NOT a particle. It is the two lowest energy eigenstates ($|0\rangle$, $|1\rangle$) of an **anharmonic LC oscillator** — a superconducting circuit containing a Josephson junction.

To understand this, imagine a simple electrical tank circuit: an inductor L (stores energy in magnetic field) and a capacitor C (stores energy in electric field). Energy sloshes back and forth between them at a resonant frequency $\omega = 1/\sqrt{LC}$. In classical physics, this sloshing can have any amplitude. In quantum mechanics, the sloshing is quantized: the circuit can hold exactly 0, 1, 2, ... units of sloshing energy. Each unit is one quantum of excitation of the circuit’s electromagnetic mode — what physicists call a “photon” of the resonator.

An ordinary LC circuit has equally spaced energy levels — it is a harmonic oscillator. You cannot isolate two levels for use as a qubit because the $|0\rangle \leftrightarrow |1\rangle$

and $|1\rangle \leftrightarrow |2\rangle$ transitions have the same frequency. A pulse intended to flip $|0\rangle$ to $|1\rangle$ would also inadvertently excite $|1\rangle$ to $|2\rangle$.

The Josephson junction solves this. Replace the linear inductor with a junction that behaves as a nonlinear inductor — its inductance depends on the current flowing through it. The resulting circuit is an **anharmonic** oscillator: the energy level spacing is not uniform. The $|0\rangle \leftrightarrow |1\rangle$ transition frequency ω_{01} is different from the $|1\rangle \leftrightarrow |2\rangle$ transition frequency ω_{12} . For a transmon with $E_J/E_C \approx 50$, the anharmonicity $\alpha \equiv \omega_{12} - \omega_{01} \approx -5\%$ of ω_{01} . This is sufficient to address $|0\rangle \leftrightarrow |1\rangle$ without leakage to higher levels.

So physically:

- $|0\rangle$ is the state where the circuit’s charge sloshing mode has zero quanta of excitation — the “vacuum” state of the plasmon mode.
- $|1\rangle$ is the state with exactly ONE quantum of excitation — one “photon” in the circuit’s resonant mode.
- The qubit is the restricted subspace $\text{span}\{|0\rangle, |1\rangle\}$ of a larger Hilbert space that also contains $|2\rangle, |3\rangle$, etc.

The excitation is a **collective oscillation of Cooper pairs** back and forth across the Josephson junction — billions of electrons moving in lockstep, not a single particle. This is what “plasmon mode” means: a collective density oscillation of the superconducting condensate.

The Electrical Seesaw Analogy

Think of the transmon as a very small electrical seesaw — a plank balanced on a pivot. When it’s empty ($|0\rangle$), the plank is still. When it’s full ($|1\rangle$), the plank is tilting back and forth rhythmically, with one unit of energy in its rocking motion. The Josephson junction makes the seesaw’s energy steps uneven, so you can push it from “still” to “rocking at level 1” without accidentally kicking it to “rocking at level 2.”

A control pulse is a gentle, rhythmic push — a microwave electric field applied at exactly the seesaw’s natural rocking frequency. If you push in phase with the rocking, you add energy and tilt the plank higher. If you push out of phase, you extract energy and calm it down. If you push just right, you can put it in a quantum blend of “still” and “rocking” — a superposition.

2.3 Platform 2: The Trapped-Ion Qubit

In a trapped-ion quantum computer [Bruzewicz2019], the qubit is NOT a circuit mode. It is **two internal electronic states** of a single ion confined in an electromagnetic trap. Common choices:

- **Hyperfine qubit:** Two hyperfine levels of the ground state (e.g., $^{171}\text{Yb}^+$: $|F=0, m_F=0\rangle$ and $|F=1, m_F=0\rangle$). Energy splitting $\sim$ GHz, driven by microwave or stimulated Raman transitions.

- **Optical qubit:** A ground state and a metastable excited state (e.g., $^{40}\text{Ca}^+$: $|S_{1/2}\rangle$ and $|D_{5/2}\rangle$). Energy splitting $\sim$ hundreds of THz, driven by narrow-linewidth lasers.

The physical ontology is different from the transmon, but the abstraction is the same: two energy eigenstates of a larger Hamiltonian, isolated and coherently manipulated. The excitation is not a collective circuit oscillation but a single electron’s transition between well-defined atomic orbitals.

Control pulses are laser or microwave fields tuned to the transition frequency. They drive Rabi oscillations between the two states — exactly the same mathematics as the transmon, but implemented in atomic physics rather than circuit physics.

Readout in trapped ions uses **state-dependent fluorescence**: one of the two qubit states (the “bright” state) can be driven to scatter many photons when illuminated by a laser, while the other (the “dark” state) scatters none. Counting photons tells you which state the ion was in — a projective measurement.

2.4 Platform 3: The Spin Qubit

In a semiconductor spin qubit [Burkard2023], the qubit is the **spin state** of a single electron confined in a quantum dot — a nanometer-scale electrostatic trap in a semiconductor (typically silicon or GaAs).

The two computational states are spin-up $|\uparrow\rangle$ and spin-down $|\downarrow\rangle$ relative to an external magnetic field. The energy splitting is the Zeeman energy $g\mu_B B$. Control pulses are oscillating magnetic fields (electron spin resonance, ESR) or electric fields combined with spin-orbit coupling (electric dipole spin resonance, EDSR).

Readout typically converts spin to charge: an electron with spin-up can tunnel out of the dot to a nearby reservoir, while spin-down cannot (or vice versa, depending on the energy-level alignment). The resulting change in charge is detected by a sensitive electrometer — a single-electron transistor or quantum point contact. The final output is a current.

2.5 The Common Abstraction

Across all three platforms, the pattern is the same:

Element	Transmon	Trapped Ion	Spin Qubit
Physical system	Superconducting circuit	Single trapped ion	Electron in quantum dot
Degree of freedom	Plasmon mode (collective charge oscillation)	Electronic state (orbital)	Electron spin

Element	Transmon	Trapped Ion	Spin Qubit
$ 0\rangle, 1\rangle$	0 or 1 quanta of mode excitation	Two internal energy eigenstates	Spin-up, spin-down
Control	Microwave electric field (charge line)	Laser/microwave (Raman/Rabi)	Magnetic/electric resonance
Readout	Dispersive shift of resonator	State-dependent fluorescence	Spin-to-charge conversion + electrometer

In every case, the qubit is NOT a “thing” — it is a **constrained two-level subspace of a physical degree of freedom**, engineered to be addressable, coherent, and measurable. The engineer does not picture a billiard ball. They picture an energy level diagram, a Rabi chevron pattern, an IQ-plane cloud.

3. What Do Control Pulses Actually Manipulate?

3.1 The Transmon Case

A microwave control pulse is a voltage signal applied to a charge line that is capacitively coupled to the qubit. In the transmon, the qubit Hamiltonian (restricted to the computational subspace) is:

$$H_q = \frac{\hbar\omega_q}{2}\sigma_z$$

The microwave drive adds a time-dependent term that, in the rotating frame at the qubit frequency, becomes:

$$H_{\text{drive}} = \hbar\Omega(t)\sigma_x$$

where $\Omega(t)$ is the Rabi frequency, proportional to the microwave amplitude. This term causes the qubit state to rotate on the Bloch sphere — the familiar Rabi oscillations.

But what is happening PHYSICALLY? The oscillating electric field couples to the **electric dipole moment** of the plasmon mode. It drives the collective charge oscillation, adding or removing energy. In the language of circuit QED [Blais2004; Wallraff2004], the drive term is:

$$H_{\text{drive}} \propto \epsilon(t)(a + a^\dagger)$$

where $a, a^\dagger$ are the annihilation and creation operators for excitations of the circuit mode. Within the two-level subspace, this maps to σ_x . But the underlying physics is mode excitation, not state vector rotation.

The two pictures are equivalent. The “Bloch sphere rotation” is the restricted-subspace representation of “mode excitation in the two-level manifold.” The engineer uses whichever picture is convenient — Bloch sphere for single-qubit gates, mode picture for understanding leakage and cross-talk.

3.2 Two-Qubit Gates and Virtual Excitation

For a two-qubit gate mediated by a bus resonator, the situation is more subtle. The qubits are detuned from the bus resonator by an amount Δ that is large compared to the qubit-bus coupling g . The bus is NEVER “really” excited — the interaction is a **virtual** exchange of a photon in the bus mode. The effective coupling is:

$$g_{\text{eff}} \approx \frac{g_1 g_2}{\Delta}$$

The bus mode occupation remains essentially zero throughout. This is NOT a “transfer of an excitation” from qubit 1 to bus to qubit 2. It is a **correlated phase accumulation** mediated by the quantum vacuum of the bus mode. The terminology of “excitation transfer” is a convenient fiction that works mathematically but misrepresents the physics.

This is a concrete example of the map-territory confusion diagnosed by “The Qubit Delusion”: we say “the excitation moves to the bus and back,” but nothing moves. The qubits and bus form a coupled quantum system whose collective energy shifts when the qubits are in different states — that energy shift translates to a phase on the two-qubit state, implementing a controlled-phase gate.

3.3 Generalization: What Pulses Always Manipulate

Across all platforms:

Platform	What the pulse couples to	Physically manipulated
Transmon	Electric dipole of plasmon mode	Collective charge oscillation amplitude and phase
Trapped ion	Electric dipole of atomic transition	Electronic wavefunction amplitudes
Spin qubit	Magnetic dipole of electron spin	Spin orientation
Photonic	Polarization/phase of optical mode	Field quadratures

In every case, the pulse manipulates the **quantum state of a collective or single-particle degree of freedom**, changing the probability amplitudes and relative phases of the computational basis states. The “gate” is an emergent description, not a fundamental operation.

4. What Does Readout Actually Measure?

4.1 Dispersive Readout (Transmon)

In the transmon, readout uses **dispersive coupling** to a linear resonator [Blais2004]. The qubit-resonator system has the Hamiltonian:

$$H = \hbar\omega_r a^\dagger a + \frac{\hbar\omega_q}{2}\sigma_z + \hbar\chi a^\dagger a\sigma_z$$

The term $\hbar\chi a^\dagger a\sigma_z$ means the resonator frequency depends on the qubit state: $\omega_r \pm \chi$ for $|0\rangle$ and $|1\rangle$.

When we send a weak microwave probe tone at the bare resonator frequency, the reflected signal acquires a qubit-state-dependent phase shift. We measure this phase shift by **homodyne detection** — mixing the reflected signal with a reference and integrating. The result is a point in the IQ-plane: one cloud for $|0\rangle$, one cloud for $|1\rangle$.

The probe tone energy is FAR below the single-photon level in the resonator ($\bar{n} \ll 1$ in the steady state). The readout is “quantum non-demolition” (QND) to the extent that the probe does not induce transitions between the computational states.

4.2 The Amplification Chain

The reflected probe tone carries a phase shift of order 10^{-3} to 10^{-2} radians — far too small for room-temperature electronics. The signal passes through:

1. **Josephson Parametric Amplifier (JPA):** A near-quantum-limited amplifier operating at 10-20 mK. Adds noise of order one photon ($\sim \hbar\omega$) — the minimum allowed by quantum mechanics.
2. **High Electron Mobility Transistor (HEMT):** A semiconductor amplifier at 4 K. Adds ~ 10 -20 photons of noise but provides high gain.
3. **Room-temperature amplifiers and digitizers:** Convert the signal to a voltage trace, which is digitized and processed.

The crucial question: **where in this chain does the measurement actually occur?** This is the “Heisenberg cut” problem — the boundary between quantum coherence and classical irreversibility.

4.3 The Heisenberg Cut Problem

The standard operational answer is: the projection happens at the first amplification stage where the signal becomes irreversible (the JPA), because the measurement result is encoded in too many degrees of freedom to be coherently reversed. But this is an operational definition, not a physical demarcation.

From the perspective of decoherence theory [Zurek2003], the measurement is complete when the qubit's state information is irreversibly transferred to the environment — a process that can be modeled as continuous (not instantaneous) and that depends on the coupling strength, amplifier gain, and temperature.

For practical calibration purposes, the Heisenberg cut matters because:

1. If projection occurs while the probe tone is still in the resonator (before amplification), the qubit experiences measurement-induced dephasing that depends on the probe power and the χ/κ ratio.
2. If projection occurs only after the JPA adds noise, our readout fidelity models must account for amplifier-added noise as part of the measurement operator, not as post-measurement classical noise.

The distinction may be operationally negligible at current fidelities (98-99%), but at the 10^{-4} and below regime required for fault tolerance, the location of the cut could matter for error model accuracy.

5. The Self-Referential Metrology Problem

5.1 The Circularity

Quantum state tomography reconstructs the density matrix ρ by measuring the qubit in multiple bases and applying maximum-likelihood estimation [Gross2010]. To do this, you must:

1. Prepare the qubit in known states using calibrated gates.
2. Apply measurement operators whose calibration you trust.
3. Collect statistics and reconstruct ρ .

But how do you calibrate the gates and measurement operators? You prepare what you THINK is a known state (using gates you calibrated), measure it (using readout you calibrated), and adjust until the outcomes match expectations. This is the **calibration circle**:

Calibrated gates → Prepare "known" states → Calibrated readout → Measure → Update calibration

Every element is defined in terms of every other element. The fear is not that the system is inconsistent — self-consistency can always be achieved — but that it may be **CONSISTENTLY WRONG**. The entire characterization framework

could be locked into a local minimum of the calibration landscape that is self-consistent but does not correspond to physical reality.

5.2 Gate Set Tomography (GST)

Gate Set Tomography [BlumeKohout2013] is the most sophisticated response to this circularity. Rather than treating the circularity as a bug, GST treats it as a feature: jointly estimate ALL gates and measurement operators simultaneously, without any pre-calibrated reference.

GST works by:

1. Preparing the qubit in a fiducial set of states using a fiducial set of gates.
2. Applying sequences of the gate(s) to be characterized.
3. Measuring in a fiducial set of measurement bases.
4. Fitting the entire dataset to a single self-consistent model.

The output is a **gauge-dependent** estimate of the gates and SPAM (state preparation and measurement) errors. Gauge freedom means that certain transformations of the gate set produce exactly the same measurement statistics — you cannot distinguish between them by any experiment.

The critical question [Merkel2013]: is the gauge freedom operationally irrelevant? For error correction thresholds, the answer may be “no.” Different gauge choices assign errors to different parts of the circuit — gates vs. measurements vs. state preparation. A decoder that assumes errors come from gates will perform differently from one that assumes errors come from measurements, even if both are self-consistent with the same data.

5.3 Randomized Benchmarking (RB)

Randomized Benchmarking [Magesan2011] provides a partially independent check. RB measures the average gate fidelity by applying random sequences of Clifford gates and measuring the decay of the sequence fidelity with increasing sequence length.

RB does NOT require pre-calibrated gates — it self-averages over gate errors. However, RB still uses the same physical qubits, the same control electronics, and the same readout chain as GST. It is “partially independent” in that it probes a different statistical quantity (average fidelity rather than full process matrix), but it is not truly independent — it shares the same physical infrastructure.

5.4 The Spectroscopic Anchor

The best candidate for an **independent anchor** is multi-level spectroscopy of the bare Hamiltonian — before the qubit subspace restriction is imposed.

For a transmon, the anharmonicity $\alpha = \omega_{12} - \omega_{01}$ can be measured by:

1. Applying a two-tone spectroscopy: a probe tone near ω_{01} that populates $|1\rangle$, and a second tone whose frequency is swept. When the second tone hits ω_{12} , the $|1\rangle$ population decreases — a clear spectral feature.
2. This measurement only depends on the bare Hamiltonian’s eigenvalues. It does not assume the qubit subspace exists — it treats the transmon as the multi-level system it is.
3. The measured ω_{01} , ω_{12} , and α are physical energy differences, not calibration conventions. They anchor the computational subspace in the larger Hilbert space.

Spectroscopic anchoring is not circular in the way that GST is. It probes the Hamiltonian directly, without needing pre-calibrated gates or measurements in the qubit subspace. The only requirement is that the spectroscopy tones are frequency-calibrated (which can be done with a standard frequency counter, independently of any qubit operations).

However, even spectroscopy is not perfectly independent. The readout chain (JPA, HEMT, digitizer) is the same as for qubit readout. A systematic error in the readout could shift the apparent spectral features. This residual circularity is small (bounded by the readout fidelity) but not zero.

5.5 How Big Is the Problem?

At current gate fidelities (99.9% for single-qubit gates, 99% for two-qubit gates), the calibration circularity is a second-order concern. The dominant errors are physical (decoherence, leakage, cross-talk), not metrological.

But the fault-tolerance threshold requires per-gate error rates of $\sim 10^{-4}$ to 10^{-3} , and achieving logical error rates of 10^{-10} or below requires well-characterized physical error rates at comparable levels. In this regime, calibration circularity could become the limiting factor — not because the qubits are bad, but because we cannot verify how good they are.

This is the core insight of the “No Thing There” project: **the self-referential metrology problem is negligible now, but it becomes the bottleneck at the fault-tolerance threshold.** The particle-qubit “delusion” is pedagogical; the calibration circularity is operational — and it will get worse with scale.

6. Why Do We Need Quantum Error Correction?

6.1 The Fragility of the Seesaw

The electrical seesaw is never perfectly isolated. Stray electric fields, magnetic fluctuations, thermal photons, and even cosmic rays all gently bump it. These bumps cause:

- **Bit flips:** The qubit spontaneously transitions from $|0\rangle$ to $|1\rangle$ or vice versa (energy relaxation, T_1).
- **Phase flips:** The superposition’s phase relationship drifts (pure dephasing, T_ϕ).
- **Leakage:** The qubit escapes the computational subspace to $|2\rangle$ or higher.

These are all perfectly allowed quantum mechanical processes — they are noise, not a failure of quantum mechanics itself. We are not “correcting quantum mechanics.” We are correcting for unwanted interactions that quantum mechanics itself allows.

6.2 Why Not Just Build Better Qubits?

You can build a qubit to be extremely quiet — and we do. State-of-the-art transmons have $T_1 > 300 \mu s$ and $T_2 > 100 \mu s$. Trapped-ion qubits can have coherence times of seconds to minutes.

But there is a fundamental limit: **if a qubit is perfectly isolated from everything, you cannot control it or read it out.** The very wires and lasers you need to push the seesaw and listen to its echo are also paths for noise to sneak in. Any usable qubit must be somewhat open, and therefore somewhat leaky. This is not an engineering limitation — it is a thermodynamic necessity [DiVincenzo2000].

6.3 The Crowd Protection Strategy

Error correction solves this by using **redundancy across space**, not improved isolation. Instead of trying to make one qubit perfect, we spread one logical qubit across many physical qubits and constantly check them against each other.

Analogy: a crowd protecting one voice. Imagine you want to transmit a message across a noisy room. Rather than shouting louder (better isolation), you have multiple people all sing the same note. When one person wobbles off pitch, the others hold steady — and a conductor (the decoder) notices the wobble and sends a gentle correction signal to bring the wobbling singer back in tune. The correction never needs to know the exact note that was lost. It only needs to detect and fix the wobble.

This is the miracle of quantum error correction [Devitt2013; Fowler2012]: it continuously detects and fixes tiny random nudges, indefinitely, while the computation runs, without ever measuring the logical qubit’s state. The syndrome measurements (parity checks) reveal only the error, never the information.

6.4 The Two-Level System as Strategic Choice

Why a two-level system rather than a continuous variable? Because errors in analog systems smear values continuously — a small noise bump changes the value slightly, and you cannot distinguish noise from signal. In a two-level

system, errors are digitized: a bit flip is a complete change from 0 to 1. This means:

1. Errors are countable and correctable (syndrome extraction).
2. The threshold theorem applies — if the physical error rate is below a threshold, logical error rates can be suppressed arbitrarily [Fowler2012].
3. Superposition still works: the qubit can be in a blend of 0 and 1, giving quantum computational power while retaining digital correctability.

The two-level system is the minimal unit that is both quantum (can superpose) and digitally correctable (errors flip a rung, not smudge a value). This is not a limitation — it is a strategic choice to domesticate quantum richness into a language that can be checked, corrected, and scaled.

7. The Calibration Circle and Its Anchor

7.1 The Full Stack as Layered Calibration

We can now see the entire quantum computing stack as a hierarchy of calibration loops:

```

Level 0: Bare Hamiltonian (spectroscopy)
    Anchors
Level 1: Qubit subspace (Rabi, Ramsey)
    Anchors
Level 2: Gate characterization (GST, RB)
    Anchors
Level 3: Error models for QEC
    Anchors
Level 4: Logical qubit verification

```

Each level is calibrated using the level below it, with residual circularity at each step. The anchor at Level 0 (spectroscopy) is the strongest but not perfect. The circularity grows as we ascend the stack.

7.2 The Three Anchors

Anchor	What it measures	Independence	Limitation
Spectroscopy	Bare Hamiltonian eigenvalues (ω_{01} , ω_{12} , α)	High — probes multi-level system before subspace restriction	Same readout chain as qubit operations

Anchor	What it measures	Independence	Limitation
Randomized Bench-marking	Average gate fidelity via sequence-length scaling	Medium — probes a different statistical quantity than GST	Same physical hardware as GST
Gate Set Tomography	Full process matrices with gauge freedom	Low — self-consistent by design	Gauge freedom may mask systematic errors

The three anchors form a **triangulation**: GST provides comprehensive but gauge-dependent estimates; RB provides a single-number check that is partially independent; spectroscopy provides a physical anchor in the bare Hamiltonian. Together, they bound the calibration uncertainty.

7.3 The Scaling Problem

At 5-10 physical qubits (current mature devices), the three anchors provide adequate cross-validation. But as systems scale to 100, 1,000, 10,000 qubits:

1. **Spectroscopy must be repeated** for each qubit — but qubit frequencies vary across the chip due to fabrication variability.
2. **RB and GST become exponentially expensive** — full GST of an N -qubit system requires resources exponential in N .
3. **Cross-talk introduces correlated errors** that are not captured by single-qubit calibration.

The calibration circularity that is manageable at 10 qubits may become the limiting factor at 10,000 qubits — not because any individual calibration is wrong, but because the residual circularity accumulates across the system in ways that current metrology cannot detect.

7.4 Is This Fatal?

Probably not. The fault-tolerance threshold theorem [Fowler2012] is robust to calibration errors as long as the errors are BELOW the threshold and approximately independent. The question is whether calibration circularity introduces systematic errors that violate the independence assumption.

The calibration register (§9) provides eight dated, falsifiable predictions to prevent post-hoc rationalization. The key prediction: by 2032, calibration circularity will be recognized as a distinct research frontier, not merely a footnote to error correction.

8. Logical Qubits as “Relations of Relations”

8.1 The Layered Ontology

If a physical qubit is already a relational construct — a constrained two-level subspace defined by its Hamiltonian symmetries, not by any localized “substance” — then what is a logical qubit?

A logical qubit in the surface code [Fowler2012] is a non-local property of a two-dimensional lattice of physical qubits. It is not “stored” in any particular physical qubit. It is a **topological invariant** of the code space — a property that is robust to local perturbations as long as the error rate is below threshold.

If physical qubits are “relations” (between a microscopic degree of freedom and its classical control infrastructure, as argued in §2), then logical qubits are indeed **relations of relations** — non-local properties of an already-relational substrate.

8.2 Does the Layering Introduce Fragility?

The question is whether relational abstraction is fragile or robust under iteration. Two perspectives:

The robust view: Each level of abstraction (physical qubit $\rightarrow$ logical qubit $\rightarrow$ fault-tolerant computation) is a protected subspace of the level below. The protection is provided by error correction, which is a physical process, not merely a mathematical abstraction. The “relation of relations” is as physical as any relation in quantum mechanics — which is to say, entirely relational, and entirely real.

The fragile view: Each layer of abstraction introduces new gauge freedoms. The logical qubit’s fidelity can only be verified by measurements on physical qubits, whose calibration is circular. The gauge freedom at Level 3 (error models) compounds with the gauge freedom at Level 2 (GST) and the residual circularity at Level 1 (readout calibration). The “relation of relations” may be a house of cards — internally consistent but externally unmoored.

8.3 The QNFO Synthesis

The QNFO research program, from “The Qubit Delusion” through the ZBW p-adic observable work [ZBWPadic2026] and the Adelic QEC proposal, has consistently argued that the relational character of quantum mechanics demands a re-thinking of the entire computational stack.

But the “No Thing There” project adds a crucial nuance: **acknowledging that the stack is relational does not make it invalid.** The calibration circle has an anchor (spectroscopy). The error correction threshold is robust to the residual circularity, at least at current scales. The “delusion” is in thinking qubits are particles — not in thinking they exist.

The challenge is not ontological but metrological. We must develop calibration methods that are provably independent at the fault-tolerance scale, not merely self-consistent at the few-qubit scale. This is a genuine research frontier, and it is where the QNFO critique meets constructive engagement with the quantum computing industry.

9. Conclusion

9.1 Summary

1. **A qubit is NOT a particle.** It is a constrained two-level subspace of a physical degree of freedom — a collective circuit mode (transmon), electronic states (trapped ion), or spin orientation (quantum dot). Working quantum engineers have never thought otherwise.
2. **Control pulses manipulate the quantum state of that degree of freedom.** In a transmon, they couple to the electric dipole of the plasmon mode, driving collective charge oscillations. The “Bloch sphere rotation” and “mode excitation” pictures are mathematically equivalent.
3. **Readout measures a macroscopic observable that correlates with the qubit state.** In the transmon, the qubit-state-dependent phase shift of a probe tone, amplified through a chain of near-quantum-limited amplifiers. The “Heisenberg cut” — where projection occurs — is operationally defined but philosophically unresolved.
4. **Self-referential metrology is genuinely circular, but has an anchor.** Multi-level spectroscopy of the bare Hamiltonian provides an independent reference for the computational subspace. Gate set tomography provides self-consistency. Randomized benchmarking provides a partial cross-check. Together they bound, but do not eliminate, calibration uncertainty.
5. **Error correction is necessary because perfect isolation is impossible.** QEC uses redundancy across space to protect quantum information, not improved isolation. This is a thermodynamic necessity, not an engineering shortfall.
6. **The calibration circularity becomes the bottleneck at the fault-tolerance threshold.** At 10-100 qubits, calibration errors are dominated by physical noise. At 10,000 qubits, residual circularity may become the limiting factor for error-model accuracy.
7. **The “Qubit Delusion” is primarily pedagogical, not operational.** The particle-qubit picture misleads students and the public, but practicing engineers work with modes, excitations, and relational observables. Fixing the pedagogy matters for workforce development, not for hardware design.

8. **Logical qubits as “relations of relations” is a novel framing that deserves investigation.** Whether layered relational abstraction is robust or fragile under iteration is an open question with implications for fault-tolerant quantum computing at scale.

9.2 Calibration Register

The following dated, falsifiable predictions are locked as of 2026-07-20 to prevent post-hoc rationalization:

#	Prediction	Check Date	P(true)
P1	Multi-level spectroscopy remains an independent anchor for qubit calibration	2028	0.90
P2	GST gauge freedom introduces systematic errors $>10\%$ of estimated error rate below 10^{-4} fidelities	2030	0.55
P3	Calibration drift patterns at $>1,000$ qubits require new calibration methods beyond those adequate at <100 qubits	2032	0.40
P4	Consensus emerges that particle-qubit confusion is pedagogical, not operational	2030	0.65
P5	Mode-based pedagogy produces measurably better calibration intuitions than particle-based pedagogy	2035	0.50
P6	“Self-referential metrology” appears as a distinct research area in 3 major QC conference tracks	2032	0.45

#	Prediction	Check Date	P(true)
P7	Heisenberg cut location becomes experimentally testable via high-fidelity QND measurements	2035	0.30
P8	Logical qubit verification at 10^{-6} error level remains circular but bounded by 10^{-3} independent checks	2035	0.70

First audit due: 2027-07-20.

9.3 The \$35 Billion Question

Does the failure of quantum computing to deliver commercially viable machines reflect a map-territory confusion at industrial scale, as “The Qubit Delusion” argues?

The nuanced answer: At the level of public communication and investment narrative, yes — the particle-qubit picture has enabled systematic overpromising. At the level of working physics, no — engineers build and calibrate qubits using the correct relational, mode-based framework.

The real epistemic risk is not that qubits don’t exist. It is that we cannot verify, with sufficient independence, that our error models are correct at the 10^{-10} level required for fault-tolerant quantum computation. The calibration circle is real, it has an anchor, but the anchor’s grip weakens as we approach the fault-tolerance threshold. Whether this is a manageable metrological challenge or a fundamental limitation is the question that the calibration register is designed to answer.

References

- [@QubitDelusion2026]: QNFO Research Collective. “The Qubit Delusion: How Particle Ontology Sabotaged Quantum Computing.” 2026-07-08.
- [@BeyondQubit2026]: QNFO Research Collective. “Beyond the Qubit: Constructive Paradigms for Post-Particle Computation.” 2026-07-08.

- [@ZBWPadic2026]: QNFO Research Agent. “Zitterbewegung as a p-Adic Observable: Ultrametric Readout and Intrinsic Topological Protection for Majorana Qubits.” 2026-07-05.
- [@Koch2007]: Koch, J., et al. “Charge-insensitive qubit design derived from the Cooper pair box.” *Physical Review A* 76, 042319 (2007).
- [@Blais2004]: Blais, A., et al. “Cavity quantum electrodynamics for superconducting electrical circuits: An architecture for quantum computation.” *Physical Review A* 69, 062320 (2004).
- [@Wallraff2004]: Wallraff, A., et al. “Strong coupling of a single photon to a superconducting qubit using circuit quantum electrodynamics.” *Nature* 431, 162 (2004).
- [@Bruzewicz2019]: Bruzewicz, C. D., Chiaverini, J., McConnell, R., & Sage, J. M. “Trapped-ion quantum computing: Progress and challenges.” *Applied Physics Reviews* 6, 021314 (2019).
- [@Burkard2023]: Burkard, G., et al. “Semiconductor spin qubits.” *Reviews of Modern Physics* 95, 025003 (2023).
- [@BlumeKohout2013]: Blume-Kohout, R., et al. “Robust, self-consistent, closed-form tomography of quantum logic gates on a trapped ion qubit.” *arXiv:1310.4492* (2013).
- [@Magesan2011]: Magesan, E., Gambetta, J. M., & Emerson, J. “Scalable and robust randomized benchmarking of quantum processes.” *Physical Review Letters* 106, 180504 (2011).
- [@Merkel2013]: Merkel, S. T., et al. “Self-consistent quantum process tomography.” *Physical Review A* 87, 062119 (2013).
- [@Gross2010]: Gross, D., et al. “Quantum state tomography via compressed sensing.” *Physical Review Letters* 105, 150401 (2010).
- [@Devitt2013]: Devitt, S. J., Munro, W. J., & Nemoto, K. “Quantum error correction for beginners.” *Reports on Progress in Physics* 76, 076001 (2013).
- [@Fowler2012]: Fowler, A. G., et al. “Surface codes: Towards practical large-scale quantum computation.” *Physical Review A* 86, 032324 (2012).
- [@DiVincenzo2000]: DiVincenzo, D. P. “The physical implementation of quantum computation.” *Fortschritte der Physik* 48, 771 (2000).
- [@Zurek2003]: Zurek, W. H. “Decoherence, einselection, and the quantum origins of the classical.” *Reviews of Modern Physics* 75, 715 (2003).
- [@Rovelli1996]: Rovelli, C. “Relational quantum mechanics.” *International Journal of Theoretical Physics* 35, 1637 (1996).