```
2:
       libxbee - a C library to aid the use of Digi's Series 1 XBee modules
                 running in API mode (AP=2).
 3:
 4:
 5:
       Copyright (C) 2009 Attie Grande (attie@attie.co.uk)
 6:
 7:
       This program is free software: you can redistribute it and/or modify
 8:
       it under the terms of the GNU General Public License as published by
       the Free Software Foundation, either version 3 of the License, or
9:
10:
       (at your option) any later version.
11:
12:
       This program is distributed in the hope that it will be useful,
13:
       but WITHOUT ANY WARRANTY; without even the implied warranty of
       MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
14:
15:
       GNU General Public License for more details.
16:
17:
       You should have received a copy of the GNU General Public License
18:
       along with this program. If not, see <a href="http://www.gnu.org/licenses/">http://www.gnu.org/licenses/>.
19: */
20:
24:
25: /* this file contains code that is used by Win32 ONLY */
26: #ifndef _WIN32
27: #error "This file should only be used on a Win32 system"
28: #endif
29:
30: #include "win32.h"
31: #include "win32.dll.c"
32:
33: static int init_serial(int baudrate) {
34:
     int chosenbaud;
35:
     DCB tc;
36:
     int evtMask;
37:
     COMMTIMEOUTS timeouts;
38:
39:
      /* open the serial port */
40:
     xbee.tty = CreateFile(TEXT(xbee.path),
41:
                           GENERIC_READ | GENERIC_WRITE,
                           0, /* exclusive access */
42:
                           NULL, /* default security attributes */
43:
44:
                           OPEN_EXISTING,
45:
                           FILE_FLAG_OVERLAPPED,
46:
                          NULL);
47:
      if (xbee.tty == INVALID_HANDLE_VALUE) {
48:
       perror("xbee_setup():CreateFile()");
49:
       xbee_mutex_destroy(xbee.conmutex);
50:
       xbee_mutex_destroy(xbee.pktmutex);
51:
       xbee_mutex_destroy(xbee.sendmutex);
52:
       Xfree(xbee.path);
53:
       return -1;
54:
55:
56:
     GetCommState(xbee.tty, &tc);
57:
                           haudrate;
     tc.BaudRate =
58:
      tc.fBinary =
                           TRIE;
59:
      tc.fParity =
                           FALSE;
60:
      tc.fOutxCtsFlow =
                           FALSE;
61:
     tc.fOutxDsrFlow =
                           FALSE;
62:
      tc.fDtrControl =
                           DTR_CONTROL_DISABLE;
63:
      tc.fDsrSensitivity =
                           FALSE;
      tc.fTXContinueOnXoff = FALSE;
64:
65:
     tc.fOutX =
                           FALSE;
     tc.fInX =
66:
                           FALSE;
67:
     tc.fErrorChar =
                           FALSE;
68:
      tc.fNull =
                           FALSE;
69:
      tc.fRtsControl =
                           RTS CONTROL DISABLE;
70:
      tc.fAbortOnError =
                           FALSE;
71:
     tc.BvteSize =
                            8;
72:
      tc.Parity =
                           NOPARITY;
73:
      tc.StopBits =
                           ONESTOPBIT;
     SetCommState(xbee.tty, &tc);
74:
75:
76:
      timeouts ReadIntervalTimeout = MAXDWORD;
77:
      timeouts.ReadTotalTimeoutMultiplier = 0;
78:
      timeouts.ReadTotalTimeoutConstant = 0;
79:
      timeouts.WriteTotalTimeoutMultiplier = 0;
:08
      timeouts.WriteTotalTimeoutConstant = 0;
81:
      SetCommTimeouts(xbee.tty, &timeouts);
82:
83:
      SetCommMask(xbee.tty, EV_RXCHAR);
84:
     return 0;
85:
```

```
87:
88: /* a replacement for the linux select() function... for a serial port */
89: static int xbee_select(struct timeval *timeout) {
90: int evtMask = 0;
       COMSTAT status;
91:
92:
      int ret;
93:
94:
       for (;;) {
95:
         /* find out how many bytes are in the Rx buffer... */
96:
         if (ClearCommError(xbee.tty,NULL,&status) && (status.cbInQue > 0)) {
97:
            * if there is data... return! */
          return 1; /*status.cbInQue;*/
98:
         } else if (timeout && timeout->tv_sec == 0 && timeout->tv_usec == 0) {
99:
100:
          /* if the timeout was 0 (return immediately) then return! */
101:
          return 0;
102:
103:
         /\ast otherwise wait for an Rx event... \ast/
104:
105:
        memset(&xbee.ttyovrs,0,sizeof(OVERLAPPED));
106:
        xbee.ttyovrs.hEvent = CreateEvent(NULL,TRUE,FALSE,NULL);
107:
         if (!WaitCommEvent(xbee.tty,&evtMask,&xbee.ttyovrs)) {
108:
           if (GetLastError() == ERROR_IO_PENDING) {
109:
             DWORD timeoutval;
110:
             if (!timeout) {
111:
              /* behave like the linux function... if the timeout pointer was NULL
                 then wait indefinately */
112:
113:
              timeoutval = INFINITE;
114:
             } else {
115:
               /* Win32 doesn't give the luxury of microseconds and seconds... just miliseconds! */
116:
              timeoutval = (timeout->tv_sec * 1000) + (timeout->tv_usec / 1000);
117:
118:
            ret = WaitForSingleObject(xbee.ttyovrs.hEvent,timeoutval);
119:
            if (ret == WAIT_TIMEOUT) {
120:
              /* cause the WaitCommEvent() call to stop */
121:
              SetCommMask(xbee.tty, EV_RXCHAR);
122:
               /* if a timeout occured, then return 0 */
123:
              CloseHandle(xbee.ttyovrs.hEvent);
124:
              return 0;
125:
            }
126:
           } else {
127:
            return -1;
           }
128:
129:
130:
         CloseHandle(xbee.ttyovrs.hEvent);
131:
132:
133:
       /* always return -1 (error) for now... */
134:
      return -1;
135: }
136:
137: /* this offers the same behavior as non-blocking I/O under linux */
138: int xbee_write(const void *ptr, size_t size) {
     if (!WriteFile(xbee.tty, ptr, size, NULL, &xbee.ttyovrw) &&
139:
140:
           (GetLastError() != ERROR_IO_PENDING)) return 0;
141:
      if (!GetOverlappedResult(xbee.tty, &xbee.ttyovrw, &xbee.ttyw, TRUE)) return 0;
142:
      return xbee.ttyw;
143: }
144:
145: /* this offers the same behavior as non-blocking I/O under linux */
146: int xbee_read(void *ptr, size_t size) {
147:
     if (!ReadFile(xbee.tty, ptr, size, NULL, &xbee.ttyovrr) &&
148:
           (GetLastError() != ERROR_IO_PENDING)) return 0;
149:
      if (!GetOverlappedResult(xbee.tty, &xbee.ttyovrr, &xbee.ttyr, TRUE)) return 0;
150:
      return xbee.ttvr;
151: }
152:
153: /* this is because Win32 has some weird memory management rules...
154:
     - the thread that allocated the memory, must free it... */
155: void xbee_free(void *ptr) {
156:
     if (!ptr) return;
157:
      free(ptr);
158: }
159:
160: /* enable the debug output to a custom file or fallback to stderr */
161: int xbee_setupDebugAPI(char *path, int baudrate, char *logfile, char cmdSeq, int cmdTime) {
162:
      int fd, ret;
163:
       if ((fd = _open(logfile,_O_WRONLY | _O_CREAT | _O_TRUNC)) == -1) {
164:
        ret = xbee_setuplogAPI(path,baudrate,2,cmdSeq,cmdTime);
165:
       } else {
166:
        ret = xbee_setuplogAPI(path,baudrate,fd,cmdSeq,cmdTime);
167:
168:
       if (fd == -1) {
169:
        xbee_log("Error opening logfile '%s' (errno=%d)... using stderr instead...",logfile,errno);
170:
```

```
return ret;
172: }
173: int xbee setupDebug(char *path, int baudrate, char *logfile) {
174:
     return xbee_setupDebugAPI(path,baudrate,logfile,0,0);
175: }
176:
177: /* These silly little functions are required for VB6
       - it freaks out when you call a function that uses va_args... */
178:
179: xbee_con *xbee_newcon_simple(unsigned char frameID, xbee_types type) {
180:
     return xbee_newcon(frameID, type);
181: }
182: xbee_con *xbee_newcon_16bit(unsigned char frameID, xbee_types type, int addr) {
183:
      return xbee_newcon(frameID, type, addr);
184: }
185: xbee_con *xbee_newcon_64bit(unsigned char frameID, xbee_types type, int addrL, int addrH) {
186:
      return xbee_newcon(frameID, type, addrL, addrH);
187: }
188:
189: /* for vb6... it will send a message to the given hWnd which can in turn check for a packet */
190: void xbee_callback(xbee_con *con, xbee_pkt *pkt) {
191:
      win32_callback_info *p = callbackMap;
192:
193:
       /* grab the mutex */
194:
       xbee_mutex_lock(callbackmutex);
195:
196:
       /* see if there is an existing callback for this connection */
197:
       while (p) {
198:
        if (p->con == con) break;
199:
        p = p->next;
200:
201:
       /* release the mutex (before the SendMessage, as this could take time...) */
202:
203:
      xbee_mutex_unlock(callbackmutex);
204:
205:
       /* if there is, continue! */
206:
       if (p) {
       xbee_log("Callback message sent!");
207:
208:
         SendMessage(p->hWnd, p->uMsg, (int)con, (int)pkt);
209:
       } else {
210:
         xbee_log("Callback message NOT sent... Unmapped callback! (con=0x%08X)",con);
211:
212: }
213:
214: /* very simple C function to provide more functionality to VB6 */
215: int xbee_runCallback(int(*func)(xbee_con*,xbee_pkt*), xbee_con *con, xbee_pkt *pkt) {
216:
      return func(con,pkt);
217: }
218:
219: void xbee_attachCallback(xbee_con *con, HWND hWnd, UINT uMsg) {
220:
     win32_callback_info *1 = NULL, *p = callbackMap;
221:
       /* grab the mutex */
222:
223:
       xbee_mutex_lock(callbackmutex);
224:
225:
       /* see if there is an existing callback for this connection */
226:
       while (p) {
227:
        if (p->con == con) break;
228:
         1 = p;
229:
        p = p->next;
230:
       ,
/* if not, then add it */
231:
232:
      if (!p) {
233:
       p = Xcalloc(sizeof(win32_callback_info));
234:
        p->next = NULL;
235:
        p->con = con;
236:
        if (!1) {
237:
          xbee_log("Mapping the first callback...");
238:
          callbackMap = p;
239:
         } else {
240:
          xbee_log("Mapping another callback...");
241:
          1->next = p;
242:
243:
       } else if (xbee.log) {
244:
        xbee_log("Updating callback map...");
245:
246:
       /* setup / update the parameters */
       xbee_log("hWnd = [%d]...",hWnd);
247:
248:
       xbee_log("uMsg = [%d]...",uMsg);
249:
       p->hWnd = hWnd;
250:
       p->uMsg = uMsg;
251:
       /* setup the callback function */
252:
253:
       con->callback = xbee_callback;
254:
255:
       /* release the mutex */
```

```
xbee_mutex_unlock(callbackmutex);
257: }
258:
259: void xbee_detachCallback(xbee_con *con) {
     win32_callback_info *1 = NULL, *p = callbackMap;
260:
261:
       xbee_mutex_lock(callbackmutex);
262:
263:
       / \ensuremath{^{*}} see if there is an existing callback for this connection \ensuremath{^{*}}/
264:
       while (p) {
265:
        if (p->con == con) break;
266:
         1 = p;
267:
         p = p->next;
268:
       /* if there is, then remove it! */
269:
270:
       if (p) {
271:
        if (!1) {
          callbackMap = NULL;
272:
         } else if (1->next) {
   1->next = 1->next->next;
273:
274:
275:
         } else {
276:
           1->next = NULL;
277:
278:
         xbee_log("Unmapping callback...");
279:
         xbee_log("hWnd = [%d]...",p->hWnd);
         xbee_log("uMsg = [%d]...",p->uMsg);
280:
281:
         Xfree(p);
282:
283:
284:
       con->callback = NULL;
285:
286:
       /* release the mutex */
287:
      xbee_mutex_unlock(callbackmutex);
288: }
289:
290: /* win32 equivalent of unix gettimeofday() */
291: int gettimeofday(struct timeval *tv, struct timezone *tz) {
     if (tv) {
292:
        struct _timeb timeb;
293:
294:
295:
         _ftime(&timeb);
296:
         tv->tv_sec = timeb.time;
         tv->tv_usec = timeb.millitm * 1000;
297:
298:
       /* ignore tz for now */
299:
300:
      return 0;
301: }
```