```
/*
 1
 2
      UTMconsersion.h - Library to convert in UTM coordenates.
 3
       TinyTrackGPS v0.4
 4
 5
      Copyright © 2019-2021 Francisco Rafael Reyes Carmona.
 6
      All rights reserved.
 7
      rafael.reyes.carmona@gmail.com
 8
 9
         This file is part of TinyTrackGPS.
10
11
         TinyTrackGPS is free software: you can redistribute it and/or
12
         modify
         it under the terms of the GNU General Public License as published
13
         by
14
         the Free Software Foundation, either version 3 of the License, or
         (at your option) any later version.
15
16
         TinyTrackGPS is distributed in the hope that it will be useful,
17
         but WITHOUT ANY WARRANTY; without even the implied warranty of
18
19
        MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
         GNU General Public License for more details.
20
21
         You should have received a copy of the GNU General Public License
22
         along with TinyTrackGPS. If not, see <a href="https://www.gnu.org/">https://www.gnu.org/</a>
23
         licenses/>.
       */
24
25
26
      #if ARDUINO >= 100
         #include "Arduino.h"
27
28
      #else
         #include "WProgram.h"
29
30
      #endif
31
      #ifndef UTMconversion h
32
      #define UTMconversion h
33
34
      class GPS_UTM {
35
         private:
36
37
           int _h;
           char _letter;
38
39
           long _x;
40
           long _y;
41
42
         public:
43
           GPS_UTM(){
44
             h = 0;
              1attan - 171.
15
```

```
40
46
            x = 0L;
            _y = 0L;
47
48
          };
49
          void UTM(double lati, double longi) {
50
51
             * Transformación de las coordenadas geográficas a UTM
52
            */
53
            /* // Sobre la geometría del delipsoide WGS84
54
            double a = 6378137.0;
55
            double b = 6356752.3142;
56
57
            // float e = sqrt((a*a) - (b*b))/a; //< Excentricidad.
58
            double e = sqrt(sq(a) - sq(b))/b; ///< Segunda excentricidad.
59
            double e2 = sq(e); ///< al cuadrado. Usaremos esta
60
            directamente.
            double c = sq(a) / b; ///< Radio Polar de Curvatura.
61
62
63
            /// Se realiza las declaraciones para agilizar el calculo a
64
            UTM de X e Y.
            double e2 = 673949675659e-14; ///< Segunda excentricidad al
65
            cuadrado.
            double e2 2 = 336974837829e-14; // (e2 / 2.0)
66
67
            double c = 639959362580397e-8; ///< Radio Polar de Curvatura.
            double PI_180 = 1745329251994e-14;// (PI / 180.0)
68
            double alf = 505462256744e-14; // (0.75 * e2)
69
            double bet = 425820155e-13; // ((5.0 / 3.0) * alf * alf)
70
            double gam = 16740579e-14; // ((35.0 / 27.0) * alf * alf *
71
            alf)
72
            /// Sobre la longitud y latitud. Conversión de grados
73
            decimales a radianes.
74
75
76
            * Cálculo del signo de la longitud:
                    - Si la longitud está referida al Oeste del meridiano
77
            de Greenwich.
                     entonces la longitud es negativa (-).
78
79
                    - Si la longitud está referida al Este del meridiano
            de Greenwich.
                     entonces la longitud es positiva (+).
80
            */
81
82
83
            double latRad = lati * PI_180; ///< Latitud en Radianes.</pre>
            double lonRad = longi * PI_180; ///< Longitud en Radianes.</pre>
84
85
```

```
/// Sobre el huso.
 86
             float huso = ((longi + 180.0) / 6.0) + 1.0; ///< Nos
 87
             interesa quedarnos solo con la parte entera.
  •
             h = (int)huso;
 88
 89
             // Handle special case of west coast of Norway
 90
 91
             if ( lati >= 56.0 && lati < 64.0 && longi >= 3.0 && longi <
             12.0) {
 .
               h = 32;
 92
             }
93
94
95
             // Special zones for Svalbard
             if ( lati >= 72.0 && lati < 84.0 ) {
96
               if ( longi >= 0.0 && longi < 9.0 ) {
97
98
                 h = 31;
               }
99
100
               else if ( longi >= 9.0 && longi < 21.0 ) {
                  _h = 33;
101
               }
102
               else if ( longi >= 21.0 && longi < 33.0 ) {
103
                 h = 35;
104
               }
105
106
               else if ( longi >= 33.0 && longi < 42.0 ) {
107
                 _{h} = 37;
108
               }
             }
109
110
             int landa0 = _h * 6 - 183; ///< Cálculo del meridiano central
111
             del huso en grados.
             double Dlanda = lonRad - (landa0 * PI_180); ///<</pre>
112
             Desplazamiento del punto a calcular con respecto al meridiano
             central del huso.
113
             if ((84 >= lati) && (lati >= 72))
114
115
               letter = 'X';
116
             else if ((72 > lati) && (lati >= 64))
                letter = 'W';
117
             else if ((64 > lati) && (lati >= 56))
118
                letter = 'V';
119
             else if ((56 > lati) && (lati >= 48))
120
121
                letter = 'U';
             else if ((48 > lati) && (lati >= 40))
122
123
                _letter = 'T';
124
             else if ((40 > lati) && (lati >= 32))
               _letter = 'S';
125
             else if ((32 > lati) && (lati >= 24))
126
               letter = 'R';
127
             else if ((24 > lati) && (lati >= 16))
128
```

```
---- -- ((-- / ----/ --- (---- / --//
               letter = 'Q';
129
             else if ((16 > lati) && (lati >= 8))
130
               letter = 'P';
131
             else if (( 8 > lati) && (lati >= 0))
132
               letter = 'N';
133
             else if (( 0 > lati) && (lati >= -8))
134
135
               letter = 'M';
             else if ((-8> lati) && (lati >= -16))
136
               letter = 'L';
137
138
             else if ((-16 > lati) && (lati >= -24))
               letter = 'K';
139
             else if ((-24 > lati) && (lati >= -32))
140
               letter = 'J';
141
             else if ((-32 > lati) && (lati >= -40))
142
               letter = 'H';
143
             else if ((-40 > lati) && (lati >= -48))
144
                _letter = 'G';
145
             else if ((-48 > lati) && (lati >= -56))
146
147
               letter = 'F';
             else if ((-56 > lati) \&\& (lati >= -64))
148
                letter = 'E';
149
150
             else if ((-64 > lati) && (lati >= -72))
151
               letter = 'D';
152
             else if ((-72 > lati) && (lati >= -80))
               letter = 'C';
153
             else
154
               _letter = 'Z'; // This is here as an error flag to show
155
                                        // that the latitude is outside the
156
                                        UTM Limits
157
158
             /*!
             * Ecuaciones de Coticchia-Surace para el paso de Geográficas
159
             a UTM (Problema directo);
             */
160
161
             /// Cálculo de Parámetros.
162
163
             double coslatRad = cos(latRad);
             double coslatRad2 = sq(coslatRad);
164
165
             double A = coslatRad * sin(Dlanda);
166
167
             double xi = 0.5 * log((1 + A) / (1 - A));
             double n = atan(tan(latRad) / cos(Dlanda)) - latRad;
168
             double v = (c / sqrt(1 + e2 * coslatRad2)) * 0.9996;
169
             double z = e2 2 * sq(xi) * coslatRad2;
170
             double A1 = sin(2 * latRad);
171
172
             double A2 = A1 * coslatRad2;
             double J2 = latRad + (A1 / 2.0);
173
```

```
double J4 = (3.0 * J2 + A2) / 4.0;
174
             double J6 = (5.0 * J4 + A2 * coslatRad2) / 3.0;
175
             double Bfi = 0.9996 * c * (latRad - alf * J2 + bet * J4 - gam)
176
             * J6);
177
178
             /*!
              * Cálculo final de coordenadas UTM
179
              */
180
             /*
181
             Serial.println (" Las coordenadas GPS que se van a
182
             transformar son: ");
             Serial.print (" Latitud: "); Serial.println (lati,6);
183
             Serial.print (" Longitud: "); Serial.println (longi,6);
184
185
             Serial.println (" Coordenadas UTM actuales: ");
186
             Serial.print("UTM: "); Serial.print( h); Serial.print("
187
              "); Serial.println(_letter);
188
              */
              _x = round(xi * v * (1 + (z / 3.0)) + 500000);
189
190
              /*!< 500.000 es el retranqueo que se realiza en cada huso
             sobre el origen de
             coordenadas en el eje X con el objeto de que no existan
191
             coordenadas negativas. */
192
193
              _y = round(n * v * (1 + z) + Bfi);
             if (lati < 0.0) _y += 10000000;
194
195
             /*!< En el caso de latitudes al sur del ecuador, se sumará al
             valor de Y 10.000.000
             para evitar coordenadas negativas. */
196
197
             Serial.print (" X = "); Serial.print (_x); Serial.println ("
198
             (m)");
199
             Serial.print (" Y = "); Serial.print ( y); Serial.println ("
             (m)");
200
             */
201
           };
202
203
           int zone(){
204
             return h;
205
           };
206
207
           char band(){
             return letter;
208
209
           };
210
           long X(){
211
212
             return _x;
213
           }:
```