```
1 /*
 2 UTMconsersion.h - Library to convert in UTM coordenates.
 3 TinyTrackGPS v0.7
 4
 5 Copyright © 2019-2021 Francisco Rafael Reyes Carmona.
 6 All rights reserved.
 7
 8 rafael.reyes.carmona@gmail.com
 9
     This file is part of TinyTrackGPS.
10
11
12
     TinyTrackGPS is free software: you can redistribute it and/or modify
     it under the terms of the GNU General Public License as published by
13
14
     the Free Software Foundation, either version 3 of the License, or
15
     (at your option) any later version.
16
     TinyTrackGPS is distributed in the hope that it will be useful,
17
     but WITHOUT ANY WARRANTY; without even the implied warranty of
18
19
     MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
     GNU General Public License for more details.
20
21
22
     You should have received a copy of the GNU General Public License
23
     along with TinyTrackGPS. If not, see <a href="https://www.gnu.org/licenses/">https://www.gnu.org/licenses/</a>.
24 */
25
26 #if ARDUINO >= 100
27
     #include "Arduino.h"
28 #else
     #include "WProgram.h"
29
30 #endif
31
32 #ifndef UTMconversion_h
33 #define UTMconversion_h
34
35 class GPS UTM {
36
     private:
       int _h;
37
       char _letter;
38
39
       long _x;
40
       long _y;
41
42
     public:
43
       GPS UTM(){
         _h = 0;
44
45
         _letter = 'Z';
         _x = 0L;
46
         _y = 0L;
47
       };
48
49
50
       void UTM(double lati, double longi) {
51
52
     * Transformación de las coordenadas geográficas a UTM
53
54
55
     /*// Sobre la geometría del delipsoide WGS84
56
     double a = 6378137.0;
57
     double b = 6356752.3142;
58
59
       float e1 = sqrt((a*a) - (b*b))/a; ///< Excentricidad.
     double e = sqrt(sq(a) - sq(b))/b; ///< Segunda excentricidad.</pre>
60
```

```
61
        double e2 = sq(e); ///< al cuadrado. Usaremos esta directamente.
 62
        double c = sq(a) / b; ///< Radio Polar de Curvatura.
      */
63
64
 65
      // Se realiza las declaraciones para agilizar el calculo a UTM de X e Y.
      double e2 = 673949675659e-14; ///< Segunda excentricidad al cuadrado.
 66
      double e2_2 = 336974837829e-14; // (e2 / 2.0)
67
      double c = 639959362580397e-8; ///< Radio Polar de Curvatura.</pre>
68
      double PI_180 = 1745329251994e-14;// (PI / 180.0)
69
      double alf = 505462256744e-14; // (0.75 * e2)
 70
      double bet = 425820155e-13; // ((5.0 / 3.0) * alf * alf)
71
 72
      double gam = 16740579e-14; // ((35.0 / 27.0) * alf * alf * alf)
 73
 74
        /// Sobre la longitud y latitud. Conversión de grados decimales a radianes.
 75
76
77
        * Cálculo del signo de la longitud:
 78
               - Si la longitud está referida al Oeste del meridiano de Greenwich,
 79
                 entonces la longitud es negativa (-).
80
               - Si la longitud está referida al Este del meridiano de Greenwich,
                 entonces la longitud es positiva (+).
 81
        */
 82
83
84
        double latRad = lati * PI_180; ///< Latitud en Radianes.</pre>
85
        double lonRad = longi * PI 180; ///< Longitud en Radianes.</pre>
86
87
        /// Sobre el huso.
88
        //float huso = ((longi + 180.0) / 6.0) + 1.0; ///< Nos interesa quedarnos solo
    con la parte entera.
        //_h = (int)huso;
89
 90
      h = (int)((longi + 180.0) / 6.0) + 1;
91
92
      // Handle special case of west coast of Norway
      if ( lati >= 56.0 && lati < 64.0 && longi >= 3.0 && longi < 12.0 ) {
93
        h = 32;
 94
95
96
97
      // Special zones for Svalbard
      if ( lati >= 72.0 && lati < 84.0 ) {
98
99
        if ( longi >= 0.0 && longi < 9.0 ) _h = 31;
        else if ( longi >= 9.0 && longi < 21.0 ) _h = 33;
100
        else if ( longi >= 21.0 && longi < 33.0 ) _h = 35;
101
        else if ( longi >= 33.0 && longi < 42.0 ) _h = 37;
102
103
      }
104
        int landa0 = _h * 6 - 183; ///< Cálculo del meridiano central del huso en
105
    grados.
        double Dlanda = lonRad - (landa0 * PI_180); ///< Desplazamiento del punto a</pre>
106
    calcular con respecto al meridiano central del huso.
107
108
      if ((84 >= lati) && (lati >= 72))
109
        _letter = 'X';
      else if ((72 > lati) && (lati >= 64))
110
111
        letter = 'W';
112
      else if ((64 > lati) && (lati >= 56))
        _letter = 'V';
113
114
      else if ((56 > lati) && (lati >= 48))
        _letter = 'U';
115
      else if ((48 > lati) && (lati >= 40))
116
117
        _letter = 'T';
```

```
118
      else if ((40 > lati) && (lati >= 32))
        _letter = 'S';
119
      else if ((32 > lati) && (lati >= 24))
120
        _letter = 'R';
121
122
      else if ((24 > lati) && (lati >= 16))
        _letter = 'Q';
123
      else if ((16 > lati) && (lati >= 8))
124
125
        letter = 'P';
126
      else if (( 8 > lati) && (lati >= 0))
        _letter = 'N';
127
128
      else if (( 0 > lati) && (lati >= -8))
129
        letter = 'M';
      else if ((-8> lati) && (lati >= -16))
130
131
        letter = 'L';
132
      else if ((-16 > lati) && (lati >= -24))
        letter = 'K';
133
      else if ((-24 > lati) && (lati >= -32))
134
        _letter = 'J';
135
      else if ((-32 > lati) && (lati >= -40))
136
        _letter = 'H';
137
      else if ((-40 > lati) && (lati >= -48))
138
139
        _letter = 'G';
140
      else if ((-48 > lati) && (lati >= -56))
141
        _letter = 'F';
      else if ((-56 > lati) && (lati >= -64))
142
        _letter = 'E';
143
144
      else if ((-64 > lati) && (lati >= -72))
145
        letter = 'D';
      else if ((-72 > lati) && (lati >= -80))
146
147
        _letter = 'C';
148
      else
149
           _letter = 'Z'; // This is here as an error flag to show that the latitude is
    outside the UTM limits
150
151
152
153
        * Ecuaciones de Coticchia-Surace para el paso de Geográficas a UTM (Problema
    directo);
        */
154
155
156
        /// Cálculo de Parámetros.
        double coslatRad = cos(latRad);
157
        double coslatRad2 = sq(coslatRad);
158
159
160
        double A = coslatRad * sin(Dlanda);
        double xi = 0.5 * log((1 + A) / (1 - A));
161
162
        double n = atan(tan(latRad) / cos(Dlanda)) - latRad;
        double v = (c / sqrt(1 + e2 * coslatRad2)) * 0.9996;
163
        double z = e2 2 * sq(xi) * coslatRad2;
164
        double A1 = sin(2 * latRad);
165
        double A2 = A1 * coslatRad2;
166
        double J2 = latRad + (A1 / 2.0);
167
        double J4 = (3.0 * J2 + A2) / 4.0;
168
        double J6 = (5.0 * J4 + A2 * coslatRad2) / 3.0;
169
        double Bfi = 0.9996 * c * (latRad - alf * J2 + bet * J4 - gam * J6);
170
171
172
173
        * Cálculo final de coordenadas UTM
        */
174
175
```

```
Serial.println (" Las coordenadas GPS que se van a transformar son: ");
176
        Serial.print (" Latitud: "); Serial.println (lati,6);
177
        Serial.print (" Longitud: "); Serial.println (longi,6);
178
179
        Serial.println (" Coordenadas UTM actuales: ");
180
      Serial.print("UTM: "); Serial.print(_h); Serial.print("
181
    "); Serial.println(_letter);
182
      x = \text{round}(xi * v * (1 + (z / 3.0)) + 500000);
183
      /*!< 500.000 es el retranqueo que se realiza en cada huso sobre el origen de
184
        coordenadas en el eje X con el objeto de que no existan coordenadas negativas.
185
186
187
        _{y} = round(n * v * (1 + z) + Bfi);
      if (lati < 0.0) _y += 10000000;
188
      /*!< En el caso de latitudes al sur del ecuador, se sumará al valor de Y
189
    10.000.000
        para evitar coordenadas negativas. */
190
191
192
        Serial.print (" X = "); Serial.print ( x); Serial.println (" (m)");
193
        Serial.print (" Y = "); Serial.print (_y); Serial.println (" (m)");
194
195
196
       };
197
198
      int zone(){
199
      return _h;
200
      };
201
      char band(){
202
203
      return letter;
204
      };
205
206
      long X(){
207
       return _x;
208
      };
209
210
      long Y(){
211
       return _y;
212
      };
213 };
214
215 #endif
216
```