

TSRN AI SMART REPAIR PRICING MATRIX

SMART REPAIR ELIGIBILITY CHECK

Before generating a quotation, the AI must determine whether the damage is suitable for a SMART repair.

ELIGIBLE FOR SMART REPAIR

- Localised cosmetic damage
- Localised scratches
- Localised scuffs
- Localised paint damage
- Localised dents
- Wheel kerb damage
- Paintless dent removal (PDR) where paint is not broken

NOT ELIGIBLE FOR SMART REPAIR

- Structural damage
- Panel replacement required
- Large-scale lacquer peel
- Significant corrosion
- Extensive previous repair work
- Damage exceeding repair size limits

PANEL PRICING

Repair Area	Base Price (£)	Minimum Charge (£)
Front Bumper (Corner)	280	265
Full Front Bumper	450	400
Rear Bumper (Corner)	280	265
Full Rear Bumper	450	400
Front Wing	195	185
Front Door	265	250
Rear Door	265	250
Rear Quarter Panel (4-Door Vehicle)	230	210

Rear Quarter Panel (2-Door Vehicle)	290	270
Sill / Rail	220	210
Roof	460	450
Bonnet	460	450
Alloy Wheel Refurbishment (Painted)	80	70
Alloy Wheel Refurbishment (Special Finish)	150	150
Diamond Cut Wheel Refurbishment	95	85
Paintless Dent Repair (PDR)	120	100

DAMAGE SIZE MULTIPLIER

Damage Size	Multiplier
Up to 5cm	0
5cm - 15cm	1.10
15cm - 30cm	1.50
30cm - 50cm	2.00
Over 50cm	Manual Review

AI RULE:

Measure the longest visible dimension of the damage and apply the appropriate multiplier.

DAMAGE DEPTH MULTIPLIER

Damage Depth	Multiplier
Surface Scratch / Scuff Only	0

Very Shallow Dent (Minimal Filler Required)	1.15
Moderate Dent (Light Filler Required)	1.50
Deep Dent (Moderate Filler Required)	1.80
Severe Dent (Heavy Filler Required)	Manual Review

AI RULE:

Assess the depth of the damage and estimate the level of filler required to achieve a quality repair.

Examples:

Surface Scratch / Scuff Only

- No dent present
- Paint damage only

Very Shallow Dent

- Dent visible only under certain lighting
- Minimal panel distortion

Moderate Dent

- Clearly visible dent
- Light filler required during preparation

Deep Dent

- Significant panel distortion
- Multiple filler applications may be required

Severe Dent

- Extensive panel distortion
- Excessive filler likely required
- Refer for manual review or bodyshop assessment

PANEL COMPLEXITY MULTIPLIER

Complexity Level	Multiplier
Flat Panel	0
Curved Panel	1.05

Bodyline Present	1.10
Multiple Bodylines	1.30
Complex Contour	1.40

Examples:

Flat Panel

- Bonnet centre
- Roof centre

Curved Panel

- Front wing
- Rear quarter panel

Bodyline Present

- Door crease
- Wing bodyline

Multiple Bodylines

- Modern SUV panels
- Complex side panels

Complex Contour

- Bumper corners
- Highly sculpted areas

PAINT TYPE CHARGES

Paint Type	Additional Charge (£)
Solid Colour	0
Metallic	1.20
Pearlescent	1.50

Tri-Coat Pearl	1.50
----------------	------

BLENDING CHARGES

Adjacent Panels Requiring Blend	Additional Charge (£)
1 Panel	180
2 Panels	350
3 Panels	500

AI RULE:

Apply blending charges where colour matching requires adjacent panel blending.

PDR RULES

Paintless Dent Repair (PDR) may only be selected when:

- Paint is intact
- No cracking
- No paint fracture
- No exposed metal
- No previous filler damage
- Dent depth is classified as Very Shallow Dent

If paint damage is detected:

- Convert to SMART repair pricing
-

MULTIPLE DAMAGE RULE

Number of Damages	Discount / Multiplier
1	0
2	1.05
3	1.10

4+	1.50
----	------

AI CONFIDENCE RULES

Confidence Level	Action
------------------	--------

95%+	Generate Estimate
------	-------------------

80% - 94%	Generate Estimate & Flag for Review
-----------	-------------------------------------

Below 80%	Manual Review Required
-----------	------------------------

PRICING FORMULA

Final Price =

(Base Price

× Damage Size Multiplier

× Damage Depth Multiplier

× Panel Complexity Multiplier)

- Paint Type Charge
- Blending Charges

If Final Price is less than the minimum charge for that repair area:

Use the Minimum Charge.

AI DECISION PROCESS

Step 1

Identify repair area. From photo and user text input.

Step 2

Determine SMART repair, wheel repair and PDR repair eligibility.

Step 3

Determine repair type:

- SMART Repair
- Alloy Wheel Refurbishment

- Diamond Cut Wheel Refurbishment
- Paintless Dent Repair (PDR)

Step 4

Measure damage size.

Step 5

Apply damage size multiplier.

Step 6

Assess damage depth.

Step 7

Apply damage depth multiplier.

Step 8

Determine panel complexity.

Step 9

Apply complexity multiplier.

Step 10

Determine paint type.

Step 11

Apply paint and blending charges.

Step 12

Check minimum charge.

Step 13

Generate estimate or refer for manual review.