
# Date Submitted: 11/02/19

# Task 01:

Youtube Link: <a href="https://youtu.be/aEmIbTRMqOU">https://youtu.be/aEmIbTRMqOU</a>

# Modified Schematic (if applicable):



fritzing

#### Screenshot of terminal:

```
E COM3 ⋈
Sent:
'80'
Received:
'80'
Sent:
'80'
Received:
'80'
Sent:
'82'
Received:
'82'
```

```
Modified Code:
// Ricky Perez
// CpE 403
// Lab 8
// Task 1
#include <stdbool.h>
```

```
#include <stdint.h>
#include "inc/hw_memmap.h"
#include "driverlib/gpio.h"
#include "driverlib/pin map.h"
#include "driverlib/ssi.h"
#include "driverlib/sysctl.h"
#include "driverlib/uart.h"
#include "utils/uartstdio.h"
#include "driverlib/adc.h"
#include "driverlib/debug.h"
#define NUM_SSI_DATA
                             1
uint32_t ui32ADC0Value[4];
volatile uint32_t ui32TempAvg;
volatile uint32_t ui32TempValueC;
volatile uint32_t ui32TempValueF;
void configADC(void);
void InitConsole(void)
   // Enable GPIO port A which is used for UARTO pins.
   SysCtlPeripheralEnable(SYSCTL PERIPH GPIOA);
   // Configure the pin muxing for UARTO functions on port AO and A1.
   // This step is not necessary if your part does not support pin muxing.
   // TODO: change this to select the port/pin you are using.
   GPIOPinConfigure(GPIO_PA0_U0RX);
   GPIOPinConfigure(GPIO_PA1_U0TX);
   // Enable UARTO so that we can configure the clock.
   SysCtlPeripheralEnable(SYSCTL PERIPH UART0);
   // Use the internal 16MHz oscillator as the UART clock source.
   UARTClockSourceSet(UART0_BASE, UART_CLOCK_PIOSC);
   // Select the alternate (UART) function for these pins.
   GPIOPinTypeUART(GPIO_PORTA_BASE, GPIO_PIN_0 | GPIO_PIN_1);
   // Initialize the UARTfor console I/O.
   UARTStdioConfig(0, 115200, 16000000);
}
//
// Configure SSI0 in master Freescale (SPI) mode. This example will send out
// 3 bytes of data, then wait for 3 bytes of data to come in. This will all be
// done using the polling method.
int main(void)
```

```
uint32 t pui32DataTx[NUM SSI DATA];
   uint32 t pui32DataRx[NUM SSI DATA];
   uint32 t ui32Index;
   SysCtlClockSet(SYSCTL SYSDIV 1 | SYSCTL USE OSC | SYSCTL OSC MAIN
|SYSCTL XTAL 16MHZ);
   // Set up the serial console to use for displaying messages. This is
   // just for this example program and is not needed for SSI operation.
   InitConsole();
   // Display the setup on the console.
   UARTprintf("SSI ->\n");
   UARTprintf(" Mode: SPI\n");
   UARTprintf(" Data: 8-bit\n\n");
   // The SSIO peripheral must be enabled for use.
   SysCtlPeripheralEnable(SYSCTL PERIPH SSI0);
    // For this example SSIO is used with PortA[5:2]. The actual port and pins
   // used may be different on your part, consult the data sheet for more
   // information. GPIO port A needs to be enabled so these pins can be used.
   // TODO: change this to whichever GPIO port you are using.
   // The SSIO peripheral is on Port A and pins 2,3,4 and 5.
   SysCtlPeripheralEnable(SYSCTL PERIPH GPIOA);
   // Configure the pin muxing for SSIO functions on port A2, A3, A4, and A5.
   // This step is not necessary if your part does not support pin muxing.
   // TODO: change this to select the port/pin you are using.
   // This function/s configures the pin muxing on port A pins 2,3,4 and 5
   GPIOPinConfigure(GPIO PA2 SSI0CLK);
   GPIOPinConfigure(GPIO PA3 SSI0FSS);
   GPIOPinConfigure(GPIO PA4 SSIORX);
   GPIOPinConfigure(GPIO_PA5_SSI0TX);
   // Configure the GPIO settings for the SSI pins. This function also gives
   // control of these pins to the SSI hardware. Consult the data sheet to
   // see which functions are allocated per pin.
   // The pins are assigned as follows:
   //
          PA5 -SSI0Tx
   //
          PA4 -SSI0Rx
           PA3 -SSI0Fss
   //
           PA2 -SSI0CLK
   GPIOPinTypeSSI(GPIO PORTA BASE, GPIO PIN 5 | GPIO PIN 4 | GPIO PIN 3
|GPIO_PIN_2);
   // Configure and enable the SSI port for SPI master mode. Use SSIO,
   //system clock supply, idle clock level low and active low clock in
   // freescale SPI mode, master mode, 1MHz SSI frequency, and 8-bit data.
   // For SPI mode, you can set the polarity of the SSI clock when the SSI
   // unit is idle. You can also configure what clock edge you want to
   // capture data on. Please reference the datasheet for more information on
   // the different SPI modes.
```


```
SSIConfigSetExpClk(SSI0_BASE, SysCtlClockGet(),
SSI_FRF_MOTO_MODE_0,SSI_MODE_MASTER, 1000000, 8);
    // Enable the SSI0 module.
    SSIEnable(SSI0 BASE);
    //Set system clock
    SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_OSC_MAIN|SYSCTL_XTAL_16MHZ);
    configADC();
    while(1)
    {
        ADCIntClear(ADC0 BASE, 1);// clear interrupt flag
        ADCProcessorTrigger(ADC0_BASE, 1); // trigger ADC conversion with software
        while(!ADCIntStatus(ADC0 BASE, 1, false))
            // wait for conversion
        }
        ADCSequenceDataGet(ADC0_BASE, 1, ui32ADC0Value); //get data from a buffer in
memory
        // temperature calculations
        ui32TempAvg = (ui32ADC0Value[0] + ui32ADC0Value[1] + ui32ADC0Value[2] +
ui32ADC0Value[3] + 2)/4;
        ui32TempValueC = (1475 - ((2475 * ui32TempAvg)) / 4096)/10;
        ui32TempValueF = ((ui32TempValueC * 9) + 160) / 5;
        // Read any <a href="residual">residual</a> data from the SSI port. This makes sure the receive
        // FIFOs are empty, so we don't read any unwanted junk. This is done here
        // because the SPI SSI mode is full-duplex, which allows you to send and
        // receive at the same time. The SSIDataGetNonBlocking function returns
        // "true" when data was returned, and "false" when no data was returned.
        // The "non-blocking" function checks if there is any data in the receive
        // FIFO and does not "hang" if there isn't.
        while(SSIDataGetNonBlocking(SSI0_BASE, &pui32DataRx[0]))
        //pui32DataTx[0] = 's';
        pui32DataTx[0] = ui32TempValueF; // Initialize the data to send.
        SysCtlDelay( (SysCtlClockGet()/3));
        //SysCtlDelay( (SysCtlClockGet()/(3*1000))*1000 ); //
        // Display indication that the SSI is transmitting data.
        UARTprintf("\nSent:\n ");
        // Send 3 bytes of data.
        for(ui32Index = 0; ui32Index < NUM SSI DATA; ui32Index++)</pre>
        {
            // Display the data that SSI is transferring.
            UARTprintf("'%u' ", pui32DataTx[ui32Index]); // %u is unsigned
            // Send the data using the "blocking" put function. This function
            // will wait until there is room in the send FIFO before returning.
            // This allows you to assure that all the data you send makes it into
```

```
// the send FIFO.
            SSIDataPut(SSI0_BASE, pui32DataTx[ui32Index]);
        }
        // Wait until SSIO is done transferring all the data in the transmit FIFO.
        while(SSIBusy(SSI0 BASE))
        SysCtlDelay( (SysCtlClockGet()/3));
        // SysCtlDelay( (SysCtlClockGet()/(3*1000))*1000 ); //
        // Display indication that the SSI is receiving data.
        UARTprintf("\nReceived:\n ");
        // Receive 3 bytes of data.
        for(ui32Index = 0; ui32Index < NUM_SSI_DATA; ui32Index++)</pre>
            // Receive the data using the "blocking" Get function. This function
            // will wait until there is data in the receive FIFO before returning.
            SSIDataGet(SSI0 BASE, &pui32DataRx[ui32Index]);
            // Since we are using 8-bit data, mask off the MSB.
            pui32DataRx[ui32Index] &= 0x00FF;
            // Display the data that SSIO received.
            UARTprintf("'%u' ", pui32DataRx[ui32Index]);
        }
    }
    // Return no errors
    return(0);
void configADC(void)
{
    //Enable ADC
    SysCtlPeripheralEnable(SYSCTL PERIPH ADC0);
    //Configure ADC sequencer
    ADCSequenceConfigure(ADC0_BASE, 1, ADC_TRIGGER_PROCESSOR, 0);
    ADCSequenceStepConfigure(ADC0_BASE, 1, 0, ADC_CTL_TS);
    ADCSequenceStepConfigure(ADC0_BASE, 1, 1, ADC_CTL_TS);
    ADCSequenceStepConfigure(ADC0_BASE, 1, 2, ADC_CTL_TS);
    ADCSequenceStepConfigure(ADC0_BASE,1,3,ADC_CTL_TS|ADC_CTL_IE|ADC_CTL_END);
    //Enable ADC sequencer 1
    ADCSequenceEnable(ADC0_BASE, 1);
}
```

# Task 02:

Youtube Link: <a href="https://youtu.be/C9usz2hwrNk">https://youtu.be/C9usz2hwrNk</a>

### Modified Schematic (if applicable):



#### Modified Code:

```
// Ricky Perez
// CpE 403
// Lab 8
// Task 2
// Interface the WS2818B 1x8 RGB LED strip with TivaC using SPI interface.
// Implement a running R, G, B, RG, RB, GB, and RGB light sequence.
#include <stdbool.h>
#include <stdint.h>
#include "inc/hw_memmap.h"
#include "driverlib/gpio.h"
#include "driverlib/pin_map.h"
#include "driverlib/ssi.h"
#include "driverlib/sysctl.h"
#include "driverlib/uart.h"
#include "utils/uartstdio.h"
#include "driverlib/adc.h"
#include "driverlib/debug.h"
#define MAX_RED
                             255
#define MAX_GREEN
                             255
#define MAX BLUE
                             255
#define NUM_LEDS
                               8
uint8 t frame buffer[NUM LEDS*3];
void send_data(uint8_t* data, uint8_t num_leds);
void fill_frame_buffer(uint8_t r, uint8_t g, uint8_t b, uint32_t num_leds);
static volatile uint32_t ssi_lut[] =
0b100100100,
 0b110100100,
 0b100110100,
0b110110100,
 0b100100110,
 0b110100110,
 0b100110110,
0b110110110
};
```

```
int main(void) {
    FPULazyStackingEnable();
    // 80MHz
    SysCtlClockSet(SYSCTL_SYSDIV_2_5 | SYSCTL_USE_PLL | SYSCTL_XTAL_16MHZ |
SYSCTL_OSC_MAIN);
    SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
    SysCtlDelay(50000);
    SysCtlPeripheralEnable(SYSCTL_PERIPH_SSI0);
    SysCtlDelay(50000);
    GPIOPinConfigure(GPIO_PA5_SSI0TX);
    GPIOPinConfigure(GPIO_PA2_SSI0CLK);
    GPIOPinConfigure(GPIO PA4 SSIØRX);
    GPIOPinConfigure(GPIO PA3 SSI0FSS);
    GPIOPinTypeSSI(GPIO PORTA BASE, GPIO PIN 5);
    GPIOPinTypeSSI(GPIO_PORTA_BASE, GPIO_PIN_2);
    GPIOPinTypeSSI(GPIO_PORTA_BASE, GPIO_PIN_4);
    GPIOPinTypeSSI(GPIO_PORTA_BASE, GPIO_PIN_3);
    //20 MHz data rate
    SSIConfigSetExpClk(SSI0_BASE, 80000000, SSI_FRF_MOTO_MODE_0, SSI_MODE_MASTER,
2400000, 9);
    SSIEnable(SSI0 BASE);
    //fill frame buffer(48, 255, 255, NUM LEDS);
    while(1)
    {
        // R, G, B, RG, RB, GB, and RGB light sequence.
        // Red
        fill_frame_buffer(MAX_RED, 0, 0, NUM_LEDS );
        send data(frame buffer, NUM LEDS);
        SysCtlDelay((SysCtlClockGet()/5));// small delay
        // Green
        fill_frame_buffer( 0, MAX_GREEN, 0, NUM_LEDS);
        send data(frame buffer, NUM LEDS);
        //SysCtlDelay(80000000/5); // small delay
        SysCtlDelay((SysCtlClockGet()/5));
        // Blue
        fill_frame_buffer( 0, 0,MAX_BLUE, NUM_LEDS);
        send data(frame buffer, NUM LEDS);
        SysCtlDelay((SysCtlClockGet()/5));// small delay
        // Red and Green
        fill_frame_buffer(MAX_RED, MAX_GREEN, 0, NUM_LEDS);
        SysCtlDelay((SysCtlClockGet()/4)); // small delay
```

```
// Red and Blue
        fill_frame_buffer(MAX_RED,0, MAX_BLUE, NUM_LEDS);
        send_data(frame_buffer, NUM_LEDS);
        SysCtlDelay((SysCtlClockGet()/4)); // small delay
        // Green Blue
        fill_frame_buffer(0, MAX_GREEN, MAX_BLUE, NUM_LEDS);
        send_data(frame_buffer, NUM_LEDS);
        SysCtlDelay((SysCtlClockGet()/4)); // small delay
        // Red Green Blue
        fill_frame_buffer(MAX_RED, MAX_GREEN, MAX_BLUE, NUM_LEDS);
        send data(frame buffer, NUM LEDS);
        SysCtlDelay((SysCtlClockGet()/4));// small delay
    return_0;
}
void send data(uint8 t* data, uint8 t num leds)
    uint32_t i, j, curr_lut_index, curr_rgb;
    for(i = 0; i < (num_leds*3); i = i + 3) {</pre>
        curr_rgb = (((uint32_t)data[i + 2]) << 16) | (((uint32_t)data[i + 1]) << 8) |</pre>
data[i];
        for(j = 0; j < 24; j = j + 3) {
            curr_lut_index = ((curr_rgb>>j) & 0b111);
            SSIDataPut(SSI0_BASE, ssi_lut[curr_lut_index]);
        }
    }
    SysCtlDelay(50000); // delay more then 50us
}
void fill_frame_buffer(uint8_t r, uint8_t g, uint8_t b, uint32_t num_leds)
{
    uint32_t i;
    uint8_t* frame_buffer_index = frame_buffer;
    for(i = 0; i < num_leds; i++) {</pre>
        *(frame_buffer_index++) = g;
        *(frame_buffer_index++) = r;
        *(frame_buffer_index++) = b;
    }
}
```