

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : BKPb Auto Ta:
00011 "# Function :
00012 "# Call Program : H60.3
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 00000 MW05008 = 0;
00021 00001 MW04520 = 0;
00022
00023 " Manual PTP
00024 00002 IOW MB045241 == 1 " Recipe / Paramter Update Complete Waiting
00025
00026 " Req Break Pusher BarPosition & Speed Setting Update
00027 00003 MB50720 = 0; " Break Pusher Barparamter Update Reset
00028 00004 MSEE MPS270; " BKPb Position Update & Speed Setting
00029 00005 MB50720 = 1; " Break Pusher Barparamter Update Set
00030
00031 00006 DB00000 = 0;
00032 00007 WHILE DB00000 == 0
00033 " Req Moving Flag On
00034 00008 MB04572A = 0;
00035 00009 IOW MB04572A == 0 " BKPb Moving Flag On
00036
00037 00010 MW05008 = MW04520;
00038
00039 "Step Check
00040 00011 IF MW05008 == 1;
00041 00012 MW05008 = 10;
00042 00013 IEND;
00043 00014 IF MW05008 == 2;
00044 00015 MW05008 = 10;
00045 00016 IEND;
00046 00017 IF MW05008 == 6;
00047 00018 MW05008 = 10;
00048 00019 IEND;
00049
00050 00020 SFORK MW05008 == 1 ? LBL01 " [Step.01] Break Pusher Bar Receive Before (Unuse)
00051 MW05008 == 2 ? LBL02 " [Step.02] Break Pusher Bar Receive (Unuse)
00052 MW05008 == 3 ? LBL03 " [Step.03] Break Pusher Bar Start
00053 MW05008 == 4 ? LBL04 " [Step.04] Break Pusher Bar Execute
00054 MW05008 == 5 ? LBL05 " [Step.05]
00055 MW05008 == 6 ? LBL06 " [Step.06] Last Dummy Break Pusher Bar Receive (Unuse)
00056 MW05008 == 7 ? LBL07 " [Step.07] Last Dummy Break Pusher Bar Start
00057 MW05008 == 8 ? LBL08 " [Step.08] Last Dummy Break Pusher Bar Execute
00058 MW05008 == 9 ? LBL09 " [Step.09]
00059 MW05008 == 10 ? LBL10 " [Step.10] Break Pusher Bar Waiting Position
00060 MW05008 == 11 ? LBL11 " [Step.11] Break Pusher Bar Cleaning Start Position
00061 MW05008 == 12 ? LBL12 " [Step.12] Break Pusher Bar Cleaning End Position
00062 DEFAULT ? LBL100;
00063
00064 00021 LBL01: " [Step.01] Break Pusher Bar Receive Before
00065
00066 00022 MB04572A = 1; " BKPb Moving Flag On
00067
00068 00023 MSEE MPS260; " Break Pusher Bar Receive Before Positon 1 Cycle
00069
00070 00024 MB045211 = 1; " [ SC Res BKPb ] Command Complete
00071 00025 IOW MB045210 == 0 " [ SC Req BKPb ] Command Se
00072 00026 MB045211 = 0; " [ SC Req BKPb ] Command Se
00073 00027 MW05008 = 0; " BKPb Command Code ID Reset
00074 00028 MB04572A = 0; " BKPb Moving Flag Off
00075
00076 00029 JOINTO LBL0X;
00077
00078 00030 LBL02: " [Step.02] Break Pusher Bar Receive
00079
00080 00031 MB04572A = 1; " BKPb Moving Flag On
00081
00082 00032 MSEE MPS261; " Break Pusher Bar Receive Positon 1 Cycle
00083
00084 00033 MB045211 = 1; " [ SC Res BKPb ] Command Complete
00085 00034 IOW MB045210 == 0 " [ SC Req BKPb ] Command Se
00086 00035 MB045211 = 0; " [ SC Req BKPb ] Command Se
00087 00036 MW05008 = 0; " BKPb Command Code ID Reset

```

```

00088 00037          MB04572A = 0;                " BKPB Moving Flag Off
00089
00090 00038          JOINTO LBL0X;
00091
00092 00039          LBL03: " [Step.03] Break Pusher Bar Start
00093
00094 00040          MB04572A = 1;                " BKPB Moving Flag On
00095
00096 00041          MSEE MPS262;                " Break Pusher Bar Start Positon 1 Cycle
00097
00098 00042          MB045211 = 1;                " [ SC Res BKPB ] Command Complete
00099 00043          IOW MB045210 == 0            " [ SC Req BKPB ] Command Se
00100 00044          MB045211 = 0;                " [ SC Req BKPB ] Command Se
00101 00045          MW05008 = 0;                " BKPB Command Code ID Reset
00102 00046          MB04572A = 0;                " BKPB Moving Flag Of
00103
00104 00047          JOINTO LBL0X;
00105
00106 00048          LBL04: " [Step.04] Break Pusher Bar Execute
00107
00108 00049          MB04572A = 1;                " BKPB Moving Flag On
00109
00110 00050          MSEE MPS263;                " Break Pusher Bar Execute 1 Cycle
00111
00112 00051          MB045211 = 1;                " [ SC Res BKPB ] Command Complete
00113 00052          IOW MB045210 == 0            " [ SC Req BKPB ] Command Se
00114 00053          MB045211 = 0;                " [ SC Req BKPB ] Command Se
00115 00054          MW05008 = 0;                " BKPB Command Code ID Reset
00116 00055          MB04572A = 0;                " BKPB Moving Flag Off
00117
00118 00056          IF MB000004 == 1            " Automatic Driving
00119 00057              IF !MB045013 == 1;
00120 00058                  MB04572A = 1;        " BKPB Moving Flag O
00121 00059                  MSEE MPS265;        " Break Pusher Bar Waiting Position 1 Cycle
00122 00060                  MB04572A = 0;        " BKPB Moving Flag Off
00123 00061              IEND;
00124 00062          ELSE;
00125 00063              MB045135 = 1;                " Break Pusher Bar Breaing Execute Comp
00126 00064          IEND;
00127
00128 00065          JOINTO LBL0X;
00129
00130 00066          LBL05: " [Step.05]
00131 00067          JOINTO LBL0X;
00132
00133 00068          LBL06: " [Step.06] Last Dummy Break Pusher Bar Receive
00134
00135 00069          MB04572A = 1;                " BKPB Moving Flag On
00136
00137          " Last Break Pusher Bar Receive (Unuse)
00138 00070          MSEE MPS266;
00139
00140          " [SC Res BKPB] Comman
00141 00071          MB045211 = 1;                " [ SC Res BKPB ] Command Complete
00142 00072          IOW MB045210 == 0            " [ SC Req BKPB ] Command Se
00143 00073          MB045211 = 0;                " [ SC Req BKPB ] Command Se
00144 00074          MW05008 = 0;                " BKPB Command Code ID Reset
00145 00075          MB04572A = 0;                " BKPB Moving Flag Off
00146
00147 00076          JOINTO LBL0X;
00148
00149 00077          LBL07: " [Step.07] Last Dummy Break Pusher Bar Start
00150
00151 00078          MB04572A = 1;                " BKPB Moving Flag On
00152
00153 00079          MSEE MPS267;                " Break Pusher Bar Last Pitch Start Position 1 Cycle
00154
00155 00080          MB045211 = 1;                " [ SC Res BKPB ] Command Complete
00156 00081          IOW MB045210 == 0            " [ SC Req BKPB ] Command Se
00157 00082          MB045211 = 0;                " [ SC Req BKPB ] Command Se
00158 00083          MW05008 = 0;                " BKPB Command Code ID Reset
00159 00084          MB04572A = 0;                " BKPB Moving Flag Off
00160
00161 00085          JOINTO LBL0X;
00162
00163 00086          LBL08: " [Step.08] Last Dummy Break Pusher Bar Execute
00164
00165 00087          MB04572A = 1;                " BKPB Moving Flag On
00166
00167 00088          MSEE MPS268;                " Break Pusher Bar Last Pitch Execute 1 Cycle
00168
00169 00089          MB045211 = 1;                " [ SC Res BKPB ] Command Complete
00170 00090          IOW MB045210 == 0            " [ SC Req BKPB ] Command Se
00171 00091          MB045211 = 0;                " [ SC Req BKPB ] Command Se
00172 00092          MW05008 = 0;                " BKPB Command Code ID Reset
00173 00093          MB04572A = 0;                " BKPB Moving Flag Off
00174

```

```

00175          " Breaking Execute Moving Complete
00176 00094      MB04513A = 1;          " [Last Pitch] Breaking Execute Moving Complete Set
00177
00178 00095      JOINTO LBL0X;
00179
00180 00096      LBL09: " [Step.09]
00181 00097          JOINTO LBL0X;
00182
00183 00098      LBL10: " [Step.10] Break Pusher Bar Waiting Positi
00184
00185 00099          MB04572A = 1;          " BKPb Moving Flag On
00186
00187 00100          MSEE MPS265;          " Break Pusher Bar Waiting Position 1 Cycle
00188
00189 00101          MB045211 = 1;          " [ SC Res BKPb ] Command Complete
00190 00102          IOW MB045210 == 0      " [ SC Req BKPb ] Command Se
00191 00103          MB045211 = 0;          " [ SC Req BKPb ] Command Se
00192 00104          MW05008 = 0;          " BKPb Command Code ID Reset
00193 00105          MB04572A = 0;          " BKPb Moving Flag Off
00194
00195 00106          JOINTO LBL0X;
00196
00197 00107      LBL11: " [Step.11] Break Pusher Bar Cleaning Start Position
00198
00199 00108          MB04572A = 1;          " BKPb Moving Flag On
00200
00201 00109          MSEE MPS272;          " Break Pusher Bar Clean Start Position 1 Cycle
00202
00203 00110          MB045211 = 1;          " [ SC Res BKPb ] Command Complete
00204 00111          IOW MB045210 == 0      " [ SC Req BKPb ] Command Se
00205 00112          MB045211 = 0;          " [ SC Req BKPb ] Command Se
00206 00113          MW05008 = 0;          " BKPb Command Code ID Reset
00207 00114          MB04572A = 0;          " BKPb Moving Flag Of
00208
00209 00115          JOINTO LBL0X;
00210
00211 00116      LBL12: " [Step.12] Break Pusher Bar Cleaning End Position
00212
00213 00117          MB04572A = 1;          " BKPb Moving Flag On
00214
00215 00118          MSEE MPS273;          " Break Pusher Bar Clean End Position 1 Cycle
00216
00217 00119          MB045211 = 1;          " [ SC Res BKPb ] Command Complete
00218 00120          IOW MB045210 == 0      " [ SC Req BKPb ] Command Se
00219 00121          MB045211 = 0;          " [ SC Req BKPb ] Command Se
00220 00122          MW05008 = 0;          " BKPb Command Code ID Reset
00221 00123          MB04572A = 0;          " BKPb Moving Flag Of
00222
00223 00124          JOINTO LBL0X;
00224
00225 00125      LBL100:
00226 00126          JOINTO LBL0X;
00227 00127      LBL0X: SJOINT;
00228
00229 00128          MB045211 = 0;          " [ SC Res BKPb ] Command Complete
00230
00231          " Scribe Stop Req & Break Pusher BarStop Req & [ SC Req BKPb, TBL] Break Stop Req
00232 00129      IF MB045013 & MB045709 == 1;
00233 00130          DB00000 = 1;
00234 00131      IEND;
00235 00132      EOx;
00236 00133      WEND;
00237 00134      END;

```