

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : BKT Auto Task
00011 "# Function :
00012 "# Call Program : H60.3
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 00000 MW05508 = 0;
00021 00001 MW04522 = 0;
00022
00023 " Manual PTP
00024 00002 IOW MB045241 == 1 " Recipe / Parameter Update Complete Waiting
00025
00026 " Break Table Position & Speed Setting Update
00027 00003 MB55720 = 0; " Break Table Parameter Update Reset
00028 00004 MSEE MPS310; " BKT Position Update & Speed Setting
00029 00005 MB55720 = 1; " Break Table Parameter Update Set
00030
00031 " Break Table Unit Update Complete
00032 00006 IOW MB05571F | !MB000004 == 1;
00033
00034 " BKT Glass Carry Out Code Write
00035 00007 IF MB000004 & MB030036 & MB05572F == 1;
00036 " Break Table Y, Z Carry Out Position
00037 00008 MW04522 = 5;
00038 00009 IEND;
00039
00040 00010 DB00000 = 0;
00041 00011 WHILE DB00000 == 0 " Auto Stop
00042
00043 00012 MW05508 = MW04522;
00044
00045 00013 SFORK MW05508 == 1 ? LBL01 " [Step.01] Break Table Receive Before
00046 MW05508 == 2 ? LBL02 " [Step.02] Break Table Receive
00047 MW05508 == 3 ? LBL03 " [Step.03] Break Table Start
00048 MW05508 == 4 ? LBL04 " [Step.04] Break Table Execute
00049 MW05508 == 5 ? LBL05 " [Step.05] Break Table Carry Out
00050 MW05508 == 6 ? LBL06 " [Step.06]
00051 MW05508 == 7 ? LBL07 " [Step.07] Break Table Waiting
00052 MW05508 == 8 ? LBL08 " [Step.08] SP
00053 MW05508 == 9 ? LBL09 " [Step.09] SP
00054 DEFAULT ? LBL100;
00055
00056 00014 LBL01: " [Step.01] Break Table Receive Before
00057
00058 00015 MB04572B = 1; " BKT Moving Flag ON
00059
00060 " Break Table Receive Before
00061 00016 MSEE MPS300;
00062
00063 00017 MB045231 = 1; " [ SC Res BKT ] Command Complete
00064 00018 IOW MB045230 == 0 " [ SC Req BKT ] Command Set
00065 00019 MB045231 = 0; " [ SC Req BKT ] Command Set
00066 00020 MW05508 = 0; " BKT Command Code ID Reset
00067 00021 MB04572B = 0; " BKT Moving Flag OFF
00068
00069 00022 JOINTO LBL0X;
00070
00071 00023 LBL02: " [Step.02] Break Table Receive
00072
00073 00024 MB04572B = 1; " BKT Moving Flag ON
00074
00075 " Break Table Receive
00076 00025 MSEE MPS301;
00077
00078 00026 MB045231 = 1; " [ SC Res BKT ] Command Complete
00079 00027 IOW MB045230 == 0 " [ SC Req BKT ] Command Set
00080 00028 MB045231 = 0; " [ SC Req BKT ] Command Set
00081 00029 MW05508 = 0; " BKT Command Code ID Reset
00082 00030 MB04572B = 0; " BKT Moving Flag OFF
00083
00084 00031 JOINTO LBL0X;
00085
00086 00032 LBL03: " [Step.03] Break Table Start
00087

```

```

00088 00033      MB04572B = 1;          " BKT Moving Flag ON
00089
00090      " Break Table Start Position
00091 00034      MSEE MPS302;
00092
00093 00035      MB045231 = 1;          " [ SC Res BKT ] Command Complete
00094 00036      IOW MB045230 == 0      " [ SC Req BKT ] Command Se
00095 00037      MB045231 = 0;          " [ SC Req BKT ] Command Se
00096 00038      MW05508 = 0;          " BKT Command Code ID Reset
00097 00039      MB04572B = 0;          " BKT Moving Flag OFF
00098
00099 00040      JOINTO LBL0X;
00100
00101 00041      LBL04:          " [Step.04] Break Table Execute
00102
00103 00042      MB04572B = 1;          " BKT Moving Flag ON
00104
00105      " Break Table Execute 1 Cycle
00106 00043      MSEE MPS303;
00107
00108 00044      MB045231 = 1;          " [ SC Res BKT ] Command Complete
00109 00045      IOW MB045230 == 0      " [ SC Req BKT ] Command Se
00110 00046      MB045231 = 0;          " [ SC Req BKT ] Command Se
00111 00047      MW05508 = 0;          " BKT Command Code ID Reset
00112 00048      MB04572B = 0;          " BKT Moving Flag OFF
00113
00114 00049      JOINTO LBL0X;
00115
00116 00050      LBL05:          " [Step.05] Break Table Carry Out
00117
00118 00051      MB04572B = 1;          " BKT Moving Flag ON
00119
00120      " Break Table Carry Out Position 1 Cycle
00121 00052      IF MB56005 & MB56025 == 0;
00122 00053          MSEE MPS304;
00123 00054      IEND;
00124
00125 00055      IF !MB000004 == 1;
00126 00056          IF MW00053 <> 109;
00127 00057              MB045231 = 1;          " [ SC Res BKT ] Command Complete
00128 00058              IOW MB045230 == 0      " [ SC Req BKT ] Command Se
00129 00059              MB045231 = 0;          " [ SC Req BKT ] Command Se
00130 00060              MW05508 = 0;          " BKT Command Code ID Reset
00131 00061              MB04572B = 0;          " BKT Moving Flag OFF
00132 00062              MW04522 = 0;
00133 00063          IEND;
00134 00064      IEND;
00135
00136      " Stick Transfer1 InterFace
00137 00065      IF MB000004 & MB030036 == 1;
00138 00066          MSEE MPS311;          " Break Table → Pick Up Interface

00139 00067      IEND;
00140
00141
00142      " Break Table Standby Position 1 Cycle
00143 00068      IF !MB030036 == 1;
00144 00069          MSEE MPS305;
00145 00070          MW05508 = 0;
00146 00071          MW04522 = 0;
00147 00072          MB04572B = 0;
00148 00073      IEND;
00149
00150 00074      IF !MB000004 == 1;
00151 00075          MB045231 = 1;          " [ SC Res BKT ] Command Complete
00152 00076          IOW MB045230 == 0      " [ SC Req BKT ] Command Se
00153 00077          MB045231 = 0;          " [ SC Req BKT ] Command Se
00154 00078          MW05508 = 0;          " BKT Command Code ID Reset
00155 00079          MB04572B = 0;          " BKT Moving Flag OFF
00156 00080          MW04522 = 0;
00157 00081      IEND;
00158
00159 00082      JOINTO LBL0X;
00160
00161 00083      LBL06:          " [Step.06]
00162 00084          JOINTO LBL0X;
00163
00164 00085      LBL07:          " [Step.07] Break Table Waiting
00165
00166 00086      MB04572B = 1;          " BKT Moving Flag ON
00167
00168      " Break Table Waiting Position 1 Cycle
00169 00087      MSEE MPS305;
00170
00171 00088      MB045231 = 1;          " [ SC Res BKT ] Command Complete
00172 00089      IOW MB045230 == 0      " [ SC Req BKT ] Command Se
00173 00090      MB045231 = 0;          " [ SC Req BKT ] Command Se

```

```
00174 00091          MW05508 = 0;          " BKT Command Code ID Reset
00175 00092          MB04572B = 0;        " BKT Moving Flag OFF
00176
00177 00093          JOINTO LBL0X;
00178
00179 00094          LBL08:                  " [Step.08] SP
00180
00181 00095          JOINTO LBL0X;
00182
00183 00096          LBL09:                  " [Step.09] SP
00184 00097          JOINTO LBL0X;
00185
00186 00098          LBL100:
00187 00099          JOINTO LBL0X;
00188 00100          LBL0X: SJOINT;
00189
00190 00101          MB04572B = 0;          " BKT Moving Flag OFF
00191
00192          " Scribe Stop Request & Break Table Stop Request & [ SC Req BKP
00193 00102          IF MB045013 & MB045709 == 1;
00194 00103          DB00000 = 1;
00195 00104          IEND;
00196 00105          EOX;
00197 00106          WEND;
00198 00107          END;
```