

```

00001      " Name:Abs Origin Reset
00002      " Func:ABS Origin Setting(Reset the Address for 0)
00003      " From:MPM011
00004
00005      VAR;
00006 00000          LONG Axis_IDX1 = 0          " Axis Index1
00007 00001          LONG Axis_IDX2 = 0          " Axis Index2
00008 00002          LONG Axis_IDX3 = 0          " Axis Index3
00009      END_VAR;
00010
00011 00003          Axis_IDX1 = MW00061 - 1;
00012 00004          Axis_IDX2 = MW00062 - 1;
00013 00005          Axis_IDX3 = MW00063 - 1;
00014
00015 00006          MB102100[Axis_IDX1] = 1;
00016
00017 00007          SFORK    MW00060 == 1 ? Label1      " 1 Axis ABS Code
00018                      MW00060 == 2 ? Label2      " 2 Axis Gentry ABS Code
00019                      MW00060 == 3 ? Label3      " 3 Axis Gentry ABS Code
00020                      DEFAULT ? LabelD;
00021
00022 00008          Label1:
00023                      " Address Reset
00024
00025 00009                      MB101900[Axis_IDX1] = 1          " 1 Axis ABS Origin Setting Request
00026 00010                      IOW MB102000[Axis_IDX1] == 1      " 1 Axis ABS Origin Setting Response
00027 00011                      MB101900[Axis_IDX1] = 0          " 1 Axis ABS Origin Setting Request
00028 00012                      JOINTO LabelX;
00029
00030 00013          Label2:
00031                      " Address Reset
00032
00033 00014                      MB101900[Axis_IDX1] = 1          " 1 Axis ABS Origin Setting Request
00034 00015                      MB101900[Axis_IDX2] = 1          " 2 Axis ABS Origin Setting Request
00035 00016                      IOW MB102000[Axis_IDX1] == 1      " 1 Axis ABS Origin Setting Response
00036 00017                      IOW MB102000[Axis_IDX2] == 1      " 2 Axis ABS Origin Setting Response
00037 00018                      MB101900[Axis_IDX1] = 0          " 1 Axis ABS Origin Setting Request
00038 00019                      MB101900[Axis_IDX2] = 0          " 2 Axis ABS Origin Setting Request
00039
00040 00020                      JOINTO LabelX;
00041
00042 00021          Label3:
00043                      " Address Reset
00044
00045 00022                      MB101900[Axis_IDX1] = 1          " 1 Axis ABS Origin Setting Request
00046 00023                      MB101900[Axis_IDX2] = 1          " 2 Axis ABS Origin Setting Request
00047 00024                      MB101900[Axis_IDX3] = 1          " 3 Axis ABS Origin Setting Request
00048 00025                      IOW MB102000[Axis_IDX1] == 1      " 1 Axis ABS Origin Setting Response
00049 00026                      IOW MB102000[Axis_IDX2] == 1      " 2 Axis ABS Origin Setting Response
00050 00027                      IOW MB102000[Axis_IDX3] == 1      " 3 Axis ABS Origin Setting Response
00051 00028                      MB101900[Axis_IDX1] = 0          " 1 Axis ABS Origin Setting Request
00052 00029                      MB101900[Axis_IDX2] = 0          " 2 Axis ABS Origin Setting Request
00053 00030                      MB101900[Axis_IDX3] = 0          " 3 Axis ABS Origin Setting Request
00054
00055 00031                      JOINTO LabelX;
00056
00057 00032          LabelD:
00058 00033                      JOINTO LabelX;
00059 00034          LabelX: SJOINT;
00060
00061 00035      RET;

```