

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : [Data] Scribe Data Ca c
00011 "# Functior :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG SC_PRT_Data_L = 0;
00018 00001 LONG SC_PRT_NextData_L = 0;
00019 00002 LONG Scribe_Speed = 0;
00020 00003 LONG Upper_Roller_Set = 0;
00021 00004 LONG Lower_Roller_Set = 0;
00022 00005 LONG Scribe_Acc_Data = 0;
00023 00006 LONG Scribe_Dcc_Data = 0
00024 00007 LONG Parts_Count = 0;
00025 00008 LONG SC_PRT_DummyData_L = 0;
00026 00009 LONG Order_Index_BK = 0;
00027 END_VAR;
00028
00029 " Manual/Auto 구분
00030 00010 DB00020 = 0; " Manual Data
00031 00011 IF MB00004 == 1 " AutoRunning
00032 00012 DB00020 = 1; " Recipe Data
00033 00013 ELSE;
00034 00014 IF MB225580 == 1 " Recipe Data
00035 00015 DB00020 = 1; " Recipe Data
00036 00016 IEND;
00037 00017 IEND;
00038
00039 00018 SC_PRT_Data_L = (MW15410 - 1) * 10 " Now Scribe Index
00040 00019 SC_PRT_NextData_L = MW15410 * 10 " Next Scribe Index
00041 00020 Parts_Count = (MW15414 - 1) * 10 " Part's Number Count
00042 00021 SC_PRT_DummyData_L = (MW15410 - 2) * 10 " Now Scribe Index
00043 00022 Order_Index_BK = (MW15410 - 1) * 5 " Now Break Order No
00044
00045 " Standard Positio
00046 00023 DL00106 = ML26328; " DL00106 = ML26328 : Left Camera X Orig
in ~ Panel Center (0 Deg)
00047 " Main Transfer Turn Direction(0:0 1:90 2:180 3:-90)
00048 00024 IF GL49058 == 1 " DL00106 = ML26330 : Left Camera X Orig
in ~ Panel Center (90 Deg)
00049 00025 DL00106 = ML26330;
00050 00026 IEND;
00051 00027 IF GL49058 == 3 " DL00106 = ML26330 : Left Camera X Orig
in ~ Panel Center (90 Deg)
00052 00028 DL00106 = ML26330;
00053 00029 IEND;
00054
00055 00030 DL00108 = ML04872 " DL00108 = ML26332 : Chuck Y Origin Chu
ck Upper ~ Camera Center (0 Deg)
00056 " Main Transfer Turn Direction(0:0 1:90 2:180 3:-90)
00057 00031 IF GL49058 == 1 " DL00108 = ML26334 : Chuck Y Origin Chu
ck Upper ~ Camera Center (90 Deg)
00058 00032 DL00108 = ML04874;
00059 00033 IEND;
00060 00034 IF GL49058 == 3 " DL00108 = ML26334 : Chuck Y Origin Chu
ck Upper ~ Camera Center (90 Deg)
00061 00035 DL00108 = ML04874;
00062 00036 IEND;
00063
00064 " Align Mark Data
00065 00037 ML01110 = GL100124[SC_PRT_Data_L " Align Left X Mar
00066 00038 ML01112 = GL100126[SC_PRT_Data_L " Align Right X Mar
00067 00039 ML01114 = GL100122[SC_PRT_Data_L " Align Y Mar
00068 00040 ML01116 = GL100120[SC_PRT_Data_L " Mark ID
00069 00041 ML01118 = GL100128[SC_PRT_Data_L " Dummy Align Mode (0: Unuse / 1: Use)
00070
00071 " Next Pitch Align Mark Data
00072 00042 ML01610 = GL100124[SC_PRT_NextData_L " Align Left X Mark
00073 00043 ML01612 = GL100126[SC_PRT_NextData_L " Align Right X Mark
00074 00044 ML01614 = GL100122[SC_PRT_NextData_L " Align Y Mark
00075 00045 ML01616 = GL100120[SC_PRT_NextData_L " Mark ID
00076
00077 " Scribe Dat:
00078 " Scribe Speed
00079 " [Recipe] Scribe Speed Write
00080 00046 IF GL100048[SC_PRT_Data_L] < GL100078[SC_PRT_Data_L]
00081 00047 Scribe_Speed = GL100078[SC_PRT_Data_L];

```

```

00082 00048 ELSE;
00083 00049 Scribe_Speed = GL100048[SC_PRT_Data_L
00084 00050 IEND;
00085
00086 " [Manual] Scribe Speed Write
00087 00051 IF DB00020 == 0;
00088 00052 Scribe_Speed = ML22564;
00089 00053 IEND;
00090
00091 " Scribe Speed Setting Error
00092 00054 IF Scribe_Speed == 0;
00093 00055 MB045380 = 1;
00094 00056 DB000088 = 1;
00095 00057 IOW DB000088 == 0;
00096 00058 IEND;
00097
00098 " RollerBreak Dat
00099 00059 ML01176 = GL100170[SC_PRT_Data_L
00100 00060 ML01178 = GL100172[SC_PRT_Data_L
00101 00061 ML01180 = GL100174[SC_PRT_Data_L
00102 00062 ML01182 = GL100176[SC_PRT_Data_L
00103 00063 ML01184 = GL100178[SC_PRT_Data_L
00104 00064 ML01186 = GL100180[SC_PRT_Data_L
00105
00106 " Scribe Cutter/Roller Option Select (Unuse)
00107 " [Recipe] Roller/Cutter Use Select Write
00108 00065 Upper_Roller_Set = GL100194[SC_PRT_Data_L
00109 00066 Lower_Roller_Set = GL100196[SC_PRT_Data_L
00110
00111 " [Manual] Roller/Cutter Use Select Write (Unuse)
00112 00067 IF DB00020 == 0;
00113 00068 IF MB225584 == 1;
00114 " Upper Roller Use (Unuse)
00115 00069 Upper_Roller_Set = 1;
00116 00070 ELSE;
00117 " Upper Cutter Use (Unuse)
00118 00071 Upper_Roller_Set = 0;
00119 00072 IEND;
00120 00073 IF MB225585 == 1;
00121 " Lower Roller Use (Unuse)
00122 00074 Lower_Roller_Set = 1;
00123 00075 ELSE;
00124 " Lower Cutter Use (Unuse)
00125 00076 Lower_Roller_Set = 0;
00126 00077 IEND;
00127 00078 IEND;
00128
00129 " Scribe Acc/Dcc Value Set
00130 " [Recipe] Scribe Acc/Dcc Value Write
00131 00079 Scribe_Acc_Data = GL100008[SC_PRT_Data_L];
00132 00080 Scribe_Dcc_Data = GL100010[SC_PRT_Data_L];
00133
00134 " [Manual] Scribe Acc/Dcc Value Write
00135 00081 IF DB00020 == 0;
00136 00082 Scribe_Acc_Data = ML22566;
00137 00083 Scribe_Dcc_Data = ML22568;
00138 00084 IEND;
00139
00140 " Scribe ACC, DCC Setting Error
00141 00085 IF Scribe_Acc_Data == 0;
00142 00086 MB045381 = 1;
00143 00087 DB000088 = 1;
00144 00088 IOW DB000088 == 0;
00145 00089 IEND;
00146 00090 IF Scribe_Dcc_Data == 0;
00147 00091 MB045381 = 1;
00148 00092 DB000088 = 1;
00149 00093 IOW DB000088 == 0;
00150 00094 IEND;
00151
00152 00095 ML01120 = 0;
00153 00096 ML01122 = 0;
00154 00097 ML01124 = Scribe_Speed
00155 00098 ML01126 = 0;
00156 00099 ML01128 = 0;
00157 00100 ML01130 = 0;
00158 00101 ML01132 = 0;
00159 00102 ML01134 = 0;
00160 00103 ML01136 = 0;
00161 00104 ML01138 = 0;
00162 00105 ML01140 = 0;
00163 00106 ML01142 = Upper_Roller_Set
nuse)
00164 00107 ML01144 = Lower_Roller_Set
nuse)
00165 00108 ML01146 = Scribe_Acc_Data
00166 00109 ML01148 = Scribe_Dcc_Data

```

" Roller Break Use (Unuse)
" Roller Break Deep (Unuse)
" Roller Break Pressure (Unuse)
" Roller Break ACC (Unuse)
" Roller Break DCC (Unuse)
" Roller Break Speed (Unuse)
" Upper Roller Use Select (Unuse)
" Lower Roller Use Select (Unuse)
" Upper X Pitch Offset
" Lower X Pitch Offset (Unuse)
" Upper Cutting Speed
" Lower Cutting Speed (Unuse)
" Upper Cutting Depth
" Lower Cutting Depth (Unuse)
" Upper Cutting Pressure
" Lower Cutting Pressure (Unuse)
" Upper Push Pressure
" Lower Push Pressure (Unuse)
" Upper Push Amount
" Upper Roller Use(0:Cutter 1:Roller) (Unuse)
" Lower Roller Use(0:Cutter 1:Roller) (Unuse)
" Cutting ACC
" Cutting DCC

```

00167
00168      " Scribe Data Calc
00169 00110      ML01150 = DL00106 - (GL21002 / 2)
00170 00111      ML01152 = ML01150 + GL21002
00171 00112      ML01154 = DL00108 - GL21000 + GL2118
00172
00173 00113      ML01156 = ML01150 + ML01110
00174 00114      IF CW00001 == 1
rse)
00175 00115          ML01158 = ML01152 - ML01112 - (ML26300 - ML26302)
00176 00116          ML01160 = ML01158
00177 00117          ML01162 = ML01158
00178 00118      ELSE;
00179 00119          ML01158 = ML01152 - ML01112
00180 00120          ML01160 = ML01156
00181 00121          ML01162 = ML01156
00182 00122      IEND;
00183
00184      " Next Pitch Alignment Position
00185 00123      ML01656 = ML01150 + ML01610;
00186 00124      IF CW00001 == 1;
00187 00125          ML01658 = ML01152 - ML01112 - (ML26300 - ML26302);
00188 00126      ELSE;
00189 00127          ML01658 = ML01152 - ML01112;
00190 00128      IEND;
00191
00192      " Dummy Alignment X Pos (Unuse)
00193 00129      ML01190 = ML01150 + GL21196
00194 00130      IF CW00001 == 1
rse)
00195 00131          ML01192 = ML01152 - GL21198 - (ML26300 - ML26302)
(Unuse)
00196 00132          ML01194 = ML01158
(Unuse)
00197 00133          ML01196 = ML01158
(Unuse)
00198 00134      ELSE;
00199 00135          ML01192 = ML01152 - GL21198
00200 00136          ML01194 = ML01190
00201 00137          ML01196 = ML01190
00202 00138      IEND;
00203
00204      "Cut Line + Support Volume
00205 00139      DL00152 = GL500054[Order_Index_BK] - ML26340;
00206 00140      ML01164 = ML01154 + ML01114 - DL0015
00207
00208      " Dummy Alignment Y Pos (Unuse)
00209 00141      ML01166 = ML01154 + GL21194
)
00210
00211      " Scribe Chuck Y Break Upper Pos
00212 00142      DL00150 = GL500052[Order_Index_BK]
00213 00143      ML01168 = ML01164 + GL500054[Order_Index_BK] + DL0015
00214 00144      ML01174 = DL00108 - GL21000 + GL21186 - DL0015
00215
00216
00217
00218      " 0 Point Detection Data
00219 00145      DW00010 = 0;
00220 00146      DW00012 = 0;
00221 00147      WHILE DW00012 < 10
00222 00148          IF GL21056[DW00010] <> 0;
00223 00149              DW00010 = DW00010 + 1;
00224 00150          IEND;
00225
00226 00151          DW00012 = DW00012 + 1;
00227 00152      EOX;
00228 00153      WEND;
00229
00230 00154      IF GL21054 <> DW00010;
00231 00155          MB045390 = 1;
00232 00156      IEND;
00233
00234 00157      ML01200 = ML01154 + GL21076
ition
00235
00236 00158      IF CW00001 == 1
rse)
00237 00159          ML01210 = ML01150 + GL21056
ition 1
00238 00160          ML01212 = ML01150 + GL21058
ition 2
00239 00161          ML01214 = ML01150 + GL21060
ition 3
00240 00162          ML01216 = ML01150 + GL21062
ition 4
00241 00163          ML01218 = ML01150 + GL21064

```

```

00242 00164      ition 5      ML01220 = ML01150 + GL21060      " Upper Left Cutter X 0 Point Detect Pos
00243 00165      ition 6      ML01222 = ML01150 + GL21068      " Upper Left Cutter X 0 Point Detect Pos
00244 00166      ition 7      ML01224 = ML01150 + GL21070      " Upper Left Cutter X 0 Point Detect Pos
00245 00167      ition 8      ML01226 = ML01150 + GL21072      " Upper Left Cutter X 0 Point Detect Pos
00246 00168      ition 9      ML01228 = ML01150 + GL21074      " Upper Left Cutter X 0 Point Detect Pos
00247 00169      ition 10      ELSE;
00248 00170      ML01210 = ML01150 + GL21056 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00249 00171      ition 1      ML01212 = ML01150 + GL21058 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00250 00172      ition 2      ML01214 = ML01150 + GL21060 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00251 00173      ition 3      ML01216 = ML01150 + GL21062 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00252 00174      ition 4      ML01218 = ML01150 + GL21064 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00253 00175      ition 5      ML01220 = ML01150 + GL21066 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00254 00176      ition 6      ML01222 = ML01150 + GL21068 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00255 00177      ition 7      ML01224 = ML01150 + GL21070 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00256 00178      ition 8      ML01226 = ML01150 + GL21072 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00257 00179      ition 9      ML01228 = ML01150 + GL21074 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00258 00180      ition 10      IEND;
00259
00260 00181      ML01230 = GL21054      " 0 Point Detect Execute Count
00261 00182      IF MB15422A == 1;      " 0 Level Search Running(Table to Table)
00262 00183      ML01200 = ML01154 + GL21080      " Upper Left Cutter Y 0 Point Detect Pos
00263
00264 00184      ition      IF CW000001 == 1      " Scribe Direction (0: Forward / 1: Reverse)
00265 00185      ML01210 = ML01150 + GL21078      " Upper Left Cutter X 0 Point Detect Pos
00266 00186      ELSE;
00267 00187      ML01210 = ML01150 + GL21078 - ML2630      " Upper Left Cutter X 0 Point Detect Pos
00268 00188      ition (Unuse)
00269 00189      IEND;
00270
00271      " Chuck Y Measurement Data
00272 00190      ML01258 = ML44038      " Scribe Chuck Y Measurement Position
00273
00274 00191      RET;

```