

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : [Move] Scribe Chuck Y
00011 "# Functior :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 " Scribe Chuck
00018 00000 LONG IDX_SCHY1 = 48;
00019 00001 LONG IDX_SCHY2 = 49;
00020 " Index
00021 00002 LONG Axis_Index_SCHY1 = 0;
00022 END_VAR;
00023
00024 00003 IF MB030035 == 1;
00025 00004 IOW MB09018E | MB00800 == 1 " [Sensor] SCT Scribe Chuck All Vacuum O
n
00026 00005 IEND;
00027
00028 00006 IOW MB071020 | MB04574E == 1 " MTR Z StandBy Pos or Non Interference
Position
00029
00030
00031 // IF MB071003 & !MB071020 & MB04574E == " MTR Z Not StandBy Pos and Non Interfer
ence Position
00032 // IF ILA816 > ML16096;
00033 //// IOW ILA816 < ML16096 " SHCY Target Pos + Direction
00034 // IOW MB071020 == 1;
00035 // IEND;
00036 // IEND;
00037
00038
00039 // IF MB045013 == 0;
00040 // " Table Break Command Code
00041 // IOW MW05508 <> 5;
00042 // IEND;
00043
00044 " Index Calc
00045 00007 Axis_Index_SCHY1 = IDX_SCHY1 * 50;
00046
00047 " Sync Mode Off & Position Comp
00048 00008 IOW MB045702 & MB045704 & MB045705 == 1;
00049
00050 " Sync Mode Command OF
00051 00009 IOW !MB045700 | !MB045701 == 1;
00052
00053 " Scribe Chuck Y - CV Sync Mode Setting
00054 " Manual Sync Mode Start
00055 00010 MB045700 = 1;
00056 00011 IOW MB045700 == 1;
00057 " Sync Mode On & Position Comp
00058 00012 IOW MB045703 & MB045705 == 1;
00059
00060 " Axis Update
00061 00013 PLD [VSCHKY];
00062
00063 00014 DL00000 = ML40012[Axis_Index_SCHY1] * 60;
00064 00015 DL00002 = ML10800[IDX_SCHY1];
00065 00016 DL00004 = ML11000[IDX_SCHY1]/8;
00066 00017 DL00006 = ML11200[IDX_SCHY1]/8;
00067
00068 00018 IF MB00004 == 1;
00069 00019 IF MW04518 == 2;
00070 00020 IF ML44812 <= 100000;
00071 00021 DL00000 = (ML44812 * 2) * 60;
00072 00022 IEND;
00073 00023 IEND;
00074 00024 IEND;
00075
00076 00025 FMX tDL00002;
00077 00026 IAC tDL00004;
00078 00027 IDC tDL00006;
00079
00080 00028 IF ML26610 <> 0;
00081 00029 DL00010 = ML16096 - ILA816;
00082 00030 IF DL00010 < 0;
00083 00031 DL00010 = DL00010 * -1;
00084 00032 IEND;

```

```

00085 00033      IF DL00010 < ML26610;
00086 00034          DL00000 = ML26612 * 60;
00087 00035      IEND;
00088 00036      IEND;
00089
00090      " Scribe Chuck Y Movin
00091 00037      MVS [VSCHKY]ML16096 FDL00000 pfi
00092
00093 00038      MB045700 = 0;
00094 00039      IOW MB045700 == 0;
00095      " Sync Mode Off & Position Con
00096 00040      IOW MB045702 & MB045704 & MB045705 == 1;
00097
00098 00041      RET;

```

			MPS170 : [Move] Scribe Chuck Y	P00002
--	--	--	--------------------------------	--------