

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : [Step.06] Scribe 1 Cycle
00011 "# Functior :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 " Scribe Cutter
00018 00000 LONG IDX_CX = 32;
00019 00001 LONG IDX_CAMX = 33;
00020
00021 " Scribe Shift
00022 00002 LONG IDX_CS = 35;
00023
00024 " Scribe Chuck
00025 00003 LONG IDX_SCHY1 = 48;
00026 00004 LONG IDX_SCHY2 = 49;
00027
00028 " Scribe Camera
00029 00005 LONG IDX_LCAMY = 37;
00030 00006 LONG IDX_LCAMZ = 38
00031 00007 LONG IDX_RCAMY = 39
00032 00008 LONG IDX_RCAMZ = 40;
00033
00034 00009 LONG Axis_POS_CAMX = 0;
00035
00036 BOOL Scribe_EStop %MB047350;
00037 BOOL SCStop_Dialog %MB21462E;
00038 BOOL SCStop_DRespos %MB20522E;
00039 BOOL SCStop_RecipeCu %MB204520;
00040 BOOL SCStop_Agre %MB204540;
00041 BOOL Data_Renew
00042 END_VAR;
00043
00044 00010 Axis_POS_CAMX = IDX_CAMX * 50;
00045
00046 " Chuck Interference Check
00047 00011 DL00026 = ML04874 - ML26324;
00048 00012 IOW IL0A816 < DL00026;
00049
00050 " Manual PTP
00051 00013 DW00002 = 0;
00052 00014 IF !MB000004 == 1;
00053 00015 IF MW00051 == 83;
00054 00016 DB000020 = 1;
00055 00017 IEND;
00056 00018 IF MW00051 == 84;
00057 00019 DB000021 = 1;
00058 00020 t IEND;
00059 00021 IEND;
00060
00061 00022 DW00010 = 0;
00062 " Scribe Execute Complete Check
00063 00023 IF MB045132 == 0;
00064 " Scribe 1 Cycle
00065 " Cutter Z Waiting Position
00066 00024 IF MB045740 | MB045743 == 0;
00067 00025 IOW MW04842 == 0;
00068 00026 MW04842 = 46;
00069 00027 MSEE MPS198;
00070 00028 IOW MW04842 == 0
00071 00029 IEND;
00072 00030 IOW MB045740 | MB045743 == 1
00073
00074 00031 Data_Renew = ON;
00075 00032 IF Scribe_EStop == 1
00076 00033 IF CW00001 == 1
00077 00034 rse) DL00040 = ML04910 + ML26372
00078 00035 DL00042 = ML04906 + ML4373C
00079
00080 " Scribe StopRetry Position
00081 00036 PLD [CAMX][LCAMY];
00082 00037 MOV [CAMX]DL00040 [LCAMY]DL00042;
00083 00038 ELSE;
00084 00039 DL00040 = ML04910 + ML26302 - ML2637
00085 00040 DL00042 = ML04908 + ML4373C

```

```

00086
00087      " Scribe StopRetry Position
00088 00041      PLD [CX][LCAMY];
00089 00042      MOV [CX]DL00040 [LCAMY]DL00040;
00090 00043      IEND;
00091
00092 00044      SCStop_Dialog = 1;
00093 00045      IOW SCStop_DRespons == 1;
00094
00095 00046      IOW MB045013 | SCStop_RecipeCut | SCStop_Agree == 1;
00096
00097      " Alignment Data Check
00098      " X1/Y1 and X2/Y2 Data Not 0, Check. OK
00099 00047      IF !MB00800 & !DB000021 == 1      " Idling & don't Cutter
00100 00048          IF ML01118 == 1      " DUMMY ALIGN MODE (0: Unuse / 1: Use)
00101 00049              IF ML15102 == 0      " Alignment Data (X1)
00102 00050                  ML15102 = ML15112      " Alignment Data (X1)
00103 00051                  IEND;
00104 00052              IF ML15104 == 0      " Alignment Data (Y1)
00105 00053                  ML15104 = ML15114      " Alignment Data (Y1)
00106 00054                  IEND;
00107 00055              IF ML15106 == 0      " Alignment Data (X2)
00108 00056                  ML15106 = ML15116      " Alignment Data (X2)
00109 00057                  IEND;
00110 00058              IF ML15108 == 0      " Alignment Data (Y2)
00111 00059                  ML15108 = ML15118      " Alignment Data (Y2)
00112 00060                  IEND;
00113 00061          IEND;
00114
00115 00062          IF ML15102 == 0      " Alignment Data (X1)
00116 00063              DB000100 = 1;
00117 00064              IEND;
00118 00065          IF ML15104 == 0      " Alignment Data (Y1)
00119 00066              DB000101 = 1;
00120 00067              IEND;
00121 00068          IF ML15106 == 0      " Alignment Data (X2)
00122 00069              DB000102 = 1;
00123 00070              IEND;
00124 00071          IF ML15108 == 0      " Alignment Data (Y2)
00125 00072              DB000103 = 1;
00126 00073              IEND;
00127
00128 00074          IF DB000100 & DB000101 == 1;
00129 00075              " Alignment N.G Judge
00130 00076              MB04539B = 1;
00131 00077              MB000015 = 1;
00132 00078              EOX;
00133 00079              IEND;
00134
00135 00080          IF DB000102 & DB000103 == 1;
00136 00081              " Alignment N.G Judge
00137 00082              MB04539B = 1;
00138 00083              MB000015 = 1;
00139 00084              EOX;
00140 00085              IEND;
00141 00086          IEND;
00142
00143 00087          IF MB045013 == 1;
00144 00088              SCStop_Dialog = 0;
00145 00089              RET;
00146 00090          IEND;
00147
00148 00091          IF SCStop_RecipeCut == 1;
00149 00092              Data_Renew = ON;
00150 00093              MB047351 = 0;      " Scribe Run Chec
00151 00094              MB047350 = 0;      " Scribe_StopRetr
00152 00095              SCStop_Dialog = 0
00153 00096          IEND;
00154
00155 00097          IF SCStop_Agree == 1;
00156 00098              Data_Renew = OFF;
00157
00158 00099          IF CW00001 == 1      " Scribe Direction (0: Forward / 1:
Reverse)
00159          " UPCX START POSITION
00160 00098          IF ML01142 == 0      " Upper Roller Use(0:Cutter 1:Roller
)
00161 00099              ML04914 = ML04910 - ML20456      " Upper Cutter X
00162 00100          ELSE;
00163 00101              ML04914 = ML04910 - ML20456 - ML2634      " Upper Cutter X
00164 00102          IEND;
00165
00166          " LOCX START POSITION
00167 00103          IF ML01144 == 0      " Lower Roller Use(0:Cutter 1:Roller
)
00168 00104              ML04916 = ML04912 - ML20456      " Lower Cutter X
00169 00105          ELSE;

```

```

00170 00106          ML04916 = ML04912 - ML20456 - ML2634 " Lower Cutter X
00171 00107          IEND;
00172 00108      ELSE;
00173          " UPCX START POSITION
00174 00109          IF ML01142 == 0 " Upper Roller Use(0:Cutter 1:Roller
)
00175 00110          ML04914 = ML04910 + ML20456 " Upper Cutter X
00176 00111      ELSE;
00177 00112          ML04914 = ML04910 + ML20456 + ML2634 " Upper Cutter X
00178 00113      IEND;
00179
00180      " LOCX START POSITION
00181 00114      IF ML01144 == 0 " Lower Roller Use(0:Cutter 1:Roller
)
00182 00115          ML04916 = ML04912 + ML20456 " Lower Cutter X
00183 00116      ELSE;
00184 00117          ML04916 = ML04912 + ML20456 + ML2634 " Lower Cutter X
00185 00118      IEND;
00186 00119      IEND;
00187
00188          //MB047350 = 0, " Scribe_StopRetr
00189 00120          SCStop_Dialog = 0
00190 00121      IEND;
00191 00122      IF CW00001 == 1 " Scribe Direction (0: Forward / 1:
Reverse)
00192 00123          VEL [CAMX]ML43312;
00193          " Scribe Camera StandBy Position
00194 00124          PLD [LCAMY][LCAMZ][CAMX]
00195 00125          MOV [LCAMY]ML43730 [LCAMZ]ML43930 [CAMX]ML433;
00196 00126      ELSE;
00197          " Scribe Camera StandBy Position
00198 00127          PLD [LCAMY][LCAMZ];
00199 00128          MOV [LCAMY]ML43730 [LCAMZ]ML43930;
00200 00129      IEND;
00201 00130      IEND;
00202
00203 00131      IF Data_Renew == ON;
00204          " Scribe Data, Pitch Calc.
00205 00132          MSEE MPS167; " Scribe Data Manage
00206 00133      IEND;
00207
00208 00134      IF DB00021 == 0 " Scribe Start Position 1 Cycle Mo
00209          " Scribe Start Position
00210 00135          MSEE MPS190; " Scribe Start Positio
00211 00136      ELSE; " Scribe Complete Position 1 Cycle Mo e
00212          " CAMX Escape Position
00213 00137          ML16066 = ML43330 " CAMX Waiting Position
00214 00138          IOW MB04577A == 1 " CAMX Moving Permission
00215 00139          MOV [CAMX]ML16066;
00216 00140          IOW MB046010 == 1 " CAMX Waiting Position Check
00217 00141      IEND;
00218
00219 00142      IF MB000023 == 1;
00220 00143          MB045159 = 1; " Step Mode Next Fla
00221 00144          IOW (!MB21684D | MB20544E) | MB045013 == " Step Mode
00222 00145          MB045159 = 0; " Step Mode Next Fla
00223 00146      IEND;
00224
00225          " Scribe 1 Cycle
00226      IF DB000020 == 0 " Scribe Complete Position 1 Cycle Mo e
00227 00147          " Cutter ,Scribe - 500um Position Move
00228          IF !MB045746 == 1;
00229 00148          IF !MB00800 & MB00802 & !DB000021 == " Idling & don't Cutter
00230 00149          IOW MW04842 == 0;
00231 00150          MW04842 = 43; " Cutter Z Code Write
00232 00151          MSEE MPS198; " Cutter Z Motion
00233 00152          IOW MW04842 == 0
00234 00153      IEND;
00235 00154      IEND;
00236 00155      IEND;
00237          " Scribe Start Before Delay Tir
00238 00156          TIM TMW26246;
00239
00240          " Cutter Z Scribe Start Position Move
00241 00157          IF !MB00800 & MB00802 & !DB000021 == " Idling & don't Cutter
00242 00158          IOW MW04842 == 0;
00243 00159          MW04842 = 44; " Cutter Z Code Write
00244 00160          MSEE MPS198; " Cutter Z Motion
00245 00161          IOW MW04842 == 0;
00246 00162      IEND;
00247
00248          " Cutter Z Torque Pressure Check
00249          " Scribe Torque 80% Complete. OK
00250 00163          IF !MB00800 & MB00802 & !DB000021 == " Idling & don't Cutter

```

```

00251          " Scribe Torque Check Request
00252 00164      MB15420B = 1;
00253          " Scribe Torque Judge Waitir
00254 00165      IOW MB15420C | MB15420D == 1;
00255
00256          " Scribe Torque Setting OK
00257 00166      IF MB15420C == 1;
00258          " Scribe Start Delay Tim
00259 00167          TIM TMW26248;
00260 00168      IEND;
00261
00262          " Scribe Torque Setting N
00263 00169      IF MB15420D == 1;
00264          " Error Display
00265 00170          MB045382 = 1;
00266 00171      IEND;
00267          " Scribe Torque Check Request Result
00268 00172      MB15420B = 0;
00269 00173      IEND;
00270
00271
00272          " [Chuck Y Orign Position Camera Lens Center] - Chuck Y Escape Parameter ( Test)
00273 00174      IOW IL0A816 < ML04874 - ML26324;
00274
00275 00175      IF MB15200D == 1          " JustCutMode
00276 00176          MSEE MPS204;          " 1Scribe(JustCut)
00277 00177      ELSE;
00278 00178          MSEE MPS203;          " 1Scribe
00279 00179      IEND;
00280
00281          " Scribe End Delay Tim
00282 00180      TIM TMW26244;
00283
00284          " Cutter Z Waiting Position Move
00285 00181      IF MB045740 | MB045743 == 0;
00286 00182          IF CW00098 == 0;
00287 00183              IOW MW04842 == 0;
00288 00184              MW04842 = 46;
00289 00185              MSEE MPS198;
00290 00186              MW04842 = 0;
00291 00187              IOW MW04842 == 0;
00292 00188          ELSE;
00293 00189              IOW MW04514 == 0;
00294 00190              MW04514 = 9;          " Scribe → Scribe X Cutter Comm
00295 00191          MB045150 = 1;          " Scribe → Scribe X Cutter Comm
00296 00192      and Execute Bit ON      IOW MB045151 == 1          " Scribe ← Scribe X Cutter Comm
00297 00193      and Complete Bit ON      MB045150 = 0;          " Scribe → Scribe X Cutter Comm
00298 00194      and Execute Bit OFF      IOW MB045151 == 0          " Scribe ← Scribe X Cutter Comm
00299 00195      and Complete Bit ON
00300 00195          IOW ILA116 <= ML43446;
00301
00302 00196          IF MB053080 & !MB00080D == 1          " Break Pusher Bar Use (0: Unuse
00303 00197      1: Use)          IF MB09027F | MB000800 == 0;          " Cutting Table Vacuum Break On
00304          " Break Table Glass Data Exist
00305 00198          MB04515D = 1;          " [Cutting] Low Pressure Blow On
00306 00199      Flag          MW04846 = 2;          " [Cutting] Table Vacuum Off
00307 00200          MW04848 = 1;          " [Cutting] Table Blow On
00308 00201          IF MB030034 | (MB071023 & MB045281 & MB070271) == 1;
00309 00202              MW04946 = 1;          " [Fix] Table Vacuum On
00310 00203              MW04948 = 2;          " [Fix] Table Blow Off
00311 00204          ELSE;
00312 00205              IF MB045780 & (MB071003 & MB071023) == 1;
00313 00206                  MW04946 = 10;          " [Fix] Table Vacuum On
00314 00207                  MW04948 = 10;          " [Fix] Table Blow Of
00315 00208          ELSE;
00316 00209              MW04946 = 2;          " [Fix] Table Vacuum Off
00317 00210              MW04948 = 1;          " [Fix] Table Blow On
00318 00211          IEND;
00319 00212      IEND;
00320 00213      MSEE MPS259;          " Table Vacuum & Floating
00321 00214      IEND;
00322 00215      IEND;
00323 00216      IF MB058100 & !MB00080D == 1;
00324 00217          IF (MB09027F & MB05686F) | MB000800 == 0 " Break Table Vacuum Break C
00325 00218          MB04515D = 1;          " [Cutting] Low Pressure Blow On
00326 00219      Flag          MW04846 = 6;          " [Cutting, Break] Table Vacuum
00327 00220      Off

```

```
00327 00220          MW04848 = 5;          " [Cutting, Break] Table Blow On
00328 00221          IF MB030034 | (MB071023 & MB045281 & MB070271) == 1;
00329 00222              MW04946 = 1;      " [Fix] Table Vacuum On
00330 00223              MW04948 = 2;      " [Fix] Table Blow Off
00331 00224          ELSE;
00332 00225              MW04946 = 2;      " [Fix] Table Vacuum Off
00333 00226              MW04948 = 1;      " [Fix] Table Blow On
00334 00227          IEND;
00335 00228          MSEE MPS259;          " Table Vacuum & Floating
00336 00229          IEND;
00337 00230          IEND;
00338 00231          IEND;
00339 00232          IEND;
00340
00341          " Scribe Cutting Run Torque Fail Check
00342 00233          IF MB047352 & !MB000800 == 1;
00343 00234              MB04539D = 1;          " Lv3 Cutting Running Torque Maintain Fa

il Alarm
00344 00235          IEND;
00345
00346          " Scribe Execute Complete Set
00347 00236          IF MB000004 == 1;
00348 00237              MB045132 = 1;          " Scribe Comp
00349 00238          ELSE;
00350 00239              IF MW000051 == 98;
00351 00240                  MB045132 = 1;          " Scribe Comp
00352 00241                  MW04511 = 7;
00353                      " Scribe Start Flag Bit ON
00354 00242                  MB045728 = 0;
00355 00243              IEND;
00356 00244          IEND;
00357
00358 00245          IF MB000023 == 1;
00359 00246              MB045159 = 1;          " Step Mode Next Fla
00360 00247              IOW (!MB21684D | MB20544E) | MB045013 == " Step Mode
00361 00248              MB045159 = 0;      " Step Mode Next Fla
00362 00249          IEND;
00363 00250          IEND;
00364 00251          IEND;
00365
00366 00252          RET;
```