

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : [Step.07] Line Check Operation
00011 "# Function :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 " Line Check Dialog Display
00021 00000 MB21462A = 1;
00022
00023 " Line Check Execute Bit Rese
00024 00001 DB00010 = 0;
00025 00002 DW00010 = 0;
00026
00027 00003 MB21813B = 0; " [Line Check] Finish
00028 00004 MB21813C = 0; " [Line Check] Top Surface
00029 00005 MB21813D = 0; " [Line Check] Bottom Surface
00030 00006 MB21813E = 0; " [Line Check] Start Position
00031 00007 MB21813F = 0; " [Line Check] End Position
00032
00033 00008 MB21813C = 1; " [Line Check] Only Top Surface Select
00034
00035 00009 WHILE DB00010 == 0;
00036 " Upper Selectiong
00037 00010 IF (MB20673C | MB00000F) & !MB21813C == 1;
00038 00011 MB21813C = 1;
00039 00012 MB21813D = 0;
00040 00013 IEND;
00041
00042 " Lower Selection
00043 00014 IF (MB20673D & !MB00000F) & !MB21813D == 1;
00044 00015 MB21813C = 0;
00045 00016 MB21813D = 1;
00046 00017 IEND;
00047
00048 " Line Check Position Selectio
00049 00018 IF MB21813C & MB20673E == 1 " Top Surface Start Position
00050 00019 DW00010 = 1;
00051 00020 IEND;
00052
00053 00021 IF MB21813C & MB20673F == 1 " Top Surface End Position
00054
00055 00022 DW00010 = 2;
00056 00023 IEND;
00057
00058 00024 IF MB21813D & MB20673E == 1 " Bottom Surface Start Position
00059 00025 DW00010 = 3;
00060 00026 IEND;
00061
00062 00027 IF MB21813D & MB20673F == 1 " Bottom Surface End Position
00063 00028 DW00010 = 4;
00064 00029 IEND;
00065
00066 00030 SFORK DW00010 == 1 ? LBL01 " Top Surface Start Position
00067 DW00010 == 2 ? LBL02 " Top Surface End Position
00068 DW00010 == 3 ? LBL03 " Bottom Surface Start Position
00069 DW00010 == 4 ? LBL04 " Bottom Surface End Position
00070 DEFAULT ? LBL100;
00071
00072 00031 LBL01:
00073 " Top Surface Scribe Start Position
00074 00032 MB21813E = 1;
00075 00033 MB21813F = 0;
00076
00077 00034 MW04862 = 13;
00078 " L Camera Line Check Position Move
00079 00035 MSEE MPS192;
00080 00036 MW04862 = 0;
00081 00037 DW00010 = 0;
00082
00083 00038 JOINTO LBL0X;
00084
00085 00039 LBL02:
00086 " Top Surface Scribe End Position
00087 00040 MB21813E = 0;

```

```

00088 00041          MB21813F = 1;
00089
00090 00042          MW04862 = 14;
00091          " L Camera Line Check Position Move
00092 00043          MSEE MPS192;
00093 00044          MW04862 = 0;
00094 00045          DW00010 = 0;
00095
00096 00046          JOINTO LBL0X;
00097
00098 00047          LBL03:
00099          " Bottom Surface Scribe Start Position
00100 00048          MB21813E = 1;
00101 00049          MB21813F = 0;
00102
00103 00050          MW04862 = 15;
00104          " L Camera Line Check Position Move
00105 00051          MSEE MPS192;
00106 00052          MW04862 = 0;
00107 00053          DW00010 = 0;
00108
00109 00054          JOINTO LBL0X;
00110
00111 00055          LBL04:
00112          " Bottom Surface Scribe End Position
00113 00056          MB21813E = 0;
00114 00057          MB21813F = 1;
00115
00116 00058          MW04862 = 16;
00117          " L Camera Line Check Position Move
00118 00059          MSEE MPS192;
00119 00060          MW04862 = 0;
00120 00061          DW00010 = 0;
00121
00122 00062          JOINTO LBL0X;
00123
00124 00063          LBL100:
00125 00064          JOINTO LBL0X;
00126 00065          LBL0X:SJOINT;
00127
00128          " Line Check Complet
00129 00066          IF MB20673B == 1;
00130 00067          DB00010 = 1;
00131 00068          MB21813B = 1;
00132 00069          IEND;
00133 00070          EOX;
00134 00071          WEND;
00135
00136          " Scribe Camera StandBy Position
00137 00072          PLD [LCAMY][LCAMZ][RCAMY][RCAMZ]
00138 00073          MOV [LCAMY]ML43730 [LCAMZ]ML43930 [RCAMY]ML43830 [RCAMZ]ML44030;
00139
00140 00074          IF CW00001 == 1                                " Scribe Direction (0: Forward / 1: Reve
rse)
00141          " UCAMX Escape Position
00142 00075          PLD [CAMX];
00143 00076          ML16066 = ML43330                                " CAMX Waiting Position
00144 00077          IOW MB04577A == 1                             " CAMX Moving Permission
00145 00078          VEL [CAMX]ML43312;
00146 00079          MOV [CAMX]ML16066;
00147 00080          IOW MB046010 == 1                             " CAMX Waiting Position Chec
00148 00081          IEND;
00149
00150          " Line Check Dialog Display
00151 00082          MB21462A = 0;
00152
00153 00083          RET;

```