

```

00001      ** DL Register Area - 120Word
00002      **
00003      ** DW00000 - DW00009 (PLS Use)
00004      ** DW00010 - DW00039 (Bit Use)
00005      ** DW00040 - DW00089 (Word Use)
00006      ** DW00090 - DW00119 (Timer)
00007      ****
00008
00009      "# Program Name      : Roller Break 1 Cycle (Unuse)
00010      "# Functionior      :
00011      "# Call Program     :
00012      "# Sub Program      :
00013      "# Func Program     :
00014
00015      VAR;
00016          " Scribe Cutter
00017 00000      LONG IDX_CX = 32;
00018 00001      LONG IDX_CAMX = 33;
00019          " Scribe Shift
00020 00002      LONG IDX_CS = 35;
00021 00003      LONG Axis_Pos_CS = 0;
00022      END_VAR;
00023
00024 00004      Axis_Pos_CS = IDX_CS * 50;
00025
00026          " Scribe Cutter Z Waiting Position
00027 00005      MW04842 = 41;                                " Scribe Cutter Z Command Code Setting
00028 00006      MSEE MPS198;                                    " Scribe Cutter Z Move
00029 00007      MW04842 = 0;
00030 00008      IOW MW04842 == 0;
00031
00032          " Roller Break Position Data Calc
00033          " RollerBreak Manual Data
00034 00009      DL00140 = 0;                                " Upper Head Shift Start Position
00035 00010      DL00142 = 0;                                " Upper Head Shift End Position
00036
00037 00011      DL00120 = 0;                                " Upper Head X Start Position
00038 00012      DL00122 = 0;                                " Upper Head X End Position
00039
00040          " Servo Roller : Left Req Right
00041          " RollerBreak Recipe Data
00042 00013      IF MB45736 == 1                                " RollerBreak(0:Manual Data, 1:Recipe Da
00043 00014      ta)      DL00140 = ML40030[Axis_Pos_CS] + ML1521    " Upper Shift Y Start Position Readi
00044 00015          DL00142 = ML40030[Axis_Pos_CS] + ML1522    " Upper Shift Y End Position Reading
00045 00016      IEND;
00046 00017      IF CW00001 == 1                                " Scribe Direction (0: Forward / 1: Reve
00047 00018      rse)      DL00120 = ML15202 + ML26346        " Upper Cutter X Start Position Readin
00048 00019          DL00122 = ML15210 + ML26346        " Upper Cutter X End Position Reading
00049 00020      ELSE;
00050 00021          DL00120 = ML15202 - ML26346        " Upper Cutter X Start Position Readin
00051 00022          DL00122 = ML15210 - ML26346        " Upper Cutter X End Position Reading
00052 00023      IEND;
00053
00054          " Cutter X Pos Moving Permission
00055 00024      IOW MB45760 == 1;
00056 00025      IOW MB45768 == 1;
00057 00026      IOW MB4577A == 1;
00058
00059 00027      DW00001 = 0;
00060
00061          " Roller Break 1 Cycl
00062 00028      PFORK Line1 Line2 Line3 Line4;
00063
00064      Line1:
00065          " Roller Break X Start Position Comp
00066 00029      IOW DB00010 == 1;
00067
00068          " Left Upper Roller Z Break Positi
00069 00030      IF !MB00800 & MB00802 == 1;
00070 00031          MW04842 = 16;
00071 00032          MSEE MPS198;
00072 00033          IOW MW04842 == 0;
00073
00074 00034          DL00026 = MW15505 * 0.8;
00075 00035          IOW ILA142 >= ML26282                " Roller Break Torque Interlock Check
00076 00036      IEND;
00077
00078          " Roller Break Z Start Position Comp
00079 00037      DB00011 = 1;
00080
00081          " Roller X Break End Position Comp
00082 00038      IOW DB00012 == 1;

```

```

00083
00084      " Roller Break Z Waiting Position
00085 00039      MW04842 = 41;
00086 00040      MSEE MPS198;
00087 00041      MW04842 = 0;
00088 00042      IOW MW04842 == 0;
00089
00090      " Roller Break Z Waiting Position Comp
00091 00043      DB00013 = 1;
00092
00093 00044      JOINTO LabelX;
00094
00095      Line2:
00096
00097 00045      PLD [CX][CS];
00098 00046      VEL [CX]ML43212 [CS]ML43512;
00099
00100      " Roller Break Start Pos Moving
00101 00047      MOV [CX]DL00120 [CS]DL00140
00102
00103      " Roller X Break Start Position Comp
00104 00048      DB00010 = 1;
00105
00106 00049      JOINTO LabelX;
00107
00108      Line3:
00109      " Roller Break Z Start Position Comp
00110 00050      IOW DB00011 == 1;
00111
00112      " Roller Break End Pos Moving Speed Ca
00113
00114      " FMX Speed Set
00115 00051      DL00010 = ML10800[IDX_CX];
00116
00117      " Acc, Dcc Set
00118 00052      DL00004 = ML01182;
00119 00053      DL00006 = ML01184;
00120 00054      IF MB45736 == 0
00121 00055          ta)      DL00004 = ML21276
00122 00056                  DL00006 = ML21278
00123 00057      IEND;
00124
00125 00058      DF00020 = DL00010 / 60 / DL00004 * 100
00126 00059      DF00022 = DL00010 / 60 / DL00006 * 1000;
00127
00128      " Acc Set Data < 10 mm/s^2 ==> 10 mm/s^2 Force Set
00129 00060      IF DF00020 < 10;
00130 00061          DF00020 = 10;
00131 00062      IEND;
00132      " Dcc Set Data < 10 mm/s^2 ==> 10 mm/s^2 Force Set
00133 00063      IF DF00022 < 10;
00134 00064          DF00022 = 10;
00135 00065      IEND;
00136
00137 00066      DL00030 = DF00020;
00138 00067      DL00032 = DF00022;
00139
00140 00068      FMX tDL00010;
00141 00069      IAC tDL00030;
00142 00070      IDC tDL00032;
00143
00144      " Shift Y Moving Distance
00145 00071      DL00040 = DL00140 - DL00142;
00146      " Cutter X Moving Distance
00147 00072      DL00042 = DL00120 - DL00122;
00148
00149 00073      DF00100 = DL00040 * DL00040;
00150 00074      DF00102 = DL00042 * DL00042;
00151
00152 00075      DF00110 = DF00100 + DF00102;
00153
00154 00076      IF DF00100 >= DF00102;
00155 00077          DF00112 = DF00100;
00156 00078      ELSE;
00157 00079          DF00112 = DF00102;
00158 00080      IEND;
00159
00160 00081      DF00060 = SQT(DF00110);
00161 00082      DF00062 = SQT(DF00112);
00162
00163      " Same Data Manager
00164 00083      IF DF00060 == 0;
00165 00084          DF00060 = 1;
00166 00085      IEND;
00167 00086      IF DF00062 == 0;
00168 00087          DF00062 = 1;

```

```
00169 00088      IEND;
00170
00171 00089      DL00014 = ML01186;
00172 00090      IF MB45736 == 0                                " RollerBreak(0:Manual Data, 1:Recipe Da
ta)
00173 00091          DL00014 = ML22574                                " Manual Roller Break Speed
00174 00092      IEND;
00175
00176 00093      DF00070 = DL00014 * DF00060 / DF00062 * 60;
00177 00094      DL00080 = DF00070;
00178
00179      " Roller Break End Pos Movir
00180 00095      MVS [CX]DL00122 [CS]DL00142 FDL00080 pf        " Roller Break Start Pos Moving
00181
00182      " Roller X Break End Position Comp
00183 00096      DB00012 = 1;
00184
00185 00097      JOINTO LabelX;
00186
00187      Line4:
00188          " Left Lower Head Waiting Position Moving
00189
00190 00098      JOINTO LabelX;
00191 00099      LabelX: PJOINT;
00192
00193      " Roller Break Z Waiting Position Comp
00194 00100      IOW DB00013 == 1;
00195
00196      " Scribe Cutter Z Waiting Position
00197 00101      IF MB045740 == 0;
00198 00102          MW04842 = 41;
00199 00103          MSEE MPS198;                                " Scribe Cutter Z Command Code Setting
00200 00104          MW04842 = 0;                                " Scribe Cutter Z Move
00201 00105          IOW MW04842 == 0;
00202 00106      IEND;
00203
00204 00107      RET;
```