

```

00001      ** DL Register Area - 120Word
00002      **
00003      ** DW00000 - DW00009 (PLS Use)
00004      ** DW00010 - DW00039 (Bit Use)
00005      ** DW00040 - DW00089 (Word Use)
00006      ** DW00090 - DW00119 (Timer)
00007      ****
00008
00009      "# Program Name : [Chuck] Break Position
00010      "# Function :
00011      "# Call Program :
00012      "# Sub Program :
00013      "# Func Program :
00014
00015      VAR;
00016      " Scribe Chuck
00017 00000      LONG IDX_SCHY1 = 48;
00018 00001      LONG IDX_SCHY2 = 49;
00019      END_VAR;
00020
00021
00022      " Cutter Z Waiting Pos. Check
00023 00002      IOW MB045740 == 1;
00024
00025      " Scribe Chuck Y
00026 00003      IF MB030035 == 1;
00027 00004          IF MB09018E == 1
00028              " [Request] Moving Position
00029 00005              MW04820 = 40;
00030 00006              MSEE MPS256;
00031 00007              IOW MB04574C == 1
00032 00008              ELSE;
00033                  " [Request] Vacuum Position
00034 00009                  MW04820 = 41;
00035 00010                  MSEE MPS256;
00036 00011                  IOW MB04574B == 1
00037                      " All SCHZ Moving Pos Check
00038 00012                  MB09048E = 1;
00039 00013                  IOW MB09018E == 1
00040                      " [Sol] SCT Scribe Chuck All Vacuum On
00041                      " [Sensor] SCT Scribe Chuck All Vacuum On
00042 00014                      " [Request] Moving Position
00043 00015                      MW04820 = 40;
00044 00016                      MSEE MPS256;
00045 00017                      IOW MB04574C == 1
00046                      " All SCHZ Moving Pos Check
00047 00018                      IEND;
00048 00019                      ELSE;
00049 00020                      MB09052E = 1;
00050 00021                      MB090560 = 1;
00051 00022                      IOW MB09022E & MB090260 == 1
00052 00023                      " [Sol] SCT Scribe Chuck All Vacuum Off
00053 00024                      TIM TMW26214;
00054                      MB090600 = 1;
00055                      IOW MB090300 == 1
00056                      " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow On
00057                      " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow Off
00058                      " Scribe Chuck Vacuum Break Complete Timer
00059                      " [Sol] SCT Scribe Chuck 1,2,3,4 Blow Off
00060                      " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow Off
00061 00025                      " [Request] Standby Position
00062 00026                      MW04820 = 39;
00063 00027                      MSEE MPS256;
00064 00028                      IOW MB04574A == 1
00065                      " All SCHZ Standby Pos Check
00066 00029                      IEND;
00067 00030                      IF MB045281 == 1
00068 00031                      " MTR - SC Interface
00069 00032                      IOW MB30034 == 1;
00070                      IEND;
00071 00033                      IOW MB49440 == 0;
00072 00034                      MB49440 = 1;
00073 00035                      EOX;
00074 00036                      IF MB053080 == 1
00075 00037                      " Break Pusher Bar Use (0: Unuse 1: Use)
00076 00038                      IF MB09027F | MB000800 == 0;
00077 00039                      " Cutting Table Vacuum Break On
00078 00040                      " Break Table Glass Data Exist
00079 00041                      MB04515D = 1;
00080 00042                      " [Cutting] Low Pressure Blow On Flag
00081 00043                      MW04846 = 2;
00082 00044                      " [Cutting] Table Vacuum Off
00083 00045                      MW04848 = 1;
00084 00046                      " [Cutting] Table Blow On
00085 00047                      IF MB030034 | (MB071023 & MB045281 & MB070271) == 1;
00086 00048                      " [Fix] Table Vacuum On
00087 00049                      MW04946 = 1;
00088 00050                      " [Fix] Table Blow Off
00089 00051                      MW04948 = 2;
00090 00052                      ELSE;
00091 00053                      IF MB045780 & (MB071003 & MB071023) == 1;
00092 00054                      " [Fix] Table Vacuum On
00093 00055                      MW04946 = 10;
00094 00056                      " [Fix] Table Blow Of
00095 00057                      MW04948 = 10;
00096 00058                      ELSE;
00097 00059                      MW04946 = 2;
00098 00060                      " [Fix] Table Vacuum Off
00099 00061                      MW04948 = 1;
00100 00062                      " [Fix] Table Blow On
00101 00063                      IEND;
00102 00064                      IEND;
00103 00065                      MSEE MPS259;
00104 00066                      " Table Vacuum & Floating
00105 00067                      IEND;

```

```

00088 00054      ELSE;
00089 00055          IF CW00013 == 1;
00090 00056              IF (MB09027F & MB05684F) | MB000800 == 0 " Break Table Vacuum O
00091 00057                  MB04515D = 1; " [Cutting] Low Pressure Blow On Flag
00092 00058                  MW04846 = 7; " [Cutting] Table Vacuum Off [Break] Table V
    acuun Or
00093 00059                  MW04848 = 1; " [Cutting] Table Blow On
00094 00060                  IF MB030034 | (MB071023 & MB045281 & MB070271) == 1;
00095 00061                      MW04946 = 1; " [Fix] Table Vacuum On
00096 00062                      MW04948 = 2; " [Fix] Table Blow Off
00097 00063                  ELSE;
00098 00064                      MW04946 = 2; " [Fix] Table Vacuum Off
00099 00065                      MW04948 = 1; " [Fix] Table Blow On
00100 00066                  IEND;
00101 00067                  MSEE MPS259; " Table Vacuum & Floating
00102 00068                  IEND;
00103 00069      ELSE;
00104 00070          IF (MB09027F & MB05686F) | MB000800 == 0 " Break Table Vacuum Break C
00105 00071                  MB04515D = 1; " [Cutting] Low Pressure Blow On Flag
00106 00072                  MW04846 = 6; " [Cutting, Break] Table Vacuum Off
00107 00073                  MW04848 = 5; " [Cutting, Break] Table Blow On
00108 00074                  IF MB030034 | (MB071023 & MB045281 & MB070271) == 1;
00109 00075                      MW04946 = 1; " [Fix] Table Vacuum On
00110 00076                      MW04948 = 2; " [Fix] Table Blow Off
00111 00077                  ELSE;
00112 00078                      MW04946 = 2; " [Fix] Table Vacuum Off
00113 00079                      MW04948 = 1; " [Fix] Table Blow On
00114 00080                  IEND;
00115 00081                  MSEE MPS259; " Table Vacuum & Floating
00116 00082                  IEND;
00117 00083                  IEND;
00118 00084                  IEND;
00119 00085                  MB49440 = 0;
00120
00121 00086          IF ML05308 == 1; " Break Pusher Bar Motio
00122 00087              IOW ILB296 >= ML73802 - 100;
00123 00088          //          IOW MB56000 & MB56020 == 1 " Break Table Y,Z Waitting Pos Check
00124 00088              IEND;
00125
00126 00089          IF ML05810 == 1; " Break Table Motio
00127 00090              IOW MB056003 & MB056023 == 1;
00128 00091              IEND;
00129
00130 00092          IF CW00013 == 1;
00131 00093              IF MB58100 == 1 " Table Break Select (1:Use, 0:Not Use)
00132 00094                  MB55130 = 1; " BKT Sync Use Mode
00133 00095              IEND;
00134 00096          IEND;
00135
00136          " Scribe Chuck Break Position Setti
00137 00097          ML16096 = ML01168;
00138 00098          MSEE MPS170;
00139
00140          " Scribe Chuck Break Position. Che.
00141 00099          IOW MB046084 == 1
00142
00143 00100          IF CW00013 == 1;
00144 00101              MB55130 = 0; " BKT Sync Use Mode
00145 00102          IEND;
00146
00147 00103          IOW MB49440 == 0;
00148 00104          MB49440 = 1;
00149
00150 00105          MW04846 = 10;
00151 00106          IF CW00013 == 1;
00152 00107              MW04848 = 2; " [Cutting] Table Blow Off
00153 00108              MB04515D = 0; " [Cutting] Low Pressure Blow On Flag
00154 00109          ELSE;
00155 00110              MW04848 = 6; " [Cutting, Break] Table Blow Off
00156 00111              MB04515D = 0; " [Cutting] Low Pressure Blow On Flag
00157 00112          IEND;
00158 00113          MW04946 = 10;
00159 00114          IF CW00057 == 0;
00160 00115              MW04948 = 10;
00161 00116          ELSE;
00162 00117              MW04948 = 2;
00163 00118          IEND;
00164 00119          MSEE MPS259; " Table Vacuum & Floating
00165
00166 00120          MB49440 = 0;
00167
00168 00121          IF MB030035 == 1;
00169 00122              " [Request] Vacuum Positic
00170 00122              IF ML26284 < IL0A816;
00171 00123                  MW04820 = 41;
00172 00124                  MSEE MPS256;

```

```
00173 00125      IEND;  
00174 00126      IEND;  
00175  
00176 00127  RET;
```

			MPS236 : [Chuck] Break Position	P00003
--	--	--	---------------------------------	--------