

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : CZ Position Setting
00011 "# Functior :
00012 "# Call Program :
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 00000 LONG Axis_Pos = 0;
00018 00001 LONG Axis_IO = 0;
00019 00002 LONG Load_Tbl = 0;
00020 00003 LONG Load_Pos = 0;
00021 CONST LONG IDX_CZ = 0; " Changes when copying to other 0origi
00022 END_VAR;
00023
00024 00004 Axis_Pos = IDX_CZ * 50;
00025 00005 Axis_IO = IDX_CZ * 128 / 2;
00026 00006 Load_Tbl = IDX_CZ * 100;
00027
00028 00007 DW00010 = MW15540 " Cutter Z1 Setting Position
00029
00030 "=====
00031 " Torque Setting
00032 "=====
00033 00008 SFORK DW00010 == 0 ? LBL000 "
00034 DW00010 == 1 ? LBL001 " Standby Pos
00035 DW00010 == 2 ? LBL002 " Torque Setting Pos (Load Cell Pos - 1000um)
00036 DW00010 == 3 ? LBL003 " Load Measurement Positon
00037 DW00010 == 4 ? LBL004 " 0 Level Detect Start Pos
00038 DW00010 == 5 ? LBL005 " 0 Level Detect Pos
00039 DW00010 == 7 ? LBL007 " Scirbe Before Position
00040 DW00010 == 8 ? LBL008 " Scribing Cutting Position
00041 DW00010 == 9 ? LBL009 " Current Position
00042 DW00010 == 10 ? LBL010 " Offset Set Scribe Position
00043 DW00010 == 11 ? LBL011 " Roller Break Position
00044 DW00010 == 12 ? LBL012 "
00045
00046 00009 LBL000:
00047
00048 00010 JOINTC LBL00X;
00049
00050 00011 LBL001: " Standby Pos
00051
00052 00012 ML15750 = ML43430 " UPCZ
00053
00054 00013 JOINTC LBL00X;
00055
00056 00014 LBL002: " Torque Setting Pos (Load Cell Pos - 1000um)
00057
00058 00015 ML15750 = ML43454 - 1000 " UPCZ
00059
00060 00016 JOINTC LBL00X;
00061
00062 00017 LBL003: " Load Measurement Positon
00063
00064 00018 ML15750 = ML43454 + 2000 " UPCZ
00065
00066 00019 JOINTC LBL00X;
00067
00068 00020 LBL004: " 0 Level Detect Start Pos
00069
00070 00021 ML15750 = ML43458 " UPCZ
00071
00072 00022 JOINTC LBL00X;
00073
00074 00023 LBL005: " 0 Level Detect Position
00075
00076 00024 JOINTC LBL00X;
00077
00078 00025 LBL007: " Scribe Cutter 1000mm Up Position
00079
00080 " Upper Head
00081 //ML15750 = ML43410 - GL21004 - 100 " UPCZ
00082 00026 ML15750 = ML26410 - GL21004 - 100 " UPCZ
00083
00084
00085 00027 JOINTC LBL00X;
00086
00087 00028 LBL008: " Scribing Cutting Position

```

```
00088
00089      " Cutter Z Scribe Strart Position
00090 00029      IF MB15200D == 1;
00091 00030          ML15750 = ML15226
00092 00031      ELSE;
00093 00032          IF MW15292 <> 0
00094 00033              ML15750 = ML15266
00095 00034          ELSE;
00096 00035              ML15750 = ML15226
00097 00036          IEND;
00098 00037      IEND;
00099
00100 00038      JOINTC LBL00X;
00101
00102 00039      LBL009:      " Current Position
00103
00104 00040          ML15750 = ILA116
00105
00106 00041          JOINTC LBL00X;
00107
00108 00042      LBL010:      " Offset Set Scribe Position
00109
00110          //ML15750 = ML43410 + GL21132 - GL2100
00111 00043          ML15750 = ML26410 + GL21132;
00112
00113 00044          IF MB000800 | !MB000802 == 1;
00114 00045              ML15750 = ML43430
00115 00046          IEND;
00116
00117 00047          JOINTC LBL00X;
00118
00119 00048      LBL011:      " Roller Break Position
00120
00121          " Upper Head
00122 00049          ML15750 = ML43430
00123
00124 00050          IF MB000800 | !MB000802 == 1;
00125 00051              ML15750 = ML43430
00126 00052          IEND;
00127
00128 00053          JOINTC LBL00X;
00129
00130 00054      LBL012:      " Wheel Change Align Position
00131
00132 00055          JOINTC LBL00X;
00133
00134 00056      LBL00X: SJOINT;
00135
00136 00057      RET;
00137
00138
```